
Univ. of Toronto Library Digitized by the Internet Archive in 2011 with funding from University of Toronto





Vek M‡

147452 III/18

# UNIVERSITY OF, ILLINOIS

# ENGINEERING EXPERIMENT STATION

Bulletin No. 2 3 5-15

NOVEMBER 1905 -- /

#### TESTS OF HIGH-SPEED TOOL STEELS ON CAST IRON

BY L. P. Breckenridge, Professor of Mechanical Engineering, and Henry B. Dirks, M.E., Assistant in Mechanical Technology.

In most manufacturing processes it becomes necessary to change the form of materials in order to bring them to the desired shape for use. Among the metals used in the construction of engineering structures, including the almost endless variety of steam and gas engines, compressors, pumping machinery, marine and locomotive engines, special machinery and machine tools, it is evident that cast iron and steel represent by far the chief constituents of such machines. For the manufacture of all the various parts of these structures and machines there has been designed a great variety of machine tools. In these machine tools are placed the pieces whose shape it is desired to change, and a properly formed and hardened piece of steel is made to cut away a part of the material. The steel used for making the tool for thus cutting the softer material is called Tool Steel. time required to cut away the necessary amount of metal is an important factor in the cost of the piece under construction. It is evident that the relative hardness of the tool steel and the material it cuts, as well as the speed at which the cutting is attempted, will be important factors in the time required to do the work and of the durability of the tool steel used. have continually exerted a potent influence upon the manufacturers of tool steel and they have constantly improved the qual-

ity of their product. On the other hand, the demand for stronger and lighter materials of construction has increased the density and hardness of many materials already used, and brought into common use new materials, such as cast steel, ferro steel, chilled iron, etc., and these have imposed severer duties on the tool steels designed to cut them. The same rivalry that has existed between armor plate and the projectile intended to pierce it has existed between the tool steels and the materials they are designed to cut. Until quite recently, the rate at which tool steel could cut the various metals was from 10 to 40 feet per minute, varying with the metals cut and with the area of the cross section removed. If a higher rate of cutting was attempted, the point of the tool used became hot, lost its temper and immediately wore away. During the years 1898 to 1900, Messrs. Taylor and White, at the Bethlehem Steel Works, South Bethlehem, Pennsylvania, were seeking to discover what constituents could be combined with tool steel, and what special temperature treatment it should receive that would increase its cutting speed. As the result of their experiments, there was exhibited at the Paris Exposition of 1900 a lathe using a tool steel which removed chips of soft steel at a cutting speed of from 60 to 180 feet per minute. These chips were so hot that they turned blue upon cooling. The point of the tool steel maintained its cutting edge even when running at a dull red glow. It was natural that to such tools should have been given the name of High-Speed Tool Steels.

### PROPERTIES OF TOOL STEELS

At the time of Taylor and White's first experiments, Mushet and Jessop tool steels of the self-hardening type were in general use. According to Mr. F. Reiser in an article on high-speed steel in "Stahl and Eisen", January 15, 1903, they had the following chemical composition:

Carbon 2.0% Manganese 2.5% Silicon 1.3% Tungsten 5.0% Chromium 0.5%

The self-hardening property is called into play by the manganese, an element which favors the combining of the carbon with the iron. These steels were tempered simply by heating to a temperature of 1600° F. and then cooling in air. Mushet and Jessop tools, however, did not prove durable at high speeds, although they were far in advance of the ordinary carbon steels,

and chromium was substituted for manganese with good results. The chromium steels required an entirely different treatment, as was found by Messrs. Taylor and White in their experiments at the Bethlehem Steel Works.

The exact chemical compositions of the new tool steels are secrets of the separate makers, and probably vary; however, it is known that the steels contain the following elements in varying quantities: carbon, tungsten, chromium, manganese, molybdenum and titanium. They usually run high in these combining elements, the Taylor-White steel having as high as 12% of tungsten and 4% of chromium, while Böhler Brothers' Styrian steel, according to Mr. Reiser, has a maximum of 28% of other elements. With this increase the carbon element has greatly decreased; most of it combines with tungsten, chromium and the other elements at high temperatures, remains in that state when cooled in an air blast and forms carbides of extreme hardness and durability at high temperatures. For best results of toughness and hardness these high-speed steels require for tempering a temperature of from 2000° to 2250° F., or a white heat bordering on the fusion point, and are then cooled in an air blast, lead bath or oil bath according to the different makers. Mr. Reiser in his discussion has for this reason correctly named them "superheated steels."

#### ADVANTAGES OF HIGH-SPEED STEELS

High-speed steels, due to their hardness and durability at high temperatures, retain their edge when cutting at extremely high speeds, cases having been noted in which the tool worked at dark-red heat without losing its edge. As can be seen from the tables, the speeds obtained are from three to four times those obtained with ordinary carbon steels. This of course means an increased output for a given shop and a consequent increase in the returns. This is not the only advantage of high-speed steel. It has been proved that such steel is more economical from the power standpoint, a given power removing a greater quantity of metal per unit of time at high speed than at slow speed. Of course the total power required is increased, but the increase is by no means proportional to the increase in the amount of work done.

· There is, however, one condition that must be carefully con-

sidered before the introduction of high-speed steels in a shop. Machine tools constructed to use the old carbon steels are limited in capacity and will not stand the heavy stresses to which they would be subjected if using high-speed steels at maximum speeds and feeds. This condition, however, is being met by the machine-tool builders, who are now designing and building especially heavy tools with powerful feed mechanisms with a view towards obtaining the highest possible efficiency of the steel used.

In the following pages are described the experiments made by Mr. H. B. Dirks, Assistant in Mechanical Technology, Engineering Experiment Station, in the shops of the College of Engineering at the University of Illinois. These experiments have been in progress for nearly a year, and every effort has been made to obtain useful and correct results.

For convenience, the subject has been divided into the following parts: I. The Tool Steels Used. II. The Cast-Iron Test Pieces. III. Details of the Tests. IV. Results of the Experiments. V. Summary of Results. VI. Reference List of Articles on High-Speed Steels. Appendix,—giving instructions furnished by makers for hardening the steels used.

#### I. THE TOOL STEEL USED

# (a) The Brands Used

The following tool steels were used in these trials:

- 1. Styrian marked "Böhler Rapid"
- 2. Jessop's "Ark"
- 3. McInnes's "Extra"
- 4. Mushet's "Special"
- 5. "Air Novo"
- 6. "Rex"
- 7. "Poldi"
- 8. "A and W" (Armstrong and Whitworth)

The first six came from the American market. Poldi and "A and W" were furnished by the American Radiator Company, having been used in its foreign factories. With the exception of the Mushet, the steels used were donated for the proposed tests by the makers or agents. The Mushet was taken from stock purchased in the open market. There are doubtless other kinds of steel which could have been tested, but these eight brands were most familiar and accessible to the writers, and it is believed that

they represent fairly well the brands commonly used at the present time by American manufacturers.




Fig. 4. Shape of Cutting Tools

## (b) Size and Shape of Tools

The size of the bars of steel from which the tools were made was  $\frac{1}{2}$  in. by 1 in. for the steels from the American market. The Poldi bar was  $\frac{3}{4}$  in. by  $1\frac{3}{4}$  in., and the "A and W" bar was  $\frac{3}{4}$  in. by  $1\frac{1}{4}$  in. The shape of the tool used in the tests is shown in Fig. 4. The front clearance was  $12\frac{1}{2}$ °, the top rake was  $10^{\circ}$  and the side rake was also  $10^{\circ}$ . These angles were carefully maintained throughout the tests, the angles being measured with a bevel protractor after each grinding.

Experiments relating to the proper shape of tools have been made by Professor J. T. Nicolson,\* and the writers were guided in selecting proper tool angles by the recommendations of his paper. Professor Nicolson says: "Tools should therefore be ground for maximum endurance in the cutting of cast iron in ordinary shop practice so that their true cutting angles are about 81°, or if they are allowed 6° clearance for working on the level of the lathe centers, they should have an included angle of about 75°.

# (c) Tempering and Tempering Apparatus

Directions for forging and hardening the various steels used were furnished by the manufacturers. For convenience, these directions are published in the Appendix. It will be seen that most of the steels were to be hardened in an air blast. The "A

<sup>\*</sup>Experiments with a Lathe Tool Dynamometer. See Trans. A. S. M. E., Vol. 25, 1904, page 658 et seq.

and W'' steel was the only one in which oil was recommended for cooling, and then only after the cutting edge of the tool had been cooled to a cherry-red in the air blast. An air blast apparatus was designed and constructed for carrying out the instructions relating to the proper preparation of the tools. This is shown in Fig. 5.




FIG. 5. AIR BLAST APPARATUS

The apparatus consists of the 4-in. separating pipe, 3 ft. 6 in. long to which is connected the header of 2-in. pipe about 10 in. long. The dimensions and construction are shown in the figure. The tools to be hardened are inserted in the short lengths of  $1\frac{1}{2}$  or  $2\frac{1}{2}$ -in. pipes which serve to concentrate the air blast on

the tools. A rubber hose with a \frac{1}{8}-in. nozzle in the end is also attached to one opening, so that a strong air blast may be directed on the edge of the tool when first removed from the fire. The tools were heated in an ordinary forge with a clear coke fire. The fire was burned long enough before putting in the tool to drive off any sulphur. Care was also taken to have plenty of coke above and below the tool so that no cold blast should strike the tool while it was being heated.

#### II. THE CAST-IRON TEST PIECES

In order that the results of the tests might be of general application, it was advisable that the cast-iron test pieces be the product of several commercial foundries. Several manufacturers throughout the State agreed to furnish sample test pieces representing the grade of cast iron used in their respective foundries. A standard size of test piece was therefore decided upon, and blue prints and patterns of it sent to the different manufacturers. This standard test piece is shown in Fig. 6. The outer diameter is the maximum the lathe will swing over the carriage. This test piece was made hollow for several reasons. A solid test piece becomes soft toward the center and is more likely to contain blow holes. Test pieces of small diameter become springy and consequently produce inaccuracies in the results. The high angular velocity necessary with small diameters is also undesirable. The first test piece used in the preliminary trials was 18 in. long. This was found to be too short, the tool having to be reset too often. In Fig. 3 is given a view of all the test pieces used in the trials. These test pieces do not all conform to the standard test piece, the American Radiator Company having sent test pieces with a 6-in, core instead of a 3-in, core, from several of its plants, that being a more representative casting from its foundries. The test pieces received from the various companies, their identification marks and reference numbers are shown in Table 1.

TABLE 1 Results of Hardness Tests and Identification Marks  $$\operatorname{\textsc{of}}$$ 

CAST-IRON TEST PIECES USED IN THE TESTS

Name of company	sending test pieces	Identification mark	Test reference No.	Hardness by drill test
	Pierce plant. {	3 ″ core	3 4 5	$94.2 \\ 109.2 \\ 102.0$
	Michigan Plant.	5-8-05 6 " core	6 7 8 9 10 11	128.8 86.5 94.3 138.6 106.8 109.3
American Radiator Co. { Chicago, Ill.	Detroit plant	D. P. 1 D. P. 2 D. P. 3 D. P. 4 D. P. 5 D. P. 6	12 13 14 15 16 17	100.0 106.6 117.2 132.0 109.8 90.3
	plant. {	5-17-05	18 19 20	$   \begin{array}{c}     107.0 \\     117.2 \\     113.9   \end{array} $
	plant. {	B 5-26-05	21 22 23	$124.8 \\ 167.5 \\ 122.2$
	plant. {	B 6-2-05	24 25 26	$111.2 \\ 102.4 \\ 95.9$
Crane Company Chicago, Ill.	Ferro Steel. { Grey Iron.	F. S.	$\begin{array}{c} 1 \\ 27 \end{array}$	342.0 132.0
Root & Vandervo East Molin	ort Eng'g Co		2	175.0
	nois	U. I.—1 U. I.—2 U. I.—3 U. I.—4 U. I.—5	28 29 30 31 32	114.5 195.0 124.2 124.5 123.2

A comparative hardness test was made on all samples, comparison being made with a standard piece of soft cast iron of equal density throughout, the chemical analysis of which is as follows:

Combined Carbon = .147% Silicon = 2.35% Sulphur = .07% Graphite = 5.03 % Manganese = .33% Phosphorus=1.06%




Fig. 6. Standard Test Piece

The hardness of cast iron or any other metal as indicated by a drill test is probably as fair an indication of the particular quality of the metal that affects the cutting speed as is obtainable by any process in use at the present time. This hardness test is in itself a cutting-speed test in which the cutting speed is not varied, but is held constant and the rate of feed allowed to vary, the cutting speed and rate of feed in all probability bearing some constant relation to each other. Fig. 7 is a graphical chart giving the results of the hardness tests on the test pieces used in the experiments. The tests were made with a drill press as shown in Fig. 8. A constant load of 312 pounds was applied on the spindle of the drill press by means of the weighted lever. the spindle rotating at a constant speed of 87 r. p. m., the rate of feed of the drill in inches per minute was measured, readings being taken for every in in. of depth drilled. The drill used in these tests was a Morse standard 1-in. twist drill ground to an angle of 62%. As, however, there was some liability of variation in the sharpness of the drill, thus affecting its rate of feed, a uniform piece of cast iron was first drilled into, readings taken, and then the test made on the test piece. A comparison was thus always made with this same piece of cast iron, eliminating any




Fig. 7. Graphical Chart of Hardness Drill • Tests Made on Cast-Iron Test Pieces

small variation in the sharpness of the drill. In Fig. 7 the curves drawn through the dots represent the standard cast iron, and those drawn through the circles represent the test piece. Thus for test piece No. 1 the rate of feed is about .174 in. per minute, while in drilling the standard cast iron, the rate of feed is about .595 in. per minute. The hardness as used later and as expressed in Table 1 is  $\frac{.595}{.174} \times 100 = 342$ . Assuming 100 as the hardness of the standard cast iron, Table 1 gives the results obtained from these tests. This method of expressing the hard-




Fig. 8. Drill Press, Showing Method of Making Hardness Tests on Cast-Iron Test Pieces

ness of cast iron was also used by Professor J. T. Nicolson in his experiments with high-speed tool steels made at the Manchester Municipal School of Technology, Manchester, England.\* In these experiments the tangent of the angle made by the curve was used as the hardness.

<sup>\*</sup>Report of experiments made at Manchester Municipal School of Technology, London Engineering, October 30 and November 13, 1903.

#### III. DETAILS OF THE TESTS

#### (a) Apparatus

The apparatus used in conducting the tests consisted mainly of a high-speed lathe deriving its power from a two-phase induction motor by means of belting and a countershaft, the power required being measured by a polyphase wattmeter. The general arrangement is shown in Fig. 1 and Fig. 9. The lather used (see Fig. 2 and Fig. 10) was a Pratt and Whitney high-speed lather with a gear box head-stock, taking a maximum length of 3 ft. 9




FIG. 9. GENERAL ARRANGEMENT OF APPARATUS USED IN THE TESTS WITH HIGH-SPEED TOOL STEELS

in. between centers and a diameter of 9 in. over the carriage. The power was transmitted from the first motion shaft of the head-stock to the cone gears by means of a long pinion and an intermediate gear, the latter being fastened to the intermediate

gear frame which swivels about the first motion shaft. The intermediate gear frame has a substantial slide with rack, pinion and crank by which the intermediate gear is moved to any one of four positions, in which it is locked by the dropping of a pin into suitable holes in the frame, after which movement the frame is swiveled to drop the gear into mesh with the cone gear. The latch handle at each end of the frame holds the frame and gears in position after the gears are in mesh. From the cone gears the power is transmitted either direct to the spindle or through the usual back gears, thus making 8 changes of speed. The speeds and feeds obtainable are shown in Table 2 and Table 3. The feed mechanism is positive, being driven by two gears from the main spindle through a chain of gears to the feed box change and speed gears, thence through the feed rod to the carriage. There are 8 changes possible both for the cross and longitudinal feed. A reverse feed is obtained by shifting the reverse rod.

TABLE 2
FEEDS AND FEED GEARS FOR
PRATT & WHITNEY HIGH-SPEED LATHE

Feeds	Feed	Change Gears	Feed Box Change Gears	Feed Box SpeedGear	Worm	Apron Feed Gear	Raek Pinion	Cross Feed Screw	Feed per one Rev. of Spin- dle	Rev. of Spindle to 1" Travel
nal Feed	diate	ars	48 to 64 60 to 52 68 to 44 78 to 34	38 to 74		99	8 P.		.0076 .0116 .0156 .0232	131.6 86.2 64.1 43.1
Longitudinal Feed	Forward 28 Intermediate	Outside Change Gears 78 Intermediate	48 to 64 60 to 52 68 to 44 78 to 34	76 to 36		22 to 66	18 t-8 P.		.0312 .0478 .0642 .0952	32.0 $20.9$ $15.6$ $10.5$
Feed	44 to 88 Reverse,	78	48 to 64 60 to 52 68 to 44 78 to 34	38 to 74		with 49 lediate		single	.00508 .00782 .01045 .01554	196.8 127.7 95.7 64.3
Cross Feed	42 to 84	39 to	48 to 64 60 to 52 68 to 44 78 to 34	76 to 36		76 to 18 with Intermediate		g lead single	.0209 .0322 .0431 .0640	47.8 31.1 23.2 15.6

TABLE 3

RANGE OF SPEED RATIOS AND SURFACE SPEEDS FOR

APPARATUS USED IN HIGH-SPEED STEEL TESTS

		Povolutio	ions per minute · Surface speed of test						
Motor Pulley		nevolutio	Lathe S			et per min.			
Diameter (1120 r. p. m.)	Counter- shaft	Lathe Pulley	Direct drive	Drive through back gears	Direct drive	Drive through back gears			
6 inches	181.62	90.81	68.10 45.40 34.05 27.24	23.48 15.65 11.74 9.38	160.37 106.92 80.19 64.15	55.30 36.80 27.65 22.09			
7 inches	211.89	105.94	79.46 52.97 39.73 31.78	27.40 18.26 13.70 10.95	187.10 124.70 93.56 74.84	64.53 43.00 32.26 25.79			
8 inches	242.16	121.08	90.81 60.54 45.41 36.32	$ \begin{array}{r} 31.31 \\ 20.87 \\ 15.65 \\ 12.52 \end{array} $	213.80 142.60 106.90 85.53	$\begin{array}{c} 73.74 \\ 49.15 \\ 36.86 \\ 29.48 \end{array}$			
9 inches	272.43	136.21	102.16 68.11 51.08 40.86	35.23 23.48 17.61 14.10	$\begin{array}{c} 240.60 \\ 160.40 \\ 120.30 \\ 96.23 \end{array}$	82.97 55.30 41.47 33.21			
10 inches	302.70	151.30	113.50 75.65 56.74 45.39	$   \begin{array}{r}     39.13 \\     26.10 \\     19.56 \\     15.65   \end{array} $	267.30 178.20 133.60 106.90	92.15 61.47 46.06 36.86			
11 inches	332.97	166.48	124.90 83.24 62.43 49.94	43.07 28.73 21.52 17.12	294,10 196.00 147.00 117.60	101.40 67.66 50.68 40.32			
12 inches	363.24	181.62	136.20 90.81 68.11 54.49	46.96 31.31 23.48 18.78	320.80 213.80 160.40 128.30	110.60 73.74 55.30 44.23			




Fig. 10. Lathe used in the Tests With High-Speed Tool Steels

The power was transmitted to the lathe by means of a 4-in. double belt from the 12-in, friction clutch pulley of the countershaft. The countershaft in turn was driven through a 37-in. pulley by a 4-in, single belt from the motor. The motor is on an adjustable base, allowing changes of the motor pulley to be made without changing the length of the belt. In the tests, pullevs ranging from 6 to 12 in. in diameter were used, making possible with the 8 changes of speed on the lathe proper, 56 changes for every diameter of work. As the diameter of the test piece decreased, it was thus possible to keep the speed of the cut constant within very small limits. The motor received its current from the 440 volt main of the University power plant. As shown in Fig. 9, the current passed through an auto-starter and wattmeter into the motor, the auto-starter being used to reduce the electromotive force on the motor at starting, thus diminishing the liability of injury to the motor.

The wattmeter used is known as the Westinghouse portable long scale indicating wattmeter for alternating current circuits, and may be used for either two, three or four-phase circuits. principle, the wattmeter consists of a miniature induction motor, having for an armature a metal drum mounted on a shaft, together with a spring and pointer, giving indications on the scale proportional to the power to be measured. There is also a stationary circular core of iron inside the drum to complete the magnetic circuit through the armature As it operates on the induction principle, it has no moving wires and is not affected by external fields." "The polyphase wattmeter used in the tests is a modification of the above, having two drums mounted on the same shaft and revolving in two separate fields. This construction makes a meter which is correct for two or three-phase circuits under all conditions of unbalancing, low power factor, etc., and measures the true energy of the circuit".\*

# (b) Procedure in Making the Tests

In the preliminary trials the skin was first removed to bring the test piece to a uniform diameter throughout. This was discontinued in the later trials and a separate series of skin cut trials was run. The test piece having been made ready for the test, the tool to be used was placed in the tool rest in the position

<sup>\*</sup>Taken from instructions for the use of the W. P. L. S. I. Wattmeters.



Fig. 1 View in the University of Illinois Machine Shop showing location of Lathe and Motor drive used in Tests with High-Speed Tool Steels




Fig. 2. Lathe used in Tests with High-Speed Tool Steels



Fig. 3. Cast-Iron Test Pieces used in Tests with High-Speed Tool Steels

decided upon for all tools and trials, viz., at right angles to the work with the bottom edge of the tool horizontal and the cutting edge of the tool from  $\frac{1}{8}$  in. to  $\frac{1}{4}$  in. above the center of the work. its exact position being recorded in the log. The diameter of the test piece was then accurately measured in several places and the average recorded in the log. The tool was then fed in by hand until the cutting edge just scraped the bottom of the groove left by the last turning. The graduated disc on the cross feed having been set at zero, with the tool in the above position, the cross feed was turned back a little, and the carriage moved to the right sufficiently for the tool to clear the test piece. The cross feed was then advanced until the graduated disc showed the required cut opposite the index mark. The longitudinal feed or traverse was then set in position and recorded in the log. The diameter of the work and the surface speed required during the trial being known, the size of the pulley to be used on the motor and the position of the driving gear necessary to give the required speed were obtained from a set of curves giving the speed for various diameters of work for each of the 56 changes obtainable. having been done, the lathe was started and the surface speed tested with a Warner cutmeter. If found to be too far from the required speed, a different combination of motor pulley and cone gear was tried. A satisfactory speed having been obtained, the feed mechanism was started and the lathe allowed to run until the tool had entered the work and was taking the full cut. lathe was then stopped and the square-case revolution counter, which was actuated by the first motion shaft, set at zero. lathe was then cleared of all chips and the test started, the exact time of starting and the position of the revolution counter being recorded. During the trials, readings of the revolution counter and also of the wattmeter were taken every two minutes in order to obtain any variations in the cutting speed and the power required. After the expiration of the trial, which occurred either at the time of failure of the tool or at a specified time limit, the tool was withdrawn and the lathe run light under the same conditions of speed as in the trials, in order to observe the electrical horse-power exerted by the motor under these conditions. All cuttings were then collected, weighed and recorded in the log. To facilitate the collection of chips, sheet iron guards were placed on the bed of the lathe.

# (c) Description of Methods Adopted for Measuring the Force Required in Cutting

During the trials readings were taken at regular intervals of the total electrical watts input in the motor, while cutting, and after the tool had been withdrawn, with the lathe running light. The difference between the electrical horse-power with the tool cutting and with the lathe running without the cut should give the net horse-power required for cutting, and if this be multiplied by 33,000 and divided by the cutting speed, we obtain the force required for cutting in pounds. In thus figuring, we assume that the lost horse-power of the drive remains constant from no load to full load. To determine whether or not this was the case, a Prony brake was placed on the cast-iron test piece, as shown in Fig. 11. This could be made to offer the resistance otherwise produced by the cutting tool, and this resistance could be meas-




Fig. 11. Arrangement of Apparatus for Measuring Power
Absorbed by Friction in the Lathe, Countershaft and Belting

ured at the end of the brake arm by observing the reading on the scale beam of the platform scales. The brake arm was made 31.52 in. in length to facilitate the work of obtaining the horse-power, which would then be  $\frac{PN}{2000}$ , inwhich P is the net thrust on the scale in pounds and N the number of revolutions of the brake wheel.

Experiments were made on the lathe for both methods of driving it, either direct or through the back gearing. The results

of these experiments are given in Fig. 12. In the same figure is also shown the calibration curve for the motor alone, giving the horse-power output for a known input. The loss in the transmission for any known input could be immediately found, it




FIG. 12. CURVES GIVING RESULTS OF EXPERIMENTS TO DETERMINE
LOSS OF POWER IN LATHE AND COUNTERSHAFT
FOR VARYING LOADS

being the vertical distance between the curves at the required load. From the curves it can be seen that it is not constant, but increases at a constant ratio as the load increases. The equations derived from the curves, giving the relation between the net and gross load for both drives, are as follows:

(1) N=0.886G-0.32 (2) N=0.907G-0.41 Where N= net horse-power required for cutting, at the tool point, represented in Fig. 12 by the ordinates of the curves No. 2 and No. 3 according as the lathe is running with or without the back gears; and

G = total horse-power output of motor, represented in Fig. 12 by the ordinates of curve No. 1.

In these equations, (1) applies to the direct drive, and (2) to the drive through the back gears. The net horse-power recorded in Tables VI to X under column 6 contains the above-found correction. The nature of the results will be discussed in Part IV.

#### IV. RESULTS OF THE EXPERIMENTS

The results of the tests made with the eight brands of steel are given in full in Tables I to X below. Some of the most important relations are shown graphically on several plates. There were in fact five sets of experiments made which may properly be referred to as:

- (a) The preliminary trials
- (b) The skin cut trials
- (c) The endurance trials
- (d) Trials to obtain the durability of the steels at different cutting speeds for various sizes of cut, but on cast iron of constant hardness
- (e) Trials to obtain the durability of the steels on cast iron of varying hardness.


Tables I to V give for each of the experiments above referred to the observed and calculated data indicated in the 18 columns of results. Some of the most important results given in these tables are:

- (a) The cutting speed in feet per minute
- (b) The area of section cut
- (c) The area machined
- (d) The weight of material removed per minute
- (e) The relative durability of the tool
- (f) The hardness of the test piece

In the same way Tables VI to X give important data for each one of the sets of experiments carried out. The most interesting results which are given by these tables are:

- (a) The cutting force on the point of the tool
- (b) The net horse-power required to remove the metal
- (c) The horse-power required to run the lathe and the countershaft

The headings for the different tables are for the most part clearly indicated. It may be advisable, however, to explain some of them more fully. Referring to Tables I to V, we have in each table the same 18 headings. Columns 4, 5 and 6 give the speeds, cuts and feeds at which the trials were intended to be carried out, as calculated from the size of the pulleys and motor speeds. columns 7, 8 and 9 are given the actual speeds, cuts and feeds. The cutting speed recorded is the speed in feet per minute of the cylindrical surface of maximum diameter at the point of cutting. The depth of cut is one-half the difference of the diameters of the work before and after cutting. The feed is the advance of the tool per revolution of lathe spindle. Column 10 gives as the area of the section cut the product of the depth of cut and the feed. Columns 12 and 13 give the area of the surface machined. This was obtained by multiplying the cutting speed in feet per minute by the feed in feet per revolution of the spindle. Columns 14 and 15 give the total weight of cuttings removed during the trial and also per minute. These results were obtained by collecting and weighing the cuttings. Column 17 gives the comparative durability of the tool. An entirely arbitrary standard of durability was established as follows: A tool whose cutting edge was worn away .002 in. after one hour's use was considered perfect,



its durability being expressed as 100. The ratios of the durability of any other tools to the standard will then be the inverse of the ratios of their rates of wear to the rate of wear of the standard. The wear as assumed for the standard is shown in Figure 13 at x. In the experiments, however, the distance a

was measured and x then calculated.

TABLE I  $\ensuremath{^{\circ}}$  Experiments with High-Speed Tool Steel on Cast Iron

PRELIMINARY TRIALS

1 2	3	4	5 & 6	7	8	9	10	11
Name of Tes	Trial	Inten	ded	Actual	Ac	tual	Area	Duration
Brand of Tool Steel No	NT.	Speed	Cut & Feed	speed	Cut	Feed	Sec. of cut	of Trial
		Ft. Min.	Ins.	Ft./Min.	Ins.	Ins.	Sq.	Min.
1 04 -1 00				· ·			Ins.	
1 Styrian   28 2 ''   28		55 35	$\frac{3}{8}X\frac{3}{128}$	54.8	8	.0232	00870	33 31
$\frac{2}{3}$ " $\frac{28}{28}$	5	30	$\frac{1}{2}X\frac{1}{32}$	$\begin{array}{ c c c c c c c c c c c c c c c c c c c$	1	.0642	0.01560 $0.01600$	$15\frac{5}{6}$
4 " 28		60	$\frac{1}{4}X\frac{1}{16}$	60.5	이 보고 하는 기술을 가는 가는 이 등을 하는 것을 가는 것을 가 없다. 것을 가 되었다면 하지 않아 되었다면 가는 것을 가 되었다면 되었다면 가는 것을 가 되었다면 되었다면 가 없다면 되었다면 되었다면 되었다면 되었다면 되었다면 되었다면 되었다면 되었	.0952	.01190	5
5 " 28		60	$\begin{array}{c} \frac{1}{8} X \frac{3}{3} \frac{2}{2} \\ \frac{1}{8} X \frac{1}{16} \end{array}$	59.6	8	.0642	.00802	7 <del>1</del>
6 " 28		60	8 X 1 6 18 X 1 2	58.0	1 8	.0312	.00390	10
7 "   28		50	$\frac{3}{8}X\frac{3}{3}\frac{2}{3}$	52.1	3	.0312	.01160	15
8 " 28		50	$\frac{3}{8}X\frac{1}{32}$	47.6	8 3	.0312	.01160	8
9 " 28		40	$\frac{1}{4}X\frac{1}{32}$	41.2	i	0312	.00780	8
10 McInnes 1		30	8 X 1 6	28.4	į	.0642	.00802	10
11 " 1	24	30	66	31.8	i s	.0642	.00802	10
12 " 1		30	6.6	31.9	1 8	.0642	.00802	10
13 Novo 1		40	1 X 1 .	40.7	16	.0642	.00401	22
14 " 1		40	i	43.7	16 16 16 16 16 16 16 16 16 16 16 18	.0642	.00401	16
15 '' 1		40	"	42.5	16	.0642	.(0401	19
16 Styrian 1		40	66	41.3	16	.0642	.00401	$13\frac{1}{2}$
17 Novo 1		40		41.7	16	.0642	.00401	13
18 Styrian 27		150	$\frac{1}{8}$ $\times \frac{1}{3}$ $\frac{1}{2}$	152.1	8	.0312	.00390	111
19 Novo 27		150	1	153.1	8	.0312	.00390	9
20 McInnes 27		150	6.6	150.0	8	.0312	.00390	$\frac{1}{2}$
21 Styrian It		110	$\frac{3}{16}$ X $\frac{1}{16}$	111.0	16	.0642	.01200	7
22 Novo 10		105	8 X 1 6	107.2	8	.0642	.00802	12½ 42 42
23 Styrian 25	135	130	18X 1 3 2	133.8	8	.0312	.00390	45
± ± ± 1		130		134.3	8	.0312	.00390	26
20 20		100		102.9	8	.0312-	.00390	1/2
26 Novo 25 27 " 25		100		106.3 $101.5$	8	0.0312 0.0312	.00390	
28 Styrian 25	140	100	"	79.5	8	.0312	.00390	8
29 Jessop 31		50		53.3	8	.0642	.00802	
30 " 31		75	8 X 1 6	75.2	8	.0642	.00802	
31 " 32		85	4.6	85.0	3,16	.0642	.00802	
0.	110	00		00.0	8	.0012	.00002	222

TABLE 1—(Continued)

1	12	13	14	15	16	17	18
Name of	Ar Mach	ea ined		ight oved	Cause of	Comparative	
Brand of Tool Steel	Total	Per Min.	Total	Per Min.	Withdrawal	Durability of Tool	of Test Piece
	Sq. Ft.	Sq. Ft.	Lbs.	Lbs.			
1 Styrian	3.53		12 60	1.320	Times	100.00	114 5
2 "	2.92	.094		1.630	Time up	$\frac{100.00}{50.50}$	114.5 $114.5$
3 "	$\frac{2.32}{2.67}$	.169		$1.530 \\ 1.530$	4.6	12.90	114.5
4 "	$\frac{2.36}{2.36}$	.472		$\frac{1.930}{2.060}$	4.6	100.00	114.5
5 "	$\frac{2.30}{2.27}$	.310		1.340	66	100.00	114.5
6 "	1.51	.151	6.81	.681	66	100.00	114.5
7		.135	25.90		66	100.00	114.5
8 "		.124		1.530	66	100.00	114.5
9 "		.107	6.74	.843	4.6	100.00	114.5
0 McInnes	1.51	.151	6.43	.643	4.4	2.03	342.0
1 "	1.70		7.00	.700	Tool failed	0.00	342.0
2 "	1.70		7.37	.737	Time up	4.07	342.0
3 Novo	4.77	.217	11.80	.539	""	6.52	342.0
4 "	3.72		8.67	.542	6.6	6.93	342.0
5 "	4.31	.227	10.30	.541	4.6	4.90	342.0
6 Styrian	2.98	.221	7.26	.538	4.6	5,50	342.0
7 Novo	2.90		6.99	.538	4.4	5.30	342.0
8 Styrian	4.54	.395			Tool failed	3.12	132.0
9 Novo	3 58	.398			4.4	0.10	132.0
0 McInnes	.40	.390			6.6	0.00	132.0
21 Styrian	4.16	.594	28.75	4.107	6.6	0.00	109.8
2 Novo	7.16	.573	32.20	2.580	Time up	5.09	109.8
3 Styrian	1.61	.347		1.520	Tool failed	0.00	122.2
4 "	.75	.349		1.520	4.4	0.00	122.2
5 "	4.67	.267	21.20	1.210	Time up	3.56	122.2
6 Novo					Tool failed	0.00	122.2
7	1.76	.264		1.370	6.6	0.00	167.5
8 Styrian	1.65	.206		1.090	66	0.00	167.5
9 Jessop	[2.76]	.282	17.20		Time up	100.00	124.5
30 ''	5.92	.402	26.50		"	100.00	124.5
1 "	10.20	.454	45.60	2.030	4.6	18.30	124.5

 ${\bf TABLE~II}$  Experiments with High-Speed Tool Steel on Cast Iron

# SKIN-CUT TRIALS

. 1	2	3	4	5 & 6	7	8	9	10	11
Name of	Test	Trial	Inter	nded	Actual	Act	ual	Area	Duration
Brand of	Piece	21100		10. 1 0				of	of
Tool Steel	No.	No.	Speed	Cut & Feed	speed	Cut	Feed	Sec. of cut	Trial
	-		Ft./ Min.	Ins.	Ft./Min.	Ins.	Ins.	Sq.	Min.
1 04	90	,	'	7 3		7	.0232	Ins.	
1 Styrian .	$\frac{28}{28}$	$\frac{1}{2}$	45 35	$\frac{7}{32} \frac{X}{6128}$	45.2 36.3	372	.0232		$\frac{9\frac{1}{2}}{39}$
2 Styrian. 3 McInnes	28 29	$1\frac{2}{2}$	45	$\frac{1}{4}X\frac{1}{64}$	$\frac{30.5}{46.2}$	32	.0156		. 30
4 McInnes	29	13	60	4 X 6 4 4 X 1 2	59.5	1	.0312		$\frac{61}{6}$
5 McInnes	29	14	35	1 X 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	36.4	1	.0156		40
6 Styrian	3	97	50		50.6	324444444444444444444444444444444444444	.0312		40
7 Styrian.	6&7	98	55	$\frac{3}{16}$ $\frac{1}{6}$ $\frac{1}{6}$ $\frac{3}{6}$ $\frac{2}{6}$	55.2	1.0	.0312		$72\frac{1}{2}$
8 Novo	8	99	55	"	55.0	6.6	.0312		36
9 McInnes	9	100	55	6.6	57.4	6.6	.0312	.00585	35
10 Novo	10	101	55	4.6	55.5	6.6	.0312	.00585	35
11 McInnes	11	102	55	"	54.4	"	.0312		37
12 Poldi	12&13	103	55	6.6	55.6	66	,0312		72
13 A. & W.	14	104	55	"	55.3	"	.0312		$29\frac{1}{2}$
14 A. & W.	4	105	55	66	56.0	"	.0312		37
15 Styrian	5	106	70	_	67.9		.0312		30
16 Novo	18	107	70	8 X 3 2	68.8	1/8	.0312		21
17 McInnes	19	108	70		68.5		.0312		$8\frac{1}{2}$
18 McInnes	19	109	70		68.5		.0312	,00390	10
19 Poldi	$\frac{20}{20}$	110	70 70	66	68.0		.0312		19
20 Novo 21 Styrian.	$\frac{20}{17}$	$\begin{vmatrix} 111 \\ 112 \end{vmatrix}$	75	66	$68.2 \\ 75.3$	66	.0312		$\frac{11}{27}$
21 Styrian. 22 Novo:	26	113	75	66	75.3	6.6	.0312		$\frac{27}{27}$
23 McInnes	25	114	75	66	75.7	4.6	.0312		27
24 Poldi	16	115	75		74.7	66	.0312		$\frac{27}{261}$
25 A. & W.	24	116	75	6.6	73.9	6.6	.0312		$\frac{20_{2}}{27_{6}^{5}}$
26 Styrian.	23	117	75		72.2	66		.00390	$\frac{216}{28}$
27 Poldi	21	118	75	"	75.0	6.6		.00390	$\frac{26}{27}$
28 A. & W.	15	119	75	6.6	74.2	6.6	.0312		27
29 McInnes	22	120	75	6.6	73.8	6.6	.0312		191
30 Styrian.	22	121	75	6.6	72.5	6.6	.0312		81
31 Jessop	32	122	45	1 X 3 2	46.1	1		.00780	28
•					-				

TABLE II—(Continued)

1	12	$1\dot{3}$	14	15	16	17	18
Name of	Ar Mach		We Rem	ight oved	Cause of	Comparative	
Brand of Tool Steel	Total	Per Min.	Total	Per Min.	Withdrawal	Durability of Tool	of Test Piece
	Sq. Ft.	Sq. Ft.	Lbs.	Lbs.	1		
1 Styrian	0.83		4.6	.488	Tool failed	0.00	114.5
2 Styrian	2.76		14.4	.370	Time up	7.94	114.5
3 McInnes	1.81	.060	14.4	.480	"	6.12	195.0
4 McInnes	0.99	.155	7.1	1.105	Tool failed	5.23	195.0
5 McInnes	1.89		14.7	.367	Time up	8.16	195.0
6 Styrian	5.24		29.8	.746	"	100.00	94.2
7 Styrian		.143	57.2	.789	"	14.80	107.6
8 Novo	5.15	.143	23.3	.648	66	5.85	94.3
9 McInnes	5.21	.149	24.5	.702	66	5.70	138.6
0 Novo	5.04		33.5	.958		14.30	106.8
1 McInnes	5.22		30.0	.812	"	10.00	109.3
2 Poldi	10.40	.144	67.7	.941	"	17.85	103.3
3 A. & W	4.25	.144	$\frac{29.8}{35.6}$	$\frac{1.012}{.964}$		24.00	117.2
4 A. & W	$5.36 \\ 5.28$		34.2	1.140		15.00	109.2
5 Styrian	$\frac{3.28}{3.76}$		30.8	1.470	66	12.20	102.0
6 Novo	$\frac{3.76}{1.51}$	.178			Tool failed	4.28	107.0
18 McInnes		.178			Time up	8.13	$\frac{117.2}{117.2}$
9 Poldi	$\frac{1.76}{3.36}$		21.0	i.iio	Tool failed	0.00	117.2
20 Novo		.177	12.1	1.110	Time up	2.28	113.9
1 Styrian	5.29		24.4	.903	Time ab	22.00	90.3
22 Novo	5.26		19.0	.704	6.6	7.33	95.9
3 McInnes	5.32		23.0	.852	66	11.00	102.4
4 Poldi	5.14		$\frac{23.5}{22.5}$	.850	4.6	10.80	109.8
25 A. & W	5.34		24.6	.887	6.6	11.35	111.2
6 Styrian	5.23		$\frac{21.6}{22.6}$	.808	6.6	7.61	122.2
Poldi	5.26		19.1	.708	. 46	5.50	124.8
8 A. & W	5.21	.193	28.4	1.050	"	22.00	107.0
9 McInnes	3.70		14.5	.756	Tool failed	00.00	167.5
30 Styrian	1.60				Time up	3.46	167.5
31 Jessop	3.36		27.5	.982	"	22.80	123.2

TABLE III

EXPERIMENTS WITH HIGH-SPEED TOOL STEEL ON CAST IRON

ENDURANCE TRIALS

1 .	2	3	4	5 & 6	7	8	9	10	11
Name of Brand of	Test Piece	Trial	Inter	nded	Actual	Act	ual	Area of	Duration of
Tool Steel	No.	No.	Speed	Cut & Feed	Speed	Cut	Feed	Sec. of cut	Trial
			Ft. Min.	Ins.	Ft. Min.	Ins.	Ins.	Sq. Ins.	Min.
1 Novo	29	15	50	12X 14	47.6	다는 1 마은 1 마은 1 마은 1 마은 4 마은 4 마은 4 마은 4 마은	.0156		68
2 Styrian.	30	17 18	50		48.3	5		.00780	161
3 McInnes 4 Jessop	30 31	$\frac{18}{124}$	50 75		52.4 76.9	1		00780 $00780$	120 51
5 Novo	29	16	40	$\begin{array}{c c} \frac{1}{4}X\frac{1}{32} \\ \frac{1}{2}X\frac{1}{32} \end{array}$	37.6	1		.01560	$107\frac{1}{5}$
6 McInnes		19	75	$\frac{1}{8}X\frac{1}{32}$	77.8	į		.00390	181
7 Novo	27	20	75	8-732	75.5	î		.00390	8811
8 Styrian.	3	36	65	6.6	63 6	1 8	.0312	.00390	$195\frac{1}{2}$
9 McInnes	3	37	65	66	67.7	1 8		.00390	$181\frac{1}{2}$
10 Novo	3	38	65		67.1	1 8		.00390	$40\frac{1}{2}$
11 Styrian.	1	21	30	$\frac{1}{8}X_{\frac{1}{16}}$	28.0	8		.00802	981
12 Novo	1	22	30		27.7	8	.0642		971
13 Novo	2 2 31	34 35	50 50	46	$51.1 \\ 53.2$	8	0642	0.00802 0.00802	$153\frac{1}{2}$ $127$
14 Styrian. 15 Jessop	31	123	75	4.6	74.5	8	.0642		471
16 Rex	32	126	80	4.6	80.4	8	.0642		55
17 Styrian	12	45	85	18X32	88.7	1 8	.0952		493
18 McInnes		47	90	82.32	92.4	ì		.01190	15 Î
19 Novo	13	46	95	"	97.7	1 1	.0952	.01190	481
20 Poldi	14	48	105	4.6	105.2	1 8	.0952		171
21 A. & W.	14	49	115	66	113.6	1 8		.01190	$17\frac{1}{2}$
22 Styrian	1	26	35	16 X 16	38.7	16		.00401	88
23 McInnes		32	35	66	36.1	1 6 1 6 1 6		.00401	641
24 Styrian	1	33 125	35		36.6	16		.00401	581
25 Rex	32 6& 7	39	85 75	1	84.5 76.6	16	.0642	0.00401 $0.00595$	$\frac{62\frac{1}{2}}{125}$
26 Styrian 27 Novo	7&8	40	75	16 X 32	74.3	16 16 16 16 16 16	.0952		1193
28 McInnes		41	75	6.6	77.5	16	.0952		130
29 Poldi	9& 10	42	75	"	77.4	16		.00595	128
30 A. & W.		43	75	4.6	75.0	16		.00595	1223
31 Mushet.	11	44	75	6.6	74.6	16	.0952		$42\frac{7}{2}$
			1			' '	1		

TABLE III—(Continued)

1	12	13	14	15	16	17	18
Name of		ea nined		ight oved	Cause of	Comparative	Hardness of Test Piece  195.0 124.2 124.2 124.5 195.0 132.0 132.0 94.2 94.2 94.2 175.2 175.2 124.5 123.2 100.0 117.2 117.2 117.2 1342.0 342.0 342.0
Brand of Tool Steel	Total	Per Min.	Total	Per Min.	Withdrawal	Durability of Tool	
	Sq. Ft.	Sq. Ft.	Lbs.	Lbs.			
1 Novo	4.2	.062		1.058	Time up	27.6	
2 Styrian	10.1	.062		1.132	66	100.0	
3 McInnes	8.2	.068		1.087	6.6	100.0	
4 Jessop	10.2	.200		1.756	6.6	20.7	
5 Novo		.097		1.695	6.6	29.2	
6 McInnes	36.6	.202	161.0		44	100.0	
7 Novo	17.4	.196	77.8	.875	6.6	100.0	
8 Styrian	32.2	.165	154.0		6.6	53.1	
9 McInnes	31.9	.176	145.0		6.6	36.9	
10 Novo	+7.0	.174	30.7		"	100.0	
11 Styrian	14.7	.149	63.2			40.0	
12 Novo	14.4	.148	67.6			26.3	
13 Novo	41.9	.273		1.230	4.6	28.6	
14 Styrian	36.1	.284		1.300	"	42.8	
15 Jessop		.398		1.820	1	9.6	
16 Rex		.430		1.930		9.6	
17 Styrian		.702	163.0	3.270		20.3	
18 McInnes	. 11.3	.732	1::::::		Tool failed	2.5	
19 Novo	. 37.3	.774		3.480		13.0	
20 Poldi		.834		3.570		0.0	
21 A. & W		.902		3.710		3.8	
22 Styrian		.207	42.0		Time up	17.1	
23 McInnes		.193	38.2			17.5	
24 Styrian	$\frac{11.4}{20.2}$	.195	26.8			11.9	342.0
25 Rex	. 28.2	.452	61.5			17.0	123.2
26 Styrian		.600		1.400		50.9	107.6
27 Novo		.582		1.420		32.4	90.4
28 McInnes	$\frac{79.8}{20.6}$	.614		1.470		27.4	116.4
29 Poldi	18.0	.614		1.440		34.7	$\frac{122.7}{108.0}$
30 A. & W	12.9	.595		1.380	1	23.0	108.0
31 Mushet	. 25.1	.591	60.3	1.420		100.	109.5

TABLE IV

EXPERIMENTS WITH HIGH-SPEED TOOL STEEL ON CAST IRON

TRIALS TO DETERMINE VARIATION OF DURABILITY WITH CUTTING SPEED

1	2	3	4	5 & 6	7	8	9	10	11
Name of	Test	Trial	Inten	ded.	Actual	Act	Actual		Duration of
Brand of Tool Steel	Piece No.	No.	Speed	Cut & Feed	Speed	Cut	Feed	Sec. of cut	Trial
			Ft./ Min.	Ins.	Ft./ Min.	Ins.	Ins.	Sq. Ins.	Min.
1 Styrian	18	59	90	$\frac{1}{16} X \frac{3}{32}$	91.5	16	.0952		44
3	18	60	100	"	102.5	1 6 1 6 1 6 1 6	.0952		$28\frac{1}{2}$
3 4	18	61	110	"	110.6	16	. 0952		$43\frac{1}{2}$
4 "	18	62	120	"	120.6	1.6	.0952		$41\frac{1}{3}$
5 Mushet	5	58	90	$\frac{1}{8}X\frac{1}{32}$	91.6	8	.0312		$12\frac{1}{4}$
6 McInnes		54	95		95.3	8	.0312		62
7 "	5	55	100		100.3	8	.0312		$61\frac{1}{2}$
8 "	5	56	110	66	110.9	8		.00390	$62\frac{1}{3}$
9 "	5	57	120		123.4	8	.0312		31
10 Novo	4	50	85	1 8 X 1 6	86.1	8	.0642		29
11 "	4	51	95		98.7	8		.00800	271
12 "	4	52	105	66	105.2	8	.0642		30
13	4	53	115		114.9	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1		.00800	31 1
14 Poldi	19	63	105	$\frac{3}{16}X_{16}$	106.8	16		01200	
15 "	19	64	115	"	116.1	16	.0642		
16 "	19	65	125	, ",	125.7	3 16 3 16 4 1		.01200	
17 A. & W.	20	66	110	$\frac{1}{4}X_{\frac{1}{1}6}$	109.3	4		0.01600	
18 "	20	67	120	"	120.0	4		.01600	
19 "	20	68	130		130.4	1/4	.0642	2 .01600	194
		1		1	1			1	-

TABLE IV—(Continued)

1	12	13	3   14   15   16   17		17	18		
Name of		rea nined	We Rem	ight oved	Cause of	Comparative		
Brand of Tool Steel	Total	Per Min.	Total	Per Min.	Withdrawal	Durability of Tool	of Test Piece	
	Sq. Ft.	Sq. Ft.		Lbs.				
1 Styrian		.726	70.0	1.59	Time up	12.00	107.0	
2 "	. 23.1	.812	48.2		Tool failed	7.76	107.0	
o	. 38.1	.877	87.9		Time up	11.80	107.0	
*	. 39.5	.956	96.6			5.50	107.0	
5 Mushet		.238	12.1	.99	Tool failed	0.00	102.0	
6 McInnes		.247	65.7	1.06	Time up	50.57	102.0	
1	. 16.0	.261	[71.3]			25.60	102.0	
8 "	.17.9	.288	78.5	1.26	"	13.00	102.0	
	$\frac{9.9}{19.9}$	.321	43.7	1.41	Tool failed	6.37	102.0	
0 Novo	. 13.3	.460	61.8	2.13	Time up	7.53	109.2	
1	14.5	.527	66.0	2.40	"	5.63	109.2	
<u> </u>	10.0	.562	83.1	2.77	"	12.20	109.2	
• • • • • • • • • • • • • • • • • • • •		.614	88.8	2.82		3.31	109.2	
4 Poldi	12.9	.572	85.7	3.81		13.90	117.2	
5 " 6 "	. 13 5	.622	92.6	4.25		35.50	117.2	
7 A 0 TTT	14.8	.672	102.0	4.64		100.00	117.2	
7 A. & W 8		.584	87.1	5.28		13.40	113.9	
9 "	$. \begin{bmatrix} 11.9 \\ 12.1 \end{bmatrix}$	.642	106.0	[5.72]	"	100.00	113.9	
	. 13.4	.697	118.0	6.16		15.70	113.9	

TABLE V

EXPERIMENTS WITH HIGH-SPEED TOOL STEEL ON CAST IRON

TRIALS TO DETERMINE VARIATION OF DURABILITY WITH HARDNESS

1	2	3	4	5 & 6	ī	8	9	10	11
Name of Brand of	Test Piece	Trial	Inter	ided	Actual	Act	ual	Area	Duration of
Tool Steel	No.	No.	Speed	Gut & Feed	speed	Cut	Feed	sec. of cut	Trial
			Ft./Min.		Ft. Min.	Ins.	Ins.	Sq. Ins.	Min.
1 Novo	22	94	50	$\frac{1}{8} \times \frac{1}{32}$	50.9	Ŕ	.0312	.00390	83
2 Poldi	22	96	75		75.1	8		.00390	$88\frac{1}{2}$
3 Styrian.	23	85	75	6.6	75.2	181818181		.00390	$38\frac{1}{2}$
4 Novo	15	91	100	6.6	100.3	8		.00390	$37\frac{3}{4}$
5 A. & W.	21	88	100	6.6	101.5	1 8	.0312	.00390	38
6 McInnes	17	70	100	6.6	101.9	1 8	.0312	.00390	$36\frac{3}{4}$
7 Poldi	26	73	125	1.4	125.8	8	.0312	1.00390	301
8 A. & W.	16	79	130	66	130.0°	1 8	.0312	.00390	295
9 Styrian.	25	76	130	6.6	131.2	1	,0312	.00390	$\frac{29\frac{5}{6}}{29\frac{3}{4}}$
10 Novo	24	82	130	6.6	132.0	1818		.00390	29 <sup>3</sup> / <sub>4</sub> 33 <sup>3</sup> / <sub>4</sub>
11 Poldi	22	95	50	1/8×1/6	50.4	1		.00802	333
12 A. & W.	23	86	70	70716	70.9	1 8	.0642	.00802	235
13 A. & W.	15	- 92	95	4.6	95.0	1		.00802	28
14 McInnes	21	89	95	6.6	95.2	1	.0642		$20\frac{1}{2}$
15 Styrian	17	71	95	4.6	95.2	1	.0642		27
16 Poldi	16	80	120	66	120.0	1 5 1 8	.0642		9
17 Novo	25	77	120	6.6	121.2	1	.0642		21
18 McInnes	24	83	120	6.6	122.7	1818		.00802	211
19 A. & W.	26	74	140	6.6	143.4	1		.00802	181
120 Novo	23	87	65	_3, ×_1		3		.01200	
21 Styrian	21	90	85	$\frac{-3}{16} \times \frac{1}{16}$	85.2	1 6 3 1 6		.01200	321
22 Poldi	15	93	85	66.	86.2	3		.01200	$25\frac{3}{4}$
23 Novo	17	72	85	6.6	88.8	1.6		.01200	24
24 McInnes		75	100	. 6	101.1	1 6		.01200	22
25 Styrian	16	SI	110		101.1	1.6		.01200	131
26 A. & W.	24	84	110	4.6	110.6	1.6		01200	16
27 Poldi	25	78	110	66	111.5	1.6		01200	21
28 Rex	32	127	70	6.6	72.2	3 1 6 3		.01200	
LO ILUX	92	121	10		12.2	3 1 δ	.0042	01200	29

TABLE V—(Continued)

			L				
1	12	13	14	15	16	17	18
Name of Brand of		rea hined	Rem	eight oved Per	Cause of Withdrawal	Comparative Durability	of Test
Tool Steel	Total	Per Min.	Total	Min.		of Tool	Piece
·	Sq.	Sq. Ft.	Lbs.	Lbs.			
1 Novo	10.9	.132	55.4	.668	Time up	67.6	167.5
2 Poldi	17.2	.195	75.9	.858	"	68.1	167.5
3 Styrian	7.5	.195	35.8	.929	6.6	15.7	122.2
4 Novo	9.9	.262	45 2	1.200	6.6	100.0	132.0
5 A. & W	10.0	.264	46.0	1.210	6.6	31.0	124.8
6 McInnes	9.6	.264	44.8	1.220	6.6	60.0	90.3
7 Poldi	9.9	.327		1.580	6.6	24.8	95.9
8 A. & W	10.1	.338		1.480	6.6	12.2	109.8
9 Styrian	10.1	.341		1.540	6.6	100.0	102.4
10 Novo	10.2	.343		1.600	4.6	12.1	111.2
11 Poldi	9.0	.269		1.220	66	27.5	167.5
12 A. & W	9.0	.379		1.730	4.6	38.8	122.2
13 A. & W	44.2	.508		2.110	٠٠ .	100.0	132.0
14 McInnes	10.4	.509		2.130	Tool failed	.0	124.8
15 Styrian	13.7	.509		2.180	Time up	100.0	90.3
16 Poldi	5.7	.642		2.680	Tool failed	.0	109.8
17 Novo	13.6	.649		2.940	Time up	100.0	102.4
	14.1	.657		3.050	"	35.0	111.2
	14.2	.767		3.480	"	15.1	95.9
20 Novo	11.5	.350		2.400	6.6	$\frac{15.1}{65.5}$	122.2
	14.6	.455	98.7	3.070	4.6	13.1	124.8
	18.5	.461	73.5	2.860	"	10.4	132.0
		.475		3.220	"	100.4	90.3
	11.9	.541		3.570		35.8	95.9
25 Styrian	7.7	.588		3.850	66	3.6	109.8
26 A. & W	9.5	.592	64.3		+6	26.0	111.2
	12.5	.597	82.1		"	100.0	102.4
	11.2	.386		2.490	66	4.7	123.2
-0 1.011,		.000	12.0	2.100		7.1	1.00.0

TABLE VI  $\label{table VI}$  Experiments with High-Speed Tool Steel on Cast Iron

PRELIMINARY TRIALS

1	2	3	4	5	6	7
					<u> </u>	
Name of Brand of Tool Steel.	Test Piece No.	Trial	Total output of Motor	Horse-Power Required to drive lathe and countershaft	Net	Actual cutting speed
1 Styrian	28 "" "" "" "" "" "" "" "" "" "" "" "" ""	3 4 4 5 6 6 7 8 9 10 111 23 24 25 27 28 29 30 31 130 131 132 133 134 135 136 137 138 139 140 141	2.52 2.78 2.30 3.05 2.29 1.29 3.08 2.42 1.46 1.83 1.90 1.87 1.48 1.67 1.41 1.52 1.42 3.06 2.83  4.89 3.12 2.74 2.69 2.43 2.50 2.50	.65 .67 .63 .70 .63 .70 .64 .55 .58 .59 .59 .55 .57 .54 .55 .54 .67 .5589 .68 .64 .63 .6060 .65	cutting  Col. (4) — (5)  1.87 2.11 1.67 2.35 1.66 .76 2.38 1.78 .91 1.25 1.31 1.28 .93 1.10879788 2.39 2.28	Ft./Min. 54.8 36.2 32.5 60.5 59.6 58.0 52.1 47.6 41.2 28.4 31.8 31.9 40.7 43.7 42.5 41.3 41.7 152.1 153.1 150.0 107.2 133.8 134.3 102.9 106.3 101.5 79.5 53.3

TABLE VI-(Continued)

1	8	9	10	11	12
Name of	Cutting for of T		Size	Area	Hardness
Brand of Tool Steel	Total calculated	Per Sq. In. Area of cut	of Cut	Cut (cut × feed)	of Test Piece
	Lbs.	Lbs.	Ins.	Sq. In.	
1 Styrian	1126	129300	$\frac{3}{8} \times \frac{3}{128}$	.00870	114.5
2 ""	1925	123200	$\frac{1}{2} \times \frac{1}{32}$	.01560	114.5
3 "	1696	106000	$\frac{1}{4} \times \frac{1}{16}$	.01600	114.5
4 · · ·	1282	107800	$\frac{1}{8} \times \frac{3}{32}$	.01190	114.5
5 ''	920	114800	$\frac{1}{8} \times \frac{1}{16}$	.00802	111.5
6 "	432	110800	$\frac{1}{8} \times \frac{1}{32}$	.00390	114.1
7 "	1508	130000	$\frac{3}{8} \times \frac{1}{32}$	.01160	114.5
8 "	1235	106500	$\frac{3}{8} \times \frac{1}{32}$	.01160	114.5
9 "	728	93400	$\frac{1}{4} \times \frac{1}{32}$	.00780	114.5
10 McInnes	1451	181000	$\frac{1}{8} \times \frac{1}{16}$	.00802	342.0
11 "	1360	169800		.00802	342.0
12 "	1325	165300	6.6	.00802	342.0
13 Novo	754	188000	1 × 1 16	.00401	342.0
14 "	832	207000		.00401	342.0
15 "	675	168200	6.6	.00401	342.0
16 Styrian	773	192500		.00401	342.0
17 Novo	697	173500		.00401	342.0
18 Styrian	519	133000	$\frac{1}{8} \times \frac{1}{32}$	.00390	132.0
19 Novo	492	126000		.00390	132.0
20 McInnes	1100	*****	4.6	.00390	132.0
21 Styrian	1189	99100	$\frac{\frac{3}{16}}{\frac{1}{8}} \times \frac{1}{\frac{1}{16}}$ $\frac{1}{8} \times \frac{1}{16}$ $\frac{1}{8} \times \frac{1}{32}$	.01200	109.8
22 Novo	752	93800	$\begin{array}{c} \frac{1}{8} \times \frac{1}{16} \\ \frac{1}{8} \times \frac{1}{32} \end{array}$	.00802	109.8
23 Styrian	518	132800	$\frac{1}{8} \times \frac{1}{32}$	.00390	122.2
44	507	130000	6.6	.00390	122.2
in the	593	152000	4.6	.00390	122.2
26 Novo	****		6.6	.00390	122.2
41	595	152500	6.6	.00390	167.5
28 Styrian	768	196800	6.6	.00390	167.5
29 Jessop	1145	142800	$\frac{1}{8} \times \frac{1}{16}$	.00802	124.5
30 "	958	119300	66	.00802	124.5
31 "	847	105600	6.6	.00802	124.5

TABLE VII

EXPERIMENTS WITH HIGH-SPEED TOOL STEEL ON CAST IRON

SKIN CUT TRIALS

1	2	3	4	5	6	7
Name of Brand of Tool Steel	Test Piece No.	Trial	Total Output of Motor	Horse-Power Required to drive lathe and countershaft	Net	Actual Cutting Speed
1 Styrian 2 Styrian 3 McInnes 4 McInnes 5 McInnes 6 Styrian 8 Novo 9 McInnes 10 Novo 11 McInnes 12 Poldi 13 A & W 14 A & W 15 Styrian 16 Novo 17 McInnes 18 McInnes 19 Poldi 20 Novo 21 Styrian 22 Novo 23 McInnes 24 Poldi 25 A & W 26 Styrian 27 Poldi 28 A & W 29 McInnes 30 Styrian 31 Jessop	28 28 29 29 3 6 & 7 8 9 10 11 12 & 13 14 4 5 18 19 19 20 20 17 26 25 16 24 23 21 15 22 22 32	1 2 12 13 14 97 98 99 100 101 102 103 104 105 106 107 108 111 112 113 114 115 116 117 118 119 120 121 122	1.22 0.82 1.47 2.53 1.14 1.38 1.67 1.48 1.74 1.86 1.38 1.82 2.00 2.12 2.29 2.29 2.50 2.41 1.88 1.88 1.88 1.88 1.88 1.88 1.88 1	.52 .49 .55 .65 .52 .54 .57 .55 .57 .60 .57 .59 .54 .58 .60 .61 .63 .63 .65 .64 .59 .59 .58 .58 .60 .58 .58 .60	Col. (4) - (5) 0.70 0.33 0.92 1.88 0.62 0.84 1.10 0.93 1.17 1.36 1.17 1.27 0.84 1.24 1.40 1.51 1.66 1.66 1.85 1.77 1.29 1.29 1.20 1.25 1.36 1.26 1.27 1.42 1.18 1.40	Ft./ Min.  45.2 36.3 46.2 59.5 36.4 50.6 55.2 55.0 57.4 55.5 54.4 55.6 55.3 56.0 67.9 68.8 68.5 68.5 68.0 68.2 75.3 75.2 75.7 74.7 73.9 72.2 75.0 74.2 73.8 72.5 46.1

TABLE VII—(Continued)

1	8	9	10	11	12
Name of	Cutting For		Size	Area of	Hardness of
Brand of Tool Steel	Total Calculated	Per Sq. In. Area of Cut	of Cut	$\operatorname{Cut}_{(\operatorname{cut} \times \operatorname{feed})}$	Test Piece
	Lbs.	Lbs.	Ins.	Sq. In.	
1 Styrian 2 Styrian	511 300	101000 59300	$\frac{7}{32}X_{\frac{1}{4}}\frac{3}{28}$	.00507	$114.5 \\ 114.5$
3 McInnes	$658 \\ 1042$	168500 133800	$\begin{array}{c} \frac{1}{4} X \frac{1}{64} \\ \frac{1}{4} X \frac{1}{32} \end{array}$	.00390	195.0 195.0
5 McInnes 6 Styrian	562 548	144000 93800	$\begin{array}{c} \frac{1}{4}X\frac{1}{64} \\ \frac{3}{16}X\frac{1}{32} \end{array}$	.00390 .00585	$195.0 \\ 94.2$
7 Styrian 8 Novo	658 558	112500 95500	4.4	.00585 .00585	$107.6 \\ 94.3$
9 McInnes 10 Novo	673 809	115000 138300	66 66	.00585 .00585	$138.6 \\ 106.8$
11 McInnes 12 Poldi	710 754 502	121300 129000 85800	44	.00585	109.3 $103.3$
13 A & W	732 682	125000 116300	"	.00585 .00585 .00585	$117.2 \\ 109.2 \\ 102.0$
16 Novo	725 800	185800 205000	$\frac{1}{8}X_{\frac{3}{44}2}^{\frac{1}{32}}$	.00390	107.0 117.2
18 McInnes 19 Poldi	800 899	205000 230000	"	.00390	$117.2 \\ 113.9$
20 Novo 21 Styrian	858 565	219600 145000	6.6	.00390	113.9 90.3
22 Novo	$\frac{567}{524}$	145200 134300	"	.00390	$95.9 \\ 102.4$
24 Poldi	553 608	141800 155800	6 6 6 6	.00390	109.8 $111.2$
26 Styrian	577 559 699	147800 143200 179000	66	.00390	$122.2 \\ 124.8 \\ 107.0$
29 McInnes 30 Styrian	636 538	163000 137800	4.6	.00390 .00390 .00390	167.5 167.5
31 Jessop	1001	128500	$\frac{1}{4}$ X $\frac{1}{3}$ $\frac{1}{2}$	.00780	123.2

TABLE VIII EXPERIMENTS WITH HIGH-SPEED TOOL STEEL ON CAST IRON ENDURANCE TRIALS

1	2	3	4	5	6	7
		m ! )		Horse-Power		
Name of Brand of	Test Piece	Trial	Total	Required to	Net	Actual Cutting
Tool Steel	No.	No.		drive lathe and		Speed
***************************************			Motor	countershaft	Cutting	
		,			(5)	Et Min
					Col. $(4) - (5)$	
1 Novo	29	15	2.83	.68	2.15	47.6
2 Styrian	30	17	2 52	. 65	1.87	48.3
3 McInnes	30	18	2.31	.63	1.68	52.4
4 Jessop	31	124	3.10	.68	2.42	76.9
5 Novo	29	16	3.58	.75	2.83	37.6
6 McInnes	27	19	1.57	.56	1.01	77.8
7 Novo	27	20	1.49	.49	1.00	75.5
8 Styrian	3	36	1.34	.54	0.80	63.6
9 McInnes	3	37	1.33	.47	0.86	67.7
10 Novo	3	38	1.27	.47	0.80	67.1
11 Styrian	1	21	1.56	.56	1.00	28.0
12 Novo	1	22	.1.66	.56	1.10	27.7
13 Novo	2 2	34	2.13	.61	1.52	51.1
14 Styrian		35	1.78	.58	1.20	53.2
15 Jessop	31	123	2.98	.66	2.32	74.5
16 Rex	32	126	3.05	.67	2.38	80.4
17 Styrian	12	45	3.16	.68	2.48	88.7
18 McInnes	14	47	3.53	.73	2.80	92.4
19 Novo	13	46	3.67	.74	2.93	97.7
20 Poldi	14	48	4.49	.83	3.66	105.2
21 A. & W	14	49	4.83	.87	3.96	113.6
22 Styrian	1	26	1.19	.52	0.67	38.7
23 McInnes	1	32	1.24	.53	0.71	36.1
24 Styrian	1	33	1.29	.47	0.82	36.6
25 Rex		. 125	2.03	.57	1.46	84.5
26 Styrian	6 & 7	39	1.89	.57	1.32	76.6
27 Novo	788	40	1.56	.50	1.06	74.3
28 McInnes	8 & 9	41	1.92	.59	1.33	77.5
	9 & 10	42	2.04	.60	1.44	77.4
	10 &11	43	1.96	.54	1.42	75.0
31 Mushet	11	44	1.79	.53	1.26	74.6

TABLE VIII—(Continued)

1	8	9	10	11	12
Name of		Cutting Force on Point of Tool		Area of	Hardness of
Brand of Tool Steel	Total Calculated	Per Sq. In. Area of Cut	of Cut	Cut (cut×feed)	Test Piece
	Lbs.	Lbs.	Ins.	Sq. Ins.	
1 Novo	$\frac{1492}{1275}$	191500 163500	$\frac{1}{2} \times \frac{1}{64}$	.00780	$195.0 \\ 124.2$
2 Styrian	1059	135800	66	.00780	$\frac{124.2}{124.2}$
3 McInnes 4 Jessop	1040	133300	$\frac{1}{4} \times \frac{1}{3^{\frac{1}{2}}}$	.00780	124.5
5 Novo	2482	159100	$\frac{4}{2} \times \frac{32}{32}$	.01560	195.0
6 McInnes	428	109700	$\begin{array}{c} \frac{1}{4} \times \frac{1}{32} \\ \frac{1}{2} \times \frac{1}{32} \\ \frac{1}{8} \times \frac{1}{32} \end{array}$	.00390	132.0
7 Novo	437	112000	$\frac{1}{8} \times \frac{1}{32}$	.00390	132.0
8 Styrian	415	106400	6.6	.00390	94.2
9 McInnes	419	107300	4 6	.00390	94.2
10 Novo	394	101000	6.6	.00390	94.2
11 Styrian	1179	147000	$\frac{1}{8} \times \frac{1}{16}$	.00802	342.0
12 Novo	1310	163500	6.6	.00802	342.0
13 Novo	982	122500	4 6	.00802	175.2
14 Styrian	745	93000	6.6	.00802	175.2
15 Jessop	1029	128300	6.6	.00802	124.5
16 Rex	978	122000	4 6	.00802	123.2
17 Styrian	924	77900	$\frac{1}{8} \times \frac{3}{32}$	.01190	100.0
18 McInnes	1000	84000	66	.01190	117.2
19 Novo	1010	84900	4.6	.01190	106.6
20 Poldi	1148	96500	66	.01190	117.2
21 A. & W	1151	96800		.01190	117.2
22 Styrian 23 McInnes	571	142300	16 X 16	.00401	342.0
	649 739	161600	6 5	.00401	342.0
		184000 142000	6.6	.00401	$342.0 \\ 123.2$
25 Réx	570 569	95700	1 🗸 3	.00401	107.6
27 Novo	471	79200	$\frac{1}{16} \times \frac{3}{32}$	.00595	90.4
28 McInnes	567	95300	6.6	.00595	116.4
29 Poldi	615	103200	66	.00595	122.7
30 A. & W	625	105000	6.6	.00595	108.0
31 Mushet	557	93800	* 66	.00595	109.3
or muchous,	001	00000		.00000	100.0

TABLE IX

EXPERIMENTS WITH HIGH-SPEED TOOL STEEL ON CAST IRON

TRIALS TO DETERMINE VARIATION OF DURABILITY WITH CUTTING SPEED

1	2	3	4	5	6	7
Name of	Test	Trial		Horse-Power		Actual
Brand of	Piece	Triai	Total	Required to	Net	Cutting
Tool Steel	No.	No.	Output of	drive lathe and	Required for	Speed
2001.0000		2.01	Motor	countershaft	Cutting	
					Col. (4)—(5)	Ft./ Min.
1 Styrian	18	59	2.38	.59	1.79	91.5
2 Styrian	18	60	$\frac{2.50}{2.71}$	.63	2.08	102.5
3 Styrian	18	61	2.84	.65•	2.19	110.6
4 Styrian	18	62	3.08	.67	2.41	120.6
5 Mushet	5	58	1.77	.52	1.25	91.6
6 McInnes	5	54	1.58	.50	1.08	95.3
7 McInnes	5	55	1.78	.52	1.26	100.3
8 McInnes	5	56	2.16	.59	1.57	110.9
9 McInnes	5 4	57	$\frac{2.19}{2.61}$	.57	$\frac{1.62}{1.99}$	123.4 86.1
10 Novo	4	50 51	$\frac{2.01}{2.92}$	.66	2.26	98.7
12 Novo	4	52	3.14	.68	2.46	105.2
13 Novo	4	53	3,76	.75	3.01	114.9
14 Poldi	19	63	4.48	.83	3.65	106.8
15 Poldi	19	64	5.06	.90	4.16	116.1
16 Poldi	19	65	5.20	,92	4.28	125.7
17 A. & W	20	66	6.50	1.07	5.43	109.3
18 A. & W	20	67	5.98	1.01	4.97	120.0
19 A. & W	20	68	6.04	1.01	5.03	130.4

TABLE IX—(Continued)

1	8	9	10	11	12
Name of Brand of Tool Steel	· ·	rce on Point Cool Per Sq. In. Area of Cut	Size of Cut	Area of Cut (cut×feed)	Hardness of Test Piece
	Lbs.	Lbs.	Ins.	Sq. Ins.	
1 Styrian 2 Styrian	647 670	$\begin{array}{c c} 108800 \\ 112600 \end{array}$	$\frac{1}{16} \times \frac{3}{32}$	.00595	107.0 107.0
3 Styrian	653	109800	66	.00595	107.0
4 Styrian 5 Mushet	$\frac{661}{450}$	111000 115400	$\frac{1}{8} \times \frac{1}{32}$	.00595	$107.0 \\ 102.0$
6 McInnes	374	96000	66 33	.00390	102.0
7 McInnes 8 McInnes	414 468	106100 120000	46	.00390	$102.0 \\ 102.0$
9 McInnes 10 Novo	433 763	111100 95300	1 × 1 1 6	.00390	$102.0 \\ 109.2$
11 Novo	757	94400	1 × 1 16	.00802	109.2
12 Novo	772 866	96300 108000		.00802	$\frac{109.2}{109.2}$
14 Poldi 15 Poldi	1128 1182	94000	$\frac{3}{16} \times \frac{1}{16}$	.01200	117.2 117.2
16 Poldi	1124	98500 93750		.01200	117.2
17 A. & W 18 A. & W	1640 1366	102500 85500	$\frac{1}{4} \times \frac{1}{16}$	.01600	113.9 113.9
19 A. & W	1273	79600	66	.01600	113.9

TABLE  $\, {
m X} \,$  Experiments with High-Speed Tool Steel on Cast Iron

TRIALS TO DETERMINE VARIATION OF DURABILITY WITH HARDNESS

1	2	3	4	5	6	7
Brand of 1	Test Piece No.	Trial	Total output of Motor	Horse-Power Required to drive lathe and countershaft	Net	Actual cutting speed
1 Novo 2 Poldi 3 Styrian 4 Novo 5 A. & W 6 McInnes 7 Poldi 8 A. & W 9 Styrian 10 Novo 11 Poldi 12 A. & W 13 A. & W 14 McInnes 15 Styrian 16 Poldi 17 Novo 18 McInnes 19 A. & W 20 Novo 21 Styrian 22 Poldi 23 Novo 24 McInnes 25 Styrian 26 A. & W 27 Poldi 28 Rex	22 22 23 15 21 17 26 16 25 24 22 23 15 21 17 16 25 24 22 23 21 17 26 25 24 27 27 26 27 27 26 27 27 27 27 27 27 27 27 27 27 27 27 27	94 96 85 91 88 70 73 79 86 92 89 71 80 77 83 74 87 90 93 72 75 81 84 78 127	1.57 2.03 2.08 1.88 2.18 1.87 2.51 2.38 2.26 2.54 2.44 2.73 2.62 4.07 2.65 3.88 3.33 3.27 3.83 3.55 4.05 3.68 4.02 4.02 4.02 4.03 4.03 4.04 4.04 4.04 4.04 4.04 4.04	.56 .55 .56 .54 .57 .53 .61 .59 .58 .61 .64 .63 .62 .80 .62 .77 .70 .70 .76 .75 .79 .78 .79 .78 .70 .74 .84	Col. (4) — (5)  1.01 1.48 1.52 1.34 1.61 1.34 1.90 1.79 1.68 1.93 1.80 2.10 2.00 3.27 2.03 3.11 2.63 2.57 3.07 2.80 3.26 3.18 2.66 2.94 3.74 3.24 3.42 2.78	Ft./Min.  50.9  75.1  75.2  100.3  101.5  101.9  125.8  130.0  131.2  132.0  50.4  70.9  95.2  120.0  121.2  122.7  143.4  65.5  85.2  86.2  88.8  101.1  109.8  110.6  111.5  72.2

TABLE X—(Continued)

Name of Brand of Tool Steel         Cutting Force on Point of Tool Total Calculated         Size of Cut           Lbs.         Lbs.         Ins.           1 Novo         655         168000 $\frac{1}{8} \times \frac{1}{32}$ 2 Poldi         650         166500 $\frac{1}{8} \times \frac{1}{32}$ 3 Styrian         668         171100 $\frac{1}{8} \times \frac{1}{32}$ 4 Novo         441         113100 $\frac{1}{8} \times \frac{1}{32}$ 6 McInnes         434         111200 $\frac{1}{8} \times \frac{1}{32}$ 7 Poldi         498         127700 $\frac{1}{8} \times \frac{1}{32}$ 8 A. & W         454         116300 $\frac{1}{8} \times \frac{1}{32}$ 10 Novo         482         123500 $\frac{1}{8} \times \frac{1}{32}$ 11 Poldi         1179         147100 $\frac{1}{8} \times \frac{1}{32}$ 12 A. & W         978         122000 $\frac{1}{8} \times \frac{1}{32}$ 13 A. & W         695         86700 $\frac{1}{8} \times \frac{1}{32}$ 14 McInnes         1134         141500 $\frac{1}{8} \times \frac{1}{32}$ 15 Styrian         704         87800 $\frac{1}{8} \times \frac{1}{32}$ 16 Poldi         855         106500 $\frac{1}{8} \times \frac{1}{32}$ <tr< th=""><th>11</th><th>12</th></tr<>	11	12
$\begin{array}{c ccccccccccccccccccccccccccccccccccc$	Area of Cut (cut×feed)	Hardness of Test Piece
21 Styrian     1264     105300     """       22 Poldi     1219     101509     ""       23 Novo     989     82400     ""       24 McInnes     958     79800     ""       25 Styrian     1123     93700     ""       26 A. & W     967     80600     ""       27 Poldi     1012     84500     ""       28 Rex     1271     106000     ""	.00390 .00390 .00390 .00390 .00390 .00390 .00390 .00390 .00802 .00802 .00802 .00802 .00802 .00802 .00802 .00802	167.5 167.5 122.2 132.0 124.8 90.3 95.9 109.8 102.4 111.2 167.5 122.2 132.0 124.8 90.3 109.8 102.4 111.2 95.9 122.2 124.8 132.0 95.9 109.8 111.2 95.9 109.8

#### V. SUMMARY OF RESULTS

## (a) Variation of Cutting Force with Area of Cut

The effort exerted by the tool in cutting was determined as explained in Part III (c). The horse-power lost in driving the lathe and countershaft was deducted from the total horse-power used during the trial, the difference being the net horse-power required for cutting. This was reduced to foot-pounds per minute, and divided by the cutting speed, giving the force exerted. The figures so obtained were reduced to pounds per unit area of cut, and plotted as ordinates upon a base of area of cut in Fig. 14. The curves show that the cutting force was not directly proportional to the area of cut, but decreased as the area increased, and that the average cutting force varied from 50 tons per square inch for soft cast iron to 85 tons per square inch for hard cast iron. Each curve shown in the figure represents a different hardness of cast iron. The relative hardness is shown in the table on the figure.

# (b) Variation of Durability of Tool with Cutting Speed

In Fig. 15 are shown the curves which represent the relation between the durability of the tool and the cutting speed. These are important curves. Each curve represents a different hardness of cast iron. Referring to the middle curve, which is for cast iron of medium hardness, it will be seen that a cutting speed of 50 feet per minute is satisfactory, the durability being 100. If the speed is increased very materially, the durability decreases quite rapidly. It is evident that for each hardness of cast iron, the cutting speed allowable for a maximum durability exists where the vertical line indicating cutting speed is tangent to curves similar to those drawn.

# (c) Variation of Cutting Speed with the Hardness of Cast Iron

The curve shown in Fig. 16 represents the advisable cutting speed on cast iron of varying hardness. This curve represents the result of all the tests of the different steels tested. This curve shows: (a) that any of the steels tested can remove very hard cast iron at a rate of 25 feet per minute; (b) that all of the steels tested begin to wear rapidly at speeds a little above 125 feet per minute. Between these two points the relation between a safe cutting speed and the hardness of the cast iron seems to be defi-




Fig. 14. Curves Showing Relation Between Cutting Force ON POINT OF TOOL AND AREA OF CUT FOR CAST Iron of Varying Hardness




Fig. 15. Curves Showing Variation of Durability of Tool with Cutting Speed for Cast Iron of Varying Hardness—Average of all Tool Steels

nitely expressed by the curve. It would seem that cast iron of medium hardness, 100 to 120, could be cut at 125 feet per minute just as readily as at 70 feet per minute, as far as any injury to the tool is concerned. It must be remembered that this curve does not take into account the effect, on the cutting speed, of the variation in the area of cut; the experiments from which the




Fig. 16. Curve Showing Cutting Speeds it is Advisable to use with a Variation in the Hardness of Cast Iron

curve was plotted were in all cases those in which the cut was very nearly  $\frac{1}{8}$  in. depth of cut by  $\frac{1}{18}$  in. feed, so that there is but a slight variation in the area of cut in all of the experiments. From the curve of Fig. 16, we find the cutting speeds given in Table 4 to be applicable to the grades of iron manufactured by the different companies sending test pieces. In order that any company may make use of the curve shown in this figure, it will be necessary simply to determine the average hardness of its cast iron, as explained elsewhere, and where the horizontal line representing this hardness cuts the curve, the possible safe cutting speed may be read on the scale below. This curve should prove useful to various manufacturers.

 ${\bf TABLE} \quad {\bf 4}$  Allowable Cutting Speeds for Grades of Cast Iron Used in the Tests

Name of Company S	Average Hardness of Test Pieces	Allowable Cutting Speed	
American Radiator Co	Pierce Plant   Michigan Plant   Detroit Plant	101.8 110.7 109.3 112.7 138.1 103.1	132.0 118.0 120.0 90.0 60.0 132.0
Crane Company	o	132.0 342.0 175.2 136.3	63.0 28.0 48.0 60.0

(d) Generally speaking, all the steels tested proved equally effective. It is very evident that there are great possibilities ahead for high-speed steels. Before realizing their full benefit, however, certain advances must be made. Heavier machine tools must be built. The capacity of the motors and power plants

must be increased. Special hardening furnaces with temperature measuring devices must be available. More must be known concerning the chemical and physical properties of the various steels.

(e) Tool steels are now available that will cut cast iron from two to three times as fast as was possible a few years ago. When every advantage has been taken of these possibilities, the cost of manufacturing many articles should be materially reduced.

#### VI. REFERENCE LIST OF ARTICLES ON HIGH-SPEED STEELS

Experiments with a New Tool Steel: by F. Heissig, in Stahl and Eisen, January 1, 1901.

Results of tests made by Böhler Bros. and Co., Vienna and Berlin, on their Styrian Steel marked Böhler Rapid.

Extract of Report of Experiments of Taylor and White, at the Bethlehem Steel Co., S. Bethlehem, Pa.: in Zeitschrift des Vereines Deutscher Ingenieure, March 30, 1901.

The Taylor-White Process of Treating Tool Steel and Its Influence on the Mechanic Arts: by Charles Day, in *Journal of the Franklin Institute*, September, 1901.

High-Speed Steel: in Zeitschrift des Vereines Deutscher Ingenieure, September 28, 1901.

Report of experiments instituted by the Berlin section of the Vereines Deutscher Ingenieure. Test made on forged and cast steel and cast iron.

High-Speed Tool Steel: by F. Reiser, in Stahl and Eisen, January 15, 1903.

A discussion of the chemical properties of high-speed and self-hardening tool steels.

Speeds, Feeds and Angles of Metal-Cutting Tools: by F. Donaldson, in *American Machinist*, March 5, 1903.

Discussion of the relation of cutting angles to angles to which tools are ground.

The Requirements of Machine Tool Operation with Special Reference to the Motor Drive: by Charles Day, in American Machinist, Part 1, March 12, 1903, Part II, March 19, 1903. Discussion of tools driven by electricity.

Metal Cutting with the New Tool Steels: by Oberlin Smith, in Engineering Magazine, April, 1903, Vol. 25.

Discussion of changes in the design and operation of machines to be wrought by the new tool steels.

Notes on High-Speed Tool Steels: by Henry H. Suplee, in *Engineering*, (London), July 31, 1903, Vol. 76.

Results of tests made at the Union Pacific Shops, Omaha, Nebraska.

Rapid Tool Steels: in *Engineering* (London), August 21, 1903, Vol. 76.

Chemical properties of the new steels with attainable speeds. Editorial.

Rapid-Cutting Tool Steels: in *Engineering* (London) October 30, 1903, Vol. 76.

Report on experiments made at the Manchester Municipal School of Technology under the direction of a joint committee from the above school and the Manchester Association of Engineers. A very elaborate and interesting report by Professor J. T. Nicolson, also reported in the American Machinist, November 19 and 26, 1903.

The Analysis of High-Speed Steels: in *Engineering* (London), November 20, 1903, Vol. 76.

Methods of testing for different chemical constituents

Cutting Speeds and Feeds with New Tool Steels: by Oberlin Smith, in *Engineering Magazine*, January, 1904, Vol. 26.

Record of actual results obtained.

Rapid-Cutting Steel: by Professor J. T. Nicolson, in *Technics*, January, 1904.

A very interesting summary of Berlin and Manchester experiments. The following formula is deduced:

$$V = \frac{K}{a + L} + M$$

V = allowable cutting speed in feet per minute

a = area of cut in square inches

K, L, M = constants for different materials

See Table 5. The chemical analyses to which these tables apply are given in Table 6. It is probable that these results were obtained under the most favorable conditions

and therefore represent the maximum results obtainable at the time of these experiments. It is a question whether these results can be attained in the work shop, where the conditions are frequently not so favorable.

Table 5

Constants for Use in the Equation Giving the Relation Between Cutting
Speed and Area of Cut
(Experiments by Nicolson)

Constant	Fl	uid Pressed	Śteel	Cast-Iron Bars			
Constant	Soft	Medium	Hard	Soft	Medium	Hard	
K	1.950	1.850	1.030	3.100	1.650	1.300	
L	.011	.016	0.160	.025	.030	.035	
M	15.000	6.000	4.000	8.000	7.000	5.500	

TABLE 6
CHEMICAL COMPOSITION OF MATERIALS REFERRED TO IN TABLE 5
(Experiments by Nicolson)

	Fluid Pressed Steel			Cast-Iron		
	Soft	Medium	Hard	Soft	Medium	Hard
Carbon	.198	.275	.514			
Combined Carbon.				.459	.585	1.1500
Graphite				2.603	2.720	1.8750
Silicon	.055	.086	.111	3.010	1.703	1.7890
Manganese	.605	.650	.792	1.180	.588	.3480
Sulphur	.026	.037	.033	.031	.061	.1614
Phosphorus	.035	.043	.037	.773	.526	.7320

The Heat Treatment of Steel: in *Proceedings of the Institute of Mechanical Engineers*, January, 1904, Sixth Report of the Alloys Research Committee.

Discussion of hardening, annealing and chemical properties of steel.

- The Introduction of High-Speed Steels in Engineering Work Shops: in Engineering (London), March 4, 1904, Vol. 77.
- High-Speed Tool Steel: Its Manufacture and Use: by J. M. Gledhill, in *Technics*, Part I, June, 1904; Part II, July, 1904. Some constituents and processes used in the manufacture of high-speed steel.
- Experiments with a Lathe-Tool Dynamometer: by Professor J. T. Nicolson, in *Trans. A. S. M. E.*, Vol. 25, 1904.

  Measures all forces acting on a lathe tool while cutting. Valuable for designers of lathes. Discussion of influence of cutting angles on power required to cut.
- A Twist Drill Dynamometer: by Wm. W. Bird and Howard O. Fairfield, in *Trans. A. S. M. E.*, Vol. 26, 1904.

  Measures both the twist and torque of drill while cutting with high-speed drills.
- The Chemical Analysis of High-Speed Steels and Alloys: by Fred Ibbotson, in *Technics*, October, 1904.
- The Development and Use of High-Speed Tool Steel: by J. M. Gledhill, in American Machinist, December 22, 1904.

  Interesting results of experiments made to find the effect of various chemical constituents on the cutting powers of the tool steel.
- Feeds and Speeds for Lathe Work: by T. A. Sperry, in *American Machinist*, May 25, 1905.

  Results of observations at the shops of the Cincinnati Milling

Results of observations at the shops of the Cincinnati Milling Machine Company.

- High-Speed Steel in the Factory: by O. M. Becker and Walter Brown, in *Engineering Magazine*, beginning September, 1905.

  Conclusions of a practical study of the use of high-speed steel and its introduction into the factory.
- Economy of High-Speed Steel Tools: by F. D. Smith and H. S. Greene. Thesis for a degree in Electrical Engineering in the College of Engineering, University of Illinois, June, 1905.

Tests made at the Chicago and Eastern Illinois Railway Shops, Danville, Illinois, showing that the cost of removing a pound of metal with low-speed steel is from 2.2 to 4.8 times as great as when using high-speed steel.

#### APPENDIX

Instructions for Hardening the Steels Used furnished by the makers.

(1) Directions for working Styrian Steel, marked Böhler Rapid

For Forging:

Heat to a bright red. Do not allow the heat to run as low as a cherry-red while forging. After forging allow the tool to cool slowly before hardening.

For Hardening: Lathe, Planer and Boring Tools.

Heat to a white heat but not to a scaling or melting point, just a good white heat. Cool in the air or a cold blast.

Houghton and Richards, American Agents.

(2) Directions for working Jessop's "Ark" High-Speed Steel

For Forging:

Heat the steel to a canary color, retaining this heat until the tool is forged as nearly as possible to the shape required. The tool may be rough finished by grinding while yet hot on a dry emery wheel. It should then be laid aside in a dry place until black.

For Hardening:

Place the nose of the tool in a clear fire. Slowly heat the steel to a white or welding heat, not over one inch from the end. The nose of the tool should be made fusing hot. Then it should be placed under a strong, cold, dry air blast until cold.

WILLIAM JESSOP AND SONS, Limited,
New York.

(3) Directions for working McInnes's "Extra" High-Speed Air-Hard Steel

For Forging and Hardening:

Forge the steel at the ordinary tool-steel forging heat; after the tool is forged to the desired shape, reheat the cutting end to a light cherry-red, and cool in an air blast. In order to bring out the quality of this steel when the tool is forged to the above instructions, it should be run at high speed in the lathe or planer until the edge is worn off two or three times and reground. After each grinding the tool gets better until it gets to its limit.

McInnes's Steel Company, Limited, Corry, Pennsylvania.

(4) Directions for working Mushet "Special" High-Speed Steel

For Hardening:

When forged, the cutting end of the tool should be reheated to a white heat, and then immediately blown cold. While hot this steel must be kept from water.

(5) Directions for working "Air Novo" High-Speed Tool Steel

For Forging:

The steel must be heated thoroughly, so that it is hot all the way through. The forging color must be a very light yellow. Do not hammer the steel when it gets down to a dark red, but reheat it. After the tools are forged lay them down to cool.

For Hardening:

Heat the cutting edge only of the tool to a white welding heat. Heat it until it begins to flow. Then put the tool into a compressed air blast, or dip immediately into thin lard, linseed or fish oil until thoroughly cold.

Hermann Boker & Co., New York.

# (6) Directions for working "Rex" High-Speed Tool Steel

For Forging:

Use a clean fire and forge at a bright red heat, holding the steel at this heat as nearly as possible while the forging is being done. Forging at too low a heat will cause the steel to burst in forging. When tool is forged lay it down in a dry place to cool.

## For Hardening:

Use a clean fire or furnace and bring the point or cutting portion of the tool gradually to a sweating white heat. This heat is indicated by a flux, having the appearance of melted borax. forming on the nose of the tool. Confine the high heat as much as possible to the cutting portion of the tool. When the proper heat is reached, take from the fire and carefully remove the oxide scale which instantly forms on the heated portion of the tool. This can be done with a coarse file, and will permit the cutting portion of the tool to cool off much more uniformly and rapidly than if the oxide scale is allowed to remain. When extremely hard and tough metal is to be machined, blow cold in fan or dry compressed air blast.

CRUCIBLE STEEL COMPANY OF AMERICA,
Pittsburg, Pa.

The directions received from the American Radiator Company for hardening the two foreign steels, "A & W" and "Poldi", applied to nipple dies. The same, however, were used in the tests for lathe tools, with the exception of being heated in a forge fire. They are as follows:

(7) For Hardening "A & W" High-Speed Tool Steels, manufactured by Armstrong, Whitworth and Company, Limited, England:


"When tempering the steel for nipple dies, we placed the dies in a retort, and heated them so

that the cutting end reached a white heat; then the dies were placed in a strong air blast and cooled to a cherry-red color, after which they were dropped into a tempering oil. Tempering in this manner gives by far the best wearing point to the steel".

(8) Directions for Hardening "Poldi" High-Speed Tool Steel:

"This steel was treated in a slightly different manner from the 'A & W'. The dies were heated to a white heat in a retort, and then cooled in an air blast until they were absolutely cold."









ENGINEERING BUILDING BUILT IN 1894

# UNIVERSITY OF ILLINOIS

# ENGINEERING EXPERIMENT STATION

Bulletin No. 3

**MARCH 1906** 

#### THE ENGINEERING EXPERIMENT STATION

OF THE

#### UNIVERSITY OF ILLINOIS

By L. P. Breckenridge, Director of the Engineering Experiment Station.

The Engineering Experiment Station of the University of Illinois was established by action of the Board of Trustees, December 8, 1903. It is the purpose of the station to carry on investigations along various lines of engineering, and to make studies of problems of importance to professional engineers, and to the manufacturing, mining, railway, constructional and industrial interests of the state. It is believed that this experimental work will result in contributions of value to engineering science and to the industries of the state, and that the pursuit of such investigations will give inspiration to students and add to the value of the instructional work in the College of Engineering.

The value to the state of the work done by the Agricultural Experiment Station has suggested the possibility of doing work of similar value to the industrial interests of the state. It is believed that Illinois is the first state to establish an engineering experiment station, but there is every reason to believe that many other states will soon move in such a direction. When a number of states have established such stations, it is entirely reasonable to suppose that the federal government may be depended upon to give the same aid to these engineering stations that it now does to the agricultural experiment stations.

#### II. PLAN OF ORGANIZATION

The organization for directing and guiding the operations of the station consists of a director and a station staff. The staff consists of seven members, representing with the director the heads of the different departments of the College of Engineering. A corps of assistants will be appointed whose entire time will be devoted to the prosecution of such experimental investigations as may be approved by the station staff. Several assistants have already been appointed who have been detailed to take up special investigations under the supervision of some member of the staff. Preparations are being made for other experimental work, and as fast as the necessary apparatus and equipment can be arranged, additional assistants will be put in charge of the work. Encouragement and aid will be given to instructors already employed by the University who desire to take up some line of research work. Whenever such men prove to be successful experimenters and clear writers, some arrangement may be made whereby a part of their time may be devoted to the work of the station and a correspondingly proportionate part of their salary paid from the funds of the station.

#### III. WORK ALREADY ACCOMPLISHED

The first work undertaken by the Engineering Experiment Station was an investigation of reinforced concrete and the properties of concrete affecting reinforced concrete construction. The results of this work are recorded in Bulletin No. 1, Tests of Reinforced Concrete Beams, by Arthur N. Talbot, which was published as University of Illinois Bulletin, Volume II, No. 1. September 1, 1904. This was one of the first extensive and systematic investigations on reinforced concrete made in this country, and the results aided in clearing up a number of controverted points. While the investigation was carried on largely as senior thesis work, the character of the work and the supervision and planning given to it, together with the method of furnishing materials and apparatus, warrant giving more weight to the results than may usually be given to results of student work. The investigation covered a considerable range. The results on bond between concrete and steel (plain and deformed bars) and on the relation between compressive stress and deformation were of interest. The measured deformations obtained in plain concrete beams showed that up to the breaking point in tension the modulus of elasticity for tension is practically equal to that for compression, instead of being one-half as great, as had generally been assumed by writers on this subject. In reinforced concrete beams, the action of the steel and concrete during flexure was studied. It was shown that the concrete failed in tension at its usual breaking limit instead of carrying stress to ten times that limit, as had been claimed by some experimenters, and the added stretch in the steel at this point was clearly shown on the diagrams.

Among the results brought out by this investigation were the following: the stages of action during flexure; the accurate determination of the position of the neutral axis; a basis of calculation of resisting moment of beam based upon tension in the steel; the value of an experimental determination of the position of the neutral axis and of the percentage of steel suitable for a given concrete; the effect of elastic limit of steel and of form of bar upon strength of beam. The tests also opened up the field for further experimentation. The publication of the results was received with much interest by the engineering press and the engineering profession. The comments made gave testimony to the thoroughness of the work and to the great interest and value attached to the investigation, as throwing new light on a subject very much in need of scientific data. Requests for Bulletin No. 1 have come from all parts of the world. The investigation of reinforced concrete beams is being continued and experiments on reinforced concrete columns have been started.

Circular No. 1, High-Speed Tool Steels, by L. P. Breckenridge, was issued April 15, 1905. In this circular is given a brief review of the results of experiments made by different engineers with this new tool steel. Experiments with high-speed tool steels on cast iron have been in progress at the shops of the mechanical engineering department of the University during the last year. These tests have been carried on by H. B. Dirks, M. E., and constituted the basis for his graduate work.

Bulletin No. 2, Tests of High-Speed Tool Steels on Cast Iron, by L. P. Breckenridge and H. B. Dirks, giving the results of these experiments, was published in January, 1906. These tests were made with eight different brands of tool steel on cast-iron test pieces of varying hardness. The hardness of these test pieces was obtained by the use of a twist drill weighted to a known pres-

sure and run at a constant speed, the degree of hardness being based on the depth to which the drill would enter in a given time.

The work was divided into several sets of tests, viz., preliminary trials; skin-cut trials; endurance trials; trials to obtain the durability of the steel at different cutting speeds on cast iron of constant hardness; and trials to obtain the durability of the steels on cast iron of varying hardness. Tables giving in full the results of these different tests are supplemented by plates showing graphically some of the following relations: cutting force on point of tool and area of cut for cast iron of varying hardness; durability of tool and cutting speed for cast iron of varying hardness; cutting speed in feet per minute and hardness of cast iron.

From the last mentioned it was found that all the steels tested can remove very hard cast iron at 25 feet per minute, that all steels begin to wear rapidly at speeds a little above 125 feet per minute, and that between these two points there seems to be a definite relation between the hardness of the iron and the cutting speed. The general results show that there are great possibilities ahead for high-speed steels. Tool steels are now available that will cut cast iron from two to three times as fast as was possible a few years ago.

Circular No. 2, Drainage of Earth Roads, by Ira O. Baker, practically a reprint of Agricultural Experiment Station Bulletin No. 65, was issued in February, 1906, for the use of the Good Road Train of the Chicago and Alton Railway Company, at the expense of the latter.

Experiments are in progress under the direction of the department of Civil Engineering on the holding power of the various forms of plain and screw railroad spikes in treated and untreated timber with the view of determining the most efficient method of fastening the rails to the ties,—an important matter since the hard woods are now almost exhausted, and attention must be given to the softer woods.

Experiments on the collapse of boiler tubes are in progress by the department of Physics. For these tests the Bethlehem Steel Company has furnished a hollow nickel-steel tube, twelve feet long, with an internal diameter of five inches, capable of withstanding an internal pressure of 6000 pounds per square inch. A special pump capable of producing a pressure of 15,000 pounds per square inch has been imported for these experiments. The

department is also investigating the subject of measurement of high temperatures, such as are found in boiler and other furnaces used in industrial works. Both recording and optical pyrometers are being studied.

#### IV. CHARACTER OF THE WORK TO BE UNDERTAKEN

In determining the character of the work which the station shall undertake, the most careful consideration will be given to the needs and the interests of the state. At the same time we shall not forget the debt which Illinois owes to her older sister states or to foreign nations for furnishing freely the results of scientific investigations or experimental determinations, making it possible for Illinois more cheaply to construct its railroads, mine its coal, generate its power, harvest its crops, communicate with its neighbors, and build its factories, its public buildings and its homes.

The work of the station will also be largely determined by the funds and facilities which are available for its work. It will seek the cooperation of all the industrial enterprises of the state, both great and small, and it will give help along those lines that promise to aid the greatest number of its people.

The work of the station should also extend into some fresh fields, seeking to discover new ways and means for economizing energy and materials, for the prevention of waste, for the perfection of labor-saving machinery, for safer methods of travel, and for surer sanitary methods of water supply and sewage disposal.

As an indication of the character of the work which it is proposed to do, the following short titles are given of some of the most important investigations which have been submitted for the approval of the station staff.

#### BY THE DEPARTMENT OF ARCHITECTURE

- 1. Insulating walls and materials to prevent transmission of sound, heat, dampness, etc.;
- 2. Resistance of hollow concrete building blocks to transmission of heat, sound, dampness, etc.;
- 3. Transmission of heat, light and sound through several thicknesses of glass in windows:
- 4. Comparative strength of wooden beams in tension, spliced in various ways;

- 5. Strength of compound (flitched) steel and wooden beams;
- 6. Strength of built-up wooden girders;
- 7. Syphonage of traps and its prevention;
- 8. Collection of best plans for small country schools;
- 9. Collection of best plans for farm houses and buildings.

#### BY THE DEPARTMENT OF CIVIL ENGINEERING

- 1. Tests of road-building materials;
- 2. Tests of angles riveted by one leg;
- 3. Effects of punching, reaming and boring upon different grades of steel.

#### BY THE DEPARTMENT OF ELECTRICAL ENGINEERING

- 1. Advantageous rates of acceleration for passenger and freight service;
- 2. Loss from braking, and its partial recovery by raising the level of regular stopping points;
  - 3. Increased tractive effort due to winds in various directions;
- 4. Possible utility of some form of transmission or speed-changing ratio between motor and car for overcoming grades;
  - 5. Economical lighting of large halls;
- 6. Determination of the minimum candle-feet required for comfortable reading with lamps of different color values;
- 7. Methods for increasing the time efficiency of long distance lines.

### BY THE DEPARTMENT OF MECHANICAL ENGINEERING

- 1. Experiments with high-speed tool steels (continued);
- 2. Boiler trials with Illinois coals (continued);
- 3. Transfer of heat through scaled boiler tubes;
- 4. Comparative economy of domestic coals for residence heating;
  - 5. The economy of municipal power and pumping plants;
  - 6. Experiments with superheated steam;
  - 7. Experiments with gas producers.

## BY THE DEPARTMENT OF PHYSICS

- 1. Resistance of boiler flues to collapse;
- 2. Heat conductivity of walls of buildings;
- 3. Appliances for measuring high temperatures under furnace conditions;



Fig. 1 Mechanical Engineering Laboratory Built in 1905




Fig. 2 View in the University of Illinois Machine Shop showing location of Lathe and Motor drive used in Tests with High-Speed Tool Steels

4. Determination of vapor densities at very high temperatures and high pressures.

BY THE DEPARTMENT OF RAILWAY ENGINEERING

1. Locomotive road tests and railway train resistance.

BY THE DEPARTMENT OF THEORETICAL AND APPLIED MECHANICS

- 1. Reinforced concrete beams (continued);
- 2. Reinforced concrete columns;
- 3. Timber stringers;
- 4. Cast-iron columns;
- 5. A series of tests of interest to manufacturers and railroads on such structures as car bolsters, car frames, wheels, etc.;
  - 6. Qualities of commercial mild steels;
  - 7. A series of investigations on various hydraulic problems;
  - 8. Deep well pumping.

From the above list it will be seen that there exists a very large field for fruitful research. In many cases these investigations must extend over a series of years; in others a few months will suffice for the work.

# V. FACILITIES FOR INVESTIGATION

The recent rapid growth in attendance in the College of Engineering has made it necessary to extend its equipment considerably, and while the apparatus thus provided is intended primarily for purposes of instruction, much of it is available at certain times of the year for purposes of investigation. Certain appliances have recently been purchased and installed for the especial use of various departments in connection with such investigations as are in progress in these departments.

The Engineering Experiment Station is not quartered in any one building of the College of Engineering, but its work and experiments go on wherever the needed facilities exist in the various departments. Neither is its work confined to the College of Engineering alone. Cooperation with other University departments, such as the College of Science, State Water Survey and with the State Geological Survey enables it to complete many investigations, facilities for which are not available within the College of Engineering. Neither is its work confined within the limits of the University. Cooperation with various departments of the

federal government as well as with many industrial interests of the state is already assured.

On the following pages are mentioned some of the most important appliances which are available for use in various lines of research. Only a few words of description are possible with reference to each. In connection with this article are given several reproductions showing the laboratories in which the investigations are in progress, and also the most important apparatus.

# IN THE MECHANICAL LABORATORY

- 1. A 210 H. P. Heine water-tube boiler especially arranged for testing Illinois coals. This boiler is a duplicate of the boilers being used at St. Louis by the United States government in testing coals from various parts of the country. A Green chain grate stoker is installed under this boiler, and draft is furnished by a Sturtevant induced draft fan, drawing the gases through an economizer. The chain grate under the boiler may easily be removed and a plain furnace for hand-firing substituted. A complete equipment of auxiliary apparatus necessary for boiler tests is available, including recording and optical pyrometers, and standard and recording apparatus for continuous gas analysis. Facilities are now available in the department of Physics for calibrating all thermometers and pyrometers used in work of this character.
- 2. An independently-fired Foster superheater capable of superheating the steam from a 150 H. P. boiler 300° above its temperature at 120 pounds gauge.
- 3. Several residence heating boilers, for both steam and hot water. These boilers will serve to compare the values of such various coals as are offered in the Illinois market for domestic purposes.
- 4. A 10-ton York refrigerating plant for the production of cold or for specific tests. With this plant there are 17 cans for ice making, each holding 100 pounds. The possibility of subjecting various building stones or other material to alternate freezing and warming is worthy of consideration. The effect of fifty winters might thus be known in a single month.
- 5. A liquid-air plant with a capacity of about three quarts an hour. It consists of a Norwalk four-stage compressor, compressing up to 3000 pounds, together with a Hampson liquefier with facilities for temperature determinations.




Fig. 3 York Ice Machine of 10-ton Refrigerating Capacity in Mechanical Engineering LABORATORY




FIG. 4 OFTO GAS PRODUCER AND GAS ENGINE IN MECHANICAL ENGINEERING LABORATORY

- 6. An Ingersoll-Sergeant two-stage air compressor driven by compound steam cylinders. The steam cylinders are 12 inches and 22 inches in diameter with a 12-inch stroke, and the air cylinders are 12½ inches and 18½ inches in diameter with a 12-inch stroke. A vertical receiver 42 inches by 8 feet high is provided for use with the compressor.
- 7. A 50 H. P. suction gas producer built by the Otto Gas Engine Works. This producer is adapted to burning anthracite pea coal, coke or charcoal.
- 8. An Otto gas engine of 23 brake H. P. capacity for use in connection with the gas producer. The cylinder is 10 inches in diameter, with a 19-inch stroke. It is provided with a compressed air starting device, sparking generator, speed indicators and all other instruments necessary for testing gas engines.
- 9. A 15 H. P. De Laval steam turbine direct-connected to a compound centrifugal pump. This apparatus will deliver 140 gallons of water per minute when pumping against a head of 500 feet. The turbine wheel and small pump runner make 23,500 revolutions per minute; the large pump runner makes 2350. The turbine is provided with condensing and non-condensing nozzles.
- 10. A hot blast heating system installed to heat the Mechanical Engineering Laboratory. This consists of a series of coils making 2800 feet of 1-inch pipe and a 72-inch fan draw the air through the coils and force it into the galvanized iron pipe, 36 inches in diameter, which distributes it to different parts of the building. The fan is driven by a small vertical steam engine.
- 11. A 100 H. P. Allis-Chalmers Corliss engine, equipped with a suitable brake and other apparatus for making tests.
- 12. Several high-speed steam engines for testing and for driving other apparatus.
- 13 Several types of gasolene engines, ranging from 1 to 10 H. P., for experimental purposes.
  - 14. An automobile testing platform for testing automobiles.
- 15. A 10-ton electric crane, having three alternating current motors, for experimental work.
- 16. A Golden oil testing machine for testing lubricating oils and bearing metals.
- 17. Apparatus for tests relating to the transmission of heat through scale-covered boiler tubes with respect to the loss due to scale. The equipment now in the Mechanical Engineering Lab-

oratory for determining the loss due to the scale when transmitting heat through scale-covered tubes consists of a boiler and furnace giving approximately practical conditions, also auxiliary apparatus for making the required observations. The furnaces employed are constructed of wrought iron suitably covered, or of brick with fire-brick lining, and are equipped with gas burners for the generation of the required heat. From the furnace the hot gases pass through the tube which is being tested. This tube constitutes the single flue of the experimental boiler. The boiler is filled with water continually entering and leaving at temperatures maintained constant. The auxiliary apparatus used consists of constant-pressure tanks for air, gas and water, suitable thermometers, pyrometers, scales, etc., a Le Chatelier pyrometer being used to measure the temperature of the hot gases entering the tube.

# RAILWAY TEST CAR No. 17

18. This railway test car is a special car operated for experimental and instructional purposes. It is owned jointly by the Illinois Central Railroad and the University of Illinois. It was built by the railroad company, equipped by the University and is operated for the advantage and information of both. It is considered by the University as a part of its laboratory equipment, and affords facilities for practical railroad tests which could not otherwise be made.

The car is used principally in connection with dynamometer car work, and on this account was built especially heavy in order to withstand the usage incident to this kind of work. It is  $45\frac{1}{3}$  feet in length. A space of about 15 feet in the rear of the car is occupied by berths and lockers, the remaining space being devoted to apparatus and instruments.

The dynamometer is of the hydraulic or oil transmission type. It consists of three cylinders in tandem, and is situated near the forward end of the car just back of the draft rigging. The dynamometer is suitably connected with a recording instrument which gives the draw-bar pull record upon paper traveling at a rate of speed proportional to the speed of the train. Upon the same paper records are made of time, speed, distance and such other data as may seem desirable. In addition to the dynamometer with its attached recording instrument, paper travel mechanism, gauges and similiar apparatus, the car is equipped with a Boyer speed recorder, a Hausshalter speed recorder, rec-

ording gauges for steam pressures, train line pressures and draft, also with air and steam pressure gauges for various purposes.

In its capacity as a dynamometer car, Railway Test Car No. 17 affords facilities for work along the following lines:

Tonnage rating tests;

Engine efficiency tests;

Tests in relation to engine design and tractive force:

Tests to determine resistance of freight, passenger, loaded or empty cars;

Tests to determine resistance of trains as affected by speed, curves, temperatures, condition of track or special equipment.

Aside from its use as a dynamometer car, when no draw-bar pull record is desired, the car is used in connection with locomotive road tests or other road tests, records being made in the car automatically or otherwise that without the car would not be attempted or could be made only with difficulty. Further the car serves a most useful purpose as office, laboratory and computing room when making railroad or other shop tests in connection with railway work.

This car has already been in extensive use on the Illinois Central Railroad for the purpose of making locomotive road tests, and for establishing tonnage ratings on the various divisions. The preliminary experimental work relating to train resistance in connection with the electrification of the New York Central lines out of the Grand Central Depot, New York City, was all done with this car. A series of tests has also been made with this car comparing the relative draw-bar pull and acceleration factor of steam and electric locomotives on the experimental tracks of the General Electric Company at Schenectady, New York. Both of these tests have been reported to the American Society of Electrical Engineers in a paper by B. J. Arnold at the annual meeting 1904.

# IN THE ROAD-MATERIALS LABORATORY

The Civil Engineering department in its Road-Materials Laboratory is equipped with apparatus for testing materials for road and pavement construction as follows:

- (a) Two types of rattlers for testing brick: National Brick Manufacturers' Association and Talbot-Jones;
  - (b) A Dorrey, a Deval and a Page machine with the neces-


sary accessories for testing the road-building qualities of gravel and macadam. The laboratory is cooperating with the State Highway Commission and with the State Geological Survey in a systematic study of the road-building materials of Illinois.

#### IN THE CEMENT LABORATORY

This laboratory is equipped with briquette molds, molding machines, testing machines, etc., necessary in testing hydraulic cement, and in making investigations as to the effect of different materials and methods of manipulation upon the strength of mortars and concrete.

#### IN THE LABORATORY OF APPLIED MECHANICS

- 1. A Riehle vertical screw power testing machine of 600,000 lb. capacity fitted to take large and bulky test specimens. machine will take compression pieces 25 feet long and tension pieces of the same net length except as allowance must be made for stretch. The clear distance between screws is 36 inches. which gives room for bulky and built-up pieces. The machine is provided with a stiffened vertical frame to allow eccentric and oblique forces to be applied to test pieces, an unusual feature in testing machines. Short beams may be tested on the machine, and provision may easily be made for testing longer beams. Auxiliary appliances are used for holding the various forms of test piece in order to secure an application or distribution of the load in the manner desired. Especial attention was given in the design and construction of the machine to making it applicable to a large range of tests. The calibration of the machine shows that it is very accurate and very sensitive. For the smaller loads a second poise weighing up to 60,000 lb. is used.
- 2. An Olsen four-screw testing machine of 200,000 lb. for tests in tension, compression and flexure. This machine will take beams up to a length of 20 feet.
- 3. Three 100,000-lb. testing machines of different makes, fitted up in the usual way.
  - 4. An Olsen torsion machine of 220,000 inch-pound capacity.
- 5. An Olsen vibratory testing machine for testing stay bolts.
- 6. A variety of smaller machines for testing cast iron, timber, etc.  $\ \ \,$






Fig. 5 Laboratory of Applied Mechanics Bullt in 1901




Fig. 6 Testing 12 x 12 in. Concrete Column in 600,000 lb. Testing Machine




Fig. 7 View Showing 600,000-lb. Testing Machine as Used in Tension Tests






Fig. 8 Apparatus for Collapsing Boiler Tubes



CALLENDAR RESISTANCE PYROMETER FIG. 9 ELECTRICAL PYROMETERS THERMO-ELECTRIC PYROMETERS



WANNER

Fery Fig. 10 Optical Pyrometers

CHATELIER



- 7. A large equipment in measuring devices such as extensometers for various uses, autographic recording devices, gauges, etc.
- 8. A commodious hydraulic laboratory, well equipped with steam engine, steam pumps, centrifugal pumps, standpipe and pressure tanks, lines of piping, measuring pits, tanks, weirs, gauges, meters, motors, etc., giving excellent facilities for testing hydraulic apparatus and for making investigations in hydraulics.

#### IN THE PHYSICS LABORATORY

The Physics department is equipped with apparatus enabling it to do the following work in testing and standardization:

- 1. The testing of boiler tubes for collapse;
- 2. The checking and calibration of instruments for measuring temperatures;
- 3. The checking and calibration of electrical standards and instruments:
  - 4. Miscellaneous physical testing.

The Testing of Boiler Tubes.—The apparatus available for this work consists of a nickel-steel tube, part of a United States naval gun, capable of withstanding about 20,000 pounds per square inch internal pressure. This apparatus permits of the testing of flues and tubes up to  $3\frac{1}{2}$  inches diameter and 10 feet in length for resistance to collapse under external pressure. It is in use at the present time for the determination of a formula for predicting the failure of steel tubes under pressure. Pressures up to 14,000 pounds per square inch may be produced by means of a Cailletet pump, made by the Societe Genevoise, Switzerland. Upon the completion of the work now in progress, the apparatus will be maintained intact for testing at any time the constants of flues and tubes.

The Checking and Calibration of Instruments for Measuring Temperatures.—The department has facilities for testing and checking thermometers and pyrometers.\* Standard thermometers of the best make, graduated to 0.1° C. and certified by the Reichsanstalt, permit of tests between -25° C. and 250° C. Special con-

<sup>\*</sup>Pyrometers,—Electrical: resistance type, Callendar recorder with Whipple indicator, Cambridge Scientific Co., Ltd., Cambridge, England: thermo-electric type, Siemens & Halske, Berlin, Germany; Hartmann & Braun, Frankfort-on-the-Main, Germany; Bristol, W. H. Bristol, 41 Dey St., New York City. Optical: Wanner, American agents, Eimer & Amend, 205 Third Ave., New York City; Fery and Chatelier, Ph. Pellin, Paris, France.

stant temperature baths are being made for the convenience and rapid comparison of thermometers.

The equipment for pyrometry is the best obtainable. The department owns a Callendar recorder of the laboratory type and a Whipple indicator with a series of platinum resistance thermometers ranging from 0° C. to 1200° C. In addition to these electric resistance pyrometers, a series of thermo-electric pyrometers is available for checking and testing other pyrometers. The thermo-electric couples with Reichsanstalt certificates are calibrated for temperatures from -180° C. to 1600° C.

The laws of the relation of temperature, light and radiation, have within a few years been studied, so that it is now possible to measure temperatures by optical methods. The equipment in optical pyrometry consists of the Le Chaletier, the Wanner and Fery radiation pyrometers.

For the production of extreme temperatures, both low and high, the department is provided with a liquid-air machine, and with electric furnaces of the arc and of the resistance types. A specially protected constant temperature room has been provided for work of all kinds requiring constancy of temperature.

Electrical Standards and Apparatus.—The department owns certified standards of resistance, electromotive force and inductances, and its cabinets contain apparatus of the best make for all electrical and magnetic testing. The Kelvin ampere balances, Weston standard and semi-portable voltmeters and ammeters, and Siemen's electrodynamometers of the department are frequently checked by the potentiometer with standardized resistances and Clark and Weston cells. The laboratory is supplied not only with apparatus but also with piers and conveniences for these tests.

Miscellaneous Testing.—Besides the equipment for the work in the three lines indicated above, the department of Physics is supplied for its instructional and research work with standard apparatus of a variety of kinds, all of which is available for testing purposes. Such facilities are standard barometers, standards of length, photometric standards with photometers, standards of weight with sensitive physical balances, a dividing engine and comparator, vacuum and compression pumps with gauges, and various optical apparatus.

## IN THE ELECTRICAL LABORATORY

The Electrical Laboratory occupies a separate building and contains an excellent equipment available for many lines of research. It will not be possible to give any detailed description of this equipment but some of the more prominent facilities are mentioned below.

- 1. In the basement is a storage battery (Gould) of 60 cells each of 240 ampere hours' capacity. This is wired so that all voltages between 2 and 120 can be obtained; also current up to 100 amperes at full voltage, with greatly increased current at lower voltages. This battery is especially adapted to the calibration of electrical measuring instruments, the testing of fuse wire, and to all work where steady current is required.
- 2. The dynamo laboratory contains very complete arrangements for testing any of the usual types of machines. Power is supplied mostly at 220 volts D. C. and at 440 volts, two-phase A. C., but the transformers permit other usual voltages to be supplied. Several types of variable speed motors, having a speed range from 300 to 1200 revolutions and giving 15 H. P. at any speed, are a recent addition to the equipment. Two general electric stationary armature alternators, capable of connection as either two or three-phase generators or motors and at a variety of voltages, are available. Three rotary converters furnish current based on 110 and 500 volts D. C. An inductor alternator, built by students and designed primarily for variable frequency experiments, may be run at various frequencies up to 150.

There are also switchboards for the rapid handling of apparatus; numerous lamp banks for resistance; a small electric welding machine; various types of arc lamps, permitting experiments in lighting; inductances, condensers, and a large range of measuring instruments of all kinds.

3. A laboratory for the study of illumination is equipped in connection with the photometer rooms. Shades like wall maps line the walls, whereby a light or dark effect can be obtained. This room is lighted by both ceiling and bracket fixtures. Two photometers are available for testing globes and shades as well as lamps of various types. The efficiencies of different types of shades have been studied, also the flickering effect of alternating lighting. Some interesting developments have been made in curved coherers for space telegraphy.

- 4. A telephone laboratory of two rooms permits experiments in telegraphy and telephony. Experiments now in progress seem to show the availability of high-tension wires for the transmission of telephone messages, obviating the need for separate telephone wires on power lines. Some improvements in long-distance telephony are being tested.
- 5. An electric test car is also a part of the equipment. This is an interurban type of car, built by the Jewett Car Company, and equipped with the latest type of multiple-unit control 500 volt D. C. motors, by the Westinghouse Electric and Manufacturing Company. One end of the car contains the switch group operated by compressed air, and also the measuring instruments for determining voltage, current speed and acceleration. The car has four 50 H. P. motors, double trolley and controllers at each end of the car, and the usual equipment of head lights, air brakes, heaters, etc.

With this car determinations of the power required for the hauling of coal on electric roads are in progress, and a comparison will be made with the results of dynamometer car tests on steam roads. Traction experiments on a large scale are possible through the courtesy of the Illinois Traction System, whose line passes through the University grounds. The recent equipment of the electric test car of 200 H. P. with recording electric instruments will allow the determining with considerable accuracy of the power required to operate at different speeds and over different grades and curves. A subject of investigation will be the normal highest speed that corresponds to a given radius of curvature, from which it will be possible to determine how much a sharp curve will retard a car.

# VI. THE INDUSTRIAL INTERESTS OF ILLINOIS

The state of Illinois is singularly favored in all the conditions requisite for a rapid and permanent industrial development. It has a vast area underlaid with productive coal seams, which afford an abundant supply of bituminous coal of good quality. With the Great Lakes on the northeast, the Mississippi river on the west, and with a network of railroads having an aggregate length of nearly 12,000 miles, facilities for transportation are unexcelled. Illinois is also fortunate in its large area of arable land of extreme fertility. In view of its cheap and abundant fuel and its unex-

Fig. 11 Electric Test Car




Fig. 12 Electrical Engineering Laboratory Built in 1897

celled facilities for the transportation of raw material and finished products, it is not surprising that Illinois has pushed forward rapidly in manufacturing and allied industries. Since 1850 the growth of manufacturing in Illinois, measured by the value of the manufactured product, has been at an average rate of one hundred per cent a decade, and the rank of the state has advanced from fifteenth to third. This rate of advance is typical of the development in other industrial lines.

The industrial interests of Illinois may be grouped in four chief classes:

- 1. Agriculture
- 2. Coal and Mining
- 3. Transportation
- 4. Manufacturing

Of the five million inhabitants of Illinois, more than one-third are engaged in remunerative occupations. A rough idea of the distribution of workers among the industrial pursuits outlined above may be gathered from the following statement. According to the census of 1900, the working population of Illinois may be divided into four nearly equal parts, one of which is engaged in agricultural pursuits; one, in manufacturing; one, in trade and transportation; the last, in domestic and professional service. In the following pages the various industrial interests will be considered somewhat in detail.

Agriculture.—In the value of agricultural products, Illinois ranks second, having been exceeded in 1900 by Iowa. The value of agricultural products for 1900 was \$345,650,000. This is slightly less than 28 per cent of the value of manufactured products for the same year. From the nature of things, the value of agricultural products after reaching a certain stage can increase but little, while there is practically no limit to the value of manufactured products. Hence while Illinois will always hold high rank in agriculture, its preeminence in the future will be due to its manufacturing and transportation industries.

Coal.—The coal deposits of Illinois are included in the eastern interior coal field of the United States, which covers western Indiana, nearly the whole of the state of Illinois, and western Kentucky. Illinois has the largest coal-bearing area of any state in the Union, about two-thirds of the state, or upwards of 37,000 square miles, producing coal. A medium grade of bituminous coal is mined, suitable for the production of power, being used mostly as a steaming fuel by railroads and manufactories.

Outside of Pennsylvania, which is preeminently the first state in coal mining. Illinois leads in the production of coal, yielding about one-eighth of the entire quantity mined in the United States. The following table shows the production of coal in the leading coal states during 1902 and 1903:

PRODUCTION OF BITUMINOUS COAL IN THE UNITED STATES


Rank	State	1902	1903	Increase Per Cent	
1 2 3 4	Pennsylvania Illinois. West Virginia Ohio. United States.	98,946,000 30,031,000 26,162,000 23,929,000 258,372,000	103,000,000 34,955,000 26,882,000 24,573,000 277,077,000	4 15 2.7 2.6 6.7	


The following statistics for the year ending June 30, 1903, will give an idea of the magnitude and importance of the coal industry in Illinois: During that year there were 935 mines in operation, giving employment to 35,000 miners and 15,000 employees other than miners. The total product was 35 millions of tons, valued at more than 36 millions of dollars at the mines.

Railroads.—In the aggregate of its railway mileage, Illinois holds first rank among the states of the Union, although Texas is a close second. The rapid development of railroads in Illinois is doubtless due to some extent to the early establishment of Chicago as a distributing center of eastern products to the west and southwest. Chicago became the outlet of the traffic by way of the Great Lakes, and when the era of railroad building succeeded, naturally became a great gateway between eastern and western trunk lines. As a result, Illinois is traversed by railroads in all directions. The accompanying charts show the growth of mileage in Illinois since 1850 and the mileage in several states.









STEAM RAILROAD MILEAGE IN SEVERAL STATES-1904.

The magnitude of the railroad industry in Illinois is evidenced by the car construction and repair bill. Thus in the statistics for manufactures for 1900, the items for cars and general shop construction, and repairs by steam and street railroad companies aggregate nearly \$18,000,000.

In the mileage of street and electric railroads, Illinois is as yet somewhat behind some of the eastern states. In 1903 the mileage of street and electric railroads in several leading states was as follows:

Massachusetts	
Pennsylvania	
Ohio	
New York	
Illinois	

It is significant, however, that the wave of development in electric railroads is sweeping westwards. In the last two or three years, great progress has been made in Ohio, Michigan and Indiana. Illinois has only fairly started in the building of interurban railroads, and the next ten years will doubtless witness a development along this line that will place it well towards the first rank.

Manufacturing.—In the value of manufactured product, Illinois at present ranks third among the states of the nation. The accompanying diagram shows the relative position for several decades of the five foremost states in manufacturing. The rapid rate of increase in the case of Illinois is worthy of attention.

Statistics for 1900 showed a total value of manufactured product of \$1,260,000,000, an increase of nearly 40 per cent over the figures for 1890. The following table gives data selected from these statistics relating to leading industries somewhat allied in character to engineering:

INDUSTRIES	WAGE EARNERS	WAGES IN MILLIONS	VALUE OF PRODUCT IN MILLIONS
Agricultural implements		9.06	42.0
Cars, shop constructions and repairs steam railroads	13,803	8.29	16.6
operations of railroad companies Electrical apparatus and supplies	9,314	5,36 2,82	24.8 12.2
Foundry and machine shop products Iron and steel.	31.851	16.88 9.64	63.9 60.3
Vehicles (bicycles, carriages, etc.)		4.40	18.0

In 1900 the number of manufacturing establishments in Illinois was 38,360, and the total number of people engaged in manufacturing was nearly 400,000. The wages paid amounted to \$192, 000,000, or nearly \$500 per person employed. The value of the product, as has been stated, was \$1,260,000,000. The total manufactured product for 1905 was probably over \$2,000,000,000, an increase of sixty per cent in five years, which may be compared with the increase of forty per cent in the preceding ten years. In view of the present rate of increase in manufacturing, it seems not unlikely that in another decade, Illinois will be a sharp rival of New York and Pennsylvania for first rank.

# VII. WHAT WORK CAN THE ENGINEERING EXPERIMENT STATION DO THAT WILL AID THE INDUSTRIAL INTERESTS OF ILLINOIS?

For a number of years the agricultural industry of the state of Illinois has been greatly benefited by the work of the Agricultural Experiment Station. During the first years of its existence, this experiment station was supported by the United States government in accordance with the provisions of what is commonly known as the Hatch Act, approved by Congress March 2, 1887.

Subsequently, the increasing demands upon the station for investigations of various kinds rendered additional funds necessary, and the state was called upon for assistance. At present, the Agricultural Experiment Station receives regular support from the state at the rate of about \$85,000 per annum. The bennefits to agriculture resulting from the investigations of the station are too well known to need comment. The expenditures of the state in support of the station have been repaid many times. Millions of dollars have been added to the wealth of Illinois through the investigations on corn breeding, the soil surveys and fertility experiments, and the work of eradicating insect pests.

It is the hope of the station staff that the Engineering Experiment Station may stand in the same helpful relation to the great mining, transportation and manufacturing interests of Illinois. What has been done for agriculture may well be done for The state's investments in the Agricultural Exmanufacturing. periment Station have been rewarded with large dividends in the way of increased soil fertility and increased and improved agricultural product. Surely as large dividends await similar investments in the Engineering Experiment Station. Important problems in agriculture have been and are being successfully solved by the Agricultural Experiment Station. Important and difficult problems of engineering confront the manufacturer and power user, and press for solution. It is the aim of the Engineering Experiment Station to assist in the solution of these problems, and thus to aid and uplift the engineering industries of Illinois. It may be well to call attention here to the rapidly increasing popularity and value of the work of the Royal Testing Laboratory. located at Charlottenburg, Germany, which has been doing for the German Empire work similar in some details to that which it is now proposed shall be done by the Engineering Experiment Station.

In the following paragraphs are discussed somewhat in detail the lines of work that may be taken up for the benefit of certain industrial interests.

Fuel.—The fuel supply of Illinois is of prime importance in its industrial development, and no effort should be spared in the introduction and promulgation of improved methods and processes in the production and consumption of coal. From broad economical considerations, wasteful methods of using coal, or the rejection of any combustible part as waste, are to be discountenanced. Exhaustive and careful experiments will be required before the best conditions can be attained. These experiments must include analyses of coals from all parts of the state, a determination of the best kinds of coal for specific purposes, best methods of burning Illinois coals, effects of various methods of preparation, experiments on various kinds of furnace construction, etc.

Generation and Use of Power.—Along the line of power production there is opportunity for much investigation. New problems are confronting both the builders and users of steam and gas motors. There is at present a noteworthy drift from the recip-

rocating engine to the steam turbine. Gas engines of large power have recently been installed, and the development of this type of motor bids fair to be more rapid in the near future. Still newer types of motors are being proposed from time to time, the gas turbine being one that at present occupies much attention as an attractive possibility.

It is evident that the Experiment Station may be of considerable service in this line of work. For the user of power, it can investigate questions relative to the economy of various types of power installations with given conditions of service. For the builder of motors it can investigate the new and perplexing problems that have arisen. The properties of the various fluids used in heat motors need careful study. Superheated steam is essential to the proper working of a steam turbine, yet little is known of its properties. The properties of ammonia and other fluids used in refrigeration are not known accurately, and even the properties of saturated steam are based on Regnault's experiments made nearly seventy years ago. A careful investigation of the properties of heat media of all kinds, extending if necessary over a series of years, would furnish data of the greatest value to engineers, and would in addition be a noteworthy contribution to science.

Railroads.—Considerable work for the railroad interests has already been done by the railway mechanical engineering department of the University. The dynamometer car owned jointly by this department and the Illinois Central Railroad has been used in numerous road tests, and these tests have been used as a basis for the computation of tonnage ratings. This work will be prosecuted vigorously under the direction of the new department of railway engineering and administration recently organized.

Other problems relating to design, maintenance of way, etc., will be attacked as they arise. The question of electric traction is becoming one of great importance in Illinois. The electrical engineering department has recently added to its equipment a new dynamometer car, with which tests may be made on electric lines, and it is expected that these tests will furnish valuable data.

Manufacturing and Building.—It is expected that the Experiment Station will prove helpful to the manufacturing and building interests of Illinois in several ways. In the first place, it will supply accurate data regarding the properties of the materials used in engineering structures and buildings. The new lab-

oratory of applied mechanics with its extensive equipment furnishes ample facilities for this line of work. The new 600,000-pound vertical testing machine permits the testing of full-sized specimens 24 feet in length. The reinforced concrete tests now in progress show the possibilities in this line of work. In the near future, an extensive series of tests on cast-iron columns, and others on steel plates are contemplated. A considerable portion of the available funds of the station will be expended in this work of testing materials. Secondly, the Experiment Station will investigate manufacturing processes. As an example of this line of work, the high-speed steel tests are cited. Thirdly, problems relating to design and construction will be studied, and all useful results will be published for the benefit of those engaged in design or construction.

As a rule the Experiment Station will undertake only such investigations as will lead to results of fundamental importance, results that will be helpful to a large class of engineers or manufacturers. It will not, in general, undertake work of importance to individuals only, e. g., the testing of a device or invention for the sole benefit of the inventor.

Those in charge of the Engineering Experiment Station feel that if the work of the station be carried out along the lines here suggested, and if proper support be afforded by the state in order that the work can be so carried out, the engineering industries of Illinois will receive benefits which will amply repay all expenditures.

# VIII. COOPERATION

It is very essential that great care should be exercised in the selection of subjects to be investigated. It is equally important that the results of the investigations should be published in such shape as will best serve the purposes of engineers and manufacturers. In order that these ends may be attained it has been thought desirable that there shall be organized several committees of conference on matters of widespread interest. One such committee has already been appointed, the Conference Committee on Fuel Tests, composed of representatives appointed by the following Illinois organizations: State Geological Survey, Western Society of Engineers, Building Managers' Association of Chicago, Western Railway Club, Illinois Manufacturers' Association, Illinois Coal Operators' Association, State Electric Light Association,

Board of Trustees University of Illinois, and the State Engineering Experiment Station. It is planned to form similar committees relating to other lines of work whenever the importance of the investigations warrants it. It is hoped that suggestions may be proposed to the station from engineers, or from mining, railway, or manufacturing interests, to the end that the work of the station may grow to be of real value to the commercial interests of the state. Engineering societies will find at the University excellent facilities for meeting, and it is suggested that such societies plan to hold their meetings here as often as possible.

The desirability of cooperating with similar state experiment stations or with some of the national departments having charge of tests of fuel, timbers, structural materials, or with water surveys, etc., is also evident, and such cooperation will be sought whenever mutual good is promised. Such a method will often tend to concentrate isolated and scattered efforts, and will also tend to standardize methods of tests and forms of reports and specifications.

# PUBLICATIONS OF THE ENGINEERING EXPERIMENT STATION

Bulletin No. 1. Tests of Reinforced Concrete Beams, by A. N. Talbot. 1904.

Circular No. 1. High-Speed Tool Steels, by L. P. Breckenridge. 1905.

Bulletin No. 2. Tests of High-Speed Tool Steels on Cast Iron, by L. P. Breckenridge and Henry B. Dirks. 1905.

Circular No. 2. Drainage of Earth Roads, by Ira O. Baker. 1906.

Bulletin No. 3. The Engineering Experiment Station of the University of Illinois, by L. P. Breckenridge. 1906.





# UNIVERSITY OF ILLINOIS

# Engineering Experiment Station

Bulletin No. 5

JUNE 1906

# RESISTANCE OF TUBES TO COLLAPSE

By Albert P. Carman, Professor of Physics and Maurice L. Carr, Assistant in Physics

This paper describes a series of experiments made on the resistance of metal tubes to collapse when subjected to external hydraulic pressure. The principal use of the results of such experiments is probably their application to the design and inspection of the fire flues of steam boilers, but the results are also of great interest and importance in the theory of elasticity and the strength of materials. Engineers have used various empirical rules and formulæ for the collapse of tubes, but these formulæ have been derived from a few unsatisfactory experiments and have within recent years been generally distrusted. This distrust has not been lessened by the mathematical discussions of the last few years, in which students of elasticity have attempted to derive a rational formula for tube collapses. These proposed rational formulæ differ, as we shall see, from the empirical rules in use by engineers.

The present work was first planned by L. P. Breckenridge and A. P. Carman in the spring of 1904, but University duties prevented its prosecution at that time. In the winter of 1904 to 1905, a series of experiments on the collapse of small seamless brass tubes was carried out by A. P. Carman. These experiments were described and the results discussed in a paper read before the American Physical Society at Chicago, April 23, 1905, and published later in the Physical Review. It was there shown that the form-

A. P. Carman, Collapse of Tubes, Physical Review, Vol. XXI, pp. 381-387.

ulæ in general use, all of which are based on that of Sir William Fairbairn, are inadequate; that there is a certain "critical minimum length" beyond which the resistance to collapse of a tube is independent of the length; and that a formula of the rational type proposed by Professor G. H. Bryan was probably nearly true for these small brass tubes.

The experiments discussed in this bulletin have been made by the department of Physics of the Engineering Experiment Station of the University of Illinois. They were begun in the fall of 1905, but owing to delays in getting apparatus and materials were not completed until May 1, 1906. M. L. Carr, B. S., has been the assistant in carrying on this series of experiments. He has made the observations, and to him are due several of the special devices used as well as much of the completeness and accuracy of the calculations. Before describing our own experiments and discussing the results, we shall give a brief account of previous experiments and of the empirical and theoretical formulæ which have been proposed.

## HISTORICAL

The first and until very recently the only systematic experiments on the collapse of tubes were those of Sir William Fairbairn made nearly fifty years ago1. Fairbairn's work was done at the suggestion and with the aid of the Royal Society and of the British Association for the Advancement of Science. The common steam pressure in that day was 50 pounds per square inch or less, and so the highest pressure thought necessary by Fairbairn was less than 500 pounds. The tubes were "composed of a single thin iron plate bent to the required form upon a mandril and riveted and also brazed to prevent leakage into the interior". The ends were closed by cast-iron disks or plugs, and the tube was placed in a large cast-iron cylinder and there subjected to hydraulic pressure. Fig. 1 is reproduced from Fairbairn's original paper and shows his arrangement. The cast-iron cylinder was 8 feet long, 28 inches in diameter and the walls were 2 inches thick. The cylinder was placed in a vertical position and the tube was

William Pairbairn, On the Resistance of Tubes to Collapse, Philosophical Transactions of the Royal Society of London for 1858, pp. 389-413; also in Fairbairn's Useful Information for Engineers, Second Series, London, 1867.,




Fig. 1 Sir Wm. Fairbairn's Apparatus for Testing Tubes, Reproduced from Phil. Trans. for 1858



supported from both ends, as shown in the figure. The interior of the tested tube was connected with the atmosphere at the upper end. The pressure was produced by a hydraulic pump and was read by steam gauges. A safety valve set at 500 pounds limited the pressure. The diameters of the tubes collapsed were 4, 6, 8, 9, 10 and 12 inches with the exception of one which was 18\frac{3}{4} inches in diameter. The length of these tubes ranged from 19 to 60 inches, and nearly all had the same wall thickness of .043 of an inch. In all, about twenty-five satisfactory collapses were made. Fairbairn sums up his results in this well-known formula:

$$P = 9,675,600 \frac{t^{2.19}}{l d}$$

"Which is", he says, "the general formula for calculating the strength of wrought-iron tubes subjected to the external pressure within the limits indicated by the experiments; i. e., provided their length is not less than 1.5 feet, and not greater than 10 feet". In the above formula, P = pressure in pounds per square inch; t = thickness of wall in inches; t = length of tube in inches; and t = diameter in inches. Fairbairn adds as a foot-note the following: "By taking 2 instead of 2.19 for the index of t, this formula becomes

$$P = 9,675,600 \frac{t^2}{ld}$$

whence the value of *P* may be calculated by ordinary arithmetic. For thick tubes of considerable diameter and length, this formula may be regarded as sufficiently exact for practical purposes". This last or approximate form is sometimes known as Fairbairn's second form. Fairbairn's formula has been the text for practically all the discussions on the collapse of tubes for the last fifty years. Aside from Fairbairn's experiments, there have been no systematic experiments described until within the last year. It is noteworthy that a problem so widely discussed, the solution of which has not only great scientific interest but also valuable technical applications, should remain for so many years with so little experimental work. The only reasons that can be assigned are the considerable expense involved in the experiments and the fact that the appliances needed are not commonly available in testing laboratories.

TABLE I
FAIRBAIRN'S DATA ON THE RESISTANCE OF TUBES TO COLLAPSE

Diameter, inches	Length, incehs	Thicknes of Wall, inches	Pressure of Collapse, lb. per sq. in.	Remarks
4 4 4 4 4 4	19 19 40 38 60 60 60 30	.043 .043 .043 .043 .043 .043 .043	65 65 43 140 47	Tubes formed of plates of uniform thickness. Made in 3 sections, 1 ft. 7 in. each.  Ends of tube fractured, allowing water to enter and cause reaction pressure.
4 4 6	30 15 30 29 59	.043 .043 .043 .043	147 48	enter and cause reacting pressure.  Cast-iron ends fractured, causing collapse before outer shell attained maximum resistance.
- 6 6 6	30 30 30 30 30	.043 .043 .043 .043	52 65 85	Rod placed down axis to prevent end from approaching. Tin ring left in caused increased pressure.
8 8 8 8 10 10 12 12	40 60 30 50 30 30 60	.043 .043 .043 .043 .043 .043	31 22	
12.2 9 18.75 9 14x10.25 20.75x15.5	58.5 37 61 37 37 60 61		$ \begin{array}{c} 11 \\ (450) \\ 420 \\ 262 \\ 378 \\ 6.5 \end{array} $	Uncollapsed.  Lap joint.  Butt joint.  Elliptical tubes.  Elliptical tubes.

The most remarkable feature of Fairbairn's formula is the dependence of the collapsing pressure upon the length. This will be discussed later. Immediately after the publication of Fairbairn's paper, one writer after another began to discuss the data for the purpose of deducing a more general and convenient empirical formula. The following is a partial list of the best known of such formulae. The dimensions are given in inches just as in the form of Fairbairn's formula:

(1) By F. Grashof: in Zeitschrift des Vereines deutscher Ingenieure, p. 234, 1859.

(a) For thick tubes:

$$P = 1,033,620 \frac{t^{2,081}}{l^{0,564}d^{0,889}}$$

(b) For thin tubes:

$$P = 24,481,000 \frac{t^{2,315}}{ld^{1,278}}$$

(2) By G. H. Love: in Todhunter and Pearson's History of Elasticity, Vol. 11, p. 667. Appeared in Civilingenieur, 1861.

$$P = 5,358,150 \frac{t^2}{ld} + 41906 \frac{t^2}{d} + 1323 \frac{t}{d}$$

(3) By J. W. Nystrom: Quoted here from Van Nostrand's Engineering Magazine, Vol. XXIV, p. 213. Original reference, Treatise on Steam Engineering, by J. W. Nystrom, p. 106.

$$P = 692,800 \frac{t^2}{l^{0.5}d}$$

(4) By W. C. Unwin: in Minutes of Proceedings of Institution of Civil Engineers, Session 1875–1876, Part IV, p. 225.

$$P = 15,547,000 \ \frac{t^{2,35}}{l^{0.9}d^{1.16}}$$

for flues with longitudinal and circumferential joints.

(5) By F. Wehage: in Dingler's Polytechnisches Journal, pp. 236-243, 1881.

$$P = \begin{cases} 368,000 \frac{8t}{d} & \sqrt[3]{\frac{t}{ld}} \end{cases}$$

The coefficient 368,000 to be used for flues with lap joints riveted; the 490,000 to be used for flues with flap joints riveted on.

(6) By Theodore Belpaire: Note sur la résistance des tubes pressées de l'extérieur, par Theodore Belpaire in Annales du Génie civil, March, 1879. Quoted from Van Nostrand's Magazine, Vol. XXIV, 1881.

$$P = 3,427,152 \left[ \frac{t^2}{ld} \right] - 56,892,400 \left[ \frac{t^3}{ld^2} \right]$$

All of the above formulæ have the same fundamental form as Fairbairn's. Indeed, we might expect this, for they are simply

empirical expressions made to fit Fairbairn's observations. Most writers had seen that there must be a limit to the length of tubes for which these formulæ should be applied, but no results of experiments had been published previous to 1905 regarding this.

The previous experiments by the writer were made to test this principal characteristic of the Fairbairn formula, viz., that the collapsing pressure varies inversely as the length. Twenty-five small seamless brass tubes were collapsed by hydraulic pressure. The diameter, thickness of wall, length and collapsing pressure are shown in the following table:

TABLE II

TABLE OF COLLAPSING PRESSURES OF SMALL SEAMLESS BRASS TUBES<sup>1</sup>

Mean Diameter, inches         Thickness of Wall, inches         Length, inches         Collapsing Pressure, lb, per sq, in.           .350         .0163         .315         4125           .350         .0163         .472         3415           .350         .0163         .709         3200           .350         .0163         1.063         2248           .350         .0163         1.570         1778           .350         .0163         3.150         1850           .350         .0163         3.540         1850           .350         .0163         1.570         9525           .441         .0315         2.280         6975           .441         .0315         2.280         6975           .441         .0315         3.820         6400           .441         .0315         3.820         6400           .441         .0315         7.480         6690           .721         .0315         1.220         7750           .721         .0315         2.280         6260           .721         .0315         3.030         5120           .721         .0315         3.200         4980 <tr< th=""><th></th><th></th><th></th><th></th></tr<>				
$\begin{array}{cccccccccccccccccccccccccccccccccccc$	Diameter, inches	of Wall, inches	inches	Pressure, lb. per sq. in.
$\begin{array}{c ccccccccccccccccccccccccccccccccccc$				
.350         .0163         1.063         2248           .350         .0163         1.570         1778           .350         .0163         3.150         1850           .350         .0163         3.540         1850           .350         .0163         1.570         9525           .441         .0315         2.280         6975           .441         .0315         2.715         6690           .441         .0315         3.845         6690           .441         .0315         3.820         6400           .441         .0315         7.480         6690           .721         .0315         1.220         7750           .721         .0315         1.733         6620           .721         .0315         2.280         6260           .721         .0315         8.200         4980           .721         .0315         8.200         4980           .721         .0315         3.420         11940           .701         .0531         5.120         12090           .701         .0531         5.120         12020           .701         .0531         5.190				
$ \begin{array}{c ccccccccccccccccccccccccccccccccccc$		.0163	. 709	
$\begin{array}{cccccccccccccccccccccccccccccccccccc$		.0163	1.063	2248
$\begin{array}{cccccccccccccccccccccccccccccccccccc$	.350	.0163	1,570	1778
$ \begin{array}{c ccccccccccccccccccccccccccccccccccc$	.350	.0163	3.150	1850
$ \begin{array}{c ccccccccccccccccccccccccccccccccccc$	.350	.0163	3.540	1850
$ \begin{array}{c ccccccccccccccccccccccccccccccccccc$	.350	.0163	1.570	9525
$ \begin{array}{c ccccccccccccccccccccccccccccccccccc$	.441	,0315	2.280	6975
$ \begin{array}{c ccccccccccccccccccccccccccccccccccc$	.441	.0315	2.715	6690
$\begin{array}{c ccccccccccccccccccccccccccccccccccc$	.441	.0315		6690
$\begin{array}{c ccccccccccccccccccccccccccccccccccc$	.441	,0315	3.820	6400
$\begin{array}{cccccccccccccccccccccccccccccccccccc$	.441	.0315	7.480	6690
$ \begin{array}{c ccccccccccccccccccccccccccccccccccc$	.721	.0315	1.220	7750
$\begin{array}{c ccccccccccccccccccccccccccccccccccc$	.721	.0315	1.733	6620
$\begin{array}{cccccccccccccccccccccccccccccccccccc$	.721	.0315	2.280	6260
$ \begin{array}{c ccccccccccccccccccccccccccccccccccc$	.721	.0315	3.030	5120
$ \begin{array}{c ccccccccccccccccccccccccccccccccccc$		.0315	8.200	4980
$ \begin{array}{c ccccccccccccccccccccccccccccccccccc$	.721	.0315	3.420	11940
.701 .0531 5.120 12020 .701 .0531 5.190 11940 .701 .0531 5.270 12090		.0531	3.500	12200
$ \begin{array}{c ccccc} .701 & .0531 & 5.190 & 11940 \\ .701 & .0531 & 5.270 & 12090 \end{array} $	.701	.0531	5.120	12090
.701 .0531 5.270 12090		.0531	5.120	
	.701	.0531	5.190	11940
.701 .0531 8.270 12090	.701	.0531	5.270	12090
	.701	.0531	8.270	12090

The curve, Fig. 2, shows the relation between length and collapsing pressure for tubes 0.35 of an inch in diameter. The curves for the other diameters are of the same shape. The following conclusions were drawn. "An inspection of these data and curves shows immediately that there is a minimum length for

<sup>&</sup>lt;sup>1</sup>Data taken by Professor A. P. Carman, from Physical Review, Vol. XXI, No. 6, Dec., 1905.




Fig. 2 Curve Showing Relation of Collapsing Pressure to Length in Small Seamless Brass Tubes



each tube beyond which the collapsing pressure is constant; and further, that this minimum length is quite definite. Again, we see that for lengths less than this critical minimum length, the collapsing pressures rise rapidly. As definitely as can be determined from these small tubes, the collapsing pressure varies inversely as the length, for lengths less than the critical length. In this they follow Fairbairn's formula, and suggest that Fairbairn's tubes were all shorter than their critical lengths. An inspection of the woodcuts which Fairbairn gives for each of his experiments, and a comparison of these with the shapes of the brass tubes which have been collapsed in our experiments confirm this. Figs. 3 and 4 show shapes and sections of the collapsed tubes of the curve, Fig. 2. Fairbairn found exactly these shapes which we have obtained for lengths less than the critical length".

These previous experiments had thus shown the inadequacy of Fairbairn's formula, and they had particularly shown the very narrow range of the law of inverse lengths. When the present series of experiments on standard steel boiler flues was begun, little attention was therefore paid to the law of lengths, except to see that the tubes were longer than the critical minimum length.

## METHODS AND DATA OF EXPERIMENTS

The method followed in the present tests was similar to that used by Fairbairn. The tube to be tested was closed at both ends, placed inside a stout steel cylinder, and there subjected to increasing external water pressure until the tube collapsed. The pressures were read by hydraulic gauges. The cylinder used in all these experiments was a section of a nickel steel naval gun tube, kindly furnished at a nominal price by the Bethlehem Steel Company, Bethlehem, Pennsylvania. The dimensions of this gun tube were: length, 12 feet; external diameter, 7 inches; internal diameter, 5 inches. For a distance of six inches at one end, the external diameter was left at 9 inches, thus making a shoulder against which the end plug could be clamped. This plug was a steel disk with a projection, and was held in place by heavy castiron rings and eight 14-inch steel bolts. A lead gasket with circular grooves in the end face of the tube prevented leakage even at the highest pressures. The other end of the nickel steel cylinder was closed by a cast-iron plug, six inches long, shrunk into place.

A. P. Carman. Am. Physical Society, April, 1905.

A \(\frac{3}{4}\)-inch hole for stay rods was drilled through the center of each end plug. Leakage about the rods was prevented by packing held in place by bushing nuts. These stay rods were made of \(\frac{3}{4}\)-inch steel shafting, and were screwed, one into each end plug of the tube to be tested. The tube could thus be put under tension so as to take up the end pressures. One of these stay rods had a small hole through it connecting the interior of the tube with the atmosphere. By rubber tubing, the interior could be connected with a U manometer. This manometer was very useful in indicating any leakage.

In the first experiments, the tube to be tested was closed by steel plugs, fitted and soldered in the ends. Experience soon showed that soldering the plugs was both a tedious and an uncertain method of closing the ends. Several other plans were tried before a satisfactory and convenient method was found. The final method is shown in Fig. 5. Tool-steel clamps were made in the shape of split rings, hinged on one side and held together on the other side by bolts. These ring clamps were placed on the tube near the end as a grip, and slipping was prevented by burring the tube with a cold chisel. A steel disk faced with a sheet of lead was then drawn tight against the plane ends of the tube by bolts screwing into the clamps. After the ends were clamped on the tube it could be tested for leakage by placing the whole tube in a trough of water, and pumping air into it with a foot bicycle pump through the bored stay rod. It was seldom that a tube tested in this way leaked when subjected even to high external water pressure. The connections with the gauges, the pump and the hydrant were made through small holes bored in the nickel steel cylinder. These holes were made tight by special screw plugs and leather gaskets. The cylinder was mounted on two heavy trestles and inclined so as to allow the easy escape of the air when filling it with water. The pressures were produced by a Cailletet pump made by the Societé Genevoise, of Geneva, Switzerland. The pump was capable of producing pressures of 1000 kilograms per square centimeter, or approximately 14,000 pounds per square inch. Copper pressure tubing was used to connect the pump and the gauges with the cylinder. gauges made by Shæffer and Budenberg were used, viz.:

No. 1, reading to 8000 pounds per square inch.

No. 2, reading to 1000 kilograms per square centimeter.

No. 3, reading to 3000 pounds per square inch.

No. 4, reading to 300 kilograms per square centimeter.




Fig. 3 Appearance of Collapsed Small Seamless Brass Tubes

Referred to in Figs. 2 and 4

Fig. 4 Sections of Collapsed Small Seamless Brass Tubes




Fig. 5 Parts of Clamp for Stopping End of Tube (on the right)

Clamp in Place on Tube (on the left)




Fig. 6 Section of Nickel Steel Cylinder, with Tube to be Tested in Place, Showing END PLUGS AND CONNECTION TO PUMP




Fig. 7 APPARATUS FOR COLLAPSING TUBES




FIG. 8 TUBES WHICH HAVE BEEN COLLAPSED, SHOWING SHAPE OF COLLAPSE




Fig. 9 Tube with End Stopped and with Stay Rods, Ready to be Put into Cylinder for Test




Fig. 10 Collapsed Portions of Some Boiler Tubes

Gauges Nos. 1 and 3 had maximum pointers, and all had check valves to protect the springs from the shock at collapse. The drawing of the cylinder, Fig. 6 and the photograph, Fig. 7, of the assembled apparatus show other features not easily described.

When a test was to be made, the prepared tube was placed in the cylinder, the heavy head bolted on, and the cylinder filled with water from the hydrant. All the openings were then closed, and the pressure pump started. Several minutes of pumping were usually required before the gauges began to record. Except for a few thin tubes of large diameter, failure, which was sudden in all cases, was accompanied by a sound much like that accompanying the failure of a specimen in a testing machine. Failure was also indicated by the dropping of the gauges and the rise of the water in the manometer connected with the inside of the tube. Each specimen was carefully measured after collapse, and in the case of most of the tested tubes, the collapsed portion was sawed across and the actual average thickness of the tube was obtained. Nearly all of the tubes tested were ten feet long at the start. In many cases, three or more collapses were made by cutting off the collapsed portion after each failure, and then testing the remainder of the tube. In the tables of data, these are noted as sections of the flue, e. g., flue No. 1 was divided into three sections, 1, 2 and 3. The tubes tested were commercial steel boiler tubes, both lap-welded and cold drawn seamless. We have to thank J. T. Ryerson and Son, Chicago, for the gift of four tubes, and the Scully Steel and Iron Company, Chicago, for the gift of twenty-five tubes for these tests. The other tubes used were bought in the open market. In order to have data on entirely different material, tests were made on a set of brass tubes similar in size to the steel tubes. The advantage of the brass tube tests was that the dimensions and the material were much more uniform.

CHEMICAL TESTS OF SAMPLES OF BOILER FLUES COLLAPSED

Description of	CHEMICAL ANALYSIS							
Sample of Flue	Si	s	Р	Mn	С			
Lap-welded steel		.021 .038 .001 .002	.137 .099 .018 .013	.286 .330 .462 .525	.080 .080 .170 .220			

TABLE III DATA ON SEAMLESS COLD DRAWN FLUES

Er			£	Nominal Thickness, inches	Actual Av. Thickness, inches	Collapsing Pressure, 1b. per sq. in.	of to	00
FL	UE	z ·	Diameter, inches	ne ne	l /	Collapsing Pressure, 1b. per sq. in.	Length of Collapse, inches	Distance Collapse from Vented End
		Length	Diamet	Nomina Thickn inches	na ck	ssa pe in.	graph and a second	Distance Collapse from Vented End
NT -	Can	ű	ch	문한되	e pict		G 25	Dist Colls from Ven End
No.	Sec.	Ž.	ig is	ZE.E	F. H.A	응합을 함	13.O.E.	DO#>B
								1
25		9 ft. 6 in.	1.5	. 095	.097	4220	32	5 ft. 2 in.
$\frac{25}{26}$	1	9 ft. 7 in.	1.5	.095	.098	4260	30	5 ft. 2 in. 8 ft. 2 in.
$\frac{26}{26}$	9	6 ft. 11 in.	1.5	.095		4260	38	5 ft. 6 in.
$\frac{26}{26}$	$\frac{2}{3}$	2 ft. 8 in.	1.5	.095		3930	25	1 ft. 6 in.
$\frac{20}{27}$		9 ft. 7 in.	1.5	.095		5200	3	At extreme
41		./ 10. 1 111.	1.0	.005		02.00	"	end of flue.
28		8 ft. 4 in.	1.5	.095	.100	4330	32	4 ft. 6 in.
$\frac{10}{29}$		8 ft. 4 in.	1.5	.095	.102	4240	29	1 ft. 4 in.
$\frac{25}{45}$		9 ft. 2 in.	1.5	.095	.095	3930	29	6 ft. 4 in.
Mean					.098	4200	30.4	
42		9 ft. 7 in.	2	.095	.102	3050	27	1 ft. 0 in.
43		9 ft. 7 in.	2		.092	2420	20	6 ft. 4 in.
44		9 ft. 7 in.	2 2		.103	3390	36	6 ft. 4 in.
Mean			$\begin{array}{c c} 2.5 \\ 2.5 \\ 2.5 \end{array}$		.099	2950	28	
36		9 ft. 8 in.	2.5	.083	.084	1280	27	5 ft. 0 in.
37		9 ft. 7 in.	2.5	.083	.084	1100	26	6 ft. 8 in.
Mean					.084	1190	26.5	
39		9 ft. 7 in.	2.5	.095	.103	1820	35	4 64 0 1
40		9 ft. 6 in.	2.5	.095	.098	1730	27	4 ft. 6 in.
41		9 ft. 7 in.	2.5	.095	.098	1890	22 28	9 ft. 0 in.
Mean		10 6 0 :	9.5	.109	.099	$\frac{1810}{1720}$	28	1 ft. 2 in.
, 3	1	10 ft. 0 in.	$\frac{2.5}{2.5}$	.109	.114	1920	27	1 ft. 2 in. 2 ft. 2 in.
3	3	6 ft. 10 in. 3 ft. 4 in.	9.5	.109		2200	24	1 ft. 10 in.
3 4	1	9 ft. 8 in.	$\frac{2.5}{2.5}$	.109	.116	1980	25	1 10. 10 111.
4	9	5 ft. 10 in.	2.5	.109		2470	25 27	2 ft. 3 in.
4	2 3	0 10. 10 111.	$\frac{2.5}{2.5}$	.109		2610		
38		9 ft. 7 in.	2.5	.109	.109	1580	25	1 ft. 9 in.
Mean	1				.113	1960	27	
1	i	9 ft. 0 in.	2.5	.120	.120	1830	27	
î		4 ft. 11 in.	2.5	.120		1850	26	
î	2 3	1 ft. 9 in.	2.5	.120		2190	21	
2	1	7 ft. 9 in.	2.5	.120	.121	2320	28	5 ft. 6 in.
$\frac{2}{2}$	2	3 ft. 6 in.	2.5	.120		2650	23	1 ft. 9 in.
Mean					.120	2070	25	1
33		9 ft. 7 in.	3	.095	.094	1190	28	4 ft. 0 in.
34		9 ft. 7 in.	3	.095	.102	1160	33	8 ft. 0 in.
35		.9 ft. 7 in.	3	.095	.097	1130	32 31	8 ft. 0 in.
Mean	1	O 64 m	9 5	005	. 098	1160	37	6 ft. 0 in.
30		9 ft. 7 in.	3.5	.095	.093	900	55	7 ft. 0 in.
31		9 ft. 7 in. 9 ft. 7 in.	$\frac{3.5}{3.5}$	.095	.096	970	42	6 ft. 7 in.
32		9 ft. 7 in.	5.0	.036	.093	950	45	0 10. 7 111.
Mear					.004	1,790	10	
	1	1	1	1	1			

TABLE IV DATA ON LAP-WELDED STEEL BOILER FLUES

Tr.	UE		, i	Nominal Thickness, inches	Actual Av. Thickness, inches	£	j.	Distance of Collapse from Vented End
E 1.2	UE	_ 4	Diameter, inches	ne	ne ine	Collapsing Pressure, 1b. per sq. in.	Length of Collapse, inches	Distance Collapse from Vented End
		Length	ne	ck Sir	Actual Thickrinches	Collaps Pressu Ib. per sq. in.	la la	an lar
No.	Sec.	en	ian	lo lo	ie ii		ol	Dista Colla from Ven End
1.01	2001	Ă	U.i.	ZHE	AT.	SHE 8	H.O.H	QQ 4 V R
				1				
5	1	8 ft. 10 in.	-2.5	.109	.114	2850	29	
õ	2	5 ft. 10 in.	-2.5	. 109		3040	31	
5	3	3 ft. 0 in.	-2.5	.109		3400	29	1 ft. 1 in.
6	1	8 ft. 8 in.	$\frac{2.5}{3}$	.109	.116	2810		4 ft. 11 in.
6	2 3	6 ft. 0 in.	2.5	.109		2930	27	4 ft. 11 in.
0		3 ft. 7 in. 8 ft. 8 in.	9.5	.109	190	3080	21	0 ft. 7 in.
4	$\frac{1}{2}$	8 ft. 8 in. 2 ft. 4 in.	9.5	.109	.120	$\frac{2700}{2850}$	37	1 ft. 1 in.
6 7 7 8 8 8	ī	9 ft. 0 in.	5.5	.109	.112	$\frac{2900}{2900}$	$\frac{27}{25}$	1 ft. 1 in. 4 ft. 6 in.
8	9	3 ft. 3 in.	2.5	.109	. 1.1	2950	25	2 ft. 0 in.
8	2 3	2 ft. 6 in.	2.5	.109		3170	24	1 ft. 6 in.
9	1	9 ft. 0 in.	2.5	. 109	.120	3160	24 20	
9	$\frac{2}{1}$	5 ft. 10 in.	2.5 2.5 2.5 2.5 2.5 2.5 2.5 2.5 2.5 2.5	.109		3450	$\frac{27}{30}$	3 ft. 1 in.
10	1	9 ft. 0 in.	3	.109	.105	2080	30	1 ft. 9 in.
10	2	4 ft. 11 in.	3	.109		2150	29 29	3 ft. 5 in.
10	3	2 ft. 10 in.	3	.109		2350	29	0 ft. 8 in.
11	1	9 ft. 0 in. 6 ft. 6 in.	3	.109	.111	2190	23	8 ft. 6 in.
11 11	3	6 ft. 6 in. 3 ft. 8 in.	3	$\frac{.109}{.109}$		$ \begin{array}{r} 2430 \\ 2620 \end{array} $	$\frac{30}{26}$	1 ft. 7 in. 2 ft. 6 in.
11	4	1 ft. 8 in.	3	.109		3150	$\frac{20}{20}$	2 ft. 6 in. 0 ft. 10 in.
12	i	9 ft. 0 in.	3	.109	.105	1910	4	At extreme
			.,	1 2 2 3 47	110.5	1010	1	end of flue.
12	2	8 ft. 8 in.	3	.109		2020	27	7 ft. 6 in.
12	3	5 ft. 1 in.	3	.109		1960	30	1 ft. 4 in.
12	4	2 ft. 6 in.	3	.109		1920	26	1 ft. 9 in.
13	1	9 ft. 0 in.	3	.109	.106	2140	32	6 ft. 8 in.
13 14	2	5 ft. 1 in. 9 ft. 0 in.	3	.109	.113	2220	33	2 ft. 10 in.
14	2	9 ft. 0 in. 2 ft. 11 in.	3	.109	,115	2080 2000	32 27	4 ft. 3 in.
14	3	2 ft. 6 in.	3	.109		2230	28	1 ft. 9 in. 1 ft. 2 in.
15	1	9 ft. 5 in.	3.5	.120	.124	1940	31	1 ft. 4 in.
15	2	6 ft. 8 in.	3.5	.120		2310	30	1 ft. 2 in.
15	3	4 ft. 1 in.	3.5	.120		2470	30	2 ft. 11 in.
15	4	1 ft. 4 in.	$\frac{3.5}{3.5}$	120		2800	16	0 ft. 8 in.
16	1	9 ft. 6 in.	3.5	.120	.129	2180	31	1 ft. 1 in.
16	2	6 ft. 9 in.	3.5	.120		2500	30	5 ft. 7 in.
16	3	4 ft. 1 in.	$\frac{3.5}{3.5}$	.120	190	2790	27	2 ft. 11 in.
17 17	1 2	9 ft. 8 in. 6 ft. 8 in.	3.5	.120	.129	2150	41	1 64 5
17	3	6 ft. 8 in. 3 ft. 4 in.	3.5	.120		2240 2660	36 36	1 ft. 5 in.
18	1	9 ft. 4 in.	3.5	.120	.128	1890	39	2 ft. 0 in.
18	2	6 ft. 4 in.	3.5	.120		1870		
19	1	9 ft. 4 in.	3.5 3.5 3.5 3.5 3.5	. 120	.127	2200	32	1 ft. 4 in.
19	2	6 ft. 8 in.	3.5	.120		2290	42	4 ft. 4 in.
19	3	2 ft. 6 in.	3.5	.120		2440	30	1 ft. 2 in.
20	1	8 ft. 5 in.	2	.095	.095	3100	33	7 ft. 2 in.
20	2 3	5 ft. 5 in.	2	.095		3410	29	3 ft. 2 in.
$\frac{20}{21}$		2 ft. 3 in. 8 ft. 4 in.	2	.095	000	3640	27	1 ft. 1 in.
$\frac{21}{22}$	1	8 ft. 4 in. 8 ft. 2 in.	2	.095	.106	$\frac{2650}{3180}$	32 30	6 ft. 7 in.
22	$\begin{vmatrix} 1 \\ 2 \end{vmatrix}$	5 ft. 8 in.	2 2 2 2 2 2 2 2 2	.095	.100	$\frac{3180}{3500}$	$\frac{30}{32}$	6 ft. 6 in. 4 ft. 1 in.
		J 10. U III.		1 ,000		3900	0.2	4 10. 1 III.

TABLE IV-Concluded

FLUE No. Sec.	Length	Diameter, inches	Nominal Thickness, inches	Actual Av. Thickness, inches	Collapsing Pressure, 1b. per sq. in.	Length of Collapse, inches	Distance of Collapse from Vented End
22 3 1 23 23 2 23 23 3 24	2 ft. 8 in. 8 ft. 4 in. 6 ft. 0 in. 3 ft. 0 in. 8 it. 5 in.	2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2	.095 .095 .095 .095 .095	.102	3700 3260 3960 4030 3470	26 28 37 27 31	1 ft. 1 in.  1 ft. 8 in. 2 ft. 0 in. 4 ft. 2 in.

TABLE V

Data on Brass Tubes

TUBE	th	eter, nes	Тинсь	XNESS	Collapsing Pressure, 1b. per sq. in.	th of apse, les
No.   Sec.	Length	Diameter, inches	Gauge	Inches	Colla Pres Ib. F	Length Collap inches
1 1 2 1 1 2 1 3 2 1 2 2 2 3 1 1 4 1 4 2 3 3 5 1 6 7 8 8 9 1 2 10 11	8 ft. 8 in. 3 ft. 7 in. 1 ft. 9 in. 3 ft. 11 in. 0 ft. 8 in. 8 ft. 7 in. 8 ft. 7 in. 5 ft. 11 in. 2 ft. 7 in. 2 ft. 3 in. 6 ft. 6.5 in. 6 ft. 6.5 in. 6 ft. 5.5 in. 3 ft. 4 in. 5 ft. 6.5 in. 4 ft. 7 in.	3 3 3 3 3 3 3 3 3 3 3 3 3 3 3 3 3 3 3	14 14 14 14 14 19 14 14 14 10 12 10 19 19 19	.083 .083 .083 .083 .083 .083 .083 .083	450 490 555 465 725 75 1400 1440 1440 2530 2440 3840 275 710 2600	34 24 21 26 8 41.5 23.5 22 21 23 24 27.5 31 24.5 20 23 31

### OTHER TESTS AND DATA

The present paper was practically completed when a paper appeared by Professor R. T. Stewart, entitled, "Collapsing Pressures of Bessemer Steel Lap-welded Tubes, Three to Ten Inches in Diameter". This paper was read by Professor Stewart before the American Society of Mechanical Engineers at the Chattanooga meeting, May 1 to 4, 1906, and at the present writing is available only in the advance papers of the meeting. It describes a very complete and valuable investigation made at the McKeesport

Works of the National Tube Company on the lap-welded steel tubes of that company, "the Tube Company generously providing every needful facility for carrying on the research in a most thorough manner". Tests on over five hundred tubes are recorded, so that every advantage of averages is gained. Professor Stewart's tests are certain to play an important part in future discussions of tube collapse on account of the completeness and carefulness of the work. The great number of different facts noted will be invaluable to students, although possibly at first confusing to some readers. The method of experimenting is substantially the same as described in this paper, and also the same as was used by Fairbairn. The ends of the tested tubes were not stayed, and much

TABLE VI

DATA ON LAP-WELDED BESSEMER STEEL TUBES—STEWART<sup>1</sup>

Thickness, inches (t)	Diameter, inches $(d)$	$\frac{-t}{d}$	$\left[-\frac{t}{d}\right]^2$	$\left \frac{t}{d}\right ^3$	Collapsing Pressure, Ib. per sq. in.	Source of Data
.194 .354 .279 .250 .186 .167 .327 .212 .175 .112 .165	10.026 8.673 6.987 6.677 6.024 6.028 4.014 4.026 4.014 2.997 10.041	.0193 .0408 .0400 .0374 .0309 .0277 .0815 .0527 .0436 .0374	.000372 .001670 .001600 .001400 .000950 .000768 .006640 .002780 .001900 .001400	.00000718 .00006800 .00006400 .00005240 .00002940 .00002120 .00054000 .00014600 .00008300 .00005240 .0000440	383 2028 2147 1879 1251 928 5560 3170 2280 1860 225	Table No. 37 Table No. 37 Table No. 36 Table No. 36 Table No. 35 Table No. 35 Table No. 34

longer specimens were used, particularly in the first experiments. Most of the experiments were on tubes of larger diameter than ours, Stewart's smaller tubes being indeed the same as our larger tubes. Stewart's experiments are confined to lap-welded tubes, while the tests described in the present paper include also cold drawn seamless steel and brass tubes. The experiments thus supplement each other. Professor Stewart sums up the results of his work as follows: "The principal conclusions to be drawn from the results of the present research may be stated briefly as follows:

(1) The length of tube, between transverse joints tending to hold it to a circular form, has no practical influence upon the

Data taken from a paper read by Professor R. T. Stewart before the American Society of Mechanical Engineers, at Chattanooga, May, 1906. Paper No. 091.

collapsing pressure of a commercial lap-welded steel tube so long as this length is not less than about six diameters of tube.

(2) The formulæ, as based upon the present research, for the collapsing pressure of modern lap-welded Bessemer steel tubes are as follows:

(a) 
$$P = 1,000 \left(1 - \sqrt{1 - 1600 \frac{t^2}{\ell^2}}\right)^2$$

(b) 
$$P = 86,670 \frac{t}{d} - 1386$$

Where P = collapsing pressure, pounds per square inch; d = outside diameter of tube in inches; t = thickness of wall in inches.

Formula (a) is for values of P less than 581 pounds, or for values of  $\frac{t}{d}$  less than 0.023, while formula (b) is for values greater than these.

(3) The apparent fiber stress under which the different tubes failed, varied from about 7000 pounds for the relatively thinnest to 35,000 pounds per square inch for the relatively thickest walls. Since the average yield point of the material was 37,000 and the tensile strength 58,000 pounds per square inch, it would appear that the strength of a tube subjected to a fluid collapsing pressure is not dependent alone upon either the elastic limit or ultimate strength of the material constituting it".

It will, of course, be impossible to make even an abstract of Professor Stewart's voluminous data, but the substantial agreement of our curves of results with his will be shown in the discussion. A considerable amount of experimental work was done by Professor Stewart in reaching his first conclusion, viz., that the law of inverse lengths did not hold for long tubes. As mentioned above, we had reached this conclusion in experiments described and published before the present experiments were begun.

### RATIONAL FORMULÆ

We turn now to the theoretical discussion of tube collapses. The problem involved is one of unstable equilibrium, and as A. E. H. Love, the author of one of our best theoretical treatises on elasticity, says, belongs to one of the most difficult chapters in the theory of elasticity. Within the last eighteen years, three mathematicians of the University of Cambridge, England, have

discussed the problem of collapse, basing the discussion on the general equations of mechanics and elasticity.

Professor G. H. Bryan¹ seems to have been the first to deduce a formula. Mr. A. B. Basset² soon after discussed the subject and proved the same formula in a slightly different form and by other methods. Mr. A. E. H. Love,³ in his elaborate treatise on elasticity, gives Bryan's formula with a new discussion and with some additions. As stated above, these discussions are all based on the general mathematical equations of elasticity, and are too long and complicated to be presented here. The results, however, have been summed up in excellent form by Love. He says: "Combining the results of this and the previous article, we conclude:

(1) That no flue, however long, can collapse unless the pressure exceed

$$\left[\frac{2 E}{1 - \sigma^2}\right] \frac{h^3}{\alpha^3}$$

(2) That when the pressure exceeds this limit, any flue will collapse if its length exceed a certain multiple of the mean proportional between the diameter and the thickness".

In the above formula, E is the coefficient of elasticity; h is one-half of the thickness; a is the radius of the mean section; and  $\sigma$  is Poisson's ratio. So far as known, no use of this formula has been made in experiments or in engineering practice. It has been developed wholly from the general theory of elasticity, and is distinctly limited by the assumptions, to thin tubes, i. e., where "the thickness 2 h is small compared with the mean radius a".

Previous to this work of the three Cambridge mathematicians, we know of only two published attempts to deduce a rational formula for tube collapses, one by Professor W. C. Unwin and the other by Dr. F. Grashof. Professor Unwin was an assistant of Fairbairn in the original experiments, and nearly twenty years later, in 1876, gave a new discussion of these experiments. He says that the formulæ which have been based on Fairbairn's experiments have no relation to ordinary formulæ of applied me-

G. H. Bryan. Application of the Energy Test to the Collapse of a Long Thin Pipe under External Pressure, Proceedings of the Cambridge Philosophical Society. October 29, 1888. Vol. 6.

<sup>&</sup>lt;sup>2</sup>A. B. Basset, On the Difficulties of Constructing a Theory of the Collapse of Boiler Flues, Philosophical Magazine, London, 1892, Vol. 200, pp. 221-233.

A. E. H. Love, Mathematical Theory of Elasticity, Cambridge, 1903, Vol. II, pp. 308-316.

chanics, and notes the advantages if "the collapse of tubes could be expressed by the ordinary laws of the resistance of materials". Unwin then discusses tube collapse on the analogy of this to the failure of long thin columns, and deduces from Euler's formula for columns a similar expression for the collapsing pressures of tubes. After making certain assumptions, he concludes, "The lowest collapsing pressure for long tubes is:

$$P_{\text{min.}} = \frac{8}{3} E \frac{t^3}{d^3}$$

If t is less than 28 t, the collapsing pressure at the limit is:

$$P_{\text{max.}} = \left[ \frac{\pi^2 E}{4704} \right] \frac{t}{d}$$

If t is greater than  $\frac{1}{36}d$ , the formulæ cease to be applicable". The above formulæ are thus proposed only for very thin tubes. Unwin then modified his theory to make it agree with Fairbairn's experiments, and reached as an approximation the formula already quoted on page 5. Like other writers, he did not appreciate the very limited range of Fairbairn's experiments as regards length of tubes. Grashof's attempt to deduce a rational expression for tube collapses was made much earlier, but seems generally to have been overlooked. It is added at the end of his paper on Fairbairn's experiments, in which he gives the empirical formula already noted on page 5. Grashof deduces

$$P = \frac{2k\frac{t}{d}}{1 + \frac{3}{2} \cdot \frac{d}{t}}$$

the formula where P = collapsing pressure: t = thickness of wall; d = diameter of tube; k = yielding strength of the material; and  $a = \frac{a - b}{a}$ , where a is the maximum diameter, and b the minimum diameter of the distorted tube at the instant of failure.

<sup>1</sup> Unwin, Institution of Civil Engineers, 1876, Part IV, p. 232.

<sup>&</sup>lt;sup>2</sup> F. Grashof, Zeitschrift des Vereines deutscher Ingenieure, Vol. III, p. 241,

# CURVES AND FORMULÆ

An inspection of the data of our experiments shows that the portion of a long tube affected by the collapse from hydraulic pressure is generally not longer than twelve times the diameter, and that for greater lengths the collapsing pressure is independent of the length. The law according to which the collapsing pressure varies inversely as the length, is true only for very short tubes, i. e., tubes shorter than a certain "critical minimum length", which in most cases is from four to six times the diameter. We can thus omit further consideration of all formulæ of the Fairbairn type in which the length appears in the denominator.

All considerations show that the collapsing pressure of a tube is a function of t, the thickness of the tube wall, and also of d, the diameter, varying directly as some function of t, and inversely as some function of d. Further, all the theoretical discussions indicate that this collapsing pressure varies as a function of the

ratio  $\frac{t}{d}$ , i. e., that t and d have the same exponents. The simplest method of showing and studying the relation between p, the

collapsing pressure, and the ratio,  $\frac{t}{d}$ , is the graphic one, construct-

ing curves from the experimental data. In Figs. 11, 12 and 13 such curves are drawn. In all these curves, the ordinates represent the values of P, and the abscissas represent the cor-

responding values of  $\frac{t}{d}$ ,  $\frac{t^2}{d^2}$  and  $\frac{t^3}{d^3}$ . Fig. 11 is for drawn brass

tubes, Fig. 12 for cold drawn seamless steel tubes, and Fig. 13 was made by taking the numerical results from Professor Stewart's paper on lap-welded steel tubes and calculating the ratios. While our tables contain results of a large number of tests of lap-welded tubes, these tubes were all thick and also of about the same thickness, so that they gave but few points of a curve. We relied on the cold drawn steel and the brass tubes for the form of the complete curve, as these tubes were more uniform in thickness, diameter, and probably in material also than the lap-welded tubes. The agreement in the general shape of these curves for tubes of different materials and from independent observations is good evidence of the general reliability of the experimental data. An examination of these curves shows the following:




Fig. 11 Curves Showing Relation of Collapsing Pressures of Drawn Brass Tubes to

$$\left[\frac{t}{d}\right], \quad \left[\frac{t}{d}\right]^2 \text{ and } \left[\frac{t}{d}\right]^3$$




Fig. 12 Curves Showing Relation of Collapsing Pressures of Seamless Cold Drawn Steel Tübes to

$$\left( \frac{t}{d} \right)$$
,  $\left( \frac{t}{d} \right)^2$  and  $\left( \frac{t}{d} \right)^3$ 




FIG. 13 CURVES SHOWING RELATION OF COLLAPSING

PRESSURES AND 
$$\left\{\frac{t}{d}\right\}$$
,  $\left\{\frac{t}{d}\right\}^2$  and  $\left\{\frac{t}{d}\right\}^3$  IN

BESSEMER STEEL TUBES, DATA FROM PROF. R. T. STEWART

- (1) For thin tubes, i. e., for values of  $\frac{t}{d}$  below about .025, the formula,  $P = k \left[ \frac{t}{d} \right]^3$ , is very nearly true. This assumes that for this portion of the curve of P and  $\left[ \frac{t}{d} \right]^3$ , the curve is practically a straight line. So far, this is in agreement with the theoretical conclusions of Bryan and Unwin. The limit agrees with the value of  $t = \frac{d}{36}$ , given by Unwin. The values of k are also of the same order as the coefficient of Bryan's formula, although no very close agreement need be expected, as it is difficult to get extremely accurate readings of the small collapsing pressures. The constants have been calculated and the formulæ are as follows:
  - (a) For thin brass tubes:

$$P = 25,150,000 \left[ \frac{t}{d} \right]^3$$

(b) For thin cold drawn seamless steel tubes:

$$P = 50,200,000 \left(\frac{-t}{d}\right)^3$$

All of the lap-welded tubes tested by us were thick tubes. This formula with practically the same numerical coefficient applies to the thin tubes given in Stewart's tables of results.

(2) The curve of P and  $\frac{t}{d}$  is nearly straight for the thick tubes, i. e., for tubes having a value of  $\frac{t}{d}$  greater than about .03. For thinner tubes, the curve bends rapidly toward the axis. The straight part of the curve can evidently be represented by an equation,  $P = k \left[ \frac{t}{d} \right] - c$ , where k and c are constants. We have calculated these constants from our data, and find the following formulæ for tubes having a ratio  $\frac{t}{d}$  greater than .03:

(a) For brass:

$$P = 93,365 \frac{t}{d} - 2474;$$

(b) For seamless cold drawn steel:

$$P = 95,520 \frac{t}{d} - 2090;$$

(c) For lap-welded steel:

$$P = 83,270 \frac{t}{d} - 1025.$$

Professor Stewart found for his lap-welded tubes the formula

$$P = 86,670 \frac{t}{d} - 1386.$$

This formula, as thus stated, is purely empirical, and its lower limit is entirely arbitrary. From a suggestion of Professor A. N. Talbot, department of Theoretical and Applied Mechanics, University of Illinois, attention was called to Grashof's rational formula:

$$P = \frac{2k \frac{t}{d}}{1 + \frac{3}{2} a \frac{d}{t}}$$

as a possible solution. When plotted for P and  $\frac{t}{d}$ , assigning constant values to k and a, this gives a curve suggesting the experimental curves but no possible constant values of k and a satisfy the data. It is probable that a is not a constant, being approximately so for thick tubes, but having quite different values for thin tubes. The formula thus becomes too complicated for use. The above formulæ and their limits are suggestive in showing where the stiffness of the material is the important factor, and where the effect of the strength of the material comes in as the controlling factor. Bryan's formula for thin tubes involves the modulus of elasticity, not the strength of the material. If we suppose that such a formula as Grashof's rational form expresses the facts for thick tubes, the yield point of the material is the factor.

(3) An approximate formula of the form  $P = k \left(\frac{t}{d}\right)^2$  is suggested by the curves of P and  $\left(\frac{t}{d}\right)^2$ , particularly for the steel tubes. For cold drawn seamless steel tubes, this approximate formula is

$$P = 1,000,000 \quad \left[\frac{t}{d}\right]^2.$$

and this can be used for tubes for which  $\frac{t}{d}$  is less than .06. For lap-welded steel tubes, the same formula becomes

$$P = 1,250,000 \left[ \frac{t}{d} \right]^2$$

and this can also be used for values of  $\frac{t}{d}$  less than .06. This approximate formula has been useful to us in getting probable collapsing pressures, and gives satisfactory rough values for tubes of the most common commercial thickness.

In applying any formula to calculate the collapsing pressure of a particular tube, a considerable factor of safety should be used. The constants in all these formulæ are large, and  $\frac{t}{d}$  (or a power of  $\frac{t}{d}$ ) is a comparatively small quantity, so that a small

change in the numerical value of  $\frac{t}{d}$  greatly affects the result.

Lack of uniformity in the material, and slight deformations are also very important factors. It is to the credit of modern manufacturers of tubes that their product is as uniform as these tests show. With the knowledge which this discussion gives of the law of tube collapse, the user of tubes is in a position to calculate with fair approximation the collapsing pressure, particularly if he can get tests made of one or more sample tubes of the material so as to fix the constants.

While the advance in this field of investigation is thus considerable, yet much work remains to be done especially in connecting the subject more closely with the ordinary equations of elasticity.

## BIBLIOGRAPHY ON COLLAPSE OF BOILER TUBES

- Bach, C.—Berechnung der Wandstarke der Flammroehre: in Zeitschrift des Vereines deutscher Ingenieure, October 31, 1891.
- Basset, A. B.—On the Difficulties of Constructing a Theory of the Collapse of Boiler Tubes, in *Philosophical Magazine*, September, 1892.
- Belpaire, Theodore.—Note sur la résistance des tubes pressées de l'extérieur: in *Annales du Genie civil*, March. 1879. Referred to by C. R. Roelker in *Van Nostrand's Magazine*, Vol. 24, p. 215.
- Briggs, Robert.—Editorial comment on article in *Engineering*, Vol. 21, p. 511; also *Journal Franklin Institute*, Vol. LXXII, p. 175.
- Brown and Company, John, Sheffield, England.—Report of Test of Four Cambered Furnaces: *Trade Catalog, Marine Specialties*, Fifth Edition, 1902.
- Bryan, G. H.—Application of the Energy Test to the Collapse of Long Thin Pipe under External Pressure: in *Proceedings Cambridge Philosophical Society*, Vol. VI, 1888.
- Clark, D. K.—Manual of Rules, p. 694, London, 1877. Strength of Furnace Flues; London Engineering, September 21, 1888.
- Clark, S. E.—Vol. I, p. 643. Referred to in Kent's Handbook, Fifth Edition, p. 265.
- Fairbairn, W.—The Resistance of Tubes to Collapse: in *Philosophical Transactions*, Vol. 148, 1858, pp. 389-413.
  - Useful Information for Engineers: Vol. II. p. 175, London, 1867.
  - Report of British Association for Advancement of Science: 1858, p. 174.
  - On the Collapse of Glass Globes and Cylinders: B. A. A. S. Report, 1858, p. 174.
- Fletcher, L. E.—Monthly Reports of the Manchester Steam Users Association. Referred to by D. K. Clark in *Engineering*, September 21, 1888.

- Grashof, F. W.—Fairbairn's Versuche ueber den Widerstand von Roehren gegen Zusammendrueckung: Zeitschrift des Vereines deutscher Ingenieure, Vol. 3, 1859, 234.
  - Theorie der Elasticitat und Festigkeit, p. 328. Referred to by C. R. Roelker in *Van Nostrand's Magazine*, Vol. 24, p. 212.
- Hutton, W. S.—Steam Boiler Construction, p. 179. Fourth Edition, London, 1903.
- Julian and Bataille.—Machines à Vapeur p. 240. Reference by C. R. Roelker, p. 211, Vol. 24, Van Nostrand's Magazine.
- London Engineering. —The Strength of Boiler Flues, Vol. 21, p. 511, June 16, 1876.
- Love, A. E. H.—Mathematical Theory of Elasticity, Vol. 2, p. 315, Cambridge, 1903.
- Love, G. H.—Sur la résistance des conduits intérieurs à funiél dans les chaudières à vapeur: Referred to by Todhunter and Pearson in *History of Theory of Elasticity*, Vol. II, Part I, p. 667, Cambridge, 1893.
- Nystrom, J. W.—A New Treatise on Steam Engineering, p. 106. Referred to in Kent, Fifth Edition, p. 265.
- Roelker, C. R.—Experimental Investigation of the Resistance of Flues to Collapse, Van Nostrand's Magazine, Vol. XXIV, p. 208, March, 1881.
- Seaward, John.—Discussion of Formulæ for the Collapse of Boiler Flues: Journal of Franklin Institute, Vol. XXVI, p. 349.
- Shock, W. H.—Steam Boilers, Their Construction and Management, p. 113, New York, 1880.
- Unwin, W. C.—On the Resistance of Flues to Collapse: Proceedings of the Institute of Civil Engineers, Vol. XLVI, p. 225. The Strength of Boiler Flues: London Engineering, June 9, 1876, Vol. 21, p. 482; also July 7, 1876; also Journal of Franklin Institute, Vol. LXXII, p. 171.
- Wehage, Zur Berechnung der Flammroehre von Dampfkesseln: Dingler's Polytechnisches Journal, pp. 236-243, 1881.
- Wilson, Robert.—The Strength of Boiler Flues: London Engineering, Vol. 21, June 2, 1876.

# Publications Of The Engineering Experiment Station

Bulletin No. 1. Tests of Reinforced Concrete Beams, by A. N. Talbot. 1904.

Circular No. 1. High-Speed Tool Steels, by L. P. Breckenridge. 1905.

Bulletin No. 2. Tests of High-Speed Tool Steels on Cast Iron, by L. P. Breckenridge and Henry B. Dirks. 1905.

Circular No. 2. Drainage of Earth Roads, by Ira O. Baker. 1906.

Bulletin No. 3. The Engineering Experiment Station of the University of Illinois, by L. P. Breckenridge. 1906.

Bulletin No. 4. Tests of Reinforced Concrete Beams, Series of 1905, by A. N. Talbot. 1906.

Bulletin No. 5. Resistance of Tubes to Collapse, by A. P. Carman. 1906.





## UNIVERSITY OF ILLINOIS

# ENGINEERING EXPERIMENT STATION

BULLETIN No. 6

JUNE 1906

#### HOLDING POWER OF RAILROAD SPIKES

BY ROY I. WEBBER, C. E., INSTRUCTOR IN CIVIL ENGINEERING

The determination of a proper fastening between the rail and the tie has become a matter of considerable importance. During the period when the supply of suitable hard wood timber was sufficient, the ordinary spike satisfactorily fulfilled the requirements of traffic; but with the increase in the amount of traffic handled, and the heavier weights of cars and locomotives, and also with the use of soft deciduous and coniferous woods for ties, the common spike has proved deficient. Variations in the form of the ordinary spike have been developed, and new forms of spikes have been devised in an attempt to overcome the loss of efficiency attendant upon the use of inferior timbers.

In view of these conditions, and the meager supply of published data on the holding power of spikes in ties, the writer has carried out a series of experiments to determine the resistance to withdrawal offered by the same type of spike in different timbers and by different forms of spikes in the same timber, and also to determine whether or not the preservative has any influence upon this resistance.


The writer wishes to express his thanks for the hearty cooperation received from the various persons, firms and corporations mentioned in the text. He wishes also to express his indebtedness for personal aid, to Mr. Robert Trimble, Chief Engineer Maintenance of Way, Pennsylvania Lines; Mr. George E.

## ILLINOIS ENGINEERING EXPERIMENT STATION

TABLE I
DESCRIPTION OF THE TIES

No. of Tie	Kind of Timber	Kind of Treatment	Date Treated	Remarks
1	Dlue tels	Zinc-Creosote	1905	Seasoned: sound
$\frac{1}{2}$	Blue Ash Blue Ash	Zinc-Creosote	1905	Seasoned: sound Seasoned: sound
3	Sweet Gum	Zinc-Creosote	1904	Seasoned; sound
4	Water Oak	Zinc-Tannin	1904	Seasoned; sound
5	Water Oak	Zine-Tannin	1904	Seasoned; sound
6	Red Oak	Zine-Tannin Zine-Tannin	1904	Seasoned; sound
7	Red Oak	Zinc-Tanini Zinc-Creosote	1905	Seasoned: sound
8	Red Oak	Zinc-Creosote	1905	Seasoned: sound
9	Red Oak	Zinc-Creosote Zinc-Tannin	1904	Seasoned; sound
10	Rock Elm	Zinc-Creosote	1905	Seasoned: sound
11	Poplar	Zinc-Creosote	1905	Seasoned: sound
12	Elm	231110 01005000		Seasoned; sound
13	Elm			Seasoned; sound
14	Beech			Seasoned: sound
15	Elm			Seasoned: sound
16	Black Oak	Zinc-Creosote	1902	Seasoned
17	Red Oak	Zinc-Creosote	1902	Seasoned
18	Black Oak	Zinc-Creosote	1902	Seasoned
19	Poplar	Zinc-Creosote	1902	Seasoned
20	Loblolly	Zinc-Tannin	1905	Treated Decem-
	Pine			ber, 1905; sound
21	Lob'y Pine	Zinc-Tannin	1905	Treated Dec: '05; sound
22	Red Oak	Zinc-Tannin	1905	Treated Dec: '05: split
23	Black Oak	Zine-Tannin	1905	Treated Dec; '05
24	Black Oak	Zinc-Tannin	1905	Treated Dec; '05
25	Water Oak	Zinc-Tannin	1905	Treated Dec; '05
26	Water Oak	Zinc-Tannin	1905	Treated Dec; '05
27	Black Oak	Zine-Tannin	1905	Treated Dec: '05
28	Red Oak	Zine-Tannin	1905	Treated Dec: '05
29	Water Oak	Zinc-Tannin	1905	Treated Dec; '05
30	Red Oak	Zinc-Tannin	1905	Treated Dec; '05
31	White Oak			Seasoned; in track
32	White Oak		* * * *	two years Indiana Oak: sap wood showed slight decay
33	White Oak			Georgia Oak; seasoned; sound
34	Water Oak	Greosote	1904	Sound
35	Burr Oak	Creosote	1904	Sound
36	Beech	Creosote	1904	Sound
37	Elm	Creosote	1904	Sound
38	Beech			Sound
39	Lob'y Pine			Seasoned; sound
40	Chestnut			Seasoned: sound
41	Red Oak	Creosote	1904	Showed tendency to split
42	Beech			Sound
43	Beech			Sound
44	Beech			Sound

# PLATE I



TESTING MACHINE WITH TIE IN POSITION FOR TEST



Boyd, Roadmaster of the Illinois Central Railroad; Mr. A. L. Kuehn. Superintendent of Maintenance of Way, of the Cleveland, Cincinnati, Chicago and St. Louis Railway; Dr. Octave Chanute, President of the Chicago Tie Preserving Company, Chicago, Illinois; and to Professor Ira O. Baker and Professor C. H. Hurd of the University of Illinois.

THE TIES

The ties used in these experiments were furnished gratuitously as follows: Nos. 1 to 11, and 16 to 30 by the Chicago Tie Preserving Company, Chicago, Illinois; Nos. 12 to 15 by the Illinois Central Railroad Company; Nos. 31 to 41 by the Cleveland, Cincinnati, Chicago and St. Louis Railroad Company. Table I gives a description of the several ties used. The ties were taken either from the stock pile of the railroad companies or from those of the treating plant. No attempt has been made to trace their history farther back than the place of growth and the date of treatment. Treated ties were used in a majority of the experiments, since in the future, as the inferior grades are pressed into service, the tendency will doubtless be toward the use of preserved timber.

#### EXPERIMENTS

Two distinct lines of experiments were undertaken: (1) The determination of the resistance to direct pull of several forms of spikes; and (2) An investigation of the resistance to lateral thrust. Therefore the paper naturally divides itself into two parts: Part I, Resistance to Direct Pull; Part II, Resistance to Lateral Displacement.

All of the experiments were made in the Laboratory of Applied Mechanics, University of Illinois.

## PART I RESISTANCE TO DIRECT PULL

The experiments were made with a Riehle 100,000-pound testing machine. Plate I shows the machine with a tie in position for a test. The pulling device for ordinary spikes, also shown in Plate I, was a Verona spike-puller threaded into a piece of steel gripped between the lower jaws of the machine; the pulling device for the screw spikes was of the same general pattern and was designed especially for these tests. A scale graduated to 1-16 of an inch was so set that the distance moved through the lower head of the machine could be measured directly. A load of 500

pounds was applied to insure the tie's having a good bearing before any records were taken. The machine was geared to move at the rate of 5-8 of an inch per minute, which allowed time for carefully balancing the machine and for taking the readings of the scales. Five observations were usually taken; viz.. when the lower head of the machine had moved through 1-8, 1-1, 1-2 and 3-4 of an inch, and also at the point at which the maximum fiber resistance was developed. No observations were made after the spike had been pulled 3-4 of an inch, as it would have lost its usefulness long before that point had been reached.

Further consideration of this part of the paper will be continued under the following heads: Art. 1, Holding Power of Ordinary Spikes; Art. 2, Holding Power of Screw Spikes without Linings; and Art. 3, Holding Power of Screw Spikes with Helical Linings.

#### ART. 1 HOLDING POWER OF ORDINARY SPIKES

The ordinary spikes were received from the following companies, the numbers in this list being the designations in the subsequent tables: Nos. 1 and 2 from the Pennsylvania Railroad Company; Nos. 3 and 4 from the American Iron and Steel Manufacturing Company, Scranton, Pennsylvania; Nos. 5 to 10 from Dillworth. Porter and Company, Pittsburg, Pennsylvania; No. 11 from the W. A. Zelnicker Supply Company, St. Louis, Missouri, and Nos. 12 to 14 from the Illinois Steel Company, Chicago, Illinois.

The nominal dimensions of the four sizes of spikes are shown in Table II. The actual lengths varied considerably from the nominal lengths, usually being less. This was particularly true concerning the 6-inch spike. The actual cross sections were nearly the same as the nominal, the variation in thickness rarely being over 1-64 of an inch. As the range in thickness of the spikes was only 1-16 of an inch, some experiments were made with plain, square and chisel-pointed bars 1-2, 3-4, and 7-8 of an inch thick to determine the relation between the holding power and the cross section. The spikes had differently shaped points, as shown in Table II. Three spikes were used for each experiment, and these three were always of the same size and lot number.


The spikes were driven by Mr. M. Flood, an experienced track foreman detailed for this purpose by the division engineer of the Cleveland, Cincinnati, Chicago and St. Louis Railway.

TABLE II
. DESCRIPTION OF THE ORDINARY SPIKES

Record	Nominal Length, inches	Section, inches square	Area, square inches	Type of Point	Depth Inserted, inches	Condition of Surface of Spike
1 2 3 4 5 6 7 8 9 10 11 12 13 14	6 5 1-2 5 1-2 5 1-2 6 5 1-2 5 1-2 5 1-2 5 1-2 5 1-2 5 1-2 6	5-8 5-8 5-8 5-8 5-8 19-32 19-32 5-8 9-16 9-16 9-16 9-16 5-8	0.372 0.372 0.372 0.372 0.372 0.352 0.352 0.352 0.316 0.316 0.316 0.316 0.316	Chisel Chisel Blunt Blunt Sharp Chisel Blunt Blunt Sharp Chisel Sharp Chisel Sharp Chisel Chisel	1010101010101010101010101010	Smooth Smooth Smooth Smooth Smooth Smooth Smooth Smooth Smooth Smooth Smooth Smooth


Whole ties were used to insure freedom from splitting in driving the spikes, and care was exercised to avoid driving the spike into knots or cracks. The spikes were driven into the tie to a depth of 5 inches. In some instances, as shown in the record, holes were bored for the ordinary spikes, the hole being 1-16 or 1-8 of an inch less in diameter than the cross sectional dimensions of the spike. The depth of boring was not quite as great as the depth of insertion, so that the pointed end of the spike was forced into the undisturbed wood. Table III gives the detailed numerical results of the tests and Plates II and III show graphically the curves of average resistances of the different ties.

# PLATE II



Curves Showing Resistance to Withdrawal of the Spike from the Tie.

# PLATE III



Curves Showing Resistance to Withdrowal of the Spike from the Tie.

TABLE III DETAILED RECORD OF TESTS OF DIRECT PULL OF ORDINARY SPIKES

				Re		in Poun ull of	ds	Maxi Resis	
Kind of Tie	Tie No.	Spike No.	Test No.	1-8 inch	1-4 inch	1-2 inch	3-4 inch	Pounds	Distance Withdrawn, inches
Blue Ash	1	12	-1 2 3	1800 4040 4270	4460 5060 4340	5220 4510 3860	4450 3990 3370	6840 7260 6330	3-8 3-16 3-16
	•)	6	$\frac{1}{\frac{2}{3}}$	4150 2220 3390 2860	4630 4700 6940 5670	4530 5250 4710 4890	3970 5230 4710 4830	6810 8740 8020 8540	3-16 3-8 5-16 3-8
			Λv.	3000	5770	4890	4830	8640	3-8
Sweet Gum	3	5	1 2 3	2630 3940 5180	1930 4010 3920	2010 3000 4620	2220 2550 4560	4300 5640 5180	3-16 3-16 1-8
	3	14	Av. 1 2 3	3920 2900 3470 3540	3960 4030 4100 3580	2690 3260 2750 3030	2470 2720 2780 2500	5040 5610 5370 4900	3-16 3-16 3-16 3-16
	3	5	$\frac{1}{2}$	3300 3030 2690 5030	3900 5100 5570 3400	3010 2930 4040	2640 2930 3100	5330 5100 5570 5700	3-16 1-4 1-4 3-16
	3	11	$\frac{1}{\frac{2}{3}}$	3580 2110 2780 1680	4370 4030 3190 4100	3440 2340 2320 3730	3420 1680 3340	5440 4030 4810 4980	1-4 1-4 3-16 5-16
	3	3	Av.	2190 2650 3890 2910 3150	3770 6500 4100 6180 	2790 4410 3590 4800 4190	2510 4030 3340 4070 3810	4610 6500 5460 6180 6050	1-4 1-4 3-16 1-4 1-4

TABLE III—Continued

	1	ī	ī	l 5		. 7		1.5	
				R		e in Pour Pull of	nds		imum stance
Kind of Tie	Tie No.	Spike No.	Test No.	1-s inch	1-4 inch	1-2 inch	3-4 inch	Pounds	Distance Withdrawn, inches
Water Oak	4	14	1 2 3	2790 3300 2220	6580 7060 5330	4190 2970 3920	3930 2940 3200	7560 7060 7740	5-16 1-4 5-16
			Av.	2770	6320	3660	3360	7450	5-16
	5	14	$\frac{1}{2}$	2870 1610	6040 4460	4270 5060	3400 4240 	7720 7780	5-16 3-8
			Αv.	2240	5250	4660	3820	7750	3-8
	26	14	$\frac{1}{2}$	$2560 \\ 3440 \\ 3160$	5430 3340	3610 3050 3200	3530 2590 3210	6150 4960 5810	1-4 3-16 3-16
			Av.	3050	4380	3290	3110	5640	3-16
	29	14	1 2 3	1580 1470 2190	3900 3550 4070	3970 3450 2990	3160 3090	6000 5110 4070	5-16 5-16 1-4
			Av.	1740	3840	3470	3130	5060	5-16
	4	4 6	$\frac{1}{2}$	1960 2390 3200	6030 5320 6380	5420 4380	4530 4100	8690 8040 7320	5-16 3-8 5-16
			Av.	2520	5920	4900	4320	8020	5-16
	õ	6	1 2 3	2750 4330 1610	6070 4890 4360	5260 3430 3190	4560 3040 3020	8580 5270 4760	3-8 3-16 1-4
			Av.	2930	5240	3960	3870	6200	1-4
	25	7	$\frac{1}{2}$	$   \begin{array}{r}     3370 \\     1800 \\     2550   \end{array} $	3860 5440 4490	3380 3370 3680	3180 3130 3230	4910 5440 4490	3-16 1-4 1-4
			Av.	2570	4600	3350	3180	4940	1-4
	26	6	1 2 3	3200 2130 3500	5300 5710 5820	4020 4200 4620	3820 3700 4340	5300 5710 5820	1-1 1-1 1-1
			Av.	2940	5610	4280	3950	5610	1-4

TABLE III—Continued

				Re	esistance for P	e in Pour Pull of	nds		mum stance					
Kind of Tie	Tie No.	Spike No.	Test No.	1-s inch	1-4 inch	1-2 inch	3-4 inch	Pounds	Distance Withdrawn, inches					
Water Oak	29	6	1 2 3	2810 4620 3720	4480 3450	3750 4070 2910	3160 3720	4480 4760 3720	1-4 3-16 1-8					
			Av.	3720	3970	3240	3440	4320	3-16					
	4	13	1 2 3	2820 3130 3430	5920 5600 6330	4360 4170 4440	4360 3460 4060	9000 7450 9000	3-8 5-16 3-8					
			Αv.	3160	5980	3320	4260	8380	3-8					
	5	11	1 2 3	3000 3200 3230	6020 8010 5800	3340 4720 3900	2750 5300 3890	6240 9180 6490	5-16 5-16 5-16					
			Av.	3140	6610	3950	3980	7300	5-16					
,	26	11	1 2 3	3080 2270 1990	5090 5420	2650 3360 3610	2270 2940 3000	4240 5090 5420	3-16 1-4 1-4					
			Av.	2450	5260	5210	2770	4920	1-4					
	25 13	13	$\frac{1}{2}$	2440 3440 1840	5100 6680 3710	4230 4000 2830	3640 3980 2540	6450 6680 4550	5-16 1-4 5-16					
			Λv.	3570	5160	3680	3380	5860	5-16					
	34	34 13	34 13	34 13	34 13	34 13	34   13	1 2 3	2340 1700 3360	5620 3730 6560	5770 2830 3600	5080 2260 3010	9070 4970 6560	3-8 5-16 1-4
			Av.	2470	5300	4070	3950	6870	5-16					
	34	14	1 2 3	4090 3090 3180	7000 6780 7280	$\begin{array}{c} 4070 \\ 3550 \\ 4660 \end{array}$	$\begin{array}{c} 4020 \\ 2900 \\ 2870 \end{array}$	8430 6780 8040	5-16 1-4 5-16					
			Av.	3450	7020	4090	3260	7750	5-16					
	34	6	$\frac{1}{2}$	2370 3010 3900	4720 6670 8130	4940 5210 5060	4730 4930 4540	6400 7360 8130	5-16 5-16 1-4					
			Av.	3130	6510	5070	4740	7290	5-16					

TABLE III—Continued

TABLE III—Continued												
				Re	esistance for F	e in Pour Pull of	nds	Max Resis	imum stance			
Kind of Tie	Tie No.	Spike No.	Test No.	1-8 inch	1-4 inch	1-2 inch	3-4 inch	Pounds	Distance Withdrawn, inches			
Black Oak	16	8	1 2 3	3010 3880	6880 7220 8500	5950 4620	4930 4380 3180	9000 9100 8700	3-8 3-8 5-16			
			Av.	3450	7530	5300	4160	8940	3-8			
	16	14	1 2 3	3230 2090	6110 6280 4390	3270 4120 3980	2890 3760 3540	6110 6540 7760	1-4 5-16 3-8			
			Αv.	2660	5590	3790	3390	6810	5-16			
	23	1	1 2 3	2980 3380 1220	6740 7940 2920	3460 4290	3290 3850 4050	8210 7940 9060	5-16 1-4 1-2			
			Av.	2200	5130	3870	3730	8070	3-8			
	27	ā	$\frac{1}{2}$	3430 2870	8070 5910 7570	5300 4500 4200	4740 4170 3850	10000 8970 7070	5-16 5-16 1-4			
			Δv.	3150	7020	4670	4250	8680	5-16			
	27	7 8	$\frac{1}{2}$	3510 2750 2940	8470 7130 6690	3370 2900 4480	3370 2930 2940	8470 8780	1-4 5-16 1-4			
			Δv.	3070	7430	4600	3080	8620	1-4			
	18	11	1 2	2650	5240	3340	2670	7130	5-16			
			3	2660	6190	5040	4440	8250	9-16			
			Δv.	2660	5720	4190	3550	7690	5-16			
	18	10	1 2 3	1700 2120 2250	3410 3900 4000	3330 3170 2830	2570 2900 3090	5860 5660 4000	3-8 3-8 1-4			
			Δv.	2020	3770	3110	2850	4880	3-8			
	16	11	1 2 3	3650 4370 2400	5890 4430 6230	4010 3790 5320	3410 3550 4380	5890 6170 8620	1-4 3-16 5-16			
			Δv.	3470	5520	4370	3780	6890	1-1			

TABLE III--Continued

TABLE IIICommunica											
				Re	esistance for P		nds	Maxi Resis	stance		
Kind of Tie	Tie No.	Spike No.	Test No.	1-8 inch	1-4 inch	1-2 inch	3-4 inch	Pounds	Distance Withdrawn.		
Black Oak	27	11	1 2 3	4900 3780 2730	7070 5740 6550	3890 3670	3140 3260 3440	7070 5740 6550	1-4 1-4 1-4		
			Λv.	3800	6450	3780	3280	6450	1-4		
	24	10	1 2 3	3950 1810 2960	6580 4050 5390	4150 3460 3600	3650 2780 3410	6880 6510 6500	1-4 5-16 5-16		
			$\Delta v$ .	2910	5340	3740	3280	6530	5-16		
	24	4	1 2 3	2330 1880 3450	5070 5570 6500	5820 4320 4300	5710 3740 3800	7740 7010 7360	3-8 5-16 5-16		
			Λv.	2550	5710	4810	4740	7240	5-16		
	23	7	1 2 3	1820 2250 2960	4690 4110 7120	2800 5520 4590	2880 3880 3620	8790 7120	5-16 7-16 1-4		
			Λv.	2340	5760	3930	3120	7700	3-8		
	24	6	1 2 3	$\begin{array}{c} 2520 \\ 1810 \\ 3020 \end{array}$	6110 5710 6480	4040 4160 3980	3490 3490 3710	7070 7070 7360	5-16 5-16 5-16		
			Δv.	2650	6130	4030	3560	7130	5-16		
Red Oak	6	8	$\frac{1}{\frac{2}{3}}$	1870 2320	4750 6750	4410 4150	4190 3760	7190 8300	3-8 5-16		
			Δv.	2050	5750	4280	3980	7750	3-8		
	9	8	$\frac{1}{2}$	2210 2940 3170	5460 6840 6570	4310 3730 3410	4100 3370 3360	7300 7200 6570	5-16 5-16 1-4		
			Αv.	2640	6290	3820	3610	6790	5-16		

TABLE III—Continued

						. D	1	3.5					
	5			Re		in Pour ull of	nas	Resi	imum stance				
Kind of Tie	Tie No.	Spike No.	Test No.	1-8 inch	1-4 inch	1-2 inch	3-4 inch	Pounds	Distance Withdrawn, inches				
Red Oak	7	1	$\frac{1}{2}$	1450 2030	3300 4200	8700 7780	4920 4220	9210 8800	5-8 7-16				
			Av.,	1740	3750	8240	4570	\$()()()	1-2				
	8	8	$\frac{1}{\frac{2}{3}}$	1570 1730 1950	3100 3750 4890	2910 3220 4200	2600 2990 3220	7330 7230 8970	7-16 7-16 7-16				
			Δv.	1680	3910	3440	2920	7840	7-16				
	22	8	1 2 3 4 5 6	2500 2970 3490 2210 3770 2620	3940 2890 3490 4670 3250 5490	2760 2510 2460 2570 2620 3780	2770 2370 2370 2550 2440 3400	5120 4990 5270 4670 5150 5490	3-16 3-16 3-16 1-4 3-16 1-4				
			Av.	2930	3950	2800	2650	5120	3-16				
	41	41 1	1 2 3	2170 3900 1930	4400 3650 4300	4540 2230 2690	3630 2420 2530	7040 6040 5650	5-16 3-16 5-16				
			Av.	2660	4110	3150	2860	6240	1-4				
	17	1	1 2 3	1710 2240 3280	5030 5240 6400	5420 9900 7550	6260 6710 7020	9720 11900 10940	3-8 1-2 7-16				
							Λv.	2410	5560	7620	6660	10850	3-8
	6	12	1 2 3 4	3520 3700 3690 3320	4480  4350	3300 3500 3710 3550	2910 3640 3080 2990	5950 6930 4460 6240	3-16 1-4 3-16 3-16				
			Αv.	3550	4410	3520	3150	5900	3-16				
	6	11	1 2 3	2150 2990 3240	5330 7830 7000	4640 4570 4710	3420 3200 3670	7580 7830 8280	5-16 1-4 5-16				
			Av.	2760	6740	4640	3430	7890	5-16				

TABLE III—Continued

				LADLE	111-	-			
				R		e in Pour Pull of	nds		mum tance
Kind of Tie	Tie No.	Spike No.	Test No.	1-8 inch	l-4 inch	1.2 inch	3-4 inch	Pounds	Distance Withdrawn, inches
Red Oak	7	12	-1 2 3	2430 3430	5010 6110	7120 4930	5630 4300	9080 7020	3-8 5-16
			Δv.	2930	5560	6030	4960	8030	3-8
	9	12	$\frac{1}{2}$	3530 3000 3720	5410 6280 7140	3790 3950 4350	3680 3510 4300	5410 6280 7140	1-4 1-4 1-4
			Δv.	3420	6280	4030	3830	6280	1-4
	9	13	1 2 3	3270 3740 3690	4600 4610	3790 3730 3540	3630 3110 3180	7030 6660 6130	1-4 3-16 3-16
			Δv.	3560	4600	3680	3320	6610	3-16
	17	12	1 2 3			11620* 11230 10630			
			Λv.			11490			
	28	12	1 2 3	3910 3810	7150 5000	3430 4410 4270	3130 3480 3670	6390 7150 6760	1-4 1-4 3-16
			Λv.	3860	6080	4040	3530	6770	1-4
	28	11	1 2 3	6250 2880	4000 6870	5200 3280 3740	3710 2600 3280	8200 6250 6870	5-16 1-8 1-4
			Δv.	4570	5440	4070	3200	7100	1-4
	8	12	1	3030	6800	6080	4950	9420	5-16
			3	2680 3580	6250	6680	4640	9240	3-8
			Av.	3060	6530	6380	4790	9330	5-16

<sup>\*</sup>This was the first tie tested, and gave unusually high results.

TABLE III—Continued

				TADLI	7 111 (	опиниси			
				R	esistance for F	e in Pour Pull of	nds	Max Resis	imum stance
Kind of Tie	Tie No.	Spike No.	Test No.	1-s inch	1-4 inch	1-2 inch	3-4 inch	Pounds	Distance Withdrawn, inches
Red Oak	22	13	1 2 3	2440 2850 1880	5810 5040 4530	3270 2770 3700	3340 2170 3450	5810 5040 6280	1-4 1-4 3-8
			Αv.	2390	5130	3250	2990	5710	1-4
	30	12	1 2	3700 1700	3960 3560	2950 2920	2460 3150	5500 4720	3-16 3-8
			Δv.	2700	3760	2940	3010	5110	1-4
	30	10	1 2 3	1680 2020 2540	3580 4070 4590	3070 2490 3070	$3030 \\ 2480 \\ 2890$	5570 5220 6080	3-8 5-16 3-8
			Αv.	2040	4070	2870	2760	5620	3-8
	41	12	1 2 3	4500 4750 1930	7690 5840	3530 3200 3370	3340 3300 3750	7690 7210 7430	1-4 3-16 5-16
			Λv.	3730	6760	3360	3460	744()	1-4
	41	9	1 2 3	3670 3760 4620	7950 7110 4500	3100 3450 4450	2420 3300 3960	7950 7110 6230	1-4 1-4 3-16
			Δv.	4010	6520	3660	3220	7090	1-1
	28	3	1 2 3			5290 4940 4190	4000 4420 3510	8290 7840 4940	5-16 5-16 1-8
			Δv.			4810	3970	7020	5-16
Burr Oak	35	1	$\frac{1}{2}$	2960 1410 3090	4960 3570 6850	8240 9450 5930	5560 6220 5600	8240 9450 9440	1-2 1-2 3-8
			Δv.	2490	5130	7540	5780	9040	1-2
	35	11	1 2 3	4020 2200 2230	8640 3390 5020	6210 9240 6290	5770 4500 5250	10560 9240 9000	3-16 1-2 3-8
			$ _{\Lambda v}$	2820	5680	7250	5170	9600	3-8

TABLE III--Continued

TABLE III Continued												
Parameter 1				Re	esistance for I	in Pour Pull of	ıds	Maxi Resis	mum tance			
Kind of Tie	Tie No.	Spike No.	Test No.	1-8 inch	1-4 inch	1-2 inch	3-4 inch	Pounds	Distance Withdrawn, inches			
Burr Oak	35	8	1 2	2690 2740	7040 5840	4820 4060	4110 3700	10090 7920	3-8 3-16			
			Δv.	2710	6440	4440	3950	9000	1-4			
White Oak	31	1	$\frac{1}{2}$	3240 2430 3700	7030 5870 7500	3400 4390 4180	3140 3850 3330	7030 7580 7500	1-4 3-8 1-4			
			Λv.	3150	6800	3990	3440	7370	3-16			
	31	14	1 2 3	3960 2250	4020 7100 5580	3600 4000 3650	3280 3750 3200	7830 7100 8980	3-16 1-4 3-8			
			Λv.	3110	5560	3750	3410	7940	3-16			
	33	1	1 2 3	4220 1950 3190	3570 3670 5260	3810 4640 3810	3040 3340 3500	7520 6940 6410	3-16 3-8 5-16			
			Λv.	3120	4160	4090	3290	6990	5-16			
	32	7	1 2 3	$\frac{3860}{3460}$ $\frac{1610}{}$	9440 6400 3740	5930 3710 4670	4650 3680 5570	9440 8650 9360	1-4 5-16 1-2			
			Δv.	2980	6530	4770	4300	9150	3-8			
	33	7	1 2 3	4790 4150 4630	3910 4930 3840	2860 3510 3070	2530 3270 2450	5750 6500 6030	3-16 3-16 3-16			
			Λv.	4520	4230	3150	2750	6090	3-16			
	32	10	1 2 3	2400 3100 2570	3490 4840 6410	8280 5410 10670	3820 3880 4400	8280 10190 10670	1-2 3-8 1-2			
			Αv.	2690	4910	8120	4030	9710	1-2			
	33	10	$\frac{1}{2}$	2930 3080 3890	5490 6360 6810	2390 2860 3540	2330 2460 3360	5490 6360 6810	1-4 1-4 1-1			
			Λv.	3300	6220	2930	2720	6220	1-4			

TABLE III -Continued

1.1DIE III — Continuent											
				Re	esistance for P	in Pour ull of	ids		mum tance		
Kind of Tie	Tie No.	Spike No.	Test No.	1-s inch	1-4 inch	1-2 inch	3-4'inch	Pounds	Distance Withdrawn, inches		
White Oak	32	9	$\frac{1}{2}$	3630 2960 3490	7500 6760 8270	5340 4250 4810	4650 4500 4590	9640 10650 10750	3-8 3-8 5-16		
			Δv.	3360	7510	4800	4430	10350	3-8		
	31	3	$\frac{1}{2}$	4000 4100	7490 8450	5200 3980 5010	4330 3770 4240	8380 7490 8450	3-8 1-4 1-4		
			λr.	4050	7920	4730	4080	8770	3-16		
	33	1	$\frac{1}{2}$	4200 4200 5900	7530 3850	4330 4390 3100	3790 3630 2790	7330 7530 6590	3-16 1-4 3-16		
			Δv.	4830	5690	3940	3410	7150	3-16		
Rock Elm	10	ā	$\frac{1}{2}$	2250 3260 2910	6530 7160 5880	4460 4620 4650	4420 3850 4340	8280 7160 7300	5-16 1-4 3-8		
			Av.	2810	6520	4580	3210	7910	5-16		
	10	2	1	1920	3770	6060	5310	7410	7-16		
			3	1960	4510	4420	4160	7730	3-8		
			Αv.	1940	4140	5240	4730	7570	3-8		
	10	11	1 2 3 4 5	3730 2800 3300 1600	7760 5820 6270 6070 7810	4310 4460 4120 5030 5210	3930 3580 3550 4140 4490	7760 6800 7840 7700 7810	1-4 5-16 5-16 5-16 1-4		
Dod El			Δv.	2800	6950	4620	3340	7600	5-16		
Red Elm	13	14	1 2 3	1240 3000 1760	6500 5970	6430 5080	4380 4960 4040	9230 10040 8810	7-16 7-16 3-8		
			Δv.	2000	6235	5750	4460	9350	5-16		

TABLE III—Continued

TABLE 111—Continued										
				Re	esistance for P	in Pour ull of	nds		mum stance	
Kind of Tie	Tie No.	Spike No.	Test No.	1-8 inch	1-4 inch	1-2 inch	3-4 inch	Pounds	Distance Withdrawn, inches	
Red Elm	13	2	1 2 3	1930 2240 1960	3990 3860 4200	4540 5250 4540	3760 3970 3850	7730 8100 7120	5-16 7-16 3-8	
	13	10	Λv. 1	2040 2810	4020 4930	4770 4850	3890 3510	7650 7550	7-16 3-8	
	10	10	$\frac{2}{3}$	2450 2140	4800 5030	4930 3790	3740 3210	7430 8690	3-8 7-16	
			Λv.	2460	4920	4520	3490	7890	3-8	
White Elm	·12	14	1 2 3	1750 2810 1890	4500 5500 5610	3270 3530 3620	2720 3010 2770	5330 5590 5610	3-8 5-16 1-4	
			Δv.	2150	5200	3470	2830	5510	5-16	
	12	5	1 2 3	2460 2140 1770	5790 5410 5270	3590 2830 2520	2980 2770 2430	6280 5410 5270	5-16 1-4 1-4	
			Δv.	2120	5490	2980	2720	5650	1-4	
	15	5	1 2 3	2630 3810 2810	6330 7260 6100	5580 4680 4160	4310 3620	9500 9560 8050	3-8 3-8 5-16	
			Δv.	3080	6560	4770	4000	9030	3-8	
	37	5	1 2 3	2490 2790	8130 5760 6540	3900 4040 3770	3660 3330 3420	8130 6650 7460	1-4 5-16 5-16	
			Δv.	2640	6810	3910	3470	7410	5-16	
	15	13	1 2 3	1600 2230 1450	4600 5770 4200	5530 9310	5900 4820 6190	9670 8760 9310	7-16 3-8 1-2	
			Λv.	1760	4860	7420	5630	9250	7-16	
	12	10	$\frac{1}{2}$	1990 1920 1830	3560 4320 3930	3350 3540 2360	2700 2690 1650	5370 5450 4100	3-8 3-8 1-4	
			Ā٧.	1910	3970	3080	2010	4970	3-8	

TABLE III -Continued

-				TABLI	3 111 -(	ontinued			
				R		e in Pou Pull of	nds		imum tance
Kind of Tie	Tie No.	Spike No.	Test No.	1-8 inch	1.4 inch	l-9 inch	3-4 inch	Pounds	Distance Withdrawn, inches
White Elm	15	12	1 2 3	2430 2600	5590 5630 5550	4670 3870 3140	3810 3350	7860 6140 5550	3-8 5-16 1-4
			$\Lambda v$ .	2510	5920	3890	3580	(5,52)()	5-16
	37	2	1 2 3	2100 $2920$ $3150$	4710 5160 5900	3390 4070 4300	3330 3840 3860	7170 6310 7570	3-8 5-16 3-8
			Αv.	2390	5290	3920	3680	7()2()	3-8
Beech	14	6	1 2 3	2870 2230	5150 5660	5390 4870 5310	4670 4320 4940	7680 7190 7820	1-4 3-8 5-16
			Αv.	2550	5400	5190	4470	7560	5-16
	36	6	1 2 3	4330 3610 2640	4740 8100 8120	4400 6230 5470	4510 5320 4640	7120 8560 9080	3-8 1-4 5-16
			Δv.	3530	6990	5030	4820	8250	5-16
	14	2	1 2 3	2550 2200 2120	$\begin{array}{r} 4740 \\ 5570 \\ 4910 \end{array}$	4570 $5690$ $4800$	4100 4190 3970	7670 8170 7860	5-16 3-8 3-8
			Δv.	2290	5070	4700	4090	7900	3-8
	36	2	$\frac{1}{2}$	3210 3110 2120	5940 6900 5440	$4010 \\ 4170 \\ 5240$	3840 3900 4130	8460 10400 8270	3-8 3-8 5-16
			Av.	2850	6090	4470	3960	9040	3-8
	14	9	$\frac{1}{2}$	2660 1500 1490	5070 2820 3810	9910 8900	3560 5060 5280	8130 9910 9220	3-8 1-2 7-16
			Λv.	1880	3900	8960	4630	9090	7-16
	36	9	$\frac{1}{2}$	2130 2940 2370	$\frac{4900}{6640}$ $\frac{4920}{4920}$	4240 3860 3830	4210 3650 3600	9890 9430 8900	3-8 5-16 3-8
			Λv.	2480	5490	3980	3820	9410	3-8

TABLE III-Continued

				Re	sistance for P	in Poun all of	ds	Maxi Resis	mum tance
Kind of Tie	Tie No.	Spike No.	Test No.	1-s inch	1-4 inch	1-2 inch	3-4 inch	Pounds	Distance Withdrawn, inches
Poplar	11	2	$\frac{1}{2}$	2700 4690 3000	4690 5100	3980 3240 3240	3520 2890 2900	4690 4980 5100	1-4 3-16 1-4
			Δv.	3460	4890	3490	3100	4920	1-4
	19	2	1 2 3	2750 2710 3100	4510 5270 6050	4400 2840 4080	3980 2610 3650	6990 5270 6050	3-8 1-4 1-4
			Δv.	2850	5240	3760	3410	5900	1-4
	11	12	1 2	2220 2750	5130 4940	2960 3800	2750 3590	5350 5070	5-16 5-16
			Αv.	2480	5040	3280	3170	5210	5-16
	19	12	1 2	2610 2460	5670 6220	4400	4170	6250 7040	5-16 5-16
			Λv.	2530	5990	4400	4170	()(55()	5-16
Chestnut	40	14	$\frac{1}{2}$	2300 2330 3730	3100 2600 3370	2410 2860 2370	2260 2460 2100	4300 4060 5050	3-16 3-16 3-16
			Δv.	2490	3060	2540	227()	4470	3-16
	40	5	$\frac{1}{2}$	3010 3300	2720 3570	2650 2950	2650 2400	5830 5180 5500	3-16 3-16 3-16
			Av.	3150	3150	2800	2520	5510	3-16
	40	12	1 2 3	3320 5110 2000	6230 4000	3050 2490	2270 2430	6230 5110 4000	1-4 1-8 1-4
			Av.	3480	5110	277()	2350	5110	1-4
	40	4	1 2 3	1300 2300 2440	3780 5420 5640	3170 3360 3190	2940 2780 2590	5420 5420 6220	3-16 1-4 5-16
			Av.	2850	4950	3240	2770	5690	1-4

TABLE III—Concluded

				Re	esistance for P	in Pour ull of	nds		imum stance
Kind of Tie	Trie No.	Spike No.	Test No.	. 1-8 inch	1-4 inch	1-2 inch	3-4 inch	Pounds	Distance Withdrawn, inches
Loblolly Pine	39	14	1 2 3	3390 3760 4050	2970 3980 2860	2620 2790 2020	2590 2420 1850	3390 3980 4050	1-8 1-4 1-8
			Αv.	3730	3270	2480	2290	3810	1-8
	21	14	1 2 3	2880 1980 4510	4550 2110 3910	2370 1890 3340	$\begin{array}{c} 1870 \\ 1570 \\ 2880 \end{array}$	4550 3520 5200	1-4 3-16 3-16
			Av.	3120	3520	2560	2110	4420	3-16
	20	5	1 2 3 4	2250 2810 3610 1890	4550 2670 2690	2930 2720 2290	2540 2640  2030	$\begin{array}{c} 4550 \\ 4570 \\ 3610 \\ 3710 \end{array}$	1-4 3-16 1-8 3-16
			Δv.	2640	3270	2650	2410	4110	3-16
	21	10	$\frac{1}{2}$	3570 2550	4450 4890	$\frac{2500}{3400}$	2230 3020	$\frac{4450}{4890}$	1-4 1-4
			Αv.	3060	4670	2950	2630	4670	1-4
	20	3	1 2 3	3090 2610 1870	4800 2330 3810	2730 2300 2510	2320 2030 2280	4800 3440 3810	1-4 3-16 1-4
			Λv.	2860	3650	2510	2210	4020	1-4
	39	6	$\frac{1}{2}$	3110 1560 1630	2120 3880 3330	2170 3060 2640	1710 2380 2650	3110 3880 3330	1-8 1-4 1-4
			Av.	2100	3110	2060	2250	3440	1-4

A study of the results of Table III has been made to determine: (A) Comparative holding power in untreated ties; (B) Comparative holding power in treated ties; (C) Comparative holding power of the same timber, treated and untreated; (D) Effect of preservative on the holding power; (E) Relation between the cross section of the spike and holding power; (F) Relation between the depth of pene-

tration and the holding power; (G) Effect of the point of the spike on the holding power; (H) Effect of bored holes on the holding power; (I) Effect upon the holding power of re-driving the spike.

#### A Comparative Holding Power in Untreated Ties

Table IV is compiled from Table III to show the average holding power for different untreated ties. Each result in Table IV is the average of the corresponding results in Table III.

TABLE IV
AVERAGE HOLDING POWER IN UNTREATED TIES

	sts ikes		Poun	Resistance in Pounds for		imum tance	per e	Resistance in per cent of that		
Kind of Tie	No. of Tests	No. of Spil	a Pe	1-4 inch	Pounds	Distance Pulled, inches	1-8 inch			
White Oak Elm Beech Chestnut Loblolly Pine	10 11 3 4	30 33 9 12 6	3510 2310 2240 2990 2920	3950 5390 3790 4070 3190	7870 7290 8180 5190 3630	5-16 3-8 3-8 3-16 3-16	100 66 64 86 85	100 136 96 103 81	100 93 104 66 46	

Table IV shows the comparative holding power of five kinds of timber. The last three columns show the holding power in terms of that of white oak. It is thought that a pull of 1-4 of an inch gives results which are of more value in comparing the holding power of the different kinds of ties than the results for either greater or less distances, since the results for the 1-4-inch pull represent the resistances of the various timbers to the withdrawal of the spike for a distance which should not be exceeded in practice. and since the maximum resistance and the results for a pull of 1-8 of an inch represent the resistances for distances which are therefore not of so much consequence as the 1-4-inch pull. Notice that with chestnut and loblolly pine the maximum resistance occurs at 3-16 of an inch, which is a reason for comparing their maximum resistance with that of white oak at 1-4 of an inch instead of with its maximum resistance, as in Table IV. If this is done, the efficiencies of chestnut and loblolly pine for a 1-4-inch pull or less are 131 and 85 per cent respectively.

The fact that the maximum resistance did not occur until the spike had been pulled from 3-16 to 3-8 of an inch is interesting. While the spike is being driven the fibers of the wood are bent downward and are pressed outward, and as the spike is withdrawn the friction between the spike and the wood tends to draw the fibers into their original position, which causes them to crowd laterally against the spike and also toward the surface of the tie, until finally the external pull exceeds the internal resistance and the spike slips. When the fiber structure is open, there is considerable cellular space for the displaced fibers to occupy, and therefore the maximum resistance is low, and is quickly attained; but when the fiber structure is compact, the reverse is true.

As the loblolly pine ties should always be preserved, the results in Table IV for this timber are of doubtful value. For the best results elm ties also should be treated; but as some species of elm do not absolutely require treatment, elm is properly included in Table IV. Arranging these timbers in the descending order of their resistances for a 1-4-inch pull, we have elm, chestnut, white oak, beech and loblolly pine.

The maximum holding power for the first three timbers in Table IV is satisfactory, but that for the last two is quite low. The last fact indicates that when timber of the softer varieties or timber having loose fiber structure is used for ties, some more efficient form of fastening should be devised.

## B Comparative Holding Power in Treated Ties

Table V is compiled from Table III to show the average holding power obtained with various treated ties, each result in this table being the mean of the corresponding values in Table III. The average results obtained with untreated white oak are also included so that comparisons can be made.

The average for the resistances for all of the treated timbers is shown at the foot of the table. Excluding the last two timbers, the average resistance for the 1-4-inch pull is 5690 pounds. The maximum resistance of the last two timbers should be averaged with the resistances of the others for the 1-4-inch pull, in which case the average resistance for all of the timbers for a 1-4-inch pull or less is 5400 pounds.

Table V shows that the resistances of the several timbers do not differ widely, and that the soft timbers give results which

 $\label{eq:table_v} {\sf TABLE~V}$  Average Holding Power in Treated Ties

Kind of	Tests	Spikes	Poun	ance in ds for all of	Resis	mum tance	per c	istane ent of Vhite (	that
Tie	No. of	No. of	1-8-inch	1-4 inch	Pounds	Distance Pulled, inches	1-8 inch	1-4 inch	Maxi- num
White Oak (Untreated) Water Oak Black Oak Red Oak Burr Oak Ash Elm Beech Poplar Loblolly Pine Sweet Gum	10 16 13 20 3 2 5 5 3 4 4 4 7 5	30 48 39 60 9 6 15 9 12 12 15	3510 2870 2910 2950 2670 3570 2590 2950 2830 2920 3230	3950 5730 5890 5350 5750 5200 5940 6190 5290 3780 5320	7870 6780 7230 7730 9210 7730 7500 8900 5670 4310 5300	5-16 5-16 5-16 5-16 3-8 5-16 5-16 3-8 5-16 1-4 3-16	100 82 83 84 76 101 74 84 81 83 92	100 145 149 135 145 131 150 157 134 109 96	100 86 92 98 117 98 96 113 72 55 67
Av.			2950	5320	7040		84	135	89

compare favorably with those obtained for the hard woods. This table also shows that the range for the maximum resistances is much greater than that for either the 1-8-or the 1-4-inch pull. The resistances for the different species of oak are very nearly the same, the mean for a 1-8 inch pull being 2850 pounds, for a 1-4-inch pull 5680 pounds and for the maximum 7740 pounds. Notice that with nearly all of the timbers the maximum resistance was obtained after the spike was pulled more than 1-4 of an inch, but there is no apparent relation between the amount of the holding power and the distance through which the spike has been pulled.

Comparing the resistances of treated timbers with that of untreated white oak, we see that the initial resistance of the white oak is higher than any of the other woods except one; while on the other hand, the resistance at 1-4 of an inch in white oak is less than in any of the other woods save one. The maximum resistances of all but the last three timbers are practically the same.

Considering the uniformity of the results obtained with a pull of 1-4 of an inch in the few timbers which were available, there appears to be no strong reason for much discrimination between the different treated timbers.

# C Comparative Holding Power of the Same Timber, Treated and Untreated

Table VI has been compiled from Table III for the purpose of studying the effect of the treatment upon the holding power of a timber.

TABLE VI
RELATIVE HOLDING POWER IN TREATED AND UNTREATED TIES

	sos			Re	Resistance and Gain in Pounds Due to Treatment						
Kind of Tie	No. of Ties	No. of Spikes	Condition of Tie	l-s in. Pull	Gain	1-4 in. Pull	Gain	Maximum Resistance	Gain		
Elm	3 2	27 15	Untreated Treated	2310 2590	280	539°) 5940	550	7290 7500	210		
Beech	1 1	9 9	Untreated Treated	2240 2950	710	3790 6190	2400	8180 8900	820		
Loblolly Pine	$\frac{1}{2}$	6 12	Untreated Treated	2920 2920	000	3190 3730	640	3630 4310	680		
Red Oak	3 4	15 21	Untreated Treated					6460 7730	1270		

Table VI shows that higher resistances are developed in treated than in untreated ties. The average increase due to treatment for a 1-8 inch pull was 330 pounds; for a 1-4 inch pull, excluding the seemingly unreasonable increase in beech, 685 pounds; and for the maximum resistance 747 pounds.

Considerable reliance is placed upon the conclusions drawn from Table VI, inasmuch as the methods of making the tests were exactly the same for the treated and untreated ties, and since the same number of spikes, fifty-seven, was used in both cases, and also since the preserved ties were treated by different processes and at different plants.

The increased resistance due to treatment has two causes: (1) The presence of the preservative in the cells, thus reducing the space into which the fibers can crowd as the spike is withdrawn; and (2) The hardening of the fibers by the steaming, preparatory to treatment, which renders them less pliable.

The movement which took place among the fibers near the surface of the tie is interesting. In the untreated ties there was a crumpling of the fibers close to the spike, while the fibers in the treated ties were torn out in deep slivers extending from the spike to the blocks which supported the tie.

## D Effect of the Preservatives on the Holding Power

Three distinct kinds of preserving solutions were used in the ties tested,—creosote, zinc-creosote and zinc-tannin.

Table VII has been compiled from Table III to study the effect produced by the treating solution upon the holding power of the tie.

Table VII does not show any marked difference between the resistances in ties treated with the different preservative solutions. For example, the maximum resistance of the red oak is lower when treated with zinc-tannin than when treated with zinc-creosote, but the reverse is true of the initial resistance of the red oak and also of the maximum resistance of black oak. With elm the initial resistance is higher in creosoted ties than in those treated with zinc-creosote, but the maximum resistance is lower. If any rating were made in order of efficiency, it would appear about as follows: (1) creosote, (2) zinc-creosote, and (3) zinc-tannin. However, there are too many uncertain quantities involved to make such a rating reliable: and morever, the effect of the treating solution upon the holding power is only one of the many elements which must be considered when choosing between the different treating solutions.

### E Relation between the Cross Section of the Spike and the Holding Power

The question to be answered here is, which size of spike will develop the highest holding power. To answer this question, Table VIII showing the relation between the cross section and the holding power has been compiled from Table III.

From a study of the results of Table VIII it will be noticed that no general rating can be made for the various sized spikes in order of the resistances developed, since the spike which develops the lowest holding power for the 1-8 inch or the 1-4 inch pull seldom develops the highest maximum resistance. For example, in white oak, the 19-32-inch spike developed the highest resistance for the

TABLE VII
EFFECT OF DIFFERENT PRESERVATIVES ON THE HOLDING POWER

Kind of Tie	Tie No.	Preservative	Poun	ance in ds for all of	Maximum Resistance, Pounds
	Comparicon	of Zina Tannin az			
	Comparison	of Zine-Tannin ar	id Creoso	te	
Water Oak	4, 5, 25, 26, 29 34	Zinc-Tannin Creosote	2380 3020	5010 6270	6260 7310
Red Oak	6, 9, 22, 28, 30 41	Zinc-Tannin Creosote	3170 3120	$\frac{5470}{5800}$	6580 6920
	Comparison	of Zinc-Creosote a	and Creos	sote	
Red Oak	7. 8 41	Zinc-Creosote Creosote	2350 3120	4940 5800	8500 6920
Elm	10 37	Zinc-Creosote Creosote	2520 2600	5870 6350	7690 7210
	Comparison	of Zine-Tannin an	d Zinc-Cı	reosote	
Red Oak	6, 7, 8, 9, 22 28, 30	Zinc-Creosote Zinc-Tannin	2350 3170	$\frac{4940}{5470}$	8500 6580
Black Oak	16, 18 23, 24, 27	Zinc-Creosote Zinc-Tannin	2850 2830	5620 5620	7040 7550

1-8-inch pull, but the 9-16-inch spike developed the highest resistance for the 1-4-inch pull, and also the highest maximum resistance. In black oak the highest resistance for the 1-8-inch pull was developed by the 9-16 spike, but that for the 1-4-inch pull was developed by the 19-32-inch size and the maximum resistance by the 5-8-inch spike. Averaging all of the resistances for the 1-8-inch pull, the 1-4-inch pull and the maximum resistance collectively, we see that the average holding power of the 9-16-inch spike is 4990 pounds, for the 19-32-inch spike 5420 pounds and for the 5-8-inch spike 5290 pounds. Because of the large number of spikes tested, seventy-two 9-16-inch, thirty-six 19-32-inch, and one hundred and two 5-8-inch, and the irregularity of the results, it was decided that no conclusions could be drawn from Table VIII as to the relative holding power of the different sizes of spikes. However, the thick-

TABLE VIII

Relation Between the Cross Section of the Spike and its Holding Power

		ses		ike,		ance to wal, Po	
Kind of Tie	No. of Ties	No. of Spikes	Condition of Tie	Size of Spike, inches	s in. Pull	4 in. Pull	Maximum Resistance
		F-4			<u>x</u>		7.II
White Oak	2 2 3	9 6 15	Seasoned	9-16 19-32 5-8	3110 3750 3650	6280 5380 6030	8760 7620 7620
Black Oak	1 2 1	15 6 18	Treated	9-16 19-32 5-8	2910 2650 2550	5340 6130 5710	6530 7130 7240
Water Oak	5 6 5	15 18 15	Treated	9-16 19-32 5-8	2960 2970 2650	5560 5310 5360	6670 6010 6730
Red Oak	7 9	21 36	Treated	9-16 5 8	2300 3260	4760 5990	7650 6780
Beech	1 1 1	3 3 3	Seasoned	9-16 19-32 5-8	1880 2550 2290	3900 5400 5070	9410 7660 7900
	1 1 1	3 3 3	Treated	9-16 + 19-32 5-8	2480 3530 2850	5490 6990 6090	9410 8250 9040
Sweet Gum	1 1	6 12	Treated	9-16 5-8	2190 3490	3770 4450	4610 5460

ness of the spikes varied by only 1-16 of an inch or about 10 per cent, and their areas by only 0.075 of a square inch or about 20 per cent.

To test still further the relationship between the size of the spike and the holding power, a series of experiments was made with plain square rods with the results shown in Table IX. Each result is the mean of fifteen tests in a single kind of timber.

TABLE IX

Experiments with Plain Square Rods in Beech Timber

		=	Increase for each Incremen						
Size of Rod	Area.	age imu ilts, ids	Are	a	Resistance				
	sq. m.	Avera Max Resu pour	square inches	per cent	pounds	per cent			
Success	sive incren	nents in th	e size of th	e rod=	1-8 inch				
1-2 inch square 5-8 inch square 3-4 inch square 7-8 inch square	$\begin{array}{c} 0.250 \\ 0.391 \\ 0.562 \\ 0.765 \end{array}$	6280 6970 9070 9380	0.141 0.171 0.203	53 44 35	690 2600 310	ii 37 3			
Success	sive incren	ents in the	e size of th	e rod =	1-16 inch				
8-16 inch square 9-16 inch square 10-16 inch square	$0.250 \\ 0.316 \\ 0.391$	6280 6450 6970	0.066 0.075	25 23	170 520	 3 8			

It will be seen from the results in Table IX that there is an irregular increase in the holding power as the size of the rod is increased. Notice that with increments of 1-8-inch, the successive increments in the resistance are at first large, but with the last rod this increment suddenly falls to practically nothing. This drop in the increment is principally due to the tendency of the large rod to split the tie. The results with 1-16-inch increments do not differ materially from those in the first part of the table.

The deduction for Table IX is that the holding power will be increased as the size of the rod is increased, but that it is not expedient to use rods (or spikes) larger than 3-4 of an inch unless holes are bored for them.

## F Relation between the Depth of Penetration and Holding Power

A series of experiments was made to determine the relation between the depth of penetration and the holding power. The results are given in Table X.


TABLE X

HOLDING POWER IN A WHITE OAK TIE WITH VARYING DEPTHS OF PENETRATION

	Resistance, Pounds									
Depth of Penetration		1								
	1	2	;}	1	,)	Average				
1-2 in. 1 iu. 1 1-2 iu. 2 in. 2 1-2 in. 3 in. 3 1-2 in. 4 in. 4 1-2 in. 5 in.	150 480 1440 2250 3430 3710 4760 5950 7510 8380	150 1000 2250 3840 3800 5980 7190 7510 9070	140 500 1760 2050 3050 4200 4210 6310 7720 8540	160 510 1320 2900 2940 4220 4500 5850 7340 7790	170 490 950 2760 3570 4810 5860 6080	150 500 1290 2450 3360 4210 5060 6270 7520 8340				

The spikes had a taper point approximately 1 inch long. Plate IV shows that the holding power varies directly with the penetration, not counting the taper point. It is impracticable to use a spike longer than 5 1-2 inches in a 6-inch tie, since a longer spike would either pass entirely through the tie or sliver it on the under side. In either case the fiber adjacent to the spike would quickly decay owing to the access of water. In a thicker tie, however, a longer spike could be used advantageously. The main precaution is to keep the spike from damaging the under surface of the tie, otherwise the longer the spike the greater the holding power.

# PLATE IV



Curve Illustrating Resistance to Withdrawal for Various Depths of Penetration.

#### G Effect of the Point of the Spike on the Holding Power

There were three distinct types of points on the spikes,-blunt-point, chisel-point and bevel-point.





Fig. 1 Forms of Points of Spikes

The average results obtained with spikes having these types of points have been compiled from Table III, and are shown in Table XI. The average and relative resistances of each type of spike for all timbers are shown at the foot of the table. These averages show that both the blunt-pointed and the bevel-pointed spike are higher in holding power than the chisel-pointed spike. Since the average resistances of the blunt and the bevel-pointed spikes are practically the same, and since the blunt-pointed spike develops the highest resistance for the I-8-inch and the I-4-inch pull the greatest number of times, the blunt-pointed spike is first in point of efficiency, although the bevel-pointed spike is a close competitor under all conditions. The chisel-pointed spike is last.

The two upper figures of Plate V are the two halves of a redoak tie showing the position of the fibers adjacent to the spike; and the lower figure is a portion of the other end of the same tie split after the spikes had been pulled out. The photograph was taken immediately after the tie had been split. The figures are too small to show details clearly, but an examination of the tie showed that the blunt-pointed spike disturbed more fiber than either the chisel or the bevel-pointed spikes, the last two disturbing about the same amount. The examination also showed that the blunt-pointed spike tore rather than cut the fibers, and deposited them in unequal bundles along its faces, while the chisel-pointed spike cut the fibers and deposited them quite uniformly both across and

# PLATE V



EFFECT OF SPIKES IN DISPLACING THE FIBERS OF THE TIE



TABLE X1

EFFECT OF THE FORM OF THE POINT OF THE SPIKE ON THE HOLDING POWER

	ses		Resist	ance i	n Pounds	for	Maxim	num
Kind of Tie	of Spikes	Type of Point	1-8 in. 1	Pull	1-4 in. I	Pull	Resist	ance
	No. c	,	Pounds	Rela- tive	Pounds	Rela- tive	Pounds	Rela- tive
Water Oak	33 15	Chisel Bevel	2780 3050	100 110	5520 5440	100 98	6540 6330	100 97
Black Oak	9 18 12	Blunt Chisel Bevel	3020 2850 2680	106 100 91	6890 5690 5560	121 100 98	8280 6930 6800	119 100 98
Red Oak	18 21 21	Blunt Chisel Bevel	2220 2880 3100	77 100 107	4400 5350 5580	82 100 104	5760 7630 7370	76 100 97
White Oak	10 12 6	Blunt Chisel Bevel	4080 3490 2990	117 100 86	7040 5190 5610	135 100 108	8760 7090 8010	123 100 113
Elm	21 21	Chisel Bevel	2150 2500	100 116	5240 5740	100 109	7710 7050	100 92
Beech	6 6 6	Blunt Chisel Bevel	$\begin{array}{c} 2180 \\ 2570 \\ 3040 \end{array}$	85 100 118	$\begin{array}{c c} 4670 \\ 5580 \\ 6190 \end{array}$	84 100 111	9250 8470 7900	109 100 93
Chestnut	3 3 6	Blunt Chisel Bevel	2850 2490 3320	114 100 133	4950 3060 4130	162 100 135	5690 4470 5310	127 100 119
Loblolly Pine	3 6 9	Blunt Chisel Bevel	2860 3420 2800	84 100 82	3650 3390 5010	118 100 148	4020 4120 5520	97 100 134
Average for all		Blunt	2870 2840	101 100	5340 4810	112 100	6960 6610	105 100
Timbers		Bevel	2930	100	5490	114	6800	103

in front of each face. The bevel-pointed spike forced a majority of the fibers to the front face and toward the corners. The relatively high holding power of both the blunt and the bevel-pointed spikes is due to this unequal concentration of the fibers.

### H Effect of Bored Holes on the Holding Power

A series of tests was made to study the effect of boring holes for the spike. The first step was to determine the proper size of the hole. Table XII shows the summary of a series of tests made at the University of Illinois in 1891\* to determine the relationship between the holding power and the "drift".

TABLE XII

RESULTS OF EXPERIMENTS WITH SQUARE DRIFT-BOLTS IN PINE TIMBER

	Size of	Drift.	Holding Power, Pounds		
Size of Drift-Bolt	Hole. inches	inches	6-inch depth	Per inch depth	
1 inch square 1 inch square 1 inch square 1 inch square	16-16 15-16 14-16 13-16	1-16 1-8 3-16	3972 4260 4660 4050	662 710 777 675	

This table shows that with 1-inch square drift-bolts a drift of 1-8 of an inch gives a maximum holding power, but that a drift of 1-16 of an inch gives nearly as much resistance. It is not known that this relation holds with bolts less than 1-inch square, but the author assumed that this was sufficient reason for using a drift of 1-16 and 1-8 of an inch in this investigation, which conclusion is in accord with the usual railroad practice.

The second step was to determine the resistance to the different sized spikes in different kinds of ties. The detailed results for these experiments are given in Table XIII. Notice that the results are arranged according to the drift. The average results from Table XIII are shown in Table XIV along with the results from Table III for the same spike driven in the ordinary way.

The average resistances for all timbers, recorded at the foot of Table XIV, show that for a pull of 1-4 of an inch or less the spike driven into a bored hole develops higher holding power than one driven in the ordinary way. For a 1-4-inch pull or less the relative resistances show a marked increase in a majority of cases, but the maximum resistance for spikes driven into bored holes is usually the lowest.

<sup>\*</sup> Technograph No. 5, 1891, University of Illinois

TABLE XIII HOLDING POWER OF ORDINARY SPIKES IN BORED HOLES

		Hole,	Re	sistance for P		ds		mum tance
Kind of Tie	Size of Spike, in. sq.	Diameter of Hole, inches	1-8 inch	1-4 inch	1-2 inch	3-4 inch	Pounds	Pull, inches
			Hole 1-1	6 in. Sm	aller the	an Spike		
Water Oak	9-16	1-2	2330 2050 2020 1660 2500 3250 2390	3860 3860 6470 4450 6400 3750 4890	3660 3970 4740 4090 4120 3440 3930	3180 3320 4010 3890 3600 3120 3080	5740 5730 6750 6460 6400 4940 6740	5-16 3-8 5-16 5-16 1-4 3-16 5-16
		Αv.	2310	4810	3990	3410	6110	
Black Oak	9-16	1-2	3460 3000 4590 2670 2910 2260	6770 7120 6810 6350 6710 6720	3570 3810 3550 3850 3890 3810	2850 3360 3350 3560 2970 3270	7190 8190 6810 6350 6710 8630	5-16 5-16 1-4 1-4 1-4 1-2
		Av.	3150	6750	7310	3660	3230	
Red Oak	9-16	1-2	3970 3920 2180 2830 2660 2870 2900 3950 2700 2680	6550 6930 5920 6900 4310 5710 6100 6680 7430 7410	3500 3250 4590 3770 3440 4090 3380 4690 3410 3950	3140 3720 3900 3320 2720 3410 3100 4040 3420 3420	6830 6930 6990 6900 5320 5710 6100 6680 7480 7410	5-16 1-4 5-16 1-4 5-16 1-4 1-4 1-4 1-4 1-4
	5-8	9-16	3000	5380	3610	OTail	5380	1-4
			3300 3130 2710 2600 2850 3130	5010 6240 6530 5460 5810 6800	3360 3540 4070 5160 4860 6080	3510 3600 4170 4400 4950	5010 6240 7040 6990 8800 9420	1-4 1-4 5-16 5-16 5-16
		Av.	2950	5890	4390	4140	6960	J

TABLE XIII—Continued

	6	Hole,	Re	esistance for P	in Pour ull of	nds	Maxii Resis	
Kind of Tie	Size of Spike, in. sq.	Diameter of Hole, inches	1-8 inch	1-4 inch	1-2 inch	3-4 inch	Pounds	Pull, inches
Ash	9-16	1-2	4080 2510 1980 2850 2530	7210 6540 4850 5840 5760	4720 3360 4380 3220 3510	3300 3180 4050 2290 2730	8180 8380 8830 6180 5760	5-16 5-16 7-16 5-16 1-4
		Av.	2790	6040	3840	3090	7460	
	5-8	9-16	3920 2840 1660 2100	4700 6300 5100 6340	3860 4070 5300 5150	3280 3600 4370 4540	6460 6480 8510 8760	3-16 5-16 5-16 5-16
		Av.	2630	5610	4590	3950	7550	
Beech	9-16	1-2	2960 2910 2890 2830 3360 3770 2870 3540	6820 5710 5610 2900 5450 6610 6780 6930 5110	3820 4010 3240 2800 2940 3680 3470 4740 5060	3790 3550 2850 2690 2620 3210 2890 4360 4010	7100 7270 5610 6000 5450 6610 8200 6930 7640	3-16 5-16 1-4 3-16 1-4 1-4 3-8 1-4 3-8
		Δv.	3150	5770	3750	3330	6750	
Sweet Gum	9-16	1-2	2850 2530 2250 2630 2790 2610	5840 5760 6210 3940 5220 6300	3220 3510 4640 3350 4220 3900	2290 2730 3570 2870 3680 3370	6180 5760 7170 4940 6010 6300	5-16 1-4 5-16 3-16 3-16 1-4
		Δv.	2610	5550	3810	3080	6060	
	5-8	9-16	3030 2620 2850	3080 5760 3840	2740 3560 3290	2320 2940 2730	4370 5760 5500	3-16 1-4 3-16
		lAv.	2830	4230	3200	2660	5210	

TABLE XIII—Concluded

	,	Hole,	Re		in Pour ull of	ıds	Maxi Resis	
Kind of Tie	Size of Spike, in. sq.	Diameter of Hole, inches	1-s inch	. 1-4 inch	1-2 inch	3-4 inch	Pounds	Pull, inches
			Hole 1-	8 in. Sm	aller tha	n Spike		
Red Oak	5-8	1-2	1800 2340 2630 3170 4070 4720	5710 6860 5850 4410 3000 4220	$\begin{array}{c} 5000 \\ 4490 \\ 4010 \\ 2570 \\ 2600 \\ 2550 \end{array}$	4190 3950 3440 2100 2190 2500	7270 6860 5850 4410 4410 6030	5-16 1-4 1-4 1-4 3-16 3-16
		Av.	3270	5010	3540	3060	5800	
Beech	9-16	7-16	1340 2540 4000 3560 3580 3240 2510 2290 2790 1900	4560 5620 4720 7280 5270 6900 6150 4620 6380 3790	3530 4720 3000 3800 3800 4020 3710 5410 4630 5010	3620 4100 2640 3360 3250 3810 3630 4150 3420 4360	7080 6920 6000 7280 6940 7830 6150 7950 8230 7660	3-8 5-16 3-16 1-4 3-16 5-16 1-4 7-16 5-16 7-16
		Av.	2180	5530	4160	3630	7200	
Sweet Gum	5-8	1-2	2400 2850 2950	3180 3700	2710 2920 3300	2320 2540 2240	3980 4750 5200	3-16 3-16 3-16
		Av.	2730	3430	2980	2370	4640	

TABLE XIV AVERAGE RESISTANCE OF SPIKES WITH AND WITHOUT BORED HOLES

	in. sq.	SC			sistance ounds f			Relati esista	
Kind of Tie	Size of Spike, in. sq.	No. of Spikes	How Driven	1-8 in. Pull	1-4 in. Pull	Maximum Resistance	1-8 in. Pull	1-4 in. Pull	Maximum Resistance
			Drift	1-16 of	f an in	ch			
Water Oak	9-16	7 15	Hole No Hole	2310 2960	4810 5660	6110 6670	78 100	85 100	92 100
Black Oak	9-16	6 15	Hole No Hole	3300 2970	6750 5320	7310 6490	110 100	122 100	113 100
Red Oak	9-16	10 36	Hole No Hole	3070 3260	6390 5450	6640 6820	111 100	112 100	97 100
	5-8	21 21	Hole No Hole	$\frac{2950}{2310}$	5890 4760	6960 7660	127 100	123 100	91 100
Beech	9-16	9	llole No llole	3150 2180	5770 4700	6760 9410	145 100	123 100	72 100
Ash	9-16	5 6	Hole No Hole	2790 4150	6040 4630	7460 6810	67 100	130 100	110 100
Sweet Gum	9-16	6	Hole No Hole	2610 2190	5550 3730	6060 4610	119 100	149 100	131 100
	5-8	$\frac{4}{9}$	Hole No Hole	2830 3460	4230 4450	5210 5460	82 100	95 100	96 100
Av. for all Timbers			Hole No Hole	2930 2880	5680 4840*	6570 6740	102 100	117 100	98 100
			Drift	1-8 of	an inc	:h			
Red Oak	5-8	6 21	llole No Hole	3270 2310	5010 4760	5800 7660	141 100	105 100	75 100
Beech	9-16	10	Hole No Hole	2780 2180	5530 4700	7200 9410	122 100	118 100	77 100
Sweet Gum	5-8	3 9	Hole No Hole	2730 3460	34-30 4450	4640 5460	79 100	77 100	85 100
Av. for all Timbers			Hole No Hole	2930 2650	4660 4640	6550 7510	111 100	100	87 100

As far as conclusions can be drawn from these experiments, the spike driven into a bored hole is superior to one driven in the ordinary way.

### I Effect upon the Holding Power of Re-driving the Spike

In practice, when the spike is pulled out of the tie a moderate distance, it is driven back, provided the hole is not greatly enlarged. If the hole is much enlarged the spike is driven at another point. This constant re-spiking rapidly ruins the tie. A series of tests was made to determine the effect upon the holding power of re-driving the spike. The average maximum holding power of the re-driven spikes is shown in Table XV along with the original maximum holding power of the same spike.

It will be seen that the holding power of the re-driven spike is very much less than that of the newly-driven spike. The resistance is affected so much in some woods as to make the practice of

 ${\it TABLE~XV}$  Relative Holding Power of Newly-driven and Re-driven Spikes

Kind of	of		aximum Re- e, Pounds	Per cent of
Tie	No. of Spikes	Original	After Re- driving	Original
Ash	6	8640	6490	75
Water Oak	6	8020	5760	72
Red Oak	6	8030	5230	65
Elm	6	7910	4840	61
Poplar	6	4920	3980	81
Sweet Gum	- 6	5040	4150	82

re-driving the spike a questionable procedure if the holding power alone is considered; but as the practice of re-driving the spike helps to lengthen the life of the tie, the practice can not be justly condemned so long as the holding power is not excessively reduced.

### ART. 2 HOLDING POWER OF SCREW SPIKES WITHOUT LININGS

A series of tests was made to determine the holding power of screw spikes. The tests were conducted in the same manner as those with the ordinary spikes.

The screw spikes were received from the following companies: No. 1 from the Illinois Central Railroad Company; No. 2 from the American Iron and Steel Manufacturing Company, Scranton, Pennsylvania; No. 3 from the South Side Elevated Railroad Company, Chicago. Illinois; No. 4 from the Oliver Steel and Iron Company, Pittsburg, Pennsylvania; and No. 5 from the Pennsylvania Railroad Company.

A description of the different spikes is given in Table XVI.

TABLE XVI
DESCRIPTION OF SCREW SPIKES

Spike No.	Length, inches	Diameter of Core, inches	Projection of Thread, inches	Pitch, inches	Depth of Insertion, inches	Diameter of Bored Hole, inches
1 2 3 4 5	5 5 5 1-4 5 1-2 5	21-32 11-16 11-16 11-16 21-32	3-16 1-8 1-8 1-8 1-8 3-16	1-2 1-2 1-2 1-2 1-2	4 1-2 4 1-2 4 3-4 5 4 1-2	11-16 11-16 11-16 11-16 11-16

The shank or threaded portion of the spike was usually 7-8 of an inch in diameter, and approximately one inch of the upper portion of the core tapered from the diameter of the core to that of the shank. The hole bored for the spike was not reamed, and the result was a tight fit between the wood and the spike. This tight contact is gained in practice by the head of the spike bearing against the base of the rail. The spike was driven by means of a wrench, the thread cutting its own path. The number of screw spikes obtainable was not sufficient to make as long a series of tests as with the ordinary spikes.

A study of the results with this spike has been made to determine: (A) Relation between the depth of penetration and the holding power; (B) Relation between the holding power of the screw and of the ordinary spikes; and (C) Influence of certain details of the screw spike upon its holding power.

The detailed results of the tests with screw spikes are given in Table XVII, and the average results are shown in Plates II and III.

TABLE XVII DETAILED RECORD OF TESTS WITH SCREW SPIKES

	-	ike	st	1	Resistanc a	e in Po Pull o		or		imum stance
Kind of Tie	No. of Tie	No. of Spike	No. of Test	1-8 inch	L-4 inch	1-2 inch	3-4 inch	1 inch	Pounds	Distance Pulled, inches
Blue Ash	2	2	$\frac{1}{2}$	7350° 5080 7520	10900 9930 11650	11650 13470 12300	6270 6010 6220	3370 3190 3030	13360 13470 12300	7-16 1-2 1-2
			Δv.	6650	10830	12470	6160	3190	13040	1-2
	1	4	$\frac{1}{2}$	3320 3740 4350	7480 7570 9200	10840 9410 6800	6520 5940 4870	5000 4560 3260	10840 9410 9700	1-2 1-2 3-8
			Δv.	3800	8080	9010	5780	3940	9980	1-2
Sweet Gum	3	2	1 2 3	3810 5790 4270	4940 7100 6030	4870 4900 4620	2420 3280 2820	1900 3770 3450	5980 7100 6590	7-16 1-4 3-8
			Δv.	4620	6060	4790	2840	3040	6560	3-8
	3	4	$\frac{1}{2}$	5920 4550 4780	9000 7400 7120	6000 5600 5090	4000 3410 3290	$2900 \\ 2300 \\ 1800$	9720 8100 7870	7-16 3-8 3-8
			Av.	5080	7840	5560	3560	2330	8560	3-8
Water Oak	34	3	$\frac{1}{2}$	$\frac{4820}{4670}$ $\frac{4680}{4680}$	10230 9170 7030	$\begin{array}{c} 14530 \\ 12140 \\ 14360 \end{array}$	9630 10000 9660	4600 6260 4490	14530 12640 14360	1-2 5-8 1-2
			Av.	4720	8810	13680	9800	5100	13840	7-16
	26	2	$\frac{1}{2}$	$\frac{4110}{3670}$ $\frac{5270}{}$	8010 - 7420 - 7790	7190 7850 5190	3490 3970 3540	$\begin{array}{c} 2150 \\ 2790 \\ 2600 \end{array}$	9620 8900 8060	7-16 3-8 7-16
			$\overline{Av}$ .	4350	8290	6740	3660	2510	8860	7-16
Black Oak	16	3	1 2 3	5520 4860 4260	12370 11410 9870	16930 13100 9760	10720 7390 7690	6200 4050 3970	$\begin{array}{c} 16930 \\ 14350 \\ 12160 \end{array}$	1-2 7-16 3-8
			Αv.	4880	11220	13260	8600	4740	14480	7-16
	23	2	$\begin{bmatrix} 1\\2\\3 \end{bmatrix}$	5850 4910 1090	$\begin{array}{c} 10290 \\ 10780 \\ 6370 \end{array}$	9460 8590 10400	6600 6000 7100	$\begin{array}{c} 4200 \\ 2500 \\ 6000 \end{array}$	$\begin{array}{c} 12500 \\ 12570 \\ 10400 \end{array}$	3-8 5-8 1-2
			Av.	3950	9150	9380	6560	4230	11820	5-8

TABLE XVII—Continued

	۵	ike	st	R		e in Pou Pull of	nds fo	r	Maxi Resis	mum tance
Kind of Tie	No. of Tie	No. of Spike	No. of Test	1-8 inch	1-4 inch	1-2 inch	3-4 inch	1 inch	Pounds	Distance Pulled, inches
Red Oak	9	4	$\frac{1}{2}$	2720 6390 4240	7810 11440 9770	12720 11590 11130	7970 7050 9160	3710 3600 4970	12720 12770 11790	1-2 3-8 3-8
			Av.	4450	9670	11810	8060	4130	12430	3-8
	7	4	1 2 3	3940 7890 4220	9780 13860 9780	12780 14430 14800	9560 7990 12350	4880 4530 6500	13590 15200 14800	7-16 3-8 1-2
			Αv.	5350	11140	12670	9960	6300	14860	7-16
Beech	36	2	$\frac{1}{2}$	2610 8320 5190	8400 12370 11880	8320 10820 11270	4170 6130 6880		14560 13180 14310	5-16 3-8 3-8
			Av.	5040	10850	10140	5730		14020	3-8
•	14	3	$\frac{1}{2}$	6330 6130 8240	11980 12980 15620	10240 17360 14700	4480 9930 8900	3230 3900 5890	14550 17360 16450	7-16 1-2 7-16
			Δv.	6900	13530	14000	7770	4340	16120	7-16
White Oak	31	4	$\frac{1}{2}$	3010 7950 8210	9340 12490 12080	8180 9390 7560	639 <u>0</u> 5350 4950	4530 2880 3290	11630 13200 12740	7-16 5-16 5-16
			Δv.	6390	11300	8380	5230	3570	12520	5-16
	31	3	$\frac{1}{2}$	5000 4600 5880	8290 8030 9370	5450 6600	2960 3340		8290 8700 10530	1-4 5-16 3-8
			Av.	5160	8560	5530	3150		9150	5-16
	32	3	1 2 3	6420 8590 4420	11300 14190 13000	16450 11370 Broke	9590 5490	4360 3190	16450 15580 13000	1-2 5-16 1-4
			Λv.	6480	12830	13910	7040	3780	15010	3-8
Elm	10	3	$\frac{1}{2}$	4310 5040 4200	8290 10920 9130	14190 13200 13230	6340 7950 7350	2780 3100 3460	14190 14400 13230	1-2 7-16 1-2
			Av.	4520	9450	13540	7210	3110	13940	1-2

TABLE XVII—Concluded

				177 131	IE AVI	1—Conct	шиен			
	(a)	ike	st	I	Resistanc a	ce in Pou Pull of	ands fo	r		mum tance
Kind of Tie	No. of Tie	No. of Spike	No. of Test	1-8 inch	1-4 inch	1-2 inch	3-4 inch	l inch	Pounds	Distance Pulled, inches
	13	1	$\begin{bmatrix} 1\\2\\3 \end{bmatrix}$	6090 5220 4570	11560 10400 9890	9920 11440 12400	4400 6450 7990	2420 3200 4000	11560 12740 14390	1-4 7-16 7-16
	12	4	$\Lambda v$ .	5290 6830	10280 11280	11250 10080	6260 5280	3200 2340	12890 12840	7-16 3-8
			$\frac{2}{3}$	$\frac{3270}{3700}$ ${4570}$	8650 7840 9260	$ \begin{array}{r} 9570 \\ 12480 \\ \hline 10680 \end{array} $	$ \begin{array}{r} 6350 \\ 7110 \\ \hline 6250 \end{array} $	3450 3360  3050	$ \begin{array}{r} 11610 \\ 12480 \\ \hline 12310 \end{array} $	7-16 1-2 7-16
Poplar	11	1	1 2 3	4130 2960 4760	7980 6200 7970	8000 8910 10130	4790 4820 7210	3300 2130 4480	10120 9610 10130	7-16 7-16 1-2
			Av.	3950	7380	9010	5610	3270	9960	7-16
	11	1	1 2 3	3450 3300 2640	6300 6550 5260	9340 8490 8060	5250 3860 2710	2940 1620 1520	9340 8490 8060	1-2 1-2 1-2
			Αv.	3130	6040	8290	3940	2030	8290	1-2
Chestnut	40	4	$\frac{1}{2}$	5200 2750 3240	6950 6210 6260	6400 8250 6160	3340 3800 4580		7610 8250 7290	3-8 1-2 5-16
			Δv.	3730	6480	6940	3910		7720	3-8
	40	1	$\frac{1}{2}$ 3	3070 3960 3940	5460 3270 5630	5680 5310 5580	. 3570 2820 2510	1930 1140 1400	7010 6470 6300	7-16 7-16 7-16
_			Δv.	3660	5450	5520	2960	1490	6590	7-16
Loblolly Pine	20	1	$\frac{1}{2}$	5260 3840 4830	7610 6270 7780	5510 6210 7360	2670 3630 3060	1460 2120 2390	9340 7550 8190	3-8 7-16 3-8
			Av.	4640	7270	6390	3120	2320	8690	3-8
	39	1	$\frac{1}{2}$	6180 5350	10220 8260	7590 9060 8200	$   \begin{array}{r}     4070 \\     5060 \\     5520   \end{array} $	1720 2460 3400	11840 11190 9850	3-8 3-8 7-16
			Av.	5820	9240	8280	4880	2530	10630	3-8

### A Relation between Depth of Penetration and the Holding Power

A series of tests was made to determine the relation between the depth of penetration and the holding power of the screw spikes. The experiments consisted of pulling spikes driven to depths of 1, 2, 3, 4 and 5 inches into a beech tie, three spikes being used for each depth. The numerical results are shown in Table XVIII, and their averages are shown graphically in Plate VI together with some additional matter which is shown for the sake of comparison.

TABLE XVIII
RESULTS OBTAINED FROM EXPERIMENTS ON DEPTH OF PENETRATION

Test	I	Resistance in	Pounds for a	Penetration	of
Number	1 inch	2 inches	3 inches	4 inches	5 inches
$\frac{1}{2}$	-2770 2760 2790	4560 6000 4940	9610 10000 8490	13100 14330 13330	17360 17500 16840
Av.	2770	5170	9360	13590	17230


The results in Plate VI can be quite closely represented by two intersecting straight lines. The probabilities are that the actual resistances would be more nearly represented if the two straight lines were joined by a short curve near their intersection. Only the upper portion of the diagram is of interest, since penetrations of less than four inches should never be used, at least on heavy traffic railroads, the only roads likely to use screw spikes.

The diagram shows that the resistance varies directly with the depth of penetration.

### B Relative Holding Power of Screw Spikes and Ordinary Spikes

Table XIX has been prepared from Table XVII and from Table III, to determine the relation between the holding power of the screw spike and that of the ordinary spike. As previously stated, the ordinary spikes were driven into the tie to a uniform depth of 5 inches, while the screw spikes, being of different lengths, necessarily were inserted to unequal depths. On account of the relation existing between the depth of penetration and the holding power, the resistance for the screw spikes, shown in Table XIX, is based upon a penetration of 5 inches.

### PLATE VI



From Table XIX it will be seen that the holding power of the screw spike is always greater than that of the ordinary spike, and that the relation between the two varies in the several timbers. For a pull of 1-4 of an inch in the hard woods the holding power of the screw spike is from 167 to 221 per cent of that of the ordinary spike, and in the soft woods the range is from 117 to 258 per cent; or the average gain in the hard woods is 76 per cent, and in the soft woods 98 per cent. It is interesting to note that the resistances in the several timbers for the 1-8-inch, pull with the screw spike are in eight out of eleven instances nearly the same as, or greater than, the resistances for the 1-4-inch pull with the ordinary This signifies that the screw spike is about twice as efficient as the ordinary spike for a pull of 1-4 of an inch or less. The curve in Plates II and III show graphically the relative efficiency of the two forms of spikes with some information to be referred to later.

### C Effect of Certain Details of the Screw Spike upon Its Holding Power

In countries where the screw spike is extensively used it has been perfected in detail until it nearly fulfills the requirements of practice. In North America the screw spike will probably be the successor to the ordinary spike, and it may again be necessary to adjust the details to suit local conditions. Therefore a few observations on the relation of some of the details of this spike to its holding power come within the scope of this paper. The details to be discussed are the diameter of the core, the projection and pitch of the thread and the length of the thread. These details being interdependent will be discussed collectively.

The soft steel from which the screw spike is made has an ultimate strength of about 66,000 pounds per square inch, so that the tensile strength of a spike 11-16 of an inch in diameter is approximately 24,000 pounds. The ultimate compressive resistance across the grain of well-seasoned white oak is about 4,000 pounds per square inch, and experiments demonstrate that the thread of the spike in compacting the wood fibers increases the resistance about 40 per cent.\* Therefore, taking 5,600 pounds as the ultimate compressive strength of compacted white oak, and taking 17 3-4 inches and 1-8 of an inch respectively as the length and projection of the

<sup>\*</sup>Bulletin No. 50, U. S. Dept. of Agriculture.

TABLE XIX

RELATIVE HOLDING POWER OF THE SCREW SPIKE AND OF THE ORDINARY SPIKE IN SEVERAL TIMBERS

Kind of	Kind of	Resist	ance in for	Pounds	R	Relativ esistano	
Tie	Spike	1-8-in. Pull	1-4-in. Pull	Max. Resist.	1-8-in. Pull	1-4-in. Pull	Max. Resist.
Water Oak	Ordinary Screw	2870 4888	5730 9180	6780 12190	100 170	100 160	100 179
Black Oak	Ordinary Screw	2910 4760	5890 10420	7230 14110	100 164	100 177	100 203
Red Oak	Ordinary Screw	2950 4900	5350 10400	7730 13560	100 166	100 194	100 176
White Oak	Ordinary Screw	3510 6250	5950 11900	7870 $12630$	100 178	100 200	100 188
Ash	Ordinary Screw	3570 5700	5200 10470	$\begin{array}{c} 7730 \\ 12760 \end{array}$	100 162	100 200	100 165
Beech	Ordinary Screw	$\frac{2600}{6450}$	$5490 \\ 13140$	8840 16230	100 248	100 221	$\frac{100}{238}$
Elm	Ordinary Screw	2380 5120	$5580 \\ 10090$	7500 13690	100 215	100 181	100 183
Poplar	Ordinary Screw	2830 3880	5290 6210	5670 7490	100 137	100 117	100 132
Chestnut	Ordinary Screw	$\frac{2850}{3690}$	4070 6340	5200 8700	100 129	100 155	100 167
Sweet Gum	Ordinary Screw	3230 5430	4120 7710 .	5300 8280	100 167	100 162	100 156
Loblolly Pine	Ordinary Screw	2920 5750	3500 9050	4300 10620	100 197	100 258	100 247

thread on the 5-inch spike, and making no allowance for frictional resistance between the core of the spike and the wood, the theoretical resistance would be

5,600 x 17 3-4 inches x 1-8 inches=12,430 pounds. The average actual resistance obtained in white oak ties as shown in Table XIX is 12,630 pounds which agrees closely with the theoretical resistance. The tensile strength of the screw spike is

about 12,000 pounds greater than the maximum resistance of white oak, which difference is greater than necessary and indicates an uneconomical use of metal in the spike. Since the ties tested are representative of American practice, there is no apparent reason for not having the ultimate strength of the two materials in contact more nearly equal than at present, and by some slight change in the detail of the spike this could readily be accomplished. Three ways in which the ultimate strength of the materials may be made more nearly equal are: (1) increase in length of threaded portion; (2) increase in projection of thread, the length and the diameter of the core remaining the same; (3) increase in projection of thread at the expense of the core, the length remaining the same. The pitch is assumed to be 1-2 inch in all cases, since it has been found in practice that this pitch gives better results than either a greater or smaller pitch.\*

- (1) The length of the thread on the 5-inch spike is 17 3-4 inches and the width is 1-8 of an inch; therefore, the bearing area is 2.22 square inches. If the spike is made 6 inches long two convolutions of the thread will be added, the bearing area will become 2.71 square inches, and the holding power will be increased from 12,630 pounds to 15,180 pounds. This leaves a difference of only 8,900 pounds between the ultimate strength of the wood and that of the spike.
- (2) If the length of the spike and the diameter of the core are not changed, and if the projection of the thread is increased 1-32 of an inch, the total resistance would amount to 15.510 pounds, leaving the ultimate strength of the spike only 8,500 pounds greater than that of the wood.
- (3) If the length of the threaded portion of the spike remains unchanged and if the projection of the thread is increased 1-32 of an inch at the expense of the core, the maximum resistance would amount to 15,510 pounds, while the ultimate strength of the spike would be reduced to 20,200 pounds.


The diameter of the shank of the spike would have to be increased with some of the changes in the detail of the lower portion, and when the resistance to lateral displacement is taken into account, we see that this change also would be beneficial.

The conclusion is that the screw spike in its present form is

<sup>\*</sup>Bulletin No. 50, U. S. Dept. of Agriculture.



# PLATE VII



SCREW SPIKES AND TOOLS FOR INSERTING THEM

about twice as efficient as the ordinary spike; and that this efficiency could be increased by some slight change in the detail of the screw spike.

# ART. 3 HOLDING POWER OF SCREW SPIKES WITH HELICAL LININGS

A few experiments were made with screw spikes having helical linings. On account of the small number of linings obtainable the tests were limited; as this lining, being a foreign invention, is not yet used by the railroads of this country except for experimental purposes. The tests were still further limited since the linings could not be used a second time; and further since all of the linings could not be driven successfully, as the friction between the metal and the wood sometimes caused the driver to loosen its hold, which could not be regained even after carefully following printed instructions. This accounts for the use of only two linings in some of the timber. The linings together with a set of special tools for inserting them in the tie were furnished by Mr. Robert Trimble, Chief Engineer Maintenance of Way, Pennsylvania Lines, (see Plate VII).

The linings were made by Mr. J. Thiollier of Paris, France, and are described by him as being 0.33 inch by 0.17 inch in section, and also as being of the class which he calls P. M. or small sized linings. They were 4 inches long with a 1-2-inch pitch. The total diameter was 1 5-16 inches, the diameter inside of the spiral band slightly over 11-16 of an inch, and the thickness and width of the metal band 1-8 and 1-4 of an inch, respectively. The linings were evidently designed to be used with the screw spike of the French Eastern Railway, No. 1, Table XVI, and hence they were tested with this spike only.

The method of fixing the lining in place was as follows: A hole having the same diameter as the core of the spike was bored in the tie; the hole was tapped, and the lining inserted by means of special tools designed for the purpose; the spike was inserted in the usual manner.

The detailed results of these tests are shown in Table XX, and the average results are shown graphically in Plates II and III. The relative holding power of the several kinds of spikes in different timbers is shown in Table XXI. The results of this table and the diagrams in Plates II and III show that in hard woods

the resistances for a 1-8-inch pull are usually greater for the spike and lining than for the naked screw spike, but for pulls greater than 1-8 of an inch the reverse is true. In soft woods the spike and lining gave greater resistances than the naked screw spike except in sweet gum. The lower resistance in the hard woods is accounted for by the fact that the spike begins to move before the lining, and the fibers, being hard, are bent slightly upward so that the bearing surfaces of the wood and the spike are only partially in contact. Moreover, the fibers probably slip over the rounded edge of the lining, which tends to lower the resistance. In the soft woods more than in the hard woods, the fibers mash together as the spike is pulled out, consequently the bearing surfaces of the wood and the spike have full contact and the resistance is greater than with the naked screw spike.

In justice to Mr. Thiollier it is only right to say that he claims no more for the P. M. lining than is set forth in these experiments. He says that the P. M. lining will offer no more resistance than a naked screw spike. The principal claims for the P. M. lining are that it can be placed on the track without removing either the rail or the tie, and that it forms an advantageous substitute for the square wooden dowel used on some railways.

As a repair measure this lining is of doubtful value, for it extends only about 1-8 of an inch beyond the thread of the spike; and when the spike has been pulled even a small distance the adjacent wood is badly damaged, so that the wood which remains after the hole is tapped for the lining can offer but slight resistance. Moreover, it is not certain that the extreme fibers reached by the lining are not somewhat affected, hence it would be better to ream the hole, cutting out all damaged wood and to introduce a threaded hard wood dowel, or to use a lining of larger size.

The writer claims that the use of the small lining is impracticable for the following reasons: (1) It is designed to be put in place with the tie in the track; (2) The lining cannot always be inserted into the wood to its full length by means of hand tools, even with utmost precaution; (3) At best the holding power is not increased to any marked degree over that of the naked screw spike; and (4) The labor involved is more than double that required to drive the naked screw spike, and the cost is increased.

TABLE XX RESISTANCE OF SCREW SPIKES WITH HELICAL LININGS

Kind of	No.	of Tests		Resistan	ce in Po Pull of	ounds for	•	Maxin Resist	
Tie	Tie N	No. 0	1-8 in.	1-4 in.	1-2 in.	3-4 in.	1 in.	Pounds	Pull, in.
Ash	1	1 2 3	8410 5830, 5670	11380 8670 8070	10150 9410 7930	7570 6590 4690	6480 5630 4200	12160 10500 8750	1-4 3-8 3-8
		Av.	6640	9370	9160	6280	5440	10470	3-8
Sweet Gum	3	1 2 3	$\begin{array}{c} 6010 \\ 4830 \\ 4270 \end{array}$	9100 6440 6250	7750 7650 8600	5380 $6270$ $6130$	5150 4380 4410	9510 7970 8600	1-4 3-8 1-2
		Λv.	5030	7260	8000	5930	4650	8690	3-8
Water Oak	26	$\frac{1}{2}$	3420 2970	7100 6460	$\begin{array}{c} 11080 \\ 12080 \end{array}$	8290 9250	8740 9170	11080 12080	1-2 1-2
		Av.	3190	6780	11580	8780	8960	11580	1-2
White Oak	32	1 2	5810 7070	$10740 \\ 11020$	8420 6650	6890 6170	7120 6340	$\frac{12900}{11020}$	3-8 1-4
		Αv.	6440	10880	7530	6530	6750	11960	3-8
Black Oak	23	$\frac{1}{2}$	5960 5420	11130 9710	9810 10770	8560 8470	7520 7960	12550 12460	3-8 3-8
		Av.	5690	10420	10290	8510	7740	12500	3-8
Beech		$\frac{1}{2}$	$\frac{10830}{8610}$	$1012\bar{0}$ $11600$	$8070 \\ 11850$	7320 10350	5390 6280	10830 $13480$	1-8 3-8
		Λv.	9720	10860	9960	8830	5830	12150	1-4
Poplar	11	$\begin{array}{c} 1 \\ 2 \\ 3 \end{array}$	3970 4080 3670	8860 9470 8260	9900 10550 9910	5880 5940 6030	5300 5110 5250	9920 11140 9910	3-8 3-8 1-2
		Av.	3910	8860	10120	5950	3220	10320	3-8
Chestnut		1 2 3	7020 5750 6300	9600 7010 7240	8230 8890 9280	6920 8180 7660	6120 6730 6860	9770 8890 9280	3-8 1-2 1-2
		$\overline{\Lambda v}$ .	6390	7950	8810	7590	6900	9150	1-2

#### TABLE XXI


RELATIVE HOLDING POWER OF THE ORDINARY SPIKE, THE SCREW SPIKE, AND THE SCREW SPIKE WITH HELICAL LINING IN SEVERAL TIMBERS

17: 1 - 6	171-1 -6	Resistan	ice in Po	unds for	Relat	ive Resis	stance
Kind of	Kind of	1-8-in.	1-4-in.	Max.	1-8-in.	1-4-in.	Max.
Tie	Spike	Pull	Pull	Resist.	Pull	Pull	Resist.
White Oak	Ordinary	3510	5950	7870	100	100	100
	Screw*	6250	11900	12630	178	200	188
	Lining	6440	10880	11960	183	183	152
Water Oak	Ordinary	2870	5730	6780	100	100	100
	Screw*	4880	9180	12190	170	160	179
	Lining	3190	6780	11580	111	118	171
Black Oak	Ordinary	2910	5890	7230	100	100	100
	Screw*	4760	10420	14110	164	177	203
	Lining	5690	10420	12500	195	177	173
Aslı	Ordinary	3570	5200	7730	100	100	100
	Screw*	5700	10470	12760	162	200	165
	Lining	6640	9370	10470	186	180	135
Beech	Ordinary Screw* Lining	2600 6450 9720	5490 13140 10860	8840 16230 12150	100 248 373	$\frac{100}{221}$ $\frac{198}{198}$	100 238 138
Poplar	Ordinary	2830	5290	5670	100	100	100
	Screw*	3850	6210	7490	137	117	132
	Lining	3910	8860	10320	138	162	182
Chestnut	Ordinary	2850	4070	5200	100	100	100
	Screw*	3690	6340	8700	129	155	167
	Lining	6390	7950	9150	224	195	176
Sweet Gum	Ordinary	3230	4120	5300	100	100	100
	Screw*	5430	7710	8280	167	162	156
	Lining	5030	7260	8690	136	176	164

<sup>\*</sup> Screw spike with helical lining.
The \* belongs after "Lining."



# PLATE VIII



IMPACT APPARATUS

### PART II RESISTANCE TO LATERAL DISPLACEMENT

The railroad spike is subjected not only to a direct pull by the undulation of the rail, but also to a horizontal thrust due to the lateral movement of the rail. On roads having a large amount of curvature the lateral resistance is of more importance than that of direct pull.

To determine the amount of the resistance to lateral displacement which is developed by various forms of spikes the writer made a series of tests in which the lateral thrust was produced by the blows of a heavy hammer. The hammer consisted of a castiron weight suspended by a wooden rod from the joists of the floor above.

The place in which the apparatus was used was such that a good photograph could not be taken. Plate VIII is a view of the apparatus set up in a light suitable for photographing. All essential features are correctly represented. Fastened to the joists were metal strips upon which the knife edges of the rocking arm rested. These strips were 6 feet long, and were notched along the entire upper edge to permit the placing of the rocking arm in different positions. The length of the suspending rod was 9 feet.

The weight of the hammer was 100 lb. and the distance through which it was allowed to fall was 1 1-2 feet, so that the amount of the impact for each blow was 150 ft.-lb. The hammer delivered its blow on the end of a tool-steel bar which projected beyond the end of the tie, the other end of the bar being shaped to fit under the head of the spike.

The spikes used in this series of tests were 9-16 inch and 5-8 inch ordinary spikes and screw spikes. Each spike was subjected to five blows and the displacement produced by each blow was carefully measured. Usually four or five spikes of each kind were tested, but when there was much lack of uniformity in the results a larger number were tested.

All of the spikes were bent to a curve, the central point of which was about 1 1-2 inches below the surface of the tie. The ordinary spikes were pulled from the tie a short distance, but the thread of the screw spikes gripped the wood so as to prevent the spike from being pulled out even a perceptible amount.

#### ART. 3 LATERAL RESISTANCE OF ORDINARY SPIKES

The detailed results of the experiments with ordinary spikes are given in Table XXII and the average movement of the spike for each of the several blows is shown in Table XXIII. The average total movement of the 5-8 inch spikes in the first seven timbers was 0.65 inch, and that of the 9-16 inch spikes was 0.75 inch. In the last four timbers the average total movement of the 5-8 inch spikes was 0.74 inch, and that of the 9-16 inch spikes was 0.94 inch.

The total deflection of the 9-16 inch spikes was usually sufficient to allow a rail to clear the head of the spike if it were overturned. The corresponding movement of the 5-8 inch spikes was not usually sufficient to allow a like clearance, although it was considerably more than would be allowed in practice.

The first blow is of more importance than the succeeding blows in testing the efficiency of a spike. While the distances through which the different sized spikes were deflected by the first blow differ but a small amount, this difference is sufficient to show that the deflection is less for the 5-8 inch spikes than for the 9-16 inch.

These results, together with the fact that the 5-8 inch spikes were bent less by the impact than the 9-16 inch spikes, indicate that the 5-8 inch spike is more efficient in resisting lateral displacement than the 9-16 inch spike.

#### ART. 4 LATERAL RESISTANCE OF SCREW SPIKES

The method of determining the lateral resistance of screw spikes was the same as that used for ordinary spikes. The results for this set of tests are given in Table XXIV. The screw spikes used were all practically alike except that they were of various lengths. In making the tests the spikes were used indiscriminately, but since they were not all of the same length some tests were made to determine the effect of impact upon spikes which were driven into the tie to different depths. The spikes used for the latter tests were all of the same make, and were cut to lengths of 3, 3 1-2, 4, 4 1-2 and 5 inches, and were all driven into a single kind of timber. The results of these tests are shown in Table XXV. While the results for the 4- and 4 1-2-inch spikes are the same, the

TABLE XXII DETAILED RESULTS OF IMPACT TESTS OF ORDINARY SPIKES

	7.	Total	Lateral M	ovement o	of Spikes in	n Inches
Kind of Tie	Size of Spike, in. sq.		Nu	ımber of B	lows	
	III. Sq.	1	2	3	4	. 5
White Oak	9-16	0.27 :18 .10 .30 .21	0.35 .35 .22 .35 .35	0.48 .56 .33 .50 .60	0.65 .67 .45 .52 .74	0.81 .73 .54 .60 .93
	Av.	0.21	0.32	0.49	0.61	0.70
	5-8	0.11 .15 .19 .21 .20	0.20 .30 .36 .36 .34	0.26 $.41$ $.50$ $.49$ $.42$	0.30 .50 .60 .65 .50	0.39 .57 .68 .74 .57
	Av.	0.17	0.31	0.42	0.51	0.59
Water Oak	9-16	0.23 .20 .14 .20 .19	0.34 .33 .42 .35 .39	0.52 .56 .53 .48 .63	0.60 .73 .68 .54 .72	0.75 .88 .75 .65
	Av.	0.19	0.37	0.54	0.65	0.76
	5-8	0.12 $.20$ $.15$ $.19$ $.20$	0.25 .37 .25 .28 .37	0.36 .54 .31 .43 .53	0.48 .63 .39 .51 .65	0.55 .69 .50 .65 .69
	Av.	0.17	.30	0.43	0.53	0.61
Black Oak	9-16	0.25 .13 .16 .24 .23 .26	0.40 .30 .32 .44 .35 .39	$\begin{array}{c} 0.56 \\ .41 \\ .49 \\ .62 \\ .56 \\ .59 \end{array}$	0.70 .58 .58 .71 .65 .67	0.75 .72 .70 .80 .69 .78
	Δv.	0.21	0.37	0.54	0.65	0.71
Black Oak	5-8	0.23 $.17$ $.17$ $.15$ $.11$ $.22$	0.38 .30 .35 .32 .26 .35	0.50 .42 .50 .40 .37 .50	0.58 .53 .61 .49 .41 .59	0.65 .64 .77 .55 .45 .65
	Av.	0.17	0.33	0.45	0.53	0.62

TABLE XXII-Continued

	Q: a	Total I	Lateral Mo	vement of	Spikes in	Inches
Kind of Tie	Size of Spike, in. sq.		Nur	nber of Blo	ows	
	m. sq.	1	2	3	4	5
Red Oak	9-16	0.21 .19 .20 .22	0.35 .30 .37 .41	0.51 .46 .55 .49	0.61 .57 .64 .61	0.73 .75 .77 .72
	Av.	0.21	0.36	0.50	0.61	0.74
	5-8	0.12 .15 .12 .18	0.21 .24 .25 .42	0.32 .34 .35 .55	0.42 .43 .49 .72	0.49 .50 .53 .85
	Av.	0.14	0.28	0.39	0.52	0,60
Ash	9-16	0.24 .24 .20 .25	0.45 .43 .33 .41	.057 .53 .52 .60	0.68 .65 .65 .72	0.80 .74 .75 .83
	Av.	0.23	0.41	0.56	0.68	0.78
	5-8	0.19 .19 .18 .15	0.37 .33 .31 .30	0.55 .48 .44 .39	0.73 .64 .60 .54	0.84 .75 .69 .63
	Av.	0.18	0.33	0.47	0.63	0.73
Elm	9-16	0.22 .21 .25 .18	0.33 .30 .37 .30	0.50 .39 .49 .43	0.67 .56 .58 .54	0.78 .70 .66 .67
	Av.	0.22	0.33	0.45	0.59	0.70
	5-8	0.20 .21 .20 .21	0.38 .35 .35 .32	0.50 .48 .49 .44	0.61 .60 .61 .55	0.71 .72 .70 .66
	Av.	0.21	0.35	0.48	0.59	0.70
Beech	. 9–16	0.28 $0.26$ $0.21$ $0.30$ $0.19$ $0.27$	0.30 .46 .32 .54 .37 .46	0.58 .57 .53 .63 .55	0.72 .75 .65 .71 .70 .72	0.87 .86 .75 .89 .80
	Av.	0.25	0.41	0.58	0.71	0.84

TABLE XXII—Continued

		Total	Lateral M	ovement o	of Spikes in	n Inches
Kind of Tie	Size of Spike,		Nι	ımber of I	Blows	
	in. sq.	1	2	3	4	5
	5-8	0.15	0.23 .20	0.33 .29	0.46 .41	0.53
		.16 .12 .12	.27 .26 .30	.36 .43 .37	.49 .50 .46	.58 .57 .62
	1.	.14	.25	.31	.39	.50
	Av.	0.14	0.25	0.35	0.45	0.55
Poplar	9-16	0.27 .22 .30	0.41	0.59	0.75 .67 .68	0.88 .74
		.27	.45 .41	.60 .54	.05	.84
		.27	.40	.52	.61	.76
	$\Lambda v$ .	0.27	0.41	0.56	0.69	0.81
	5-8	0.10	0.29	0.41	0.50	0.63
		.16	.28	.41	.51	.60
		.20 .17	.39	.50 .39	.66	.75 .57
	Av.	0.16	0.34	0.43	0.53	0.64
Chestnut	9-16	0.35	0.65	0.90	1.06	1.40
		.35	.60	.80	.97	1.10
		.35	.60	.90	1.12	1.35
		.31	.62	.91	1.01	1.19
		.29	.52	. 75	.93	1.18
	1	.30	.50	.73	93	1.19
	Av.	0.32	0.58	0.83	1.00	1.23
	5-8	0.17	0.40	0.60	0.78	0.85
		.10	. 30	.67	.88	1.05
	1	.27	.45	.63	.80	.92
	0	.25	.48	.70	.91	1.03
		.24	.40	.57	.75	.90
		.28	.42	.53	.65	.84
	Av.	0.22	0.41	0.61	0.79	.93
Sweet Gum	9-16	0.29	0.51	0.60	0.78	0.95
		.23	.40	.66	.75	.88
		.30	.51	.67	.75	.92
		.31	.54	.72	.97	1.10
	Av.	0.28	0.49	0.66	0.81	0.96

TABLE XXII-Concluded

	G1 0	Total Lateral Movement of Spikes in Inches								
Kind of Tie	Size of Spike, in. sq.		Number of Blows							
	m. sq.	1	2	3	4	5				
Sweet Gum	5-8	0.14 .18 .16 .14	0.28 .35 .33 .38	0.45 .54 .46 .42	0.62 .62 .62 .50	0.78 $.75$ $.70$ $.61$				
	Av.	0.16	0.34	0.47	0.59	0.17				
Loblolly Pine	9-16	0.22 .23 .12 .24 .26 .23	0.33 .38 .23 .37 .42 .45	0.50 .65 .35 .58 .53 .64	0.61 .76 .42 .71 .70 .72	0.70 .81 .50 .88 .75				
	Av. 5-8	0.22 0.16 .17 .17 .15 .23 .12	0.36 0.30 .42 .22 .23 .38 .19	0.54 0.40 .63 .30 .40 .46 .29	0.65 0.50 .72 .51 .52 .61 .36	0.74 0.65 .85 .55 .59 .71 .41				
	Av.	0.18	0.30	0.43	0.56	$\frac{.78}{0.65}$				

averages in the last column of the table show that the amount of the lateral movement decreases as the depth of penetration increases. Also, the difference between the deflections of the 4-, 41-2-, and 5-inch spikes is practically negligible, but for shorter lengths the difference in the deflections becomes greater.

Table XXVI gives the lateral movement of the screw spikes for each of the several blows for which the total movements were given in Table XXIV. The number of spikes used in each kind of timber was usually three; but in case there was considerable variation in the results, more spikes were tested. By a study of this table the effect of impact upon screw spikes in different kinds of timber may be determined.

TABLE XXIII LATERAL MOVEMENT OF ORDINARY SPIKES FOR EACH BLOW

Kind of Tie	of Spike, q.	Movement for Each of the Several Blows, inches						
or tre	Size of in. sq.	1	2	3	4	õ	Average Movement, inches	
White Oak	9-16 5-8	0.21 0.17	$0.11 \\ 0.14$	0.17 0.11	$\begin{bmatrix} 0.12 \\ 0.09 \end{bmatrix}$	0.09 0.08	0.136 0.118	
Water Oak	9-16 5-8	0.19 0.17	$\begin{array}{c} 0.18 \\ 0.13 \end{array}$	0.17 0.13	0.11 0.10	$\frac{0.11}{0.08}$	$0.152 \\ 0.122$	
Black Oak	9-16 5-8	$\frac{0.21}{0.17}$	$\substack{0.16\\0.16}$	$\begin{bmatrix} 0.17 \\ 0.12 \end{bmatrix}$	$\frac{0.11}{0.08}$	0.06 0.09	$0.142 \\ 0.124$	
Red Oak	9-16 5-8	0.21 0.14	$\begin{array}{c} 0.15 \\ 0.14 \end{array}$	$\begin{smallmatrix}0.14\\0.11\end{smallmatrix}$	$0.11 \\ 0.14$	$\frac{0.13}{0.08}$	$0.148 \\ 0.122$	
Ash	9-16 5-8	$\begin{array}{c} 0.23 \\ 0.18 \end{array}$	$\begin{array}{c} 0.18 \\ 0.15 \end{array}$	0.15 0.14	0.12 0.16	$\frac{0.10}{0.10}$	$0.156 \\ 0.146$	
Elm	9-16 5-8	$0.22 \\ 0.21$	$\substack{0.11\\0.14}$	$0.12 \\ 0.13$	$\begin{array}{c} 0.13 \\ 0.11 \end{array}$	$\substack{0.11\\0.11}$	0.138 0.140	
Beech	9-16 5-8	$0.25 \\ 0.14$	0.16 0.11	0.17 0.10	$\begin{array}{c} 0.13 \\ 0.10 \end{array}$	$\begin{array}{c} 0.13 \\ 0.10 \end{array}$	0.168 0.110	
Poplar	9-16 5-8	$\begin{array}{c} 0.27 \\ 0.16 \end{array}$	$\begin{array}{c} 0.14 \\ 0.18 \end{array}$	$\begin{array}{c} 0.15 \\ 0.09 \end{array}$	$\frac{0.14}{0.10}$	$0.12 \\ 0.11$	$0.164 \\ 0.128$	
Chestnut	9-16 5-8	$\frac{0.32}{0.22}$	$\frac{0.26}{0.19}$	$\begin{array}{c} 0.25 \\ 0.20 \end{array}$	0.17 0.18	$\begin{array}{c} 0.23 \\ 0.14 \end{array}$	$0.246 \\ 0.186$	
Sweet Gum	9-16 5-8	0.28 0.16	$\frac{0.21}{0.18}$	0.17 0.13	$\begin{array}{c} 0.15 \\ 0.12 \end{array}$	$\begin{array}{c} 0.15 \\ 0.12 \end{array}$	$0.192 \\ 0.142$	
Loblolly Pine	9-16 5-8	$\frac{0.22}{0.18}$	$\begin{array}{c} 0.14 \\ 0.12 \end{array}$	0.18 0.13	$\begin{bmatrix} 0.11\\0.13\end{bmatrix}$	0.04	$0.148 \\ 0.128$	

TABLE XXIV DETAILED RESULTS OF IMPACT TESTS OF SCREW SPIKES

		Total	Lateral Mo	ovement of	f Spike, in	Inches
Kind of Tie			Nu	mber of B	lows	
		1	2	3	4	5
White Oak		0.09 .10 .07	0.16 .20 .14	0.23 .24 .21	0.30 .32 .28	0.38 .41 .40
	Av.	0.09	0.17	0.23	0.30	0.40
Black Oak		$0.11 \\ .10 \\ .11$	0.21 .19 .18	0.26 .25 .24	0.36 .33 .31	0.40 .44 .42
	Av.	0.11	0.19	0.25	0.33	0.42
Water Oak		0.09 .11 .08	0.13 .17 .18	0.22 .23 .26	0.33 .34 .35	0.42 .45 .41
	Av.	0.09	0.16	0.24	0.34	0.43
Red Oak		0.12 .11 .17	$0.21 \\ .20 \\ .23$	0.35 .34 .33	0.45 .44 .46	$0.54 \\ .52 \\ .52$
	Av.	0.13	0.21	0.34	0.45	0.53
Ash		0.17 .18 .12	0.23 .27 .25	0.34 .35 .33	0.47 .46 .45	0.54 .55 .53
	Av.	0.16	0.25	0.34	0.46	0.54
Elm		0.11 $.12$ $.21$ $.25$	0.30 .22 .40 .40	0.38 .37 .58 .52	0.48 .49 .85 .63	0.56 .53 .96 .75
	Av.	0.17	0.33	0.46	0.61	0.70
Beech		0.10 $.11$ $.12$ $.16$ $.17$ $.20$	0.18 .18 .19 .28 .31 .40	0.23 .26 .25 .38 .52 .52	0.28 .31 .32 .49 .58 .60	0.36 .37 .42 .58 .65 .68
	Av.	0.14	0.26	0.36	0.43	0.51

TABLE XXIV-Concluded

		Total I	ateral Mo	vement of	Spike, in	Inches
Kind of Tie			Nui	mber of B	lows	
		1	2	3	4	5
Poplar		0.09	0.16 .16	$0.32 \\ .27$	0.60 .40	0.78
		.09 .19 .18	.15 .35 .40	.34 .44 .53	.39 .61 .62	.49 .78 .75
		.17	.27 .30	.40 .39	.63 .51	.71
	Av.	0.17	0.24	0.38	0.54	0.67
Chestnut		0.16 .13 .12	0.23 .22 .24 .31	0.38 .37 .33	$0.43 \\ .52 \\ .42$	0.50 $.56$ $.51$
		.20 .19	.31 .28	.39	.51 .48	.59 .65
	Av.	0.16	0.26	0.37	0.47	0.56
Sweet Gum		0.20 .26 .30 .18	0.38 .46 .48 .32	0.52 .60 .51 .40	0.68 .71 .74 .49	0.78 .79 .8g .61
	Av.	0.24	$\frac{.38}{-0.40}$	$-\frac{.47}{0.50}$	0.64	.68
Loblolly Dine	21.1.					0.74
Loblolly Pine		0.20 .21 .21 .23	0.41 .39 .32 .37	0.62 .58 .48 .56	0.72 .69 .64 .66	0.88 .78 .81 .80
	Av.	0.21	0.37	0.56	0.68	0.82

Table XXVII is given to facilitate the comparison of the relative lateral resistance of ordinary and screw spikes. The data were collected from Tables XXIII and XXVI. The average total deflection of the screw spike in the first seven timbers is 0.50 inch which is 0.15 inch less than that of the 5-8-inch ordinary spike and 0.25 inch less than that of the 9-16-inch ordinary spike. In the

TABLE XXV

RELATION BETWEEN THE DEPTH OF PENETRATION AND THE RESISTANCE
TO LATERAL DISPLACEMENT

		Deflec	ction in In	ches		e
Depth of Insertion		Num	ber of Blo	ows		A verage for Five Blows
Tilsercion	1	2	3	4	5	A L
3 in.	0.24 .22 .24	0.46 .41 .43	0.64 .55 .67	0.78 .69 .76	0.87 .84 .98	
Av.	0.23	0.43	0.62	$\bar{0},73$	0.90	0.582
3 1-2 in.	0.24 .24 .19	0.46 .39 .34	0.62 .53 .49	0.77 .69 .63	0.80 .80 .74	
Av.	0.22	0.40	0.55	0.70	0.78	0.530
4 in.	.20 .21 23	0.39 .40 .33	0.49 .57 .57	0.60 .63 .62	0.71 .77 .72	
Av.	0.21	0.37	0.54	0.62	0.73	0.494
4 1-2 in.	0.24 $.20$ $.22$	0.30 .34 .36	0.50 .53 .54	0.65 .68 .62	0.74 .73 .79	
Av.	0.22	0.33	0.52	0.65	0.75	0.494
5 in.	0.22 .23 .15	0.38 .40 .34	$0.49 \\ .55 \\ .48$	0.61 .67 .57	0.71 .75 .69	
Λv.	0.20	0.34	0.51	0.62	0.72	0.478

last four kinds of timber the average total deflection of the screw spike was 0.70 inch, which is practically the same as that of the 5-8-inch ordinary spike, but which is 0.24 inch less than that of 9-16-inch common spike. The results in the last two columns of Table XXVII show that the screw spike is superior to the 9-16-inch ordinary spike in all but two kinds of timber, and that the screw spike has a higher efficiency than the 5-8-inch ordinary spike in all but three kinds of timber.

TABLE XXVI
.
LATERAL MOVEMENT OF THE SCREW SPIKE FOR EACH BLOW

Kind of Tie	Movement for Each of the Several Blows							
or rie  -	1	2	3	4	5	Average Move- ment, inches		
White Oak	0.09	0.08	0.05	0.07	0.10	0.078		
Black Oak	0.11	0.08	0.06	0.07	0.09	0.082		
Water Oak	0.09	0.07	0.08	0.10	0.09	0.086		
Red Oak	0.13	0.08	0.13	0.12	$0.0\bar{s}$	0.108		
Ash	0.16	0.09	0.09	0.12	0.08	0.108		
Elm	0.17	0.16	0.13	0.15	0.09	0.140		
Beech	0.14	0.12	0.10	0.07	0.08	0.102		
Poplar	0.17	0.07	0.12	0.16	0.13	0.130		
Chestnut	0.16	0.10	0.11	0.10	0.09	0.132		
Sweet Gum	0.24	0.16	0.10	0.14	0.10	0.148		
Loblolly Pine	0.21	0.13	0.19	0.12	0.14	0.154		

The last two columns in Table XXVII show that the ordinary spike was usually displaced more than the screw spike by each blow. This should be expected since the common spike was smaller in cross section than the screw spike, and also since the latter had better bond with the wood. While the use of the screw spike is recommended to the American railroads, it is thought that the practice of Bavarian railroads could be followed to advantage. These roads have adopted the use of the screw spike on the gage side of the rail to resist overturning, but use two square spikes on the outside to resist lateral movement. This practice has been found to give very beneficial results. The figures in the last two columns of Table XXVII show that the lateral resistance of two ordinary spikes is considerably more than that of one screw spike, and therefore if two spikes are considered as resisting the impact instead of one, the results will be in favor of the ordinary spikes. Not only is this true, but the first cost for spikes would be reduced, since the screw spike costs about four cents at

TABLE XXVII

RELATIVE LATERAL DISPLACEMENT OF ORDINARY AND SCREW SPIKES

Kind of Tie	Movement of Ordinary Spikes		Average Movement of Screw Spike,	Average Movement of Ordinary Spikes in Terms of per cent of Move- ment of Screw Spike	
	9-16 in.	5-8 in.	inches	9-16 in.	5-8 in.
White Oak	0.136	0.118	0.078	175	152
Black Oak	0.152	0.122	0.082	186	149
Water Oak	$0.14\overline{2}$	0.124	0.086	165	145
Red Oak	0.148	0.122	0.108	137	115
Ash	0.156	0.146	0.108	144	135
Elm	0.138	0.140	0.140	99	100
Beech	0.168	0.110	0.102	165	108
Poplar	0.164	0.128	0.130	126	• 99
Chestnut	0.246	0.186	0.132	186	141
Sweet Gum	0.192	0.142	0.148	129	96
Loblolly Pine	0.148	0.128	0.154	96	83

the present time, whereas the ordinary spike costs much less. The maintenance cost of either form of spike is almost negligible.

An item of interest which is properly beyond the limits of this article is that of the ninety screw spikes used in making these tests only two were broken. One was broken under a tension of 14,000 pounds, the break being caused by an incipient crack just under the head of the spike. The other spike broke under the fourth blow of the hammer, this break being due to uncombined graphite in the metal. As the spikes were obtained from different sources, and were of different manufacture, it is thought that the test was sufficiently severe to show that the screw spike, as manufactured at present, will successfully withstand the shocks of passing trains. As the spikes were used several times during the tests, the percentage of spikes broken is very low.

#### SUMMARY OF RESULTS

- (1) The maximum resistance to direct pull varies from 6,000 to 14,000 pounds for screw spikes, from 3,000 to 8,000 pounds for ordinary spikes when driven into untreated timbers, and from 4,000 to 9,000 pounds for ordinary spikes when driven into treated timbers.
- (2) The direct pull required to withdraw ordinary spikes 1-8-inch varies from 2,000 to 3,500 pounds for untreated timbers, and from 2,500 to 3,500 pounds for treated timbers.
- (3) The direct pull required to withdraw ordinary spikes 1-4-inch varies from 3,000 to 5,400 pounds for untreated timbers and from 3,800 to 5,900 pounds for treated timbers.
- (4) Timbers having loose fiber structures have lower resistances to direct pull than timbers having compact fiber structures.
- (5) The amount of withdrawal which must occur for ordinary spikes to develop the maximum resistance is less for soft woods than for hard woods.
- (6) Spikes driven into treated timber offer a greater resistance to direct pull than spikes in untreated timbers, and the difference between this resistance for treated and untreated timbers is greater for soft woods than for hard woods.
- (7) The difference in the resistance to direct pull for the different sized spikes in use (9-16 inch, 19-32 inch, and 5-8-inch) is very small.
- (8) The resistance of ordinary spikes to direct pull varies directly as the depth of penetration, neglecting the tapering point.
- (9) Blunt-pointed and bevel-pointed spikes have a slightly greater resistance to direct pull than chisel-pointed spikes.
- (10) For withdrawals less than 1-4 inch, ordinary spikes which are driven into bored holes have a little greater resistance to direct pull than spikes driven in the ordinary way.
- (11) The resistance to direct pull for re-driven spikes is from 60 to 80 per cent of the resistance of newly driven spikes.
- (12) The efficiency of screw spikes to resist withdrawal is nearly twice as great as that of common spikes.
- (13) The resistance of 5-8-inch spikes to lateral displacement is slightly greater than that of 9-16-inch spikes.
  - (14) The resistance to lateral displacement increases with

the depth of penetration, but the increase is negligible for depths of penetration greater than 4 inches.

(15) Screw spikes are more efficient than ordinary spikes in resisting lateral displacement.

# PUBLICATIONS OF THE ENGINEERING EXPERIMENT STATION

Bulletin No. 1. Tests of Reinforced Concrete Beams, by A. N. Talbot. 1904.

Circular No. 1. High-Speed Tool Steels, by L. P. Breckenridge. 1905.

Bulletin No. 2. Tests of High-Speed Tool Steels on Cast Iron, by L. P. Breckenridge and Henry B. Dirks. 1905.

Circular No. 2. Drainage of Earth Roads, by Ira O. Baker. 1906.

Bulletin No. 3. The Engineering Experiment Station of the University of Illinois, by L. P. Breckenridge. 1906.

Bulletin No. 4. Tests of Reinforced Concrete Beams, series of 1905, by A. N. Talbot. 1906.

Bulletin No. 5. Resistance of Tubes to Collapse, by A. P. Carman. 1906.

Bulletin No. 6. Holding Power of Railroad Spikes, by R. I. Webber, 1906.



VIEW IN CENTRAL HEATING STATION UNIVERSITY OF ILLINOIS

### UNIVERSITY OF ILLINOIS

## Engineering Experiment Station

BULLETIN NO. 7

AUGUST 1906

#### FUEL TESTS WITH ILLINOIS COALS

ву

L.	Ρ.	Brecki	ENR	ID	GE.	, .		Professor	OF	MECHANICAL	Engineering
S.	W.	Parr,						Professor	of	APPLIED C	HEMISTRY
Η.	В.	DIRKS,						ASSISTANT	IN	MECHANICAL	TECHNOLOGY

During the last ten years a considerable number of boiler trials have been made at the University of Illinois. Many of these have been made under the boilers in the power plant of the University. Still other trials have been made with boilers in use at the plants in neighboring cities. In some instances experts representing several special stoker and furnace companies have been present at these trials and operated the devices in which they were interested. For the most part, however, the tests have been made in order to instruct students in the usual methods of boiler testing, and the boilers themselves have been operated under such usual conditions as happened to obtain. In some of the earlier tests all of the data relating to the heating value of the coals were not obtained, and for such tests several items depending on these values are necessarily omitted. While in most cases these tests have not been made with the object of making a comparison of coals or of appliances, nevertheless, it has seemed wise to publish the results obtained and also to exhibit these results side by side as they apply to various forms of furnaces, types of boilers or kinds of coal. It is entirely probable that the results obtained are equal to those generally obtained under the varying conditions of plants using Illinois coals. Many more boiler trials have been

made than are here reported, but only such are included in this report as appear to be free from any indications of errors in methods or results. For the purpose of this bulletin all of the results of the tests have been carefully rechecked.

The work of the department of Applied Chemistry has not only supplemented the work relating to boiler trials by furnishing the composition and heating value of the coals used in these trials, but it has also examined and tested a large number of Illinois coals not yet tested under boilers. In connection with this subject this department has perfected several new devices very useful to chemists and engineers, designed for making the ordinary determinations of the heating values and composition of coals. The Parr calorimeter, one of these devices, has found ready sale among the operators of many of the power plants of the country as well as among the consulting chemists and fuel experts. It is expected that a separate bulletin will soon be published setting forth in detail many of the new methods which have been developed by this department, and giving the complete results of its investigations relating to Illinois coals. It is hoped that the tables of the chemical composition and heating values of Illinois coals, which form a part of this bulletin, will furnish engineers and manufacturers with useful information in this important field.

With the above somewhat general statement in explanation of the character of this bulletin, it may now be advisable to refer more in detail to the special features which are intended to be brought out in the following pages.

#### BOILER TESTING

For many years engineers have been making "boiler tests" with the object of finding out how many pounds of water in the boiler could be evaporated with one pound of coal. In order that the results of the tests might be comparable, it became evident that some common method of making tests should be agreed upon and also that the tests made should be reported in a uniform manner. A committee of the American Society of Mechanical Engineers recommended to that Society in 1899 a method of testing boilers and also a method of reporting such tests. These methods have been largely used since their recommendation at that time. The many expert engineers who are to-day so familiar with these methods will probably not be interested in the pages

immediately following. Having in mind the owners and operators of power plants as well as manufacturers and young technical students, it has seemed worth while to present somewhat in detail the following subjects:

- (1) Observations to be made during a boiler trial.
- (2) Appliances used during a boiler trial.
- (3) Form of report, methods of operation and explanation of computations.

#### I OBSERVATIONS TO BE MADE DURING A BOILER TRIAL

In the report of the committee of the American Society of Mechanical Eugineers, 1899, on the revision of the standard code for conducting steam boiler trials, two forms of report are submitted, a Complete Form and a Short Form. These are both shown in Section III, page 21. The observations necessary to complete either of these forms are given in Table I. An explanation of some of the methods used in obtaining these observations and the forms used in recording them follow.

#### COAL, WATER AND ASH

The two fundamental points to be determined in every test of a steam boiler or furnace, regardless of the special or specific purpose of such test, are the pounds of water evaporated by the boiler and the pounds of fuel necessary to produce such evaporation. To determine these two points it is necessary to know the number of pounds of water fed into the boiler and the pounds of fuel fed into the furnace. The possibility of an error in either throws doubt upon all the indications of the test. Each item, therefore, should be ascertained in a manner that proves its own correctness, and the records must be such that if errors are made, they will be clearly exposed.

Coal.—The weight of the coal is best obtained by means of a barrow or car with a capacity of 500 pounds. The car should be loaded uniformly each time and weighed on platform scales in front of the furnace. The total weight and the time of weighing should be recorded in the log. From the car the coal should be fired directly into the furnace and the weight of the separate

<sup>1</sup> See Trans. A. S. M. E. Vol. XXI, p. 34.

TABLE I
OBSERVATIONS TO BE MADE DURING A BOILER TRIAL

Short Trial	Standard Trial	Observations
1	1	Weight of water fed to boiler
2	2	Weight of coal as fired (sample)
3	3	Weight of ash and refuse (sample)
4	4	Moisture in coal
5	5	Steam pressure by gage
4 5 6 7	6	Force of draft: between damper and boiler
7	7	in furnace
	8	in ash-pit
8	9	Temperature: of feed water entering boiler
9	10	of escaping gases from boiler
	11	of external air
	12	of fire-room
	13	of steam
	11	of feed water entering heater
	15	of feed water entering economizer
	16	of escaping gases from economizer
	17	of gases in furnace
10	18	Moisture in steam by calorimeter
	19 '	Analysis of flue gases
	20	Smoke observations
	21	Average thickness of fire, intervals of firing

charges and time of firing entered in the log. After the entire car-load of coal has been fired, the weight of the empty car and the time should be recorded. The sum of the separate charges must then be equal to the difference in weight of the car when loaded and empty. A convenient form for recording the coal fired is shown in Form I. From each car-load of coal fired an average sample of coal should be taken for moisture determination and chemical analysis. The sample of course must be taken before the coal is weighed and should be about two per cent of every carload, or about ten pounds. At the end of the test these samples from the different cars are mixed, pounded into small sizes, and then quartered until enough is left to fill a two-quart jar. The jar should then be sealed, to prevent loss of moisture, and sent to the chemist.

Feed Water.—The water fed to the boiler should be both weighed and measured, as dependence upon measuring alone will introduce errors due to uneven filling and variations in temperature; for the latter, however, corrections may be made. The measuring tank or preferably two tanks should be set on scales in such a position that the water can be delivered directly into the suction or settling tank as shown in Fig. 1. The measuring tanks should be filled and emptied alternately, the time of each weighing to be noted when the tank is empty, the tanks being designated as No. 1 and No. 2. In no case should a simple tally be recorded for




Fig. 1 Arrangement of Tanks and Scale for Measuring Feed-water Fed to Boiler

each tankful, as the liability of error is thereby increased. When the boiler tested is of small capacity, one weighing tank will be sufficient. A convenient form for recording the feed water measurements is shown in Form II.

To guard against the loss of all data, due to accidents, it is best to have coincident records of the water and coal fed to boiler. For this reason it is well to have a float in the suction or settling tank, and each time an entire car-load of coal has been fired, the time on the feed water log should be recorded, also the height of water in the boiler and in the settling tank. This will also provide a check on the uniformity of operations.

Ash.—The ashes and refuse should be weighed dry. The time of each raking of the fire and cleaning of the ash-pit and the weight

### FORM I

	LOG OF BOILER TRIAL NO							
Made	Made at							
Date	DateBy							
Boiler	Boiler No Fireman							
TIME	COAL DELIVERED TO SCALES POUNDS	COAL ON SCALES AFTER EACH FIRING POUNDS	COAL FIRED EACH TIME POUNDS	FUEL				
				Moist coal consumed, pounds				
				Moisture in coal, per cent				
************				Dry coal consumed, pounds				
				Wood consumed, pounds				
				Coal equivalent of wood (=wood x-4) D  Total dry coal consumed including wood equivalent, pounds				
				Total dry refuse, pounds				
******				Total dry refuse, per cent				
* * * * * * * * * * * * * * * * * * * *				Total combustible				
				DESCRIPTION OF FUEL				
	,			Commercial Name				
	ļ			Commercial size				
				Lumps, per cent				
				Small coal, per cent				
• • • • • • • • • • • • • • • • • • • •				Slack, per cent				
				Appearance of coal  ! Record the times when fires are				
•••••				/ cleaned				

#### FUEL TESTS WITH ILLINOIS COALS

				FORM II					
	LOG OF BOILER TRIAL NO								
Made	at								
Date.	Date By								
Boile	Boiler No. Fireman								
	FEED WATER SHEET								
TIME	WATER DELIVERED TO FEED TANK POUNDS	TEMP. OF WATER IN TANK	TIME	WATER DELIVERED TO FEED TANK POUNDS	TEMP. OF WATER IN TANK	REMARKS			
						Test began at			
******		1			, * * * * * * * * * * * * * * * * * * *	o'clock M.			
						Date			
						Test closed at			
						oʻclock M.			
			1			Date,			
						` I			
	* * * * * * * * * * * * * * * * * * * *					\			
					1				
••••									

### FORM III

		I.	OG OF	BOILE	R TRIA	L NO.			•	
Made	at									
Date.	Date By									
Boiler	Boiler No Fireman									
PRESSURES TEMP				TEMPE	RATUF	RES		er.		
TIME	STEAM	DRAFT	BAROM- ETER	BOILER	EXTERNAL · AIR	FLUE	FEED	STEAM	HEIGHT OF WATER IN GLASS GAGE	REMARKS
										Test began at
										o'eloek M.
										Date,
*******										Test closed at
			,							o'clock M.

## BRECKENRIDGE. PARR AND DIRKS FUEL TESTS WITH ILLINOIS COALS

#### FORM IV

	LOG OF BOILER TRÍAL NO									
Made	Made at									
Date.	Date By									
Boile	Boiler No Fireman									
	CA	LORIME		D	RAFT		~	٠. د		
TIME	GAGE	STEAM DISCHARGE OR CALORI- METER TEMP.	WATER SEPARATED OR CALORI- METER PRESSURE	BETWEEN DAMPER AND BOILER	IN	IN ASH PIT	HEIGHT OF WATER IN TANK	HEIGHT OF WATER IN GLASS GAGE	REMARKS	
• • • • • • • •										
								·		
						•••••	1			
								· · · · • • · ·		
							1			

#### FORM V

				101	. A. A						
	LOG OF BOILER TRIAL NO										
Made	Made at										
Date	Date By										
Boiler No. Fireman											
	FLUE-GAS SHEET										
TIME	CO <sub>2</sub>	02	СО	HYDROGEN AND HYDROCAR- BONS	TOTAL	REMARKS					
***											
						······					
••••											
		} 									

of ash removed should be recorded in the same log as the weight of coal, Form I. A representative sample of ash should be taken at every cleaning and saved in order to determine the principal characteristics of the ash, a proximate analysis giving the actual amount of incombustible material being made of each sample.

#### GENERAL OBSERVATIONS

Although the main points to be determined in a boiler trial are the weight of water evaporated and the amount of fuel burned, the general observations of pressures, temperatures, etc., under which this evaporation takes place and which tend to secure the accuracy of these two measurements must not be overlooked. It is necessary that all available data be obtained and recorded in the log for use in making comparisons. The value of the observation will depend primarily upon its correctness and the greatest care should be exercised in obtaining and recording observations. Too often the observer is guided by personal opinion and former readings, and the value of the observation as an indication of some specific occurrence is entirely lost.

All general observations should, as nearly as possible, be taken at the same instant, the exact time in all cases being recorded in the log. As a rule all observations should be recorded in duplicate, this being necessary especially where several persons are concerned with the results. Duplicates are easily obtained by placing carbon copying paper below the original log. The duplicates are then obtained as the results are originally recorded. Forms for recording the general observations are shown in Forms III to V.

For convenience it is best to have the log sheets tacked to a board, which may be suspended on the wall at some convenient point. This avoids the accumulation of dust and dirt when the sheets are lying around unattached in a horizontal position.

Sufficient time should elapse between temperature measurements if only one thermometer serves for taking several observations, in order to allow the thermometer to assume the new temperature. Where the range of temperature is large, however, this should never be practised, and it will be preferable in most cases to take only the most important of the readings, being certain of its correctness.

Determinations of the moisture in the steam are necessary to make corrections in the amount of water evaporated, and should be made at regular intervals and entered in the log.

The analysis of the flue gases is important as it indicates to some extent the progress of combustion in the furnace. Notwithstanding, the general use of this analysis is still very limited, although in some instances a record of the CO<sub>2</sub> in the flue gases is regularly kept. The value of the analysis consists in its being an indication of the amount of excess air being used. The flue gas to be analyzed should be an average sample taken continuously over a considerable period of time. This is necessary as the composition of the gases varies from minute to minute. Under ordinary conditions an analysis every half-hour is sufficient; special readings, however, may be taken more often. The apparatus for sampling will be explained in the following section.

#### II APPLIANCES USED DURING A BOILER TRIAL

Since the corrections to be applied to the weights of fuel and water fed to the boiler are dependent on the general observations, the appliances necessary for their determination must be considered. The correctness of the observations will depend primarily on the instruments used and their location. In the following paragraphs these are discussed to some extent.

#### DESCRIPTION OF APPLIANCES

A list of the apparatus necessary to take the observations given in Section I is shown in Table II. The apparatus required

TABLE II

APPLIANCES FOR OBSERVATIONS GIVEN IN TABLE I

hort Trial	Standard Trial	Appliances
1	1	Measuring and suction tanks for measuring water
2	2	Platform scales for weighing water
3	3	Car or barrow for handling coal
4	4	Platform scales for weighing coal
5	5	Standard calibrated steam gage
в	6	Draft gages, U tubes or otherwise
7	7	Thermometers according to observations made
8	8	Flue gas thermometer
	9	Pyrometer for furnace temperatures
9	10	Throttling or separating calorimeter
	11	Orsat apparatus for fine gas analysis
	12	Smoke charts

in the determination of the weights of coal and water was discussed in the previous section and needs no explanation other than that the scales used should be calibrated so that a correction may be applied if necessary. The suction tank should also be calibrated so that the contents of the tank are known for all positions of the float.

For measurement of the steam pressure an ordinary steam gage calibrated by comparison with a standard gage or other means will suffice. A good recording steam gage carefully adjusted and compared at frequent intervals with the steam gage provides a good check. Various forms of draft gages are used to determine the draft pressure. The ordinary U tube is the most common form and gives very satisfactory results. A gage of the type shown in Fig. 2 has been extensively used at the University and gives results which can be read with greater accuracy than the U tube.




Fig. 2 Draft Gage

In the choice of thermometers care should be taken that the range of readings will fall within that of the thermometer. Where thermometers are likely to be handled constantly, a metal casing is desirable. Where temperatures within a pipe are required, as in steam or water pipes, thermometer cups, as shown in Fig. 3 will need to be used.

Either mercury or a heavy cylinder oil may be used in these cups; the former, however, is preferable both for cleanliness and accuracy. For the measurement of flue gas temperatures a special mercury thermometer is used, reading up to 1000° F., with nitrogen compressed above the mercury.

The thermometer should be calibrated from time to time to insure its correctness. The location of the thermometer will be discussed in the following section.




Fig. 3 Thermometer Cup. Used to Obtain Temperatures . Within a Pipe

The measurement of furnace temperatures is very difficult, and no especial form of pyrometer has proved to be entirely satisfactory. The Wanner optical pyrometer is being used at the Government Coal-Testing Plant at St. Louis, and seems to be giving fair results.




Fig. 4 Sampling Nozzle for Steam Calorimeter

For determining the moisture in the steam, as long as the moisture remains below three per cent, any one of several forms of calorimeters may be used with good results. Above this point, all calorimeters are inaccurate, owing to the inability to obtain an average sample of the steam. The sampling nozzle, Fig. 4, should be made of  $\frac{1}{2}$ -in. pipe, and should extend across the diameter of

the steam pipe to within half an inch of the opposite side, being closed at the end, and perforated with not less than twenty  $\frac{1}{8}$ -in. holes equally distributed along and around its cylindrical surface, but none of these holes should be nearer than  $\frac{1}{2}$  inch to the inner side of the steam pipe. The calorimeter and pipe leading to it should be well covered with felt. When a separating calorimeter with attached gage for determining the amount of steam passing through the calorimeter is used, such gage should be calibrated by taking readings over twenty minutes in length, and condensing the steam passing through the calorimeter during that time, the weight of condensed steam being compared with the indication on the gage. This should be repeated for the entire range of the gage. Superheating should be determined by means of a thermometer placed in a mercury well, inserted in the steam pipe.




Fig. 5 Flue Gas Sampler, Advised in the A. S. M. E. Standard Code for Conducting Steam Boiler Trials

For determining the composition of the flue gases a sampling tube for drawing the sample of gas from the flue is necessary, also apparatus for analyzing the gas. There has been a great diversity of opinion regarding the method to be used in obtaining the




FIG. 6 ORSAT APPARATUS FOR ANALYZING FLUE GAS

sample, due probably to the varying conditions in different boiler settings and at different points in the same flue. In the trials carried on by the United States Geological Survey at St. Louis, both the sampler advised in the A. S. M. E. code, Fig. 5, and an ordinary pipe closed at the end and perforated with holes equally spaced along its entire length have been used. The results indicate the advisability of using the latter, and it has been adopted for use in all future trials. To get a uniform flow through all the perforations, they are made of such size and number that the sum of the areas of the perforations is less than the cross sectional area of the sampling tube. The Orsat apparatus is the one mostly used for analyzing the flue gases, as it is simple in operation, and with a little care gives reliable results. To insure the




Fig. 7 The Ringelman Scale for Grading the Density of Smoke

total absorption of the various gases, care must be taken that the absorbing solutions are in good condition, and they should therefore be renewed from time to time. If the flue gas is to be collected over water, a saturated salt solution should be used, as water has a tendency to retain some of the CO<sub>2</sub> when a considerable quantity is present, and to give it up later when there is a smaller quantity of this gas, thus causing errors in the results. Fig. 6 shows the type of Orsat apparatus generally used.

If determinations of the relative density of the smoke are to be made during the trial, the Ringelman smoke charts shown in Fig. 7 may conveniently be used. These are placed in a horizontal row about fifty feet from the observer, and as nearly as convenient in line with the chimney. At this distance the lines become invisible and the cards appear as different shades of gray. The observer by glancing from the chimney to the cards determines which card most nearly corresponds to the color of the smoke and makes a record accordingly.

#### LOCATION OF APPLIANCES

Of prime importance in taking observations is the location of the apparatus used. On account of the variation in different types of boiler settings it will always be necessary to describe clearly in the report of the test the location of all apparatus. This is best done by indicating on drawings or diagrams their position on the setting.


Feed Water Temperature.—As the methods used in supplying feed water to a boiler vary, so does also the location of the thermometer for the temperature measurement of such feed water. If an injector be used, it should receive steam directly through a covered pipe from the boiler being tested, and the temperature of the feed water should in this case be taken from the supply tank furnishing the water to the injector. It is here assumed that the heat of the steam operating the injector is returned to the boiler from which it was taken, so that the supply pipe between the boiler and injector, if long, should be covered to prevent radiation. If a pump be used for feeding the boiler, the temperature of the feed water should be taken by a thermometer in the discharge pipe as near the boiler as possible. If this is done, the water may or may not be pumped through a feed water heater after leaving the pump.

It is always essential that the heat carried into the boiler by the feed water should be known, and it is well to record its temperature before and after it passes through any kind of heater or economizer in order that the effect of such device may be given proper credit.

The location of thermometers for the determination of boiler room and external air temperatures should be such that drafts or heat rays will be avoided. The flue gas temperature should be taken at a point where the gases leave the boiler and pass into the breeching on their way to the stack. As the temperature in a transverse section of the flue will vary, several readings should be taken at different points of the same section. Observations of the draft are usually made at several points of the setting. The one between the damper and the boiler is, however, the more important, and should be taken at a point close to the flue gas thermometer or possibly in the same transverse section. The force of draft in furnace and ash-pit may be taken through the firing and ash-pit doors, but is preferably taken through holes left in the side walls. The calorimeter and the thermometer cup for determining superheat should be attached to the vertical steam pipe as it leaves the boiler. The sampling tube for the flue gas was explained in the last section. It should be inserted in the flue at the point where the flue gas temperature and draft are obtained.

#### III REPORT OF THE TRIAL

Forms.—The data and results of a boiler trial should be reported in the manner given in Form VI, which is the complete form advised by the Boiler Test Committee of the American Society of Mechanical Engineers, Code of 1899. The items printed in italics correspond to the items in the "Short Form" of report recommended for commercial tests. For more elaborate trials the code recommends that the full log of the trial be shown graphically by means of a chart, Fig. 8.



#### FORM VI

#### DATA AND RESULTS OF EVAPORATIVE TESTS

Arranged in accordance with the Complete Form advised by the Boiler Test Committee of the American Society of Mechanical Engineers. Code of 1899.

Time round bottery of meeting and meeting control of	
Made by of boiler at determine	to
Principal conditions governing the trial	
Kind of fuel* Kind of furnace. State of the weather. Method of starting and stopping the test ("standard" or "alternate") 1. Dute of trial. 2. Duration of trial.	
Dimensions and Proportions	
(A complete description of the boiler and drawings of the same if of unusual ty	ype, should be
given on an annexed sheet ) 3. Grate surface	in. in. per cent sq. ft. sq. ft. —to 1
Average Pressures	
11. Sleam pressure by gage. 12. Force of draft between damper and boiler. 13. Force of draft in furnace. 14. Force of draft or blast in ash pit.	in. of water
Average Temperatures	
15. Of external air 16. Of fireroom 17. Of steam. 18. Of feed water entering heater 19. Of feed water entering economizer 20. Of feed water entering boiler 21. Of escaping gases from boiler. 22. Of escaping gases from economizer	deg. deg. deg. deg. deg. deg.
Fue i	
23. Size and condition. 24. Weight of wood used in lighting fire. 25. Weight of coal as thed 26. Percentage of moisture in coal 27. Total weight of dry coal consumed 28. Total ash and refuse	. lbs. lbs. per cent lbs. lbs.
29. Quality of ash and refuse. 30. Total combustible consumed. 31. Percentage of ash and refuse in dry coal.	lbs.
Proximate Analysis of Coal	
32. Fixed carbon per cent	Combustible. per cent per cent

<sup>\*</sup>The items printed in italics correspond to the items in the "Short Form of Code."

36. Sulphur, separately determined.....

100 per cent per cent 100 per cent per cent

		,					
37. 38. 39. 40. 41. 42.	Carbon (C). Hydrogen (H). Oxygen (O). Nitrogen (N). Sulphur (S). Ash.	oal	Of Coal. per cent per cent per cent per cent per cent per cent	per per per	mbustible. r cent r cent r cent r cent r cent r cent		
	_	100	per cent	100	per cent		
43.	Moisture in sample of coal as received		per cent		per cent		
	Analysis of Ash and Refus	3 e					
44. 45.	Carbon Earthy matter				per cent		
	Fuel per Hour						
46. 47. 48. 49.	Dry coal consumed per hour	r hou			lbs. lbs. lbs. lbs.		
	Calorific Value of Fuet						
50. 51. 52. 53.	Calorific value by oxygen calorimeter, per lb. of dry coal Calorific value by oxygen calorimeter, per lb. of combustible Calorific value by analysis, per lb. of dry coal Calorific value by analysis, per lb. of combustible	le			B. T. U B. T. U B. T. U B. T. U		
	Quality of Steam						
54. 55. 56.	Percentage of moisture in steam						
	Water						
57. 58, 59. 60. 61.	Total weight of water fed to boiler. Equivalent water fed to boiler from and at 212 degrees. Water actually eraporated, corrected for quality of steam. Factor of evaporation Equivalent water evaporated into dry steam from and at 59 × Item 60.)	t 212	degrees. (	Item	lbs. lbs. lbs. lbs.		
	Water per Hour						
62. 63. 64.	Water eraporated per hour, corrected for quality of steam. Equivalent eraporation per hour from and at 212 degrees. Equivalent eraporation per hour from and at 212 degree water-heating surface.	s per	square foo	t of	lbs. lbs.		
	Horse-Power						
<b>6</b> 5. 66. 67.	Horse-power developed. (34½ lbs of water evaporated per from and at 212 degrees, equals one horse-power.). Builders' rated horse-power Percentage of builders' rated horse-power developed				H. P. H. P. per cent		
	Economic Results						
68.	Water apparently evaporated under actual conditions per p (Hem 57 ÷ Hem 25)	ound	of coul as )	Ared.	lbs.		
69.	(flem 57+ flem 25.) Equivalent evaporation from and at 212 degrees per pou (flem 61+ flem 25.)	ind o	t coul as	fired.	lbs.		
70.	(Item 61 ÷ Item 25.)  Equivalent evaporation from and at 212 degrees per (Item 61 ÷ Item 27.)	рои	nd of dry	coal.	lbs.		
71.	(Hem 61+ Hem 27.) Equivalent eraporation from and at 212 degrees per p (Hem 61+ Hem 30.)				lbs.		
	(If the equivalent evaporation, Items 69, 70 and 71, is no quality of steam, the fact should be stated.)	ot co	rrected for	the			
	Eficiency						
72. 73.	Efficiency of the boiler; heat absorbed by the boiler per p divided by the heat value of one pound of combustible Efficiency of boiler, including the grate; heat absorbed by the of dry coal, divided by the heat value of one pound of d	he bo	iler, per pe	ound	per cent		

	Cost of Etaporation	
74. 75. 76.		\$ \$
	Smoke Observations	
77. 78. 79.	Percentage of smoke as observed.  Weight of soot per hour obtained from smoke meter.  Volume of soot per hour obtained from smoke meter.	per cent ounces cu. in.
	Methods of Firing	
81.		•
83.	are in normal condition	
	Analyses of the Dry Gases	
86.	Carbon dioxide (CO <sub>2</sub> ) Oxygen (O) Carbon monoxide (CO) Hydrogen and hydrocarbons Nitrogen (by difference) (N)	per cent
		100 per cent
	HEAT BALANCE, OR DISTRIBUTION OF THE HEATING VALUE OF THE COMB TOTAL HEAT VALUE Of 1 lb of CombustibleB.	
	B.T.U.	Per Cent
2. 3.	Heat absorbed by the boiler = evaporation from and at 212 degrees per pound of combustible $\times$ 965 7.  Loss due to moisture in coal = per cent of moisture referred to combustible÷ $100 \times [(212-t)+966+0.48(T-212)]$ ( $t=$ temperature of air in the boiler room, $T=$ that of the flue gases)  Loss due to moisture formed by the burning of hydrogen = per cent	v
	of hydrogen to combustible $\div$ 100 $\times$ 9 $\times$ [ (212-t) $\div$ 966 $\div$ 0, 4x( $T$ $\div$ 212) ] Loss due to heat carried away in dry chimney gases $=$ weight of gas per pound of combustible $\times$ 0.24 $\times$ ( $T$ $\div$ 1).  Loss due to incomplete combustion of carbon $=$ $\frac{\text{CO}}{\text{CO}_2 + \text{CO}}$ $\times \frac{\text{per cent C in combustible}}{100} \times 10,150$ .  Loss due to unconsumed hydrogen and hydrocarbons, to heating the moisture in the air, to radiation, and unaccounted for. (Some of these losses may be separately itemized if data are obtained from which they may be calculated.)	

\*The weight of gas per pound of carbon burned may be calculated from the gas analyses as follows:

 $11 \, \text{CO}_2 + \text{SO} + 7 \, \text{CO} + (\text{N})$ in which CO<sub>2</sub>, CO, O, and N are the Dry gas per pound carbon =

percentages by volume of the several gases. As the sampling and analyses of the gases in the present state of the art are liable to considerable errors, the result of this calculation is usually only an approximate one. The heat balance itself is also only approximate for this reason as well as for the fact that it is not possible to determine accurately the percentage of unburned hydrogen or hydrogen for high reason. hydrogen or hydrocarbons in the flue gases.

The weight of dry gas per pound of combustible is found by multiplying the dry gas per pound

of earbon by the percentage of carbon in the combustible, and dividing by 100.

†CO<sub>2</sub> and CO are respectively the percentage by volume of carbonic acid and carbonic oxide in the flue gases. The quantity 10,150 — Number of heat units generated by burning to carbonic acid one pound of carbon contained in carbonic oxide.

#### STARTING AND STOPPING THE TEST

Standard Method.—Steam being raised to the working pressure, remove rapidly all fire from the grate, close the damper, clean the ash-pit, and as quickly as possible start a new fire with weighed wood and coal, noting the time and the water level while the water is in a quiescent state, just before lighting the fire. At the end of the test, remove the whole fire, which has been burned low, clean the grates and ash-pit, and note the water level when the water level is in a quiescent state, and record the time of hauling the fire. The water level should be as nearly as possible the same as at the beginning of the test. If it is not the same a correction should be made by computation, and not by operating the pump after the test is complete.

Alternate Method.—The boiler being thoroughly heated by a preliminary run, the fires are to be burned low and well cleaned. Note the amount of coal left on the grate as nearly as it can be estimated; note the pressure of steam and the water level. Note the time and record it as the starting time. Fresh coal, which has been weighed, should now be fired. The ash-pits should be thoroughly cleaned at once after starting. Before the end of the test the fires should be burned low, just as before the start, and the fires cleaned in such a manner as to leave a bed of coal on the grates of the same depth and in the same condition as at the start. When this stage is reached, note the time and record it as the stopping time. The water level and steam pressure should previously be brought as nearly as possible to the same point as at the start. If the water level is not the same as at the start, a correction should be made by computation, and not by operating the pump after the test is completed.

The two methods given above for starting and stopping the test are taken from the A. S. M. E. Code for conducting steam boiler trials. When the alternate method is used, several precautions regarding the observations are necessary. The time of starting and stopping should be noted when the smallest amount of fuel is on the grate, and when it is in the most burned-out condition, i. e., just before firing fresh coal after cleaning, and when the water level is in its most quiet condition and the least raised by ebullition. This condition of fire and of water level can be duplicated immediately after cleaning the fire, but there is no certainty of duplication of any condition when there is a bright fire

BRECKENRIDGE,

and consequent rapid steaming. If the water level is noted at the starting of the test when it is raised by a bright fire, and at the end of a test when it is depressed by the stoppage of violent ebullition or of rapid circulation due to the cooling of the fire, the boiler will be credited with more water than was really evaporated. As such a fall in water level is easily produced by opening fire doors and checking draft, it should be guarded against especially when using bituminous or flaming coals. The greatest care should also be taken that the bed of coal at the end does not contain more waste material, which belongs to the ash, than it did at the beginning.

#### Computation of Results

On account of the variations in the types of boilers and furnaces, no specific directions can be given for the measurement of grate surface, height of furnace and other furnace proportions. The heating surface should be computed from the surface of shells, tubes and fire-boxes in contact with fire or hot gases. The outside diameter of water tubes and the inside diameter of fire tubes should be used in this computation. All surfaces below the mean water level which have water on one side and products of combustion on the other are to be considered as water-heating surface, and all surfaces above the mean water level which have steam on one side and products of combustion on the other are to be considered as superheating surface.

The following directions show how some of the results to be derived from a boiler trial may be obtained. The calculation of other items is self-evident.

Item 26, the moisture in the coal, should be obtained by the chemist by drying the sample collected during the test, for one hour in a sand or air bath at a temperature between 240° and 280° F. Sometimes the moisture is obtained by drying a known quantity of the coal above the boiler; however, if this method is used, it should be so stated in the report. The first method is always to be preferred. (See Section VI, page 48).

Item 27=Item  $25 \times (100-Item 26)$ 

Item 30=Item  $27 \times (100$ -Item 42)-(Item  $28 \times$ Item 44)

As this is dependent upon the ultimate analysis of the coal, which is not always available, the following may be used:

Item 30=Item 27-Item 28

The latter, however, is in error, due to the unaccounted-for ash passing over the bridge wall.

Item 
$$51$$
=Item  $50 \div (100$ -Item  $42)$   
or =Item  $50 \div [\text{Item } 27 - (\text{Item } 28 \times \text{Item } 45)]$ 

in which the former depends again upon the ultimate analysis of the coal.

Items 52 and 53=14,600 C+62,000(H
$$-\frac{O}{8}$$
)+4,000 S,

in which C, H, O and S refer to the proportions of carbon, hydrogen, oxygen and sulphur respectively, as determined by the ultimate analysis.

Item 
$$54 = 100 \times \frac{\text{H} - 1146.6 - 0.48 (T - 212)}{\text{L}}$$
  
or  $= 100 \times \frac{\text{lbs. of moisture separated}}{\text{lbs. of steam+lbs. of moisture separated}}$ 

in which H=total heat and L=latent heat per pound of steam at the pressure in the steam pipe, and T=temperature of the throttled and superheated steam in the calorimeter. The first formula applies to throttling and the second to separating calorimeters.

Item 55 should be taken as the difference between the reading of the thermometer for superheated steam and the readings of the same thermometer for saturated steam at the same pressure as determined by a special experiment and not by reference to the steam tables.

For the exact determination of the factor of correction for quality of steam we have the following:

For wet steam, 
$$F=Q+P(\frac{T_1-J_1}{H-J_1})$$
, and

For superheated steam, 
$$F=1+\frac{0.48 \text{K}}{\text{H}-\text{J}_1}$$
, in which

F = factor of correction

Q = quality of steam

P = per cent of moisture in steam

K = degrees of superheating in steam

H = total heat of the steam due to the steam pressure

Ti= total heat in the water at the temperature due to the steam pressure

J<sub>1</sub>== total heat in the feed water due to the temperature Item  $59 = \text{Item } 57 \times \text{Item } 56$ 

Item  $60 = \frac{H - h}{965.7}$ , in which H and h are respectively the total

heat in the steam of the average observed pressure and in water of the average observed temperature of the feed. This item may usually be obtained directly from steam tables giving the factors for different pressures and feed water temperatures.

Item  $61 = \text{Item } 59 \times \text{Item } 60$ 

Item  $62 = \text{Item } 59 \div \text{Item } 2$ 

Item  $63 = \text{Item } 61 \div \text{Item } 2$ 

Item 64 = Item 63 ÷ Item 7

Item  $65 = \text{Item } 63 \div 34.5$ 

This is held to be equivalent to 30 pounds of water evaporated from 100° F. into dry steam at 70 pounds gage pressure. The former equals 33,317 B. T. U. per hour and the latter 33,305 B. T. U. per hour.

Item 66.—This item should give besides the rated horsepower the basis (square feet of heating surface) upon which this rating is made.

Item  $67 = \text{Item } 65 \div \text{Item } 66$ 

The necessary computations for economic results and efficiency, items 68 to 73, are indicated in the form of report.

#### IV REPORT OF BOILER TESTS WITH ILLINOIS COALS

The following tables contain a summary of the results of boiler tests made by the department of Mechanical Engineering at the University of Illinois. For the most part these tests have been made, as stated in the introduction, for purposes of instruction in the method of boiler testing, although a considerable number were made for investigational purposes or as thesis work. As a rule, they have been conducted under the direct supervision of a member of the instructional staff of the department, but at times when experiments were being made with special appliances, the representative of the company interested was present to take charge of the test.

#### COALS TESTED

The coals used in these tests were mostly those purchased under the yearly contracts of the University. In a few cases, special coals were purchased, while other tests were made on coals sent to the University by various coal companies and manufacturing concerns to determine the evaporative efficiency or their behavior on various kinds of stokers.

35 coals were tested, representing 14 counties of Illinois. These are given in the list below together with the commercial size of the coal.

	County	Town	Commercial Size
I	Christian	.Pana	Lnmp
2	Christian	.Pana	Slack
3	Christian	. Pana	Srceenings
4	Coles	.Paradise	Lump
5	Gallatin	.Junction	Pea
6	Macon	. Niantie	Nut
7	Macoupin	. Mt. Olive	Lump
8	Madison	.Glen Carbon	Lump
9	Marion	.Odin	Lump
10	Marion	.Odin	Pea
11	Marion	.Odin	Slack
12	McLean	.Bloomington	Lump
13	McLean	.Colfax	Lump
14	Menard	.Athens	Lump
15	Perry	.Du Quoin	Lump
16	Perry	.Du Quoin	Pea
17	Perry	.Du Quoin	Slack
18	sangamon	Barelay	
19	Sangamon	.Dawson	Pea
20	Sangamon	.Divernon	Lamp
21	Sangamon	.Lowder	Slack
22	Sangamon	.Ridgely	Pea
23	Sangamon	.Riverton	Pea
24	Sangamon	.Sringfield	
25	Sangamon		Lann
26	Shelby	. Moweagua	Lump
27	Vermilion	.Catlin	Screenings
28	Vermilion	. Fairmount	Screenings
29	Vermilion	. Muncie	Slack
30	Vermilion	.Oakwood	Lnmn
31	Vermilion	Oakwood	Pea
32	Vermilion	.Oakwood	Screenings
33	Williamson	.Carterville	Washed Pea
34	Williamson	. Herrin No	w Kentucky Pea
35	Williamson	. Herrin New Ken	tneky Screenings

#### Boilers Tested

The tests were made at the power plants of the University and the neighboring towns, under water-tube and fire-tube boilers of the following types:

Stirling water-tube boiler. 2 settings
National water-tube boiler. 2 settings
Heine water-tube boiler. 1 setting
Babcock & Wilcox water-tube boiler. 8 settings
Horizontal tubular boiler. 11 settings

The settings of these boilers include the following:

- 1 Murphy smokeless furnace
- 2 Roney automatic stokers
- 2 Green chain grate stokers

- 1 Babcock & Wilcox chain grate
- 1 Brightman stoker

The remainder of the furnaces were hand-fired with plain or rocking grates.

#### RESULTS OF TESTS

The results of these tests are shown in Tables III and IV, arranged according to the counties in which the coal was mined. Table III gives the conditions of temperature, pressure, heating surface and grate area under which the tests were made, and Table IV gives a few of the most important results. In some cases the heat value of the coals used was not obtained and several of the columns dependent upon it are left vacant. The headings of the tables are self-explanatory. Where a series of tests was made with the same coals under like conditions, the average of the series is reported together with the number of tests in the series. Where the coal and steam have been assumed moisture free and when the moisture in the coal was obtained by drying a known amount above the boiler, indications have been made in the tables.

In the computation of results, the usual correction for quality of steam by proportional weights of steam and water was used. The combustible was computed from the weights of coal and ash and not from the ultimate analysis of the coal, and it is, therefore, in slight error to the extent of the ash which passed over the bridge wall. The basis for the rating of the boilers varied from 10 to 15 square feet of heating surface per horse-power according to the different types of boilers used. The B. T. U. of the coal, given in the table, were obtained from an analysis of the sample taken during the test.

#### DISCUSSION OF RESULTS

On account of the wide variation of conditions obtaining in the tests reported, an exact comparison was hardly possible. A general comparison of results with different types of boilers and grates has, however, been attempted. Such a comparison is shown in Table V, which contains the general average of the results of all trials made with the same type of boiler and grate, irrespective of all other conditions. It also shows the average of

TABLE III BOLLER TESTS WITH ILLINOIS COALS MADE BY THE MECHANICAL ENGINEERING DEPARTMENT, University of Illinois, 1894-1905. General Description and Proportions

								ĺ				
eseri	Description of Coals	13.				lsirT	-			rber		səsrə ə
	E	Commercial	Type of Boiler and Grate	Location of Boiler	Date of Trial	lo noiternu	Grate Surface	Water Heati Surface	Steam Pressi Gage Force of Dra	tween Dam	Temperature Feed Wate	Temperature ouly unique
	10001	Size		,		SinoH	Sq. ft.	Sq. ft.	Lbs.	Inches, Water	ok'ahr,	oFahr.
			A. S. M. E.	Code No.	1	2	က	2	=	12	50	21
	Christian   Pana	Slack		Urbana & Cham.	June 1891	10.12	52.1	2340	90.3	088	59.1	498
:	до	Pea	plain grate	do	June 1891	10.00	51.0	5584	91.3	9 055	6.09	484
:	ор	Screenings	ор	ор	June 1894	10.00	51.0	2264	95.9	9 008.	0.09	464
	ор	Lump and slack	:	ор	June 1894	10.18	51.0	3264	95.0	.325 6	60.7	529
<u> </u>	Paradise	Lump	Hor, Tub. No. 2, plain grate	Univ. of Illinois. M. E. Lab	Feb. 1897	8.00	18.7	533		.405 4	47.5	5.19
	Junction	Pea	National W. T. No. 4 Univ. of Illinois Murphy furnace   Cent. Heat. P 18. & W. No. 5.   do	Univ. of Illinois. Cent. Heat. Pl'nt. do	Mar. 1899 Jan. 1895	7.35	51.0	2579 1	108.1	300	49.1 49.6	481
-	Mt Olive	Lump	plain grate Hor. Tub. No. 2.	Univ. of Illinois.	43 3.	9	1			470 4	47.0	567
	Glen Carbon	Lump	plain grate B. & W. No. 2,	M. E. Lab Univ. of Illinois.	Feb. 1887	8 8	7.00	1456	c. e. e.	9 009.	0.00	571
	Odin	Lump	Hor. Tub. No. 1,	Univ. of Illinois,	May 1501	0 :				296	56.3	489
-	ор	Lump	plain grate Hor. Tub. No. 2.	M. E. Labdodo	Apr. 1895 Apr. 1895	10.10	. 7. . 0.	553	59.0	300	53.7	089
	do	Pea	: :	ф	June 1896	9.50	18.7	533	67.8	.163 6	61.1	508
-	do do		Hor. Tub. No. 1, plain grate	ф	Oct. 1896	8.00	16.6	542	73.0	.200	59.6	494

359	260	21.5	544	482	<del>291</del>	591	503	578	:	:	523	528	503	535	519	515	120	403	523	503	512	453	495
0.821	52.9	50.9	21.8	59.5	45.0	178.5	53.0	59.9	53.6	70.5	50.6	63.6	61.6	177.7	ž.	49.8	69.3	100.1	53.4	59.1	60.6	28.01	19.5
198.	918.	933	.250	910	. 730	.650	.515	£16.	.300	.500	.190	938	180	.320	.957	303	.700	.300	009.	.540	.600	325	.550
20.8	69.4	87.8	83.0	58.5	106.4	110.6	₹. ₩	65.6	.3.6	106.3	13.53	63.1	69.0	93.0	65.6	68.3	108.5	38 38 38 38	105.8	101.3	102.3	119.0	106.5
2260	1010	2450	195	1965	5564	2587	2579	533	2450	1486	533	547	533	870	1010	2450	5504	:	2150	9579	1486	22	2579
45.0	30.0	51.0	13.5	51.0	51.0	50.9	60.7	18.2	51.0	35.0	18.7	16.6	18.7	99.5	30.0	51.0	51.0	25.0	51.0	60.7	28.0	98.0	60.7
8.00	9.38	∞ ∞ 17 S	£	10.00	x 000	23.60	×.00	10.76	6.00	8.00	7.83	8.00	9.53	8.00	9.00	9.50	19.00	7.50	8.00	8.00	8.00	8.00	8.00
1897	1895	1895	1896	1881	1896	1905	1899	1895	1891	1905	1897	1895	9681	1898	1895	1895	1901	1898	1899	1899	1901	1904	6681
Jan. 1897	Mar. 1895	Jan. 1895 Mar 1899	Nov. 1896	June 1894	Dec. 1896	Mar. 1905	Jan. 1899	Feb. 1895	Dec. 1891	May 1902	Mar, 1897	Oct. 1895	June 1896	Apr. 1898	Feb. 1895	Feb. 1895	Mar. 1901	Apr. 1898	Mar. 1899	Mar. 1899	May	Apr.	Feb, 1899
3, 4	Hor. Tub. No. 4. Univ. of Illinois rocking grate Cent. Heat. Pl'nt.	B. & W. No. 5, plain grate do	Stirling No. 3.	្ត		plain grate do do	- ÷	î :	B. & W. No. 5, Univ. of Illinois.	B. & W. No. 1, Univ. of Illinois, plain grate Cent. Heat. Pl'nt	Hor. Tub. No. 2.		Hor. Tub. No. 2, plain gratedo	Hor. Tub., plain grate do	o. 1.	13. & W. No. 5, Univ. of Illinois, plain grate Cent. Heat. Pl'nt	13. & W. No. 2, plain grate do	te	B. & W. No. 5 & 6, Decatur, Illinois.	Nat. W. T. No. (, Univ. of Illinois. Murphy furnace Cent. Heat, Pl'nt	B, & W. No. 2, chain grate do	do do Mar W Wo 4	
Pea	Lump	Lump	Eump	Lump	Stack	Duff	Pea	Lump	Lump	Lump	Lump	Lump	Lump	Slack	Lump	Lump	Pea	Pea	Pea	Pea	Lump	Slack	1.62
do	до	do	do	do	do	ф	do	Bloomington	do	Colfax	Athens	Du Quoin	do	ф	do	до	op	Barclay	Dawson	ор	Divernon		Klagely
ор	do	do	do	до	do	do	ор	McLean	ф	do	Menard	Perry I	ор	do	op	do	do	Sangamon I	do	do	do	do	
14	15	91	2 2 2	19	08	es I	55	53	2:I	25	98	22	٠ 0	ಿಕ	30	31	33	33	97	32	36	37	200

TABLE III (Concluded)

10   10   10   10   10   10   10   10	8. 4. 7.7.0.7.4. 6. 9. 8. 6. 40.
.640 57.1 519	8.201
.620 63.5	
,370 73.6	
.360 79.8	
79.3	
48.0	10.
65.2	114.4
580 73.0	115.0
.700 63.7	113.7
9.09	119.4
18.3	
20	
Water •Fahr.	=
tween Damper and Boiler Temperature of Feed Water Temperature of Es-	E Sq. in.

487	301	631 616	292	58-5	593 609	53.1	657
54.0	110.0	200.0	178.0	63.5	98.3	65 0	57.8
.740	.430	.790	.330	.710	2336	540	991 -
8.00 51 0 2264 108.2 .740	74.8 .430 110.0	119.3	10.33 61 0 2860 102.0	8 03 72 0 3160 111.9	133.2 .236 132.9 .236	117.0	Peb. 1904   12.00 51.0 2353   117.9 .166
2264	10.00 22.5 1060	25587 25587	2860	3160	2353	1486 1486	9353
51 0	33.2	21.00 50.9 10.80 50.9	61.0	7.5 0	10.00 51.0 10.00 51.0	0 0 0 0	51.0
8.00	10.00	21.00 10.80	10.33	8 03	10.00	9.33 28 0	12.00
1896	Nov. 1895	1905 1905	1905	May 1905	1905 1905	1901	1904
Dec. 1896	Nov.	Mar. 1905 Apr. 1905	Apr.	May	Nov.	Apr. 1904 Apr. 1904	Feb.
Screenings R. & W. No. 2, Urbana & Cham. Plain grade Elec. J. & P. Co. Slack Hor. Tub. No. 2 & 3 Urbana & Cham.	plain grate Water Works Stirling No. 7 & 8, Urbana & Chan.	Screeningsdo	plain grate do	Pea B. & W. No. 6,   Univ. of Illinois.	W. Peak duff do	do W. Sere'n do do do W. Sere'n sk W. Wo. 5 & k.	Roney stokerdodo
Sereening Slack	Lump	Screening	Screening	Pea	W. Pea&d New Ky. 1	do W. Ser do W. Ser	
Fairmount	Oakwood		:	ф			
55 do 56	57 do	58 do do do	60 do do	ob ob	62 Williamson Carterville 63 do Herrin	64 do do do	
55	57	55	09	61	2 83	253	

TABLE IV BOILER TESTS WITH ILLINOIS COALS MADE BY THE MECHANICAL ENGINEERING DEPARTMENT

## University of Illinois 1894-1905 Averaged Results

1		Efficiency of Boiler including Grate	8	73	59.6			
	ìo	B. T. U. per pound		20	11430			11070
	ation Fahr.	Per pound of Combustible	lbs.	71	0.00 51- 1- 8.00 51- 1- 8.00 81- 1-	7.09	7. 7. 7. 7. 7. 7. 7. 7. 7. 7. 7. 7. 7. 7	7.73
Ì	Equiv. Evaporation from and at 212º Fahr.	Per pound of Dry	lbs.	20	6.50 6.50 6.50 6.50	6.36	6.96	6.13
ľ	Equiv.	Per sq. ft. of Waterheating Surface per hr.	lbs.	64	1.66 1.166 1.75 1.99	2.76	3.38	2.97 1.59 1.59
	pədo	Percentage of Rate Horsepower Develo	8	2.9	130 93.57 7.37 7.37 7.30 7.30 7.30 7.30 7.30 7.3		130.2	91.5
	ped	Horsepower Develop		99	108.5 110.8 114.9 196.4		52.1	36.6 45.9 24.6 35.5
Ì		Dry Coal per sq. ft. Grate Surface per b	lbs.	49	15.10 13.80 14.90 20.40	18.13	13.79	13.63 13.63 8.41 11.99
	eraged	Number of Tests Av	See	No.	‡±±± °	* * *	Ø₹ 65	- ***
		Type of Boiler and Grate		A. S. M. E. Code	B. & W. No. 1 & 2. plain grate  do do do do do in for Tub. No. 2. plain	National W. T. No. 4 Murphy furnace  13. & W. No. 5. plain graabe	grate	Frate. Hor. Tub. No. 2. plain grate. d do. Hor. Tub. No. 1. plain grate.
	,	Commercial Size			Slack. Pea. Screenings. Lump and Slack. Lump	PeaNut	Lump	Lump
	Description of Couls	Town			Pana do do do Paradise		nve Carbon	op
	Des	County			Cbristian do do do Coles	Gallatin		Marion do do do
			TPGL	unn	- 01 to + 10	2 0	oo ca o	252 = 0

:	:	:	. 10	:	. 20	:	:	:	4.06		66			63.1		:	:		:		
:	:	:	11633	:	11.85	:	:	:	12025		11250	:	:	00211	:	:	:		:	:	11700
7.49	1.00.7 1.00.7	7.00	25.55 .63.56 .63.56	6.51	6.83 E.E.	7.13	8.01	6.26	6.64	7.00	6.49	6.85	8.60	8.30	6.0.	5.87	7.75	7.64	6.21	6.98	7.06
699	6.91	5.91	6.92	5.74	5,92	5.86	6.61	5.30	5.06	6.49	. 5. 5. E.	6.15	7.10	00 01 17	6.5%	5.00	6.74	6.34	5.18	5.43	5.69
1.29	4.61	3.48	3.37	1.97	3.14	3.90	19.6	8.73	2.70	90.6	. <u>s</u>	1.59	2.93	00.1	2.68	x.	:	£	€0.04	~6·6·	25.25 - 10
47.0	135.0	£.	126.3	61.5	98.0	× 58.	101.7	88.	10,77	102.5	21.5	61.5	123.3	117.0	86.5	56.4	:	123.6	60.09	83.9	69.0
84.6	135.0	176.4	555.7	1.99.1	205.8 382.6	216.9	40.7	194.2	116.3	11.0	28.6	91.6	73.9	117.0	190 3	X X	118.7	543.7	15.9 9	125 9	103.5
10.31	99.49	20,30	27.10 19.91	15.20	23.51 20.78	21.01	11.34	24.76	0	11.63	10.66	7.37	15.96	18.21	19.59	16.06	24.31	29.00	15.95	28.60	99.40 18.00
23	, (c)	2	{~	+		÷1	*()1	*_	25	©₹	**	τì		*	Ğ.	23	es.	-	ಣ	ಣ	6: 9
Hor. Tub. No. 3 & 4	Hor. Tub. No. 4	I & W No. 5 plain	do No. 3 plain	B & W No. 2 plain	Stirling No. 7 & 8	National W. T. No. 1	Hor. Tub. No. 2 plain	R & W No. 5 plain	B & W No. 1 plain	Hor. Tub. No. 2 plain	Hor. Tub. No. 1 plain	Hor. Tub. No. 2 plain	grate. Hor. Tub. plain grate	Hor. Tub. No. 4	B & W No. 5 plain	B & W No. 2 plain	Hor. Tub. rocking	B & W No, 5 & 6 plain	National W. T. No.4	Murphy furnace B & W No. 2 chain	do
Pea	Lump	Lump	Реа Ентр	Lump	Slack	Pea	Lump	Lump	Lump,	Lump	Lump	Lump	Slack	Cump	Lump	Pea	Pea	Pea	Pea	Lump	Shack
do	ор	ф	op	do	do	do	Bloomington	до	Colfax	Athens	Du Quoin	фо	do	do	do	do	Barchay	Dawson	до	Diversion	LowderRidgely
ор	ф	do	do do	do	do	ор	McLean	ор	do	Menard	Perry	do	ob	ф	ор	ор	Sangamon	do	ор	op	do
7	15	16	128	10	8.5	€.	23	61	25	- 9ë	27 I	882	68	30	31	33	33	34	35	36	38.7

‡t'out assumed dry. †Moisture obtained by drying coal above boiler, \*Steam assumed dry.

TABLE IV (Concluded)

					***				721 1	. k.	.1777	10	11			
	Efficiency of Boiler including Grate	2	73	<u>:</u>	62.2	51.7	62.2	47.0	55.1	52.4	51.5		:	49.8	39.7	48.3
lo	B. T. U. per pound Dry Coal		90	*	9975	11152	11152	11287	11980	11930	12162 11537		:	18231	13026	12369
ation Fahr.	Per pound of Combustible	lbs.	71	6.76	S. 15	7.39	00 00 00	6.23	7.83	17	8.21	5.18	7.75	7.79	6.27	8.15
Equiv. Evaporation rom and at 212º Fahl	Per pound of Dry	lbs.	02	6.07	6.43	5.96	7.11	5.19	6.84	6.17	6.13	1.9.1	6.16	6.51	5.35	6.19
Equiv. Evaporation From and at 212º Fahr.	Per sq. ft. of Waterheating Surface per hr.	lbs.	64	5.7.	3.39	3.85	2.07	22	3.13	99.2	4.61	2.58	1 09	3.41	650.00	1.58
pado	Percentage of Rates Sayad 197009870H	26	29	82.1	105.3	123.4	76.6	6.09	130.7	76.4	131.3	€: E	117.5	101.4	77	66.7
peq	Horsepower Develor		65	205.2	463.1	165.7	114.0	91.1	18.3	114.6	335.8	111.3	176.3	1.888	164.4	100.1
t, of T hr.	Dry Coal per sq. f Grate Surface pe	lbs.	48	19.31	24.30	34.30	8:36	20.50	13.00	21.x1	30.52	25.70	28.20	24.37	20,78	11.27
raged	Symplet of Tests Ave	See	No.	ಣ	-	- co ·		10		©5	- T	÷ 63	Ġ₹	© ₹	*	
	Type of Boiler and Grate		A. S. M. E. Code h	National W. T. No. 4 Murphy furnace	Roney stoker		do	Hor. Tub. No. 9 ntain	grate B. & W. No. 2 chain	==	- G	rate.	rate No 6 1	stoker 8 & W No 5 plain	grate Murray Hor. Tub.	No. 1. 2, 3. rocking grate
als	Commercial Size			PeuPea	Pea	Pett	Pen	Pea	Pea	Pea	Pea	Pen	Pea	Lumn	Screenings	
Description of Coals	Town			Rivertondo	do	do	do	αο			Springfleld	do	do	113		
I	County			Sangamon	do	do	do .	0p	ф	do	do	ор		Shelby		
	T	ımpe	nN	39	971 171	€. c.	7	46	47	90	50	51	52	53	54	

39.2	:	51.0	57.9	47.1	8.99	59.1	58.6	55.5	55.0	60.5
19413	:	12503	11427	10239	11067	13251	13408	12769	13156	12364
5.95	7.50	8.07	8.30	6.59	9.64	30.50	8.89	8.74	8.89	9.21
5.08	6,07	6.63	6.85	5.03	7.66	7.15	8.14	7.34	7.50	7.75
3.51	1.76	3.33	23.33	2.01	4.18	3.39	3.52	4.55	4.88	4.55
109.6	63.5	95.7	97.6	6-1-9	109.3	98.3	103.3	130.7	140.2	139.1
230.1	107.9	497.6	507.4	166.9	388.7	230.9	240.2	196.0	210.3	620.7
30.67	13.62	25.45	25.09	17.91	23.94	22.40	19.96	32.93	34.60	26.55
1	1+		_, .	_	G E	es :	20	ಣ	-	_
B. & W. No. 2 plain grate Hor, Tub, No. 2 & 3	plain grate Stirling No. 7 & 8	plain grate	OD CO	B. & W. Plain grave	Heine chain grate B. & W. No. 6 Roney	stoker	New Ky. Pea B. & W. No. 2 chain	grate	B. & W. No. 5 & 6	Roney stoker
Screenings	Lump		:	:	Pea	TX7 13 0. TX.: 60	W. rea & Dun		do W. Screen	
Fairmount	Oakwood	do		:	do	0110	Herrin		do	
do	до	olo olo	op	do	do	Williamson	do	20	op	
55	22	NO.	300	000	61	669	3 83	6.1	53.5	

\*Steam assumed dry. †Coal assumed dry. †Moisture obtained by drying coal above boiler.
NOTE: Column headed "Number of Tests Averaged" gives the number of boiler tests, the average of whose results is recorded in the Table.

the results of the ten highest tests together with the single highest result obtained. The basis of comparison is the equivalent pounds of water evaporated from and at 212° F, per pound of dry coal. The same table also contains the average of the results of six tests with Illinois coals made by the Boiler Division of the Fuel Testing Plant of the United States Geological Survey at St. Louis. It is interesting to note that in these latter tests in which hand-firing and plain grates were used, the results obtained are better than any of the others recorded, including the results of tests in which mechanical stokers were used. This fact may be taken to indicate that the maximum efficiency of Illinois coals is rarely obtained under present average conditions. It is probable that with a closer study of furnace conditions, even these results may be improved. The general tests reported in Tables 3 to 5 include a number of trials made with special objects in view. Several of these trials are described as follows:

1. Tests of a small horizontal tubular boiler of 40 horsepower, to determine its performance with varying rates of combustion. The results of these tests are given below.

RESULTS OF A BOILER TRIAL SHOWING EFFECTS OF RATE
OF COMBUSTION ON THE PERFORMANCE OF
HORIZONTAL TUBULAR BOILER

Dry coal per square foot of grate surface per hour Equivalent evaporation	6.80	9.30	11.00	12.00	14.00
from and at 212° F. per pound of dry coal	6.20	6.55	6.57	6.37	5.75
Horse-power in per cent of rated capacity (40) Temperature of escaping	52 50	87.50	107.50	115.00	122.50
gases	432.00	447.00	501.00	516.00	553.00

The same kind of coal was used in all these tests, and conditions remained nearly constant. It is evident that the maximum results were obtained with the boiler running at its rated capacity, with the flue gas temperature about 500° F. With an increase in the rate of combustion, the capacity and flue gas temperature increased and the evaporation dropped off.

2. Tests to determine the effect of soot deposits on the evaporation of a small horizontal tubular boiler. These tests were made on the same boiler as the preceding series and with results as follows:

### RESULTS OF BOILER TRIALS MADE TO DETERMINE THE EFFECT OF SOOT DEPOSITS ON THE EVAPORATION OF A HORIZONTAL TUBULAR BOILER

	First Series (5 days) Soot allowed to remain on tubes	Second Series (5 days) Tubes cleaned each morning	Third Series (5 days) Soot allowed to remain on tubes
Equivalent evaporation from and at 2130 F. per pound of dry coal	6.20	7.04	6.23
Dry coal per sq. ft. of grate surface per hour	13.40	9.09	13.40
Horse power in per cent of rated capacity	111.00	99.00	115.00
Temperature of escaping gases	627.00	546 00	698.00

It is evident from the results that the effect of the soot deposit on the evaporation is not very marked. It is interesting to note that in the first and last series, in which the soot was allowed to remain on the tubes, the soot burned upon reaching a certain thickness, leaving but a very thin layer. In all three series the conditions were held as nearly constant as possible, although in the second series the load fluctuated somewhat on the different days.

TABLE V COMPARISON OF RESULTS OF BOILER TESTS WITH LILINOIS COALS ON

		Eff. of Boiler and Grate	73	51.2	51.2	00.00	52.5	59.9		63.7	53.4	59.6	51.8	57.9	: :	:	59.3
		B. T. U. Per lb. of Dry Coal	20	13034	13034	1,4004	11562	11821		11809 11809 11850	11532	11430	11608	11497		:	12293 12857
	d A. 2120	Per lb. Per lb. of of Combus-bry Coal	7.1	50	∞ c	T	38.7	9.01		8.1.5 8.30 8.30	7.85	200	7.85	8.39	6.64	7.09	9.81
	Equiv. Evap. F. and A. 2120	Per lb. of Dry Coal	20	200	25.5	61.1	6.39	7.33		6.81 7.38	6.38	7.05	5.75	6.85	5.87	6.36	7.55
ERS	Equiv. E	Per sq. ft. of Heating Surface per hr.	64	3,57	3.57	201	3.43	3.76		3.70	3.16	3.87	3.98	3.38	2.53	2.76	3.36
IBE BOIL	ower	Per cent. ft. of of rating Heating Dev p'd Surface per hr.	29	105	105	162	98	108		113	95	130	7.9	88	3.6	27	28.
ATER-TU	Horse-power	Develop'd Per cent by of rating Boiler Dev'p'd	65	305	305	:	180	30°3		191 191 117	45		176 220	207	189 205	202	198 201
HORIZONTAL TUBULAR AND WATER-TUBE BOILERS		Dry Coal per sq. ft. of Grate Surface Per hr.	- 48	2. 66	27 E	6.05	27.3	26.1 23.9		20.5 20.5 18.2	11.5	13.6	20.6 21.6	25.1	18.3	18.4	20.3
TUBUL		Aver. Flue Gas Temp.	21	605	605	000	521	507		473 519	534	549	509	616	4 18 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	184	595 637
ZONTAL		Aver. Force of Draft	12	214	.214	00.	.493	.710		25 52 52 52 52 53 52 53 53	.354	.405	.400	.790	.530	080.	.527
HORI		No. of Coals Aver.	de No.	10	ro -	-	6	ᠳ ─		<b>→</b> →	10	-	19		10 -	-	** ==
		No. of Tests Aver.	S. M. E. Code No.	c.	9 Highest	Single	Highest	10 Highest	Single	6 6 Highest	Andrest Highest	Highest Single	39 Highest	Highest	Highest	Highest	Highest Single
		Type of Boiler and Grate	Α.		Water-Tube	TOHOS STORES	A 100 00 00 00 00 00 00 00 00 00 00 00 00	Water-Tube chain grate		Hor. Tubular rocking grate	Hor Pulmlar	plain grate	Water-Tube	PACCALL ELECTO	Water-Tube Murphy Furnace		U.S. G.S. Tests Water-Tube plain grate

3. Tests of a water-tube boiler with chain grate stoker to determine the relative economy of a 6-inch and an 8-inch fuel bed with various rates of combustion.

The results of these tests are best shown by the curves in Fig. 9.




FIG. 9 CURVES SHOWING THE RELATIVE ECONOMY OF A 6-INCH AND 8-INCH FUEL BED IN A CHAIN GRATE STOKER

They show that under the conditions of the test, the 8-inch fire was the more efficient, giving an equivalent evaporation per pound of dry coal 10 per cent greater than the 6-inch fire, when operating at the rated capacity of the boiler. The same coal was used throughout this series. The averages of the results of these tests are reported in Tables III and IV, viz., Nos. 41, 42, 43 and 44. In Figs. 10, 11 and 12 are shown a few of the characteristic results of boiler trials made on water-tube boilers with chain grate stokers. These diagrams are plotted from the results of 38 trials, and each point on the diagram represents the average of 5 trials. It is safe to assume, therefore, that the results represent average conditions.




Fig. 10 Chart Showing Variation in Boiler Performance with Coals of Different Heat Value

Fig. 10 shows the results of trials, in which coals of highest, lowest and mean heat values were used, plotted on a basis of heat value. The sudden drop in the equivalent evaporation per pound of dry coal, with coals of low and medium heat value is no doubt due to the large increase in the flue gas temperature with constant rate of combustion and capacity. With coals of medium and high heat value the equivalent evaporation increases with increasing rate of combustion and capacity, the flue gas temperature remaining constant. It is evident from the diagram that the effect of the heat value of the coal is not very marked, a large increase, however, other conditions remaining constant, causing an increase in the evaporation per pound of coal, as will be seen in Fig. 12.




Fig. 11 Chart Showing Variation in Boiler Performance with Varying Rates of Combustion

In Fig. 11 the results of a boiler trial are plotted on a basis of rate of combustion. It is evident from the diagram that the equivalent evaporation per pound of dry coal increases with the rate of combustion until the capacity reaches 100 per cent, or the rated capacity, the heat value of the coal remaining approximately constant, the flue gas temperature at this point being 500° F. With a further increase in the rate of combustion the capacity and flue gas temperature still increase but the equivalent evaporation per pound of coal decreases. This curve, if it may be called such, might be named the characteristic curve of the boiler, and is important because it shows the rate of combustion above which the evaporation per pound of coal decreases.




Fig. 12 Chart Showing Variation in the Performance of a Boiler Working at Different Capacities

The effect of capacity on the evaporation is shown by the diagram in Fig. 12. It is seen that here as in the previous figure the evaporation per pound of dry coal again increases with an increase in the capacity due to an increased rate of combustion. However, instead of attaining a maximum at 100 per cent capacity, it increases with a further increase of capacity and rate of combustion. At first sight this seems contradictory to the previous diagram, Fig. 11; however, it is evident that this increase is not due to this further increase in the rate of combustion and capacity, but is due to the sudden increase in the heat value of the coal (about 10 per cent) used.

## V ARRANGEMENTS FOR FUTURE FUEL TESTS

In publishing this bulletin it has been the desire to record the results of the most important tests of boilers fired with Illinois

coals, that have been made up to date. During the year 1906 the Engineering Experiment Station at the University purchased and installed a plant designed especially for conducting a series of fuel tests of Illinois coals. The plant consists of a 210 H. P. Heine water-tube boiler together with a Green chain grate stoker and a Sturtevant economizer and induced draft fan and engine. This boiler is a duplicate of the boilers used by the United States government in the fuel tests in progress at St. Louis under the direction of the United States Geological Survey. It was thought that in this way the fuel tests here at the University would be in a measure comparable with the tests made by the government on coals from all parts of the United States.

The rapid growth of the industrial interests of Illinois demands a careful study of the great fuel supply, and no effort should be spared in the introduction and promulgation of improved methods and processes in the production, treatment and consumption of its coal. In the tests of Illinois coals which it is now proposed to make, less attention will be paid to routine boiler tests, familiarly known as such, and more attention will be given to a scientific study of fuel treatment before burning and to a study of those furnace constructions and conditions which give promise of maximum results. In order that future tests may be conducted along lines which will meet with the general approval of the various interests of the state, a Conference Committee on Fuel Tests has been appointed consisting of the members named below and representing the organizations indicated:

H. Foster Bain, Director State Geological Survey, Urbana, Ill., representing the State Geological Survey;

A. Bement, Consulting Engineer, Chicago, the Western Society of Engineers;


Edwin H. Cheney, President Fuel Engineering Co., Chicago, the Building Managers' Association of Chicago;

F. H. Clark, Gen. Supt. Motive Power Burlington Road, C. B. & Q. Ry., Chicago, the Western Railway Club;

Adolph Mueller, President H. Mueller Mfg. Co., Decatur, Ill., the Illinois Manufacturers' Association;

Carl Scholz, President Coal Valley Mining Co., Chicago, the Illinois Coal Operators' Association:

A. V. Schroeder, Decatur Railway and Light Company, Decatur, Ill., the State Electric Light Association; Wm. L. Abbot, Chief Operating Engineer, Chicago Edison Co., Chicago, the Board of Trustees University of Illinois;



L. P. Breckenridge, Director Engineering Experiment Station, University of Illinois, Urbana, Ill.

Reference has been made to the government fuel tests at St. Louis. It should be stated that the work of the boiler division of these tests has been carried on under the direction of the Director of the Illinois Engineering Experiment Station, who will also have charge of the tests made at the University of Illinois. Copies of Professional Paper No. 48, containing a report on the operations of the government coal testing plant at St. Louis may be obtained upon application to a member of Congress or to the Director of the United States Geological Survey, Washington, D.C.

It is not the intention of this bulletin to discuss the subject of fuel testing. A future bulletin will take up that subject and will also describe in full the plant provided for such tests at this University. Attention is called, however, to the facilities now offered for this important work. It is hoped that mine owners and manufacturers will find it advantageous to cooperate with the Engineering Experiment Station in the proposed tests. The Station Staff will always be glad to receive such suggestions concerning this work as those interested may desire to offer.

## VI CHEMICAL ANALYSIS AND HEAT VALUES OF ILLINOIS COALS

By S. W. PARR, Professor of Applied Chemistry

The accompanying results of chemical analyses of Illinois coals may be divided into three classes: first, those which were directly connected with the boiler tests conducted by the department of Mechanical Engineering, and which are listed in a separate table, covering such work from the year 1894 to 1905; second, in connection with thesis work by Mr. F. C. Koch in 1901, there were assembled by him the results of all analyses of Illinois coals which had been made by the department of Chemistry previous to that date. These results were published together with his own work in a bulletin through the courtesy of Secretary Ross of the Bureau of Labor Statistics in the report of that Bureau in 1902. They are designated in the tables by the letters B. L. S. The third series of results comprises the work on one hundred fifty samples of Illinois coal collected in 1904 and published in a separate bulletin in connection with the exhibit of mines and min-

erals at the St. Louis Exposition. These results are designated in the tables by S. W. P. The sum total of data which has thus resulted, while of a somewhat desultory nature, constitutes a very considerable contribution to our knowledge of the constituents of Illinois coals. It is to be noted that the processes employed in connection with this series were confined almost exclusively to the method of proximate analysis. In the future the more exacting demands of modern methods will require extended data such as are furnished by both proximate and ultimate analysis, including of course the determination of calorific units. It may be well therefore, at the present time, to assemble the information obtainable up to the present date, compiling it as in the accompanying tables. and also to discuss briefly some of the terms which are used in connection with the chemical work on coals. The chemist employs terms and processes which are also used by the engineer, but it does not always follow that their use of terms is in accord.

Moisture.—Moisture in coal is constantly undergoing a change as to quantity. The percentage contained at the time of breaking out the coal from the vein is greater than at any subsequent stage of its history, unless possibly it be under the conditions of rain or snow or drenching with the hose. Some of this moisture which is normally contained in the coal is lost when the coal is exposed to the air, being in this respect like water which has been poured upon the coal. But there remains moisture in the coal after air-drying and which is removed only at the temperature of boiling water. This moisture is described as hygroscopic. If now the chemist works upon a sample which is overcharged with moisture, as is the condition when the sample is freshly mined, it will be constantly losing in weight and modifying his results. larly, if he works upon a sample which has been completely dried in the oven, it will have great avidity for moisture and be constantly gaining in weight throughout his work. He, therefore, proceeds in his determinations, as a rule, with the coal in that condition which is least affected by external conditions, viz., in the airdry state with the normal amount of hygroscopic moisture present, but without the excess of water, which might be termed water of saturation.

Therefore, we have three distinctly different conditions: first, the wet coal; second, the air-dry coal; and third, the oven-dry state. The engineer, however, not having to do with the condi-

tions under which the chemist works, recognizes only the two phases, either the wet or dry, and by this latter term he means the oven-dry state. The failure on the part of the engineer and the chemist to recognize these terms often leads to misinterpretation of results. The chemists, therefore, should agree to such use of terms relating to water as have become firmly established in engineering literature: viz., that dry coal refers to moisture free coal or to the oven-dry state, and second, that wet coal refers to the condition as received or previous to any process of air-drying, and that it is one or the other of these conditions that is of interest to the engineer, regardless of how important it may be to the chemist to proceed upon the basis of the air-dry condition.

It may not be out of place further to indicate how results may be transferred from one basis to the other. It is not an uncommon practice for the chemist to report his results on the air-dry basis, in which case he should also report the amount of moisture lost upon air drying, provided his sample comes to him sealed in such a way as to make this factor possible. Suppose, for example, that the loss of moisture upon air-drying is 4 per cent, then all his results reported on the air-dry basis would be changed to the wet coal basis by multiplying each by 96 per cent; not by dividing by 104 per cent as is often erroneously done. This will make small difference in a constituent which has a low percentage factor, but the error is very considerable in a factor like the fixed carbon which is from 40 to 50 per cent. This may seem like a simple arithmetical problem to mention in this connection, but it is one not always correctly interpreted.

Conversely, if it is desired to change factors to the dry coal basis, each factor should be divided by 100 minus the percentage content of water in that condition from which the transfer is being made. For example, if we are calculating this coal from the air-dry state, supposing it to have 6 per cent of moisture present, each factor should be divided by 94 per cent, but it should be noted that if we are calculating from the wet-coal condition our divisor will not be 100 per cent minus the sum of the two factors, 6 and 4, as in the above illustration, but 100 minus 96 per cent of 6 plus 4, or 90.24. Here again is a not uncommon place for stumbling in what might seem to be a simple arithmetical problem.

Volatile Matter.—When coal is subjected to high temperature out of contact with the air, a considerable amount is driven off as

volatile matter. This includes, also, of course, any moisture in the sample, if we start with a portion which has not been dried in the oven. Now an even greater discrepancy in the use of terms has come into use in connection with this constituent than is the case with different forms of water. One of the oldest terms is that of volatile carbon. This is both incorrect and meaningless because carbon is not volatile, and because the constituents of this material are numerous and complex. The term that is perhaps most frequently met designates this material as volatile combustible. This again is incorrect and misleading, as this material in the ordinary bituminous type of coal has from one-third to one-half of its weight made up of non-combustible material. It is evident, therefore, that the only proper term among those commonly in use for this constituent is that of volatile matter. The only restriction indeed in connection with this term is to understand, as is the uniform custom, that the moisture of the coal is not included. A word may be in place here in connection with a term which is occasionally met, and is likely to be more frequently used than formerly. This term is intended to designate that part of the volatile matter which does not burn. This constituent is sometimes referred to as "water of composition". It is not included in any of the resuits listed in the following tables, and hence its use does not enter into any of the discussions in this bulletin. It is noted in this connection, however, in order that it may not be confused with any of those terms which are intended to designate the water in its ordinary form and which are capable of being driven off at the temperature of boiling water. This property does not belong to the water of composition, as this substance like the other part of the volatile matter, requires a red heat for its dissociation.

Fixed Carbon and Ash.—Concerning these constituents there is no disagreement as to the use of terms unless it be the occasional use of the word coke. Coke in its proper and technical sense should apply to the residue including the ash after subjecting the coal to destructive distillation. It is, therefore, not proper to designate the fixed carbon as coke, though it would be proper, of course, to use the term "coking carbon" in this connection. The preferable term and the one commonly employed, however, for this material is that of fixed carbon.

Methods of Analysis.—The methods of analysis employed are those in common use and their description is so easily accessible

that no repetition is necessary here. Reference may be made to the report of the committee of the American Chemical Society on coal analysis.<sup>1</sup>

Caloritic Value.—The determination of heat units in coals is, of course, a necessity in connection with any well conducted boiler test. Two systems of units are employed, viz., the kilo calories and the British Thermal Units, designated as B. T. U. Each unit is the measure of heat imparted to the water by an equal weight of coal. They would, therefore, be identical if it were not for the fact that the one is read on the Centigrade scale and the other on the Fahrenheit scale. The transfer, therefore, of calories per kilo over to B. T. U. per pound is effected by multiplying by the ratio of 9:5 or 1.8.

There are four types of instruments in use for measuring the heat value of coals. The first and most elaborate is the Mahler instrument which has numerous modifications as to detail, but which embodies the use of a steel bomb capable of maintaining oxygen from twenty to twenty-five atmospheres pressure. The next in the order of time is the Fisher calorimeter which burns the sample of coal in a small chamber supplied with oxygen at atmospheric pressure. The third type may be designated as the L. Thompson calorimeter, wherein the coal is mixed with a chemical which in itself supplies the oxygen for carrying on the combustion and in which the gaseous products are allowed to bubble up through the water, thus imparting their heat to the liquid. fourth type may be designated as the Parr calorimeter which also employs a chemical having its own supply of oxygen, but which absorbs the gaseous products, thus retaining all the heat of the reaction for more accurate measurements by the thermometer. Of the second and third types, it may be said that owing either to incompleteness of combustion or to loss of heat by transmission of the gases, results are obtained which are not of sufficient accuracy for reliable work. Results from the Thompson calorimeter are reported by certain authorities to admit of variations amounting to 15 per cent. The Mahler type of calorimeter is accurate when operated by one thoroughly familiar with such processes. The Parr calorimeter is the one used in connection with the analyses in these tables of all coals made since 1900, and is now the instru-


<sup>1</sup>Jour. Am. Chem. Soc. Vol. XXI, p. 1130.

ment most commonly used in technical work. A brief description of this apparatus follows:

Fig. 13 shows the relative position of parts. The can A.A. for the water has a capacity of 2 litres. The insulating vessels B.B. and C.C. are of indurated fiber. The charge of coal and chemical is put in the cartridge D. Upon ignition, the heat generated is imparted to the water and the rise in temperature is indicated on the finely graduated thermometer T. The cartridge or bomb rests on the pivot F and is made to revolve, and by aid of the small turbine wings attached effects a complete circulation of the water and equalization of temperature.

The reaction accompanying the combustion may be represented by the equation:

$$56 \text{Na}_2 \text{O}_2 + \text{C}_{25} \text{H}_{18} \text{O}_3 = 25 \text{ Na}_2 \text{CO}_3 + 18 \text{ NaOH} + 22 \text{ Na}_2 \text{O}$$
  
Sod. perox. Coal Sod. carb. Sod. hydrate Sod. oxide



With certain substances such as coke, anthracites, petroleums, etc., a more strongly or vigorously oxidizing medium is needed than exists in the peroxide alone. This may be secured by various additions. The most effective are: A mixture of potassium chlorate and nitrate in the proportion of 1 to 4 and this mixture used in the ratio of 1 to 10 of the sodium peroxide; another effective mixture is an addition of potassium persulphate in the ratio of 1 to 10 of the sodium peroxide. Other substances facilitate the oxidation, notably ammonium salts and certain organic substances, as tartaric or oxalic acid, benzoic acid, etc. In the work on Illinois coals, while ordinarily no extra chemical would be necessary, still in certain cases, such as extra slaty coals and coals with excessive volatile matter, and also to guard against variations in the quality of the sodium peroxide, a mixture as first described above, of chlorate and nitrate, has uniformly been used throughout these tests.

Further extension of the use of the instrument to other types of coal and to petroleum has made it necessary to extend still further the oxidizing power of the chemicals employed beyond what is afforded by the chlorate mixture. In addition to this the use of the residue for determining the total carbon and sulphur has made it highly desirable in such additional chemicals to avoid the use of compounds containing carbon or sulphur. To meet these conditions, the so-called "boro-mixture" has been devised. It consists of:

Во	ric acid		 	 	 		 	11	parts
Po	tassium	chlorate	 	 	 	 	 	4	parts
M	agnesiur	n powder	 	 	 	 	 	1	part

Its correction factor is found by trial with a pure chemical of known heat value such as napthalene or by burning with a coal whose heat value is already accurately known. This mixture has the further advantage of carrying on a combination with material so low in carbonaceous matter as to be non burning by ordinary methods, such as ashes and coals of very high ash content.

Still further modifications relate to the bomb as shown in Fig. 14, and have to do mainly with the avoidance of screw threads on the interior of the combustion chamber, especially in the upper part, where particles tend to lodge and thus escape combustion; also in jacketing the lower part of the chamber to avoid direct contact with the water, thereby avoiding rapid

cooling of the parts and extending somewhat the period of high temperature, thus securing a more perfect combustion.




Fig. 14

Calorific Values By Calculation.—Numerous methods for calculating the calorific value of coal have been proposed, but no method can be said to have any value which is not based on a knowledge of the percentage constituents of the total carbon, available hydrogen and sulphur. Even under these conditions the results by calculation are not always in agreement with the indicated results by means of the calorimeter, and in any event, of course, results from proximate analysis do not furnish the neces-

sary data for this calculation. When this method is used the Dulong formula is considered the most nearly accurate and is as follows:

Cal. = 
$$8080 + 34,500 H + 2250 S$$

In the results here recorded the necessary factors were not always available for applying this formula, but it is the one used wherever calorific values by calculation are included.

TABLE VI CHEMICAL ANALYSIS AND HEATING VALUES OF ILLINOIS COALS USED IN STEAM BOILER TRIALS AT UNIVERSITY OF ILLINOIS 1894-1905

non II II a	D. J. C. per 1b. of Total Dry Coal		:	:		11 490	001,11	11 909	11,300	19 599	2000	19 110	11 500	020 11	11,010	:	1000	12,000		11,880	4 4	12,130	11,185	:	:		020,21	130, 51 10, 100	12,174		11,761	12,174	12,174				:	11,239	11,700	:
oal	Sulphur		:	:	:	:		3,60	:		101	:	:	:	:	:	:		3.43	:	: : :			ල දු	:		 	:	:		5.14	:	:	:	:	5.63	5.00	6.03	1.73	4.19
vir-Dry C	Ash		:	:	:		6.39	10.33	20.19	10 96	15.00	0.01	18.81	20.50	10.04	22.03	00.11	7.53	11.95	6. 6.		15.13	15.86	11.95	:	X.X	3,05	10.76	D. 6	9.3]	16.40	7.66	7.66		12.90	11.61	5. 1	18.00	12.55	12.83
Proximate AnalysisAir-Dry Coal	Moisture		:	:	:	- 1	10.72	16.6	4.44	110	6:3		00.7	20.03	02:0	2 4 3 2 6 5	0.93	6.30	6.70	×.02	:	×.00	7.31	6.70		3,80	x (3	13.11	7.59	× ×	6.05	7.43	7,43	:	3.76	12.54	12.51	8.69	6.93	9.80
oximate ,	Volatile Matter			:	:		91.00	37.04	34.20	90. 19	037.10	94.00	04:40	57.95	97.	31.95	21.13	10.25	31.65	37.06	:	34 31	31.79	34.65		13.90	11.35		35.77	33.15	35.95	39.81	39.81	:	38.15	33.65	33.65	34.72	35.00	37.33
Pr	Fixed Carbon		:	:	:		48.33	43.52	40.55		40.00		40.03	42.30	45.23	39.51	CF-FF	46.05	46.70	45.10	:	42.26	45.11	46.70	:	43.50	42.58	41.95	47.53	48.59	41.60	45.10	45,10	:	45.19	41 40	41 40	38.59	45.02	40.04
	Boiler Test No.		-	S 1:	ere e	41	9	43,52	-:	DC 0	, e	0;	Ξ,	25.0	57	= :	9	16	1,5	25 25 4	19	02	201	÷	66	53	35	36	27	288	68	30	31	33	253	3,4	200	38.	37	38
	Date of Analysis		June 94	:	:	:	:	:	:	Feb 97	:	:	:	:	:	Jan. 16 '97		:	Mar. 11, '99	:	June '94	٠.	Mar. 28, 05			Dec '91	May '02	Mar '97	)et 95	June 16,, 98		:		Mar. 12, '01						Feb. '99
	Description of Coal			Pea	-	, K	Lump	Pea	Nut	Lump	Tramb	dmarl	:		:	[] ea	Lumpdmn/l		Dea		Lump		Duff	Pea	Lump	:		Lump	Lump	Lump	Slack	Lump,	Lump	Pea	Den	Dea	Pen	Lumb	Stack	
of Coal	Town		Pana	'ana	Pana	Pana	Paradise	Junction	Niantic	Mt. Olive	alen Carbon	Odin	Jain	Odir.	Odin	Odin	Odin	Odin	Odin	Odin.	Odin	Odin	Odin	Odin	Illoomington	Bloomington	Colfax	Athens	Du Quoin	Du Quoin	Du Quoin	Du Quoin	Du Quoin	Du Quoin	Barclav	Dawson	Dawson	Divernon	Lowden	Ridgely
Source of Coal	County		-		:				:			:	:			:	:		Marion	Marion	Marion	Marion		)				Menard	Perry	Perry	Perry	Perry	Perry	Perry	Sangamon	Sangamon	Ash camon	Congramon	Cangamon	Sangamon
	No.	-		_	_		<u> </u>	_	-	oc :	_		_	15							_		-				74		200	_							_		_	38

1, 150 1,	12 901
2 - 1 - 1 - 1 - 1 - 1 - 1 - 1 - 1 - 1 -	:
2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2	10.04
88888884160 : : : : : : : : : : : : : : : : : : :	00.0
88888888888888888888888888888888888888	21.10
68844444444444444444444444444444444444	00,40
**************************************	
Mar. 99 Dec. 03 Elab. 04 Mar. 04 Mar. 06 Mar. 07 Mar.	: /
Pea	
Riverton Springfield Springfield Springfield Springfield Springfield Springfield Callin Muncle Oalkwood Oalkwood Oalkwood Oalkwood Oalkwood Oalkwood Oalkwood Oalkwood Carleton Herrin Herrin Herrin	
Sangamon. Sangam	
8644564456445652555555555555555555555555	3

TABLE VII CHEMICAL ANALYSIS AND HEATING VALUES OF ILLINOIS COALS

1	Source of	of Sample	Description	no			Pro	ximate A	Proximate Analysis—Air-Dry Coal	dr-Dry (	Coal	1 6
No.	County	Town	Size	Geol. Seam	Date of Analysis	Obtained from	Fixed	Volatile Matter	Moisture	Ash	Sulphur	B. T. U. per lb. of total Dry Coal
0	Adams	Elm Grove	Drill Core	:	Mar. 28 706	Chem. Dept	47.00	35.83	4.62	12.55	9,45	996'81
: CO	Burean	Ladd Grove	W. Nur		20.0	Chem. De	50.57 45.67	38.36	3.03	20.0 0.0 0.0	89:68 	13,915
-	Bureau	Ladd	W. Slack.	१ ७१	0,	W. P. '0	16.75	38.61	6.60	0.00	9.70	14.117
10	Bureau	Lombardville	Vein Sample.	:	77	ń	51.74	81.38	9.43	7.46	2.46	
9 t	Bureau	Spring Valley	W. Sereen	:	May '99	ni o	39.01	35.58	12.40	13.01	2.81	1000
- 30	Christian	Assumption	Drill Core		58. 	200 200 200 200 200	50.10	41.90	0 % 0 %	2 G 5 7	:	12,638
6	Christian	Assumption	Block			B. L. S.	47.86	37.76	7.25	7.13	5.04	
3=	Christian	Assumption	Lump	-	FO	B. E. S. 63	43.56	37.34	7.97	11,23	 	119 7.00
120	Christian		Slack		50	12	43.28	36.26	7.74	19.73	2.60 2.60	12,621
13	_	_		:	189	B. L. S.	46.95	36.37	7.55	9.46	:	12,513
7		1'una	Slack		ž.	3. L. S.	39.35	35.45	8.55	16.65	4.77	10,727
10	Christian	Pana	Nut	:	300	5. L. S.	16.04	39.43		9.33		19,522
17.0		Pana.	Lumn	. 8		S W P '04	11.98	41.18	9.9	20.00	07.* % 80	19.840
18		l'ana	Slack	9	<b>1</b> 0,		37.44	35.84	8.08	18.66	5 12	10,915
13		Pana	Lump	9	10,	7	39.74	43.72	7.80	8.74	9.36	12,902
202		Breese	Slack	9 :	¥0, · · · · · · · · ·	¥. ₽.	43.66	34.00	8.10	14.24	3.40	13, 181
. 63	Clinton	Breese	Lumb	၁ ဗ	5,5		46.36	30.21 36.63	1 00 1 00 1 00 1 00 1 00	25.00 25.00	3.17	12,631
233	_	4 5	Nut	) {-	10.	<u>,</u> 2,	43.05	38.00	200	20.19	1.33	11.065
es e	-	Trenton	Slack	7	: 8	S. W. P. '04	45.27	29.98	9.47	15.28	1.19	11,371
26	Cules	Flatanise	Lump	:	Feb. 26 97	Chem. Dept	18.33	31.06	00.73	6.33 95.00		11,430
101		Benton	Lump		⊇ +;	Chem. Dept	51 12	36.23 36.23	30.03	9.61	20.00 00.00 00.00	12,983
82 8	inded 4	Astoria	Average		×6,	B. L. S.	39.40	40.00	12.26	8.34	3.16	12,566
2.5	Fulton	Astoria	Lump	re re	10.	K.V. V.	46.67	36.15	7.94	8,46 10,06	01.0 \(\times \)	12,953
35	-	Canton	Lump	2 10	5,5	Д	38.56	35.98	11.10	14.36	3.67	19,917
S 3	-	Canton	Nut	īG	٠.	S. W. P.	41.40	38.72	10.00	9.88	2.67	12.825
25.5	Fulton	Caba	Clouds	: 11	30, Ylul	ĸ.	10.96	36.93	10.42	11.69	9.4.60	12,056
155	-	Cuba	Lamon	o ru	3.5	W. F.	40.04	38. 18	01.10	11.11	9.10	19 (39
36	( )use(	Cuba	Lumb	10	ō		43.26	41.01	5.55	10.18	00.00	12,905
55	-	Cuba	Slack	.c	, O.	S. W. P.	40.71	36.33	7.28	15.68	3.35	11,988
X 50	Fulton	Dunfermline		:	86,	E. C. S.	36.54	35.80	10.95	17.71	35.53	11,623
40		Farmington	Voin Samulo	:	87.	<u>:</u> ~	50.30	90.00	200	3.5	0 00	11,041
7	_	Farmington	Lump	13	70.	S. W. P.	41 79	35.75	10.25	19.91	1.97	12,497
2, C	Fulton	Farmington	Slack	2	10.		37.16	33.04	9.6%	20.48	3.03	11,234
2	r utton	rate		:	July 98	ń	40.04	39.36	12.54	96.11	4.67	12,451

11,379 11,379 12,506 12,558 12,574 13,797 13,797 13,531 13	13, 164 11, 249 12, 560 12, 560 13, 154 13, 140 11, 787 12, 787	13,535 13,575 13,975 12,955 12,945 13,975 13,976 13,476 11,137 11,137 11,137 11,137 13,016 13,256 13,016 13,256 13,016 13,256 13	13,185 11,253 12,999 12,174 13,597 13,096 13,824
98 98 88 88 88 88 88 88 88 88 88 88 88 8	8 8 8 8 8 8 8 8 8 8 8 8 8 8 8 8 8 8 8	9	00 00 00 00 00 00 00 00 00 00 00 00 00
11.38 10.99 11.38 10.99 10.99 10.38	20 8 8 1 1 1 1 4 1 1 1 1 1 1 1 1 1 1 1 1 1	500 500 500 500 500 500 500 500 500 500	5.50 4.11 5.50 4.11 5.50 4.12 5.50 6.12 5.50 6
11000000001511 85488891152	5.0 5.0 5.0 5.0 5.0 5.0 5.0 5.0 5.0 5.0	858824487447888	11.00.0 0 0 1.00.0 0 0 0 0 0 0 0 0 0 0 0
28848888488888888888888888888888888888	28 8 27 27 28 8 2 2 2 2 2 2 2 2 2 2 2 2	24.88.28.28.28.28.28.28.29.29.29.29.29.29.29.29.29.29.29.29.29.	20.84 20.33 24.50 20.33
	41.32 36.54 45.87 45.87 45.87 57.50 57.50 57.50 57.50 57.50 57.50 57.50 57.50 57.50 57.50 57.50	66.37 66.37	4.20.40.40.40.40.40.40.40.40.40.40.40.40.40
S. W. P. '04.  S. W. P. '04.  Chem. Dept.  Chem. Dept.  Chem. Dept.  S. W. P. '04.  Chem. Dept.  Chem. Dept.		2	E E E E E E E E E E E E E E E E E E E
Heb. 28, 00 May 12, 00 May 12, 00 Mar. 20, 98 Mar. 20, 96 Mar. 20, 00 Mar. 20, 00 Mar. 20, 00 Mar. 31, 00 Mar. 31, 00 Jan. 31,	May 98 Nov 99 No	Mar. 99	0000380033
10 10 10 10 10 10 10 10 10 10 10 10 10 1	20	00 t-t-010101	es e
Lump Slack Slack Orth No.2 Drill Core Pea Slack Slack Lump Lumb Lumb Lumb Lumb Lumb Lumb Lumb Lumb	Vein Sample. Vein Sample. Nut. Slack Vein Sample. With Sample. No. 1 W. No. 2 W. No. 3 W. No. 4 W. No. 4 W.	Refuse From Water. Vein Sample. Lump Lump Lump Lump Slack Lump Slack Lump Slack Lump Slack Lump Pea.	and Vein 3rd Vein Beg Slack Vein Sample. Slack Lump Lump
1. 1. 1. 1. 1. 1. 1. 1. 1. 1. 1. 1. 1. 1	Augusta. Briar Bluff Galva Kewanee Kewanee Kewanee Carbondale Carbondale Carbondale Oarbondale De Soto De Soto De Soto De Soto De Soto De Soto	Mr. Carbon Murphysboro Murphysboro Murphysboro Murphysboro Etherly Soperville Soperville Kangley Kangley La Salle La Salle La Salle La Salle	
Fulton Fulton Fulton Fulton Fulton Gallatin Grandy Grundy Grundy Grundy Hamilton	55 Hanrock	Jackson. Jackson. Jackson. Jackson. Jackson. Jackson. Knox Knox La Salle	La Salle La Salle La Salle La Salle La Salle La Salle La Salle
4 4 . 4 . 4 . 4 . 4 . 4 . 4 . 4 .	**************************************	te tetetetetetetemmmmmmmmmmmmmmmmmmmmmm	22 2 2 2 2 2 2 2 3 3 5 5 5 5 5 5 5 5 5 5

TABLE VII (Continued)

Sourc	Source of Sample	Description	пc	_	Fr	oximate A	Proximate Analysis of Illinois Coal	Hinnois	Coul	B. T. II. ner
No. County	Town	Size	Geol. Seann	Date of Obtained Analysis from	Fixed	Volatile Matter	Moisture	Ash	Sulphur	lb. of Total Dry Coal
95 Livingston	Cardiff	Lumb	© ì	J.	44.59	39.36	11.28	28.	9.41	13.301
96 Livingston		Alack	G)	S. W.	41.18	36.54	10.26	12.05	2.36	12,053
	*	Slack	is.	بنم		33.76	5.30	21.50	4.36	10.870
98 Livingston	;	Lump	20	O4 S. W. P.	43.67	39.02	6.57	10.69.	100	12.959
-	-:	Drill Core	_	98 B L S	15.99	39.37	5.19	12.45	€ 61	: : : :
	-	Drill Core	\$ è	'98 B. L. S.	40.04	44.83	4.36	10.77	3.76	: : :
01 Logan	-		:	B. L. S.	46.88	34.19	8.36	10.57	2.59	
_	Lincoln		:	ń	44.55	34.99	8.45	12.06	:	12,312
03 Logan	Lincoln		:	B. L. S.	49.20	31.30	7.50	11.70		12,668
01 Logan	_	Vein Sample	:	B. L. S.	16.61	27.60	10.95	14.84	4.99	
05 Logan	_	Lump	13	S. W. P.	37.58	36.78	10.64	15.00	3.17	12,161
06 Logan	_	Nut	5	Z.	42.10	38.88	10.44	× 58	2.44	15,947
07 Logan	Z	Lump	10	S. W. P.	43.38	33.64	11.98	12 10	20.13	12,308
-	Mt. Pulaski			B. L. S.	46.53	35.82	7.68	9.97	:	12 305
09 McDonough.	h. Colchester		:	B. L. S.	40.09	34 07	9.04	16.80	1.16	11,653
	Bloomington	Vein Sample		B. L. S.	53.12	34.02	7.90	4.96	1.97	13,375
<i>r</i> -4	Bloomington	Lump		ú	43.50	43.90	08:50 08:50	£ ∞	:	12,443
	Isloomington		:	B. L. S.	45.20	35.99	4.10	14.71		11,797
13 McLean	Illoomington	Slack	© ž	S. W. P.	35.63	34.05	6.77	93.55	1.14	10,884
-	Bloomington	Lump	©₹		40.60	-10.06	7.56	11 28	3.14	12,680
,,,,,,	Isloomington	Slack	00	N N	39.04	38.06	5.61	97 91	3 10	12,069
-	Bloomington	Lump	က	04 S. W.	13.81	14.06	28.98	5.12	200	13,751
-	Colfax		:	Chem.	12.58	41.35	20.00	8.0°	08.7	12,025
	Decatur	Lump	.0	ń	11.97	38.56	8.46	2 . c	20,13	12,264
_	Niantic	Nut			44.01	36.47	10.38	- A-	03.52	12,056
_	Niantic	Slack	2	.04 S. W. P.	39.32	34.51	10.11	15.16	3.35	11.175
	Niantic	Nut	:	ų t	40.55	04.20	77.7	20.73	:	203,11
-	Niantic		:	<i>i</i> :	00.74	30.30	00.7	7 10	:	19.010
-	Niantie		:	88B. L.	45.50	64 IS	62.11	8.50		13.019
-	Brighton	l'ump		Cnem. De	10.61	99.43	10.01	01.1	200.5	19 501
	Green Kidge	Lump	20		00.44	20.00	# 10 C	00.00	9.0	10,001
-	Green Kidge	Nack	90		06.16	02.30	0000	F 1 1 2	00.00	19,086
-	Mt. Onve	Lump	00		40.10	50.54	9.90	2 1	00.00	11 492
-	Mt. Olive	Slack	0	i i	20.14	12.10	200	11.13	00.0	10,400
	Mt. Olive		:	. i.	87.44 61.44	30 13	16.1	11.11	:	16, 402
-	Mt. Olive		:	88 E. L. S. 02	06.16	90.00	00.00	000	:	12,401
-	Mt. Olive		: : : :	2000	16.44	60.00	1.33	18.0		
	Mt. Olive	Lump		01 B. L. S.	40.22	38.33	9.03	200	000	202,21
-	Palmyra	Drill Core	:	9, '05 Chem.	06.16	50.20	0.03	0.13	7 -	10.024
	Palmyra	Drill Core	:	<b>.</b>	49.41	50.02	0.53	3.55	4.13	19,000
-	Palmyra	Drill Core			42.07	32 25	22.0	0 0 0 0	0.0	010.31
	Virden	Nut	9		43.40	50.20	10.24	8.03	00.1	020,21
37 Maconnin	The state of the s				200		100			

12, 802 11, 440 13, 059 12, 997 11, 928 11, 522 12, 522	11,620	12, 665 12, 110 11, 569 11, 569 10, 619	13, 195 13, 195 15, 19	25.55 25.55	13, 157 13, 157 13, 157 12, 073	11.356 11.356 12.21.35 12.21.35 12.22.35 12.23.35 12.23.35 13.23.15 13.23.15 13.23.15 14.33.1
8488444 00088 00087 00087 00087 00087 00087	4 01 3.60 7.25			3.61	8 4 · · · · · · · · · · · · · · · · · ·	65. 10 4 4 10 10 10 10 10 10 10 10 10 10 10 10 10
11. 12. 12. 12. 12. 12. 12. 12. 12. 12.	26.40 18.36 17.41	7.53 11.50 14.68 6.34	6 × 11 7 10 13 8 5 14 15 15 15 8 15 15 15 15 15 15 15 15 15 15 15 15 15	11.20 11.35 11.50 22.03	三百00元 8 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2	65 6 2 4 4 5 6 6 6 6 6 6 6 6 6 6 6 6 6 6 6 6 6
21-27-21-21-21-21-21-21-21-21-21-21-21-21-21-	6.55 6.55 6.55 6.55 6.55 6.55 6.55 6.55	38268 888288	1-1-3 x m +	x x + 1- 5 5	244500446 24454 244564 244564	2
25.50 25.50	38.10 38.11 38.17 38.63	9 8 8 8 5 8 8 8 8 8 8 8 8 8 8	5 % 2 % 2 % 8 % 8 % 8 % 8 % 8 % 9 % 9 % 9 % 9 % 9	35.10 35.10 37.13 37.13 37.13 37.13	28.88.84.27.88.89 28.88.84.27.88.89 28.88.84.27.88.89 28.88.88.88.88.89 28.88.88.88.88.89 28.88.88.88.88.89 28.88.88.88.88.89 28.88.88.88.88.89 28.88.88.88.89 28.88.88.89 28.88.88.89 28.88.88.89 28.88.89 28.88.89 28.88.89 28.88.89 28.88.89 28.88.89 28.88.89 28.88.89 28.88.89 28.88.89 28.88.89 28.88.89 28.88.89 28.88.89 28.80 28.	88.88.88.88.81.89.88.89.89.89.89.89.89.89.89.89.89.89.
28.33 28.34 20.51 20.51 20.53 20.53 20.53 20.53 20.53	86.55 56.55 57.50	26.85 28.09 38.09 38.09 38.09 38.09	24 4 4 4 4 4 4 4 4 4 4 4 4 4 4 4 4 4 4	24 4 4 4 4 4 4 4 4 4 4 4 4 4 4 4 4 4 4	54 56 57 54 58 54 54 56 56 58 58 58 58 58 58 58 58 58 58 58 58 58	25.55.55.55.55.55.55.55.55.55.55.55.55.5
22255	22 7 21 2		388888 XXXXX XXXXX	या दो दो दो दो दो दो	44444444 8888888 8888888	
XXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXX	20 17 12 12 12 12 12 12 12 12 12 12 12 12 12	88.88.89 98.88.89 98.89.89 88.89.89	88888888888888888888888888888888888888	4888999 488888	28 28 28 28 28 28 28 28 28 28 28 28 28 2	
6 6 6 6 6 6 6 6 7 7 8 8	9 9	Jan. Feb. Apr. July. Oct.	Nov. Nov. Nov. Dec. Jan.	Feb. Feb. Mar. Mar. Mar.	Mar. Feb. May.	6 Mar. Oct. 3 6 July. 2 July. 5 5 5 Mar.
Nat. Pea. W. Nat. W. Pea. Nat. Slack	Shek Nut.	Lump Lump Cump Pea Pea	Lamp Tamp Tamp Slack Tamp	Lump Lump Lem Pen Pen	Pea Fea Eump Pea Form Wur	Slack Vein Sample Lump Camp Slack Slack
Collinsville Collinsville Donkville Donkville Edwardsville Edwardsville Glen Carbon Centralia.	Centralia Centralia Centralia Kinmundy	Odin Odin Odin Odin Odin	Odin Odin Odin Odin	Oodin Oodin Oodin Oodin	Oddin Oddin Oddin Oddin Oddin Oddin	Odin Sandoval Sandoval Sandoval Tohtea Wenona Wenona Athens Athens Athens Greenview
BEREERE	6 Marion	Marion Marion Marion Marion Marion Marion	Marion	444444	ALLKARALLA .	777 Marion. 778 Marion. 779 Marion. 810 Marion. 821 Marshall. 822 Marshall. 843 Marshall. 844 Marshall. 845 Menard. 846 Menard. 847 Menard. 848 Menard.
		4 -4 - A -4 -4		555556	22222222	

TABLE VII (Continued)

COSTRELATIONS NOW		Source of	of Sample .	Description	on		nolveie	Pro	ximate A	Proximate Analysis-Air Dry Coal	dir Dry C	Joal	B. T. U. per
Menard   Greenview   Lump   5   00   S. W. P. 94   48     Menard   Middletown   Lump   5   00   S. W. P. 94   48     Menard   Middletown   Lump   5   00   S. W. P. 94   48     Menard   Middletown   Lump   1   00   S. W. P. 94   49     Menard   Middletown   Lump   1   00   S. W. P. 94   40     Mercer   Cable   Cable	No.	County	Town	Size	Geol.	Date of Analysis	btained	Fixed	Volatile Matter	Moisture	Ash	Sulphur	lb. of Total Dry Coal
Menard   Green   Feet   Middle town   Slack   Menard   Middle town   Slack   Menard   Middle town   Slack   Menard   Middle town   Lump   5 0 01 S W P. 04   Menard   Middle town   Lump   Dec. 17. 04 Chem. Dept.   Menard   Middle town   Lump   1 0 Ches. 17. 04 Chem. Dept.   Menard   Middle town   Lump   1 0 Ches. 17. 04 Chem. Dept.   Mercer   Cable   Slack   1 1 1 0 M S W P. 04   Mercer   Sherrard   Slack   1 1 0 M S W P. 04   Mercer   Sherrard   Slack   1 1 0 M S W P. 04   Mercer   Sherrard   Slack   1 1 0 M S W P. 04   Mercer   Sherrard   Slack   1 1 0 M S W P. 04   Mercer   Sherrard   Slack   1 1 0 M S W P. 04   Mercer   Sherrard   Slack   1 1 0 M S W P. 04   Mercer   Sherrard   Slack   1 1 0 M S W P. 04   Mercer   Sherrard   Slack   1 1 0 M S W P. 04   Mercer   Sherrard   Slack   1 1 0 M S W P. 04   Mercer   Sherrard   Slack   1 1 0 M S W P. 04   Mercer   Sherrard   Slack   1 1 0 M S W P. 04   Mercer   Sherrard   Slack   1 1 0 M S W P. 04   Mercer   Sherrard   Slack   1 1 0 M S W P. 04   Mercer   Sherrard   Slack   1 1 0 M S W P. 04   Mercer   Sherrard   Slack   1 1 0 M S W P. 04   Mercer   Sherrard   Slack   1 1 0 M S W P. 04   Mercer   Sherrard   Slack   1 1 0 M S W P. 04   Mercer   Sherrard   Slack   1 1 0 M S W P. 04   Mercer   Sherrard   Slack   1 1 0 M S W P. 04   Mercer   Slack   1 1 0 M S W P. 04   Mercer   Me	9	Monowd	Owoonniou	Luman	10	of.	5	44.81	37.62	9.46	% 1.3	63	12,757
Menard   Middletown   Lumb   5   5   64   54   54   54   54   54	25	Money and	("rechiview"	Clock	3 10		, Д	35.88	36.28	9 58	14.26	3.04	11,863
Menard   Middletown   Stack   5   Dec. 17. 04 Chem   Dept. 39   Menard   Dec. 17. 04 Chem   Dept. 39   Menard   Dec. 17. 04 Chem   Dept. 39   Menard   Dec. 17. 04 Chem   Dept. 39   Mercer   Cable   Lump   1   04 S. W. P. 04   44   Mercer   Cable   Lump   1   04 S. W. P. 04   44   Mercer   Cable   Lump   1   04 S. W. P. 04   44   Mercer   Cable   Sherrard   Sh	101	Menard	Middletown	Limb	10	T.	4	43.17	36.89	10.04	9.90	2 43	12,550
Menard   Patentsburg   Slack   Diee   T.	132	Monord	Middletown	Total J	3 10	2 J. To.	7. P. '04.	37.31	33.12	10.37	19.20	3.13	10,933
Name	10.1	Menaid	Datarelung	Charle		6	De	39.54	33.32	4.69	22.45	5.68	10,806
Name	104	Monard	Patarchurg	Lumb		ĕ	m. Devt	50.89	35.04	6.30	7.27	2.40	13,027
Mercer Gable   Slack	100	Mendiu	Cable	Lumn	-	3	۵.	40.78	39,34	9.03	10.86	3.93	12,588
Mercer Gildright   July   98 B L, S. 02   35     Morecr Sherrard   Jaack   1   04 S W, P. 01   45     Montgomery Citchfield   Slack   2   06 S W, P. 01   45     Montgomery Citchfield   Slack   2   06 S W, P. 01   46     Montgomery Citchfield   Slack   2   06 S W, P. 01   46     Montgomery Citchfield   Slack   2   06 S W, P. 01   46     Peoria Elmwood   Vein Sample   5   July   98 B L, S. 02   45     Peoria Elmwood   Vein Sample   6   July   98 B L, S. 02   45     Peoria Elmwood   Vein Sample   6   July   98 B L, S. 02   45     Peoria Elmwood   Vein Sample   6   July   98 B L, S. 02   45     Peoria Elmwood   Vein Sample   6   July   98 B L, S. 02   45     Peoria Elmwood   Vein Sample   6   July   98 B L, S. 02   54     Peoria Elmwood   Vein Sample   78 B L, S. 02   54     Peoria Elmwood   Vein Sample   78 B L, S. 02   54     Peoria Elmwood   Vein Sample   78 B L, S. 02   54     Peoria Elmwood   Vein Sample   78 B L, S. 02   54     Perry Du Quoin   Lamp   8 B L, S. 02   54     Perry Du Quoin   Lamp   Sept. 95 B L, S. 02   54     Perry Du Quoin   Lamp   Sept. 95 B L, S. 02   54     Perry Du Quoin   Lamp   Sept. 95 B L, S. 02   54     Perry Du Quoin   Lamp   6   Mar 27 06 Chem Dett. 4     Perry Du Quoin   Lamp   6   Mar 27 06 Chem Dett. 4     Perry Du Quoin   Lamp   6   Mar 27 06 Chem Dett. 4     Perry Du Quoin   Lamp   6   Mar 27 06 Chem Dett. 4     Perry Du Quoin   Lamp   6   Mar 27 06 Chem Dett. 4     Perry Du Quoin   Lamp   6   Mar 27 06 Chem Dett. 4     Perry Pincknerytile Lamp   6   Mar 27 06 Chem Dett. 4     Perry Pincknerytile Lamp   6   Mar 27 06 Chem Dett. 4     Perry Pincknerytile Lamp   6   Mar 27 06 Chem Dett. 4     Perry Pincknerytile Lamp   6   Mar 27 06 Chem Dett. 4     Perry Pincknerytile Lamp   6   Mar 27 06 Chem Dett. 4     Perry Pincknerytile Lamp   6   Mar 27 06 Chem Dett. 4     Perry Pincknerytile Lamp   6   Mar 27 06 Chem Dett. 4     Perry Pincknerytile Lamp   6   Mar 27 06 Chem Dett. 4     Perry Pincknerytile Lamp   6   Mar 27 06 Chem Dett. 4     Perry Pincknerytile Lamp   6   Mar 27 06 Ch	100	Mercel	Culyla	Clarely		7	_	41 43	37 77	8.02	11.78	4 00	12,508
Morece	700	Margar	Cilebriet	Tage W		.98 B	'n	35.33	36.94	7.48	20.36	4.86	11,479
Morece	100	Margar	Cherrard	Lumn	-	S. TO.	2	45.25	39.36	9.60	£ ∞	3.05	13.136
Montgomery Literhield	000	Moreor	Sherrard	Linch	-	5.		37.05	36.72	7.84	18.39	4.78	11,004
Nontgenery Lichtlield   Lump   2   111	200	Montgomorn		Slack	0	3	2	41.88	36 34	7.91	13.84	3 10	12,101
Peorial Elimwood   Vein Sample   5 July   98 B L S. '102 49 19 19 19 19 19 19 19 19 19 19 19 19 19	100	Montgomers		Lumn	ર હ	·/	2	46.08	38.74	9.22	5.98	1.77	13,329
Peorial Elimwood   Vein Sample   3 July   988 B L S. 02   43     Peorial Elimwood   Vein Sample   5 July   98 B L S. 02   43     Peorial Elimwood   Vein Sample   5 July   98 B L S. 02   43     Peorial Elimwood   Vein Sample   5 July   98 B L S. 02   44     Peorial Holles   Vein Sample   70 B K Chem   Peorial B L S. 02 B K Chem   Peorial Holles   Vein Sample   70 B L S. 02 B K Chem   Vein Sample   70 B K Chem   Peorial B L S. 02 B K Chem   Vein Sample   70 B K Chem   7	200	Paorin				288		40.78	44.45	9.38	5.41	2 61	13,606
Peoria   Elimwood   Vein Sample   5 July   98 B L S. 02   45   45   45   45   45   45   45   4	500	Doorin	Flantood	Voin Samuela	ଟ	Z X5	1	41.30	43.63	8 70	6.37	2.75	13,603
Peoria   Elimwood   Vein Sample   6   July   78 B L x S   16   16   16   16   16   16   16	100	Doorie	Elmwood	Vein Lample	10	2 ×6.	5	42.30	26.78	10.55	10.37	1.29	12,879
Peoria   Elimond   Vein Sample   778 B. L. S. '02   55     Peoria   Holles   Nat.   14   14     Peoria   Holles   Nat.   14   14     Peoria   Holles   Nat.   14   14     Perry   Du Quoin   Vein Sample   78 B. L. S. '02   43     Perry   Du Quoin   Vein Sample   78 B. L. S. '02   43     Perry   Du Quoin   Lamp   Sept.   38 B. L. S. '02   44     Perry   Du Quoin   Lamp   Sept.   38 B. L. S. '02   44     Perry   Du Quoin   Lamp   Sept.   38 B. L. S. '02   44     Perry   Du Quoin   Nat   6   B. L. S. '02   44     Perry   Du Quoin   Nat   6   Nat   1. S. '02   44     Perry   Du Quoin   Nat   6   Nat   1. S. '02   44     Perry   Du Quoin   Nat   6   Nat   1. S. '02   44     Perry   Du Quoin   Nat   6   Nat   1. S. '02   44     Perry   Du Quoin   Nat   6   Nat   1. S. '02   44     Perry   Du Quoin   Nat   6   Nat   1. S. '02   44     Perry   Du Quoin   Nat   6   Nat   1. S. '02   48     Perry   Pinckneyville   Lamp   6   Nat   1. S. '02   48     Perry   Pinckneyville   Lamp   6   Nat   1. S. '02   48     Perry   Pinckneyville   Lamp   6   Nat   1. S. '02   48     Perry   Pinckneyville   Lamp   6   Nat   1. S. '02   48     Perry   Pinckneyville   Lamp   6   Nat   1. S. '02   48     Perry   Pinckneyville   Lamp   6   Nat   1. S. '02   48     Perry   Pinckneyville   Lamp   6   Nat   1. S. '02   48     Perry   Pinckneyville   Lamp   6   Nat   1. S. '02   48     Perry   Pinckneyville   Lamp   6   Nat   1. S. '02   48     Perry   Pinckneyville   Lamp   6   Nat   1. S. '02   48     Perry   Pinckneyville   Lamp   6   Nat   1. S. '02   48     Perry   Pinckneyville   Nat   1. S. '02   48     Perry   Perry   Perry   Nat   1. S. '02   48     Perry   Perry   Nat   1. S. '02   48     Perry   Perry   Nat   1. S. '02   48     Perry   Perry   Nat   1. S. '02   48     P	200	Dagrin	Fluwood	Vein Cample	0 00	£1 86.	T.	43.90	35 50	9.30	11 30	3.16	12,403
Peoria   Holles   Lamp   2   0.01 S. W. P. 04   44     Petry   Du Quoin   Vein Sample   778 H L. S. 02   64     Petry   Du Quoin   Vein Sample   778 H L. S. 02   64     Petry   Du Quoin   Camp   Petry   B. L. S. 02   64     Petry   Du Quoin   Camp   Petry   B. L. S. 02   64     Petry   Du Quoin   Camp   Petry   B. L. S. 02   64     Petry   Du Quoin   Camp   Petry   B. L. S. 02   64     Petry   Du Quoin   Camp   Petry   B. L. S. 02   64     Petry   Du Quoin   Camp   Petry   B. L. S. 02   64     Petry   Du Quoin   Camp   Camp   Petry   B. C. S. 02     Petry   Du Quoin   Camp	200	Daoria	Elmwood	Vein Cample	,	₹ X.	5	55 30	97 60	7 60	9 50	. es	:
Peoria   Holles   Nut.   2   June   6   98   S. W. P.   91   44	000	Doorin	Hollos	Lumn	٠	1	П	98.14	42.66	7.86	7 68	2.41	12,893
Perry   Da Quoin   Lamp   June 16, 987 (hem. Dept. 48)     Perry   Du Quoin   Vein Sample   778 H   L. S. 92     Perry   Du Quoin   Perry   Du Quoin   Perry   Du Quoin   Lamp   L. S. 92   44     Perry   Du Quoin   Lamp   Perry   Sept. 48 H   L. S. 92   44     Perry   Du Quoin   Lamp   L. S. 92   44     Perry   Du Quoin   Lamp   L. S. 92   44     Perry   Du Quoin   Lamp   L. S. 92   44     Perry   Du Quoin   Nut   6   Mar   27 96 (John Dept. 48     Perry   Puddy Vailey   Lamp   6   Ul S. 97   96     Perry   Puddy Vailey   Lamp   6   Ul S. 97   96     Perry   Pinckneyville   Lamp   96   96   96   96   96   96   96   9	000	Daoria	Hollee	Nut	। ङ	ď		43.03	41 13	8.04	7 80	3.13	12,956
Perry   Du Quoin   Vein Sample   77 H   L S   62   49	010	Darre	Da Oucin	Lumn	2	. '98 Ch		48.59	33 15	8.13	9 21	:	:
Perry   Du Quoin   Vein Sample   778 B L. S. 02 60	012	Dorns	Du Quoin	······ Ampri		76,		49.51	33.15	8.13	9.91	88.	
Perry   Du Quoin   B. L. S. 02, 44, 14, 14, 14, 14, 14, 14, 14, 14, 14	112	Darry	Du Quoin	Vein Samula			30. 30.	60.60	23.54	98.8	7.00	1.88	12,355
Perry   Din Groon   B. L. S. 02, 53, 54, 54, 54, 54, 54, 54, 54, 54, 54, 54	212	Dorm	Du Quoin	· · ordrame · · ordram		~	. v. 105	41.60	35.03	7.03	13.34	:	11,820
Perry   Din Quoin   Camp   Peb   15 S 02 45 45 45 46 46 46 46 46 46 46 46 46 46 46 46 46	511	Dorey	Du Onoin			2	T.	53.69	32.03	6.84	7.44	:	13,064
Perry   Du Quoin   Lamp   Feb. 95 B L. S. 02 45   Perry   Du Quoin   Lamp   Sept. 95 B L. S. 02 45   Perry   Du Quoin   Lamp   Sept. 96 B L. S. 02 41   Perry   Du Quoin   Slack   May 86 B L. S. 02 41   Perry   Du Quoin   Nut 6   Nat 7 5 B L. S. 02 41   Perry   Du Quoin   Nut 6   Nat 7 5 B L. S. 02 41   Perry   Du Quoin   Nut 6   Nat 7 6 B L. S. 02 41   Perry   Du Quoin   Nut 6   Nat 7 6 B L. S. 02 41   Perry   Nuddy Valley   Lamp 6   Nat 7 6 B L. S. 02 45   Perry   Pinckneyville   Lamp 6   Nut 8 B L. S. 02 45   Perry   Pinckneyville   Lamp 6   Nut 8 B L. S. 02 45   Perry   Pinckneyville   Lamp 6   Nut 8 B L. S. 02 45   Perry   Pinckneyville   Lamp 6   Nut 8 B L. S. 02 45   Perry   Lamp 6   Nut 8 B L. S. 02 48   Perry   St. John   Lamp 6   Nut 8 B L. S. 02 48   Randolph   Sparta   Nut 6   Nut 8 B D D D D D D D D D D D D D D D D D D	200	Perry	Du Quoin			В.	T.	54.08	30.35	6.67	8.30	:	13,279
Perry   Dir Quoin   Lamp   Sept. 98 B L S. 902   47     Perry   Dur Quoin   Lamp   Lam	916	Perry	Du Onoin	Lumb		'95 13.	ď.	45.10	39.81	7.43	7.66	:	
Perry	2 6	Perry	Du Quoin	['amb		:	L. S. '02	47.53	35.77	7.59	9.11	:	19,174
Perry   Du Quoin   Slack   May 98 B L S 02 41	016	Perry	Du Quoin	Lumb		٠,	L. S. '03	50.85	34.61	9.14	5.40	:	13, 273
Perry   Du Quoin   Nut   6   Jan   '9'8 B L S '02   44     Perry   Du Quoin   Nut   6   (04.8 W P '04   44     Perry   Du Quoin   Nut   6   (04.8 W P '04   44     Perry   DuQuoin   (Jamp   6   July '9'6 B L E S '02   48     Perry   Pinchecyville   Lamp   6   (01.8 W P '04   45     Perry   Pinchecyville   Lamp   6   (01.8 W P '04   45     Perry   St. John   Lamp   6   (01.8 W P '04   48     Perry   St. John   Lamp   6   (01.8 W P '04   46     Randolph   Sparta   Nat   (01.8 W P '04   45     Randolph   Shack   Shack   (01.8 W P '04   45     Randolph   Sharta   Shack   (01.8 W P '04   45     Randolph   Tilden   (01.8 W P '04   45     Ti	516	Perry	Du Quoin	Slack		98 13.	Ĵ.	41.60	35.95	6.05	16.40	5.14	11,762
Perry   Du Quoin   Nut   6   0.04.8 W P '0.04   49     Perry   Du Quoin   Nut   6   0.04.8 W P '0.04   44     Perry   Du Quoin   Nut   6   0.04.8 W P '0.04   48     Perry   Pinckneyville   Lamp   6   0.04.8 W P '0.04   48     Perry   Pinckneyville   Lamp   6   0.04.8 W P '0.04   48     Perry   Pinckneyville   Shack   0.04.8 W P '0.04   48     Perry   St. John   Lamp   0.04.8 W P '0.04     Perry   Sparta   Lamp   6   0.04.8 W P '0.04     Randolph   Sparta   Nut   6   0.04.8 W P '0.04     Randolph   Tilden   Nut   0.04.8 W P '0.04     Randolph   Tilden   0.04.8 W P '0.04     Rando	066	Perry	Da Ouoin.			. 195 13.	'n.	41.56	35.03	7.03	13.30		SIX'II
Perry   Du Quojn   Nut   6   Mar 27 '06   S W P''04   44     Perry   DuQuojn   Lamp   6   Mar 27 '06   Chem. Dent   48     Perry   Pinckrovylle   Lamp   6   01 S W P'' 01   45     Perry   Pinckrovylle   Lamp   6   01 S W P'' 01   45     Perry   Pinckrovylle   Lamp   6   01 S W P'' 01   45     Perry   St. John   Lamp   Feb   97 B I. S '02   48     Randolph   Sparta   Lamp   6   04 S W P'' 04   45     Randolph   Sparta   Shack   6   04 S W P'' 04   47     Randolph   Tilden   Shack   6   04 S W P'' 04   44     Randolph   Tilden   Shack   6   04 S W P'' 04   44     Randolph   Tilden   Shack   6   04 S W P'' 04   44     Randolph   Tilden   Shack   6   04 S W P'' 04   44     Randolph   Tilden   Shack   6   04 S W P'' 04   44     Randolph   Tilden   Shack   6   04 S W P'' 04   44     Randolph   Tilden   Shack   6   04 S W P'' 04   44     Randolph   Tilden   Shack   6   04 S W P'' 04   44     Randolph   Tilden   Shack   6   04 S W P'' 04   44     Randolph   Tilden   Chem	251	Perry	Du Quoin.	Nut	9	.0v.	٦	49.07	35.97	8.41	6.52		13,055
Perry   DuQuoin   Lamp   Mar. 27 '''' 6 Chem. Dept.   48   Perry   Muddy Valley   Lamp   6   0''' 18   18   18   18   18   18   18   1	666	Perry	Du Quoin.	Nut	8	.0. .v.	<u>-</u>	41.00	38.72	7.24	10.04	3.01	12,710
Perry   Muddy Valley   Lamp   6   July   ''96 B   L. S. '02   48.   Pincknovyllie   Lamp   6   01 S. W. P. '01   48.   Perry   Pincknovyllie   Lamp   6   01 S. W. P. '01   48.   Perry   Lamp   Feb   July   '96 B   L. S. '02   48.   Perry   St. John   Lamp   Feb   '97 B   L. S. '02   48.   Perry   St. John   Lamp   6   Peb   '97 B   L. S. '02   48.   Randolph   Sparta   Nat.   6   04 S. W. P. '04   44.   Randolph   Tilden   Slack   6   04 S. W. P. '04   44.	666	Perry	DuQuoin.	Lump		27, '06 Che	De	48 45	34.28	7.15	10.12	.71	12,218
Perry   Pinckneyville   Lump   6   01 S W P   01 S Perry   Perry   Pinckneyville   Shack   6   01 S W P   01 S Perry   Pinckneyville   Shack   6   July   96 B   L S   02 S Perry   St. John   Lump   6   Peb   97 B   L S   02 S Perry   Shack   Nandolph   Sparta   Nant   6   04 S W P   04   44   Randolph   Pilden   Shack   6   04 S W P   04   44   Randolph   Pilden   Shack   6   04 S W P   04   44   Randolph   Pilden   Pild	0.00	Perry	Muddy Valley.	Lump	:	96		48.23	40 37	7.11	4 29		12, 790
Perry   Pinckneyville   Slack   6   July   96   18   18   5   19   19   19   19   19   19   19	995	Perry	Pincknerville.	Lump	9	10		45.96	39 20	7.54	7.30	38	13,067
Perry   St. John   Lamp   July 96 B L S 92 51     Perry   St. John   Lamp   Feb 97 B L S 92 48     Randolph   Sparta   Nat. 6   04 S W P 94 45     Randolph   Tilden   Slack   6   04 S W P 94 47     Randolph   Tilden   Slack   6   04 S W P 94 47     Randolph   Tilden   6   04 S W P 94 47     Randolph   Tilden   6   04 S W P 94 47     Randolph   Tilden   6   04 S W P 94 44     Randolph   Tilden   6 S W P 94 44     Randolph   Tilden	226	Perry	Pinckneyville.	Zlack	9	5.		39.16	31.36	7 26	22. 22	3.10	10,784
Perry   St. John   Lamp   6   Peb   97 B. L. S. '02   48.   Randolph   Sparta   Nat.   6   OH S. W. P. '04   41.   Randolph   Tilden   Slack   6   OH S. W. P. '04   44.	266	Perry.	Tohu.	Lump.		96.		51.10	37.00	9.63	2.27	:	13,215
Randolph   Sparta   Lump   6   00 S W P 04   47   18   18   19   19   19   19   19   19	223	Perry	St. John	[ramb	:	26.		18.34	31.56	10.72	5 5 5 5 5 5 5 5 5 5 5 5 5 5 5 5 5 5 5		13, 104
Randolph Sparta Nat 6 713 W P. 01 47 Randolph Tilden Slack 6 704 S. W. P. 04 44	529	Randolph	Sparta	Lump	8	7. 70,		16.23	37.61	# do	#0 0 0	2.40	16, 150
Randolph [Filden   Slack 6   04 S. W. P. 04	230	Randolph	Sparta.	Nat	9			47.23	36.75	50.7	10 43	0.40	19 212
	231	Randolph	.  Tilden	Slack	9			4-1-30	31.10	, , , ,	10.10	0.10	2000

12,620 12,564 11,443	12,670	11,760	12,074	13,431	10,874	12,825	11,879	12.000	13.603	14,113	13,886	13,665	10,993	11.913	13,099	11,602	12, 228	11,831	12,100			12,821	19,093	11.319		:	11,239	11,700	:	12.426	13,608		11,818	0.8.01	10,542	110,51	12.571	12,032	12,217	12,591	12,364	11.939
3.35	3 33	 	5.00	2 2 2	2.00	00.4	07.50	90.6	× × ×	1.15	1.61		0F:2	02.30	9.60	3.50	2.73	3.03		3.31	• 1	- 55	0.40	33.53	5.09	.83 .83	6.03	1.73	4,03	7.7		4.33	4.10		1.01	66.6	06.8	3.90	4.08	6.14	3.55	2.90
7,73 8.38 16.31	7 37	13.77	4- x	06.8	23.58	10.88	20 08	3.5	8.18	5.36	5.50	7.01	00.01	14.58	7.67	16.37	10,49	14.19	10.70	17.00	12.90	30 g	20.01	16.91	19.41	12.20	18.00	12,55	12.00	000	6.15	14.10	16.46	20.12	10.40	36	11.34	12.96	12.16	15.55	25. 178	13.67
8.68 8.08 8.13	7.78	7.15	5.92	5.68	4.36	70.5	9.5	7 ₹10	6.01	4.29	4.20	3.76 3.6	0.70	4.72	10.46	9.38	6.46	10.10	7.40	10.08	3,76	10.03	19,04	11,44	12.54	9.38	8.69	6.9%	- 0X	6.38	11.10	8.83	90 90 90 90 90 90 90 90 90 90 90 90 90 9	9 20 20	19 47	10.45	17.1	11.32	11.56	5.42	00.00 00.00	10.95
37.06 41.30 35.41	40.78	57.07	2 00 1 50 00 00 00 00 00 00 00 00 00 00 00 00	33.32	39.36	34 36	21.75	33.91	31,19	34.06	37.12	36.11	97.17	200	38.96	31.50	39.52	35.78	35.70	27.35	38.15	200.00	34 10	29.18	33.65	35.25	34.72	98.00	200	35,39	38.45	36.51	36.96	96.00	35.41	35.89	36.61	37.08	34.54	36.59	50.15	34.26
46.53 42.24 40.23	44.10	200	26.75	52.10	45.70	19.73	75 o o 1	200	56.39	56.29	53.18	03.12	71.00	48.98	49.91	39.75	13.60	40.00	46.30	45.60	45.19	43.45	13.41	45.44	41,40	43.17	38.59	20.02	40.01	48.45	44.30	40.56	9.50	12 90	40.57	41.68	47.38	38.64	41.74	42.4	27.07 27.07 27.07 27.07	41.19
	S. W. P.	7 5	1 '05 Chem. De				Apr. '04 Chem Dent	haly '05, Chem. Pept	vpr. 26, '05 Chem. Dept	Apr. 1, '05 Chem, Dept		104 O. W. P. Od.	12	0. d. W. P.	2	ď.	귝.	ച്:	B. L. S. '02.	<i>i</i>	9,2	10 M M 2 10	- 2	0.1 S. W. P.	T,	99 B. L. S.	χif	04 Chem	. 99 B. L.		'89 B. L.	_i; 		Jen 109 Chem Dept.	97 B. L.	.97 B. L. S.				20,	Sep. 23 to Chem Dept	Apr. 27, '06  Chem. Dept
999	90	0	P	22			. 4		Α	Α	101	G M	5 rc	10	9	9	9	9	:		¥	G 10	7.0	10	M		N	¥ !	N				9				7.0	5	10	20	F G	A
Lump	Lump	Nut.	Lump	Lump	Slack	Stack	[,11111]		Lump	Lump	Lump	Land	Lump	Stack	Lump	Slack	Nut	Slack		vern sample	red	Flaci	Nut	Slack	Pea	Fea	Lump	olden	Pea			-ea	Slack	Jea	umn)		dun	dun'r	Slack	'ea	dimen.	ea
TildenFrench Village French Village	Marissa	Marissa	Marissa	Eldorado	Eldorado	Eldorado	Eldorado	Galatia	Harrisburg	Harrisburg	Harrisburg	Harrisburg	Harrisburg	Harrisburg	Auburn	Auburn	Auburn	Auburn	Barelay	Barelay	Cantrall	Cantrall	Dawson	Dawson	Dawson	Dawson	Javernon	Ridgely	Ridgely	Riverton	Riverton	Kiverton	Riverton	Riverton	Spaulding.	springfield	Springfleld	:	:	Springheld		d
Ran St.	รู้เก็	St. Clair	3	X.	25.7	Saline	Saline	£ 2.	Sal		3 3 3 3						-		-	Sangamon .	2 0	200	,,	94.	91 .	1111	Cangamon .	Sangamon	Sangamon	Sangamon		12.3	Sangamon	191	Sangamon	Sangamon	Sangamon	Sangamon	Sangamon	Sangamon	Sangamon	Sangamon
2333	235	937	238	239	0+2	242	50	214	245	246	7.5% G	510	250	251	255	253	102	200	000	2000	950	096	261	262	263	204	966	267	368	69%	270	112	57.5	51.6	275	926	277	87.0	8/2	281	585	283

# TABLE VII (Concluded)

Source of Sample	f Sample	Dogoniostion				5			-		
		ndi iseaci	uc		Analysis	Fro	ximate A	Proximate Analysis-Air-Dry Coal	ir-Dry (	oal	R T II nor
	Town	Size	Geol. Seam	Date of Analysis	Obtained from	Fixed	Volatile Matter	Moisture	Ash	Sulphur	lb. of Total Dry Coal
	Springfield Jc			:	'99 B. L. S. '02	55.55	37.04	9.11	10.33	3.65	
		ramb	:	Feb97	Chem Dept	40.57	32.4	13.47 0 11	11.52	2 67	11,980
Sangamon				: :	Chem. Dept	41.57	36.56	x.73	13.08	3.43	12,162
angamon				:	5 Chem. Dept	41.33	. 32. 28	9.19	17.20	3.76	11,537
-	Moweagua	[Jump		:	5 E. L. S. '03	43.75	39.58	9.18	7.49	:	13,026
	Moweaqua	Fum1	(	:	5 B. L. S. 02	45.57	36.57	8.77	9.00	:	:
	Moweagna	Lump	2 k		5 L. S. 02	42.14	2.3	7.08	7.98	:	:
: : :	Moweadua	ramb	o.	Dec 35		46.00	39.93	3.3	6.47	:	- 1
	Moweaqua	NTt			3; 3;	30.2	37.00	7.17	13.74		11,185
::	Mowearing	Clark	O ro	5.	40	10.5	67.14 90 00	20.00	82.03	330	12, 157
Zermilion (	Athin	Lumb	3 6			46.06	50.02 90.10	9.19	10.16	3.27	13,401
:	Latlin	Shady	- [-			4.1 93	00.10	00.00	2 10	7.1.0	11 407
:	totlin	Voin County				10.10	31.00	 06.3	50.00	200.20	11,457
:	atlin	Sereen		Mar.	<u> </u>	13 10	90-16	7.41	10.75	9.30	19 960
_	Buville	Vein Sample		( )	9	11.56	31.90	09.6	11 61	0.70	000,00
	)apville	and the state of t			Z	45.37	43.70	200	6.15	2	13, 134
ermilion	Janville				Z. Z.	46.49	37.07	5.62	10.88		12,349
_	)anville				B. L. S. 62	53.00	32.35	11.00	3.65		13.803
ermilion 1	)anville	Sereen		May 96	B. L. S.	31.20	33.30	01 6	93.10		10.331
-	)anville	Lump			B. L.	40.50	47.47	7.56	4.47	3.63	
ermilion	)anville	Lump	:	Mar '00	'n	17.37	40.61	.00°	3.93	1.97	
ermilion	Janville	Slack	{-	.0.	1 S. W. P. 704	48.14	35.06	3.41	13.36	3.38	12,333
ermilion	)anville	Lump	{-	.0,	a,	13.01	45.96	8.38	5,65	\$3.00 \$3.00	13,740
:	)anville	Slack	{-	0.	٦.	37.70	34.83	30°x	19.47	3.10	11,525
-	Janville	Lump	9	0,	S. W. P.	11.80	18.14	9.30	7.06	3.40	12,553
ermilion P	dairmount	Slack	7-	to,	S. W. F.	37.35	36.47	7.59	18.69	3.67	11,134
ermilion k	airmount	Screen	:	Dec 39	.96 B. L. S. '02	39.82	36.46	10.67	13.05	:	12,191
-	"airmount	Sereen	:		i.	17 05	31.80	8.10	13.05	:	12,438
ermilion C	Jrape Creek	Vein Sample	:	July 72		51.33	28.34 28.34	9.74	10.60	3.63	
:	trape Creek	l'umb	9	Ď. :::::	۲.	92 91	35.49	11.85	5.90	2,43	13,120
:	Srape Creek	Cump	9	0	٠.	18, 48	34.81	11.57	5.14	22.	13,186
:	Oakwood		:		'89 B. L. S. '02.	46.00	37.55	7.80	8.65	:	13.587
:	Oakwood	Lump		٠.	05 Chem. Dept	15.13	37.40	6.8(	10.67	3.40	19,503
rermilion C	Oakwood,	Sereen			05'Chem, Dept	12.19	35.55	8.2	14.05	3, 23	11,497
)	akwook	Sereen		Apr 02	05, Chem. Dept	38.88	33.43	6.03	21.67	3.21	10,299
ermilion C	)akwood	Sereen		May 0	05 Chem, Dept,	41.76	35.25	80.9	16.91	3.14	11.067
	)akwood	Pea		25.	05 Chem. Dept	41.17	39.85	5.62	13.06	3.63	13.251
	Westville	Mine Run		0	00 Chem Dept	48.19	39.86	×.0.×	6.00	1.97	14.384
	S. Westville	Lumn	8		10. 10 M 2. 10.	47 19	25. 25.	11.90	36	ž	13.315
		TAMBLE AND A S S S S S S S S S S S S S S S S S S									

		12,760	10.819	13.866	14.014	13.844	668.61	19.477	13,499	13,563	19,986	12,839	19.836	13.517	19.976	13,179	12,716	13,352	12,986	13, 408	19.769	12,364	12,974	13,498	19.846	13.590	19 508	19 672	11 991	13.001	
1 29	0 - 0	CA. 1	2.34	6.0	2.01	2.43	1.97	1.15	1.03	1.00	£.	.85	17.	98.	1.15	<u>x</u>	1 05	3.10	£6.	1.97	1,49	:	0.00	.83	1.85	30	30	2.5			
9	00.0	4.20	16.38	4.49	4.14	× 5.	96.6	19.91	7.62	6.10	% 20° 20° 20°	12.3°	7.14	5.56	6.59	6.67	6.11	9.87	∞ 20.00 00.00	8.76	10.64	10.62	10.62	6.36	11.17	5.46	9.63	÷	17.80	68.9	
6.03	11 11	## C	10.55	11.98	10.35	11.52	5.90	4.9%	6.04	6.3%	30.00	.8.7	1.66	4.31	4.86	5.76	7.35	5.00	33.28	63 89.50 89.50	2.94	5,00	5.00	5.83	5.46	6.00	1.93	37.00	6.35	3.97	
41.30	20.00	25.50	32.57	38.05	36.57	36.36	35.00	35.64	33.18	33,58	35.00	37.	33.99	35.12	33.26	30.25	34.30	35.15	33.00	33.10	33.10	31.13	31.76	53.53	30.96	32.32	34.66	39.30	10.31	33.86	
48.79	48 09	2010	40.03	45.55	48,84	47,94	49.14	47.30	53.16	54,99	96.20	52.17	54 31	55.01	55.39	57.32	52.34	49.98	56.30	55.52	53.32	53.96	52.62	54.24	59.41	56.35	51.49	53.20	35.04	55.28	
Jan '01 B. L. S. '02	10. d W 8. po.		:	:	ă,	05 Chem. De	4,	1,0		i		00 B. L. S	Z : T : S : : : : : : : : : : : : : : : :	00 B. L. V	00 R. L. S.	39 B. L. S.	S . T . S	May. 26, '05 Chem. Dept	5.	:	Apr 04 Chem. Dept	:	:	ı,	41	4	j.	ó		ń	
Hand Sample.	Lump 2	Slack	2007		NO. 2	0.0%1	Clouds	Stack	Lames	W Whit	Mino Dun	W No 1	Wr No a	W. No. 4	Att Att a	M. No. 3	W. NO. 2	W. Nut No. 3	IV Doe Doeff	N 15 m Date	N L. W Co.	W Clock	IAT Nint	W. Classic	I man	Training	· vein Sample		Tack		-
6  Wabash, Sugar Creek	W 111	Will	Will	W:11	Will	Williamson	Williamson	Williamson	Williamson	Williamson	Williamson.	Williamson	Williamson	Williamson	Williamson	Williamson	Williamson.		Williamson	Williamson	Williamson Herrin	Williamson		Williamson	Williamson	Williamson Howin	Williamson I also Guard	Williamson Landen	Williamson	Williamson. Sundyside	
326	32	33	32	23	33	33	33	33	33	333	333	333		3.5	34	3.4	3.	5 65	3.4	3.4	334	33	34	35	35	25	0 6	3 5	35	3	

## TABLE VIII LIST OF ILLINOIS COALS ANALYZED. ARRANGED BY TOWNS

Town	County	Ref. Number in Table of Analyses
ssumption	Christian	8-12
storia	Fulton	28-30
thens	Menard	185-188
uburn		252-255
Barelay		256-258
Benton	Evantrin	27
senton	Mal con	110-116
Bloomington	Chunds	50-51
Braceville	Will.	327-328
Braidwood	Clinton	20-21
Breese	CIIIIIOII	57
Briar Bluff	Henry	
Brighton	Maeoupin	124
Bush	Williamson	332
Buxton	Clinton	22
able	Mercer	196-197
Canton	Fulton	31-32
Cantrall	Sangamon	259 260
	Jackson	62-65
ardiff		95-96
arterville	Williamson	331-345
Catlin	Vermilion	296-299
Centralia	Marion	145-148
Colchester		109
Colfax		117
Collinsville	Madison	138-139
luba	Fulton	33-36
Danville.	Vermilion	300-310
Dawson	Sangamon	261-264
Deeatur		118
Delafield		54
De Soto	Jackson	66-71
Divernon	Sangamon	265
Oonkville		140-141
Ounfermline		38
Ou Quoin		210-223
Edwarderilla	Madison	142 143
Eldorado	Saline	239 -243
Elm Grove		1-2
Ilmwood.		203-207
Etherly		76-77
airbury		97-98
Alroury		311-313
Pairmount		39-42
'armington	Fulton	43
Motroule	Crawford	26
orest	Livingston	99-100
rench Village		233-234
rench Village		244
aliva		58
		198
Gilchrist		141
Hen Carbon	Vermilion	314-316
Tape Creek	Menard	189-191
Freenview		125-126
Freenridge		245-251
Harrisburg	Williamson	346-352
Tella.	Paoria	208-209
	Peoria	7
vesdale	Will	329-331
	. Will	49
Junction	. Gallatin	79-80
aangley	La Salle	59-61
Kewanee	Henry	149-150
Ainmundy	. Marion	3-4
n d d	. Bureau	0.4

## TABLE VIII (Concluded)

Town	County	Ref. Number in Table of Analyses
La Salle	La Salle.	· 81-84
Lauder		354
_incoln		101-106
zitchfield		201-202
ombardville		5
owder		266
IcLeansboro		55
	St. Clair.	235-238
liddletown		192-193
Ioweagua		289-295
It. Carbon		72
It. Olive		127-132
It. Pulaski		107-108
	Perry	224
	Jackson.	73-75
	Macon	119-123
	Fulton	44-45
	Vermilion	317-322
	Marion	151-178
	La Salle.	85-88
	Macoupin	133-135
	. Christian	13-19
	Coles	25
	. La Salle.	89-90
	Menard	194-195
	. Perry	225-226
	Sangamon	267-268
liverton	. Sangamon	269-274
	Fulton	46-48
t. John	. Perry	227-228
andoval	Marion	179-181
herrard	. Mercer	199-200
	. Knox	78
	. Randolph	229-230
paulding	. Sangamon	275
	Sangamon	276-283
	Sangamon	284
	. Bureau	6
	. La Salle	91-94
	. Wabash	326
unnyside	. Williamson	355
ilden	. Randolph	231-232
	Marshall	182
renton	. Clinton	23-24
	. Macoupin	136-137
	. Marshall	183-184
	Vermilion	323
	Vermilion	324-325
. Wilmington	Grundy	52-53

## PUBLICATIONS OF THE ENGINEERING EXPERIMENT STATION

Bulletin No. 1. Tests of Reinforced Concrete Beams, by A. N. Talbot. 1904.

Circular No. 1. High-Speed Tool Steels, by L. P. Breckenridge. 1905.

Bulletin No. 2. Tests of High-Speed Tool Steels on Cast Iron, by L. P. Breckenridge and Henry B. Dirks. 1905.

Circular No. 2. Drainage of Earth Roads, by Ira O. Baker. 1906.

Bulletin No. 3. The Engineering Experiment Station of the University of Illinois, by L. P. Breckenridge. 1906.

Bulletin No. 4. Tests of Reinforced Concrete Beams, Series of 1905, by A. N. Talbot. 1906.

Bulletin No. 5. Resistance of Tubes to Collapse, by A. P. Carman. 1906.

Bulletin No. 6. Holding Power of Railroad Spikes, by R. I. Webber. 1906.

Bulletin No. 7. Fuel Tests with Illinois Coals, by L. P. Breckenridge. 1906.

# UNIVERSITY OF ILLINOIS

# ENGINEERING EXPERIMENT STATION

BULLETIN No. 8

SEPTEMBER 1906

# TESTS OF CONCRETE: I. SHEAR; II. BOND.

By Arthur N. Talbot, Professor of Municipal and Sanitary Engineering and in Charge of Theoretical and Applied Mechanics.

#### I. SHEAR.

Reference to current engineering literature and discussions will show that there exists in the minds of engineers quite diverse notions of the shearing resistance of concrete. Values as low as the tensile strength of the concrete are cited; others name a shearing resistance nearly as great as the compressive strength of the concrete. It seems evident that these divergent estimates must be due to inconsistent experimental methods or to improper conceptions of the nature of shearing action.

Shear is defined to be the action of two equal and oppositely directed forces whose lines of action are in planes very close together. Manifestly, in the actual application of forces to structures or even to test pieces, the applied forces are not in adjacent planes, and the shearing forces used in the analysis and calculation are forces which exist by virtue of the mechanics of the problem. The shearing stresses in concrete test pieces are discussed on the basis of some distribution throughout the section, generally a uniform or nearly uniform distribution. The importance of determining this distribution is not usually recognized. Shear should be differentiated from cutting action, in that the latter begins at the surface and involves, in some degree at least, a gradual tearing or detrusive action and a concentration of the

force at a single point. Shear should also be distinguished from the phenomena which may accompany it, as bearing action, diagonal tension, etc. In fact, the difficulties surrounding the determination of the shearing resistance of concrete are due largely to the accompanying cutting action, bearing pressures, and beam stresses involved in the test. In the breaking of reinforced concrete beams, shearing failures have been confused with diagonal tension failures (see Bulletin No. 4, p. 25), and calculations made from the results of such beam tests are evidently a source of low values given in texts and in the building ordinances of many of the cities of the country.

Fig. 1 illustrates a common conception of shear. The shearing force is considered to act along the line AB, and the shearing




FIG. 1. COMMON CONCEPTION OF SHEAR.

resistance is assumed to be uniformly distributed over the section on this line. Evidently these assumptions do not give the real action. Cutting action begins at the surface. The fibers are pushed inward immediately in front of the cutting edge. As this impression is increased, the bearing pressure is extended over a greater surface of the tool, though not uniformly so distributed, and the resultants of the applied forces will be moved away from the line AB. This separation of the applied forces gives a couple, with resulting beam action and horizontal and diagonal tensile and compressive forces. It is evident that the bearing action and resulting im-

pression modify conditions and also that the shearing stresses are not uniformly distributed over the section, and that cutting action may injuriously affect results. A little calculation will show that the bearing pressure for a thin tool would exceed the resistance of the concrete. Besides, a test piece could not be held in the position shown, and a further support will be necessary.

Fig. 2 shows a method which has been proposed and which is open to similar objections. Fig. 3 shows a test piece arranged to get double shear. Evidently the bearing bars, which are only about ‡ in. wide, will produce such high bearing pressures as to cause cutting action or at least cutting stresses. Fig. 4 is a

beam form of test piece. Here the test is complicated by flexural stresses and by deflection or opposition to flexure. The attempts at clamping the ends of the test piece to approximate to a restrained beam, such as are hereinafter described, are also open to objection. Punching tests do not give ideal conditions, as will be seen in the tests of plain plates.

It will be seen that these methods of making tests and of applying the load are open to some objection or other. What is wanted is to get as near ideal conditions as is possible and to approach the conditions which exist in structures under investigation. Take for illustration vertical shear in beams, which forms one of the most common and most important applications for the values to be obtained for shearing resistance. In this case, bearing stresses have little effect. Cutting action does not exist. The vertical shearing stresses are nearly uniformly distributed over the section below the neutral axis and vary only moderately over the compression area. (See Bulletin No. 4, p. 20.) Again attention should be called to the inconsistency of using the terms "shear failure" and "diagonal shear failure" in the case of beams failing by diagonal tension.

This bulletin records the results of shear tests made in the Laboratory of Applied Mechanics of the University of Illinois, together with statements of other available data. It is known that the methods used in the tests and the forms of test pieces used are open to objection, but investigations of this kind are experimental in methods as well as in materials, and the experiments in methods are of themselves of value. It is believed, too, that the results, when compared with those made elsewhere, will go toward establishing the general or comparative value of the shearing strength of concrete, and that no end would be subserved in holding the results for more complete data.

The tests were made principally as thesis work. The tests of 1905 were made by C. S. O'Connell and J. E. Shoemaker of the class of 1905 in civil engineering; those of 1906 by J. E. Schoeller and N. E. Seavert of the class of 1906. These men are entitled to credit not only for the care and industry displayed in their work but for the thought and study given to the problem. Acknowledgment is made to V. R. Fleming, 1905, for aid in the preparation of this bulletin.

#### Data from Various Sources.

Before taking up the University of Illinois tests, a few pages will be devoted to data taken from various sources and to a brief examination of these data.

It has already been stated that the prevailing notion among engineers is that the shearing strength of concrete is comparatively low. The text-books on concrete and reinforced concrete quote values equal to, or a little more than, the tensile strength of concrete and but a small part of the compressive strength. In the following data, instead of referring to the original publication of the experiments, reference is generally made only to the books which may be available to the general reader.

A set of tests on shearing strength of mortar which have been frequently quoted was made by Bauschinger\* in 1878. The test specimens were taken from test pieces 2.4 in.  $\times$  4.8 in.  $\times$  12 in. which had been broken in flexure. The results were interpreted to show that the shearing strength of the mortar was 20% greater than the tensile strength of similar mortars. It seems probable that in the method of testing used tension and not shear was the controlling element. Results of later tests seem to indicate that these values are not representative of the resistance of portland cement mortar in simple shear.

Marsh† quotes Feret as concluding "that the ultimate shearing resistance is proportional to that for compression, and obtains the relation that the shearing resistance is from 0.16 to 0.20 of the compressive strength; this would give us, taking 2175 pounds per square inch, (the mean compressive resistance at from four to six weeks) a shearing strength of from 350 to 435 pounds per square inch, and at a period of three months from 415 to 520 pounds per square inch".

Marsh also makes the following statement: "In a paper presented at the 1901 Budapest Congress, M. Considère gives the value of the resistance of concrete to shearing deduced from M. Mesnager's experiments as from 20% to 30% higher than the tensile resistance; this gives, taking the values from 260 to 285 pounds per square inch, as the mean at a period from four to six weeks, and 310 to 340 pounds per square inch at three months, which are

<sup>\*</sup> Sabin's Cement and Concrete, p. 328. Falk's Cements, Mortars and Concretes, p. 27.

<sup>†</sup> Marsh's Reinforced Concrete, p. 222.

TABLE 1.\* . STRENGTH OF PORTLAND CEMENT MORTARS. By R. Feret. .

(),()

.46

<sup>\*</sup> Taken from Concrete, Plain and Reinforced, by Taylor and Thompson, p. 136.

considerably below those found by M. Feret. Many authors assume that the resistance of concrete to shearing is less than its resistance to tension, and consequently give it a much lower value, but this assumption appears to be erroneous."

Taylor and Thompson\* give data from Feret's investigation which indicate a much higher shearing strength for mortar than that given in the preceding paragraph. Table 1 gives the shearing, tensile, and compressive strength of these mortars. It will be seen that the shearing strength ranges from 46% to 97% of the compressive strength and is three to six times the tensile strength.

The method of testing (see Fig. 2) may be open to criticism. The specimen is subjected to single shear, and the small bear-




FIG. 2. SHEAR TEST USED BY FERET.

ing area may produce excessive compressive stresses. Tensile stresses may govern the failure.

Considère † states that the experiments made by Mesnager tend to show that the resistance of mortar to shearing exceeds its tensile resistance as it is determined by the usual tests. Tests, which may be too few to allow of general conclusions, have shown a difference of 20% to 30% between these two resistances. Marsh‡ quotes Considère as applying the same statement to concrete.

Falk  $\S$  gives values of the shearing strength of concrete ranging from 65 to 314 pounds per square inch, and amounting to 10% to 18% of the compressive strength of the concrete.

<sup>\*</sup> Taylor and Thompson's Concrete, Plain and Reinforced, p. 136, taken from "Etudes sur la Constitution Intime des Mortiers Hydrauliques", in Bulletin de la Societe D'Encouragement pour L'Industrie Nationale, 1897. Series 5, Vol. 11, p. 1591.

<sup>†</sup> Considere's Reinforced Concrete, translated by Moisseiff, p. 104.

<sup>#</sup> Marsh's Reinforced Concrete, p. 222.

<sup>§</sup> Falk's Cements, Mortars and Concretes, p. 95. Figure showing method of test, p. 87.

# TABLE 2.\* SHEARING AND CRUSHING STRENGTH OF 1-3-5 CONCRETE.

	Br	M.	S.	$\mathbf{F}_{A}$	LK	
--	----	----	----	------------------	----	--

No.		Ultimate Crushing Resistance		Ultimate Shearing Resistance		
	Of 6-inch cube lb. per sq. in.	Age	lb. per sq. in.	Age days	Compression	
1 5 6 8 10 22 23	1870  1246 1196 863 922 600	177 164 157 151 128 128	195 314 166 187 158 104 65	169 165 164 157 151 128 128	.10 .13 .15 .18 .11	

Table 2 summarizes the data. The method of making the shearing test (Fig. 3) is open to criticism, particularly in that the high




Fig. 3. Shear Test Used by Falk.

bearing stresses cause a cutting action, and the failure of the specimens can hardly be said to be due to shear. The values obtained can not be considered to be representative of the shearing strength of concrete.

Tests made by Zipkes† on prisms  $7 \times 7 \times 15.8$  in. gave values of 357 pounds per square inch

for shearing strength of concrete 50 days old. The prisms were supported but not clamped, and the conditions resemble beam failure so much that the results can not be considered to represent ordinary shearing strength. Fig. 4 shows the form of test specimen.

<sup>\*</sup> Taken from Cements, Mortars and Concretes, by Falk, p. 95.

<sup>†</sup> Beton und Eisen, January, 1906, p. 15, et seq. Translation printed in Cement, March, 1906.

Tests on slotted concrete beams reported in the same article

are open to the objection that web stresses other than shearing stresses probably were the cause of the failure.

A valuable set of tests on the shearing strength of concrete was made at the Massachusetts Institute of Technology under the direction of Professor Spofford and the auspices of the Joint Committee on Concrete and Reinforced Concrete in 1905. A summary of the data is given in Table 3.

Fig. 4. Shear Test Used by Three grades of concrete were used Zipkes. and test pieces were stored in air and also in water. The cylindrical test piece was 5 in. in diameter and  $15\frac{1}{2}$  in. long and the ends were securely clamped above and below in cylindrical bearings. The load was applied along a length of  $5\frac{7}{16}$  inches of a semi-cylindrical bearing block. This manner of testing permitted the test piece to break first as a beam but final failure was by shear. Tensile stresses may have affected the results somewhat; if so, the values given are less than the true shearing stength.

TABLE 3.

SUMMARY OF SHEAR TESTS.

MADE AT MASSACHUSETTS INSTITUTE OF TECHNOLOGY.

Kind of	Method of		ng Streng per sq. in	Crushing Strength	Ratio of Shear to		
Concrete		Maximum	Mini- nium	Average	lb. per sq. in.	Compression	
1-2-4 1-2-4 1-3-5 1-3-5 1-3-6 1-3-6	Air Water Air Water Air Water	1630 2090 1590 1380 1450 1200	960 1180 890 840 950 1030	1310 1650 1240 1120 1180 1120	2070 2620 1310 1360 950 1270	0.63 0.63 0.94 0.32 1.25 0.88	

# MATERIALS, TEST PIECES AND TESTS.

The materials, forms of test pieces, method of testing and phenomena of the tests made at the University of Illinois in 1905 and 1906 will now be described.

Materials.—The broken stone used in the 1905 tests was Kankakee limestone screened through a 1-in. and over a \(\frac{1}{4}\)-in. screen. It was taken from the lot described more fully in Bulletin No. 4. The stone for the 1906 tests was similar in character but somewhat harder. The sand was coarse mortar sand, that used in the 1905 tests being the same as that described in Bulletin No. 4 and that used in 1906 being similar in character. The cement used in 1905 was the mixture of American portland cements furnished by the Joint Committee on Concrete and Reinforced Concrete described in Bulletin No. 4. The tensile strength of the neat cement was 723 pounds per square inch at age of 7 days, and 1-3 mortar gave 354 pounds per square inch at 7 days and 533 pounds per square inch at 75 days. The cement used in 1906 was similar in character.

Test Pieces.—As has already been stated, it is extremely difficult to make a test of concrete which will determine the shearing strength. Other stresses, tensile, bearing, and web stresses complicate the problem, and their action may be the controlling element of failure even when shearing action is the apparent cause. The form of test piece to be used was the first point to study, and one purpose of these tests was to find the effect of different forms of test pieces and learn what form is open to the least objection. Two methods of testing were used. In the first, a hole was punched in a concrete plate or block, and this method will be referred to as a punching test. The second method consisted in breaking a short concrete beam which was restrained at the ends. This method will be referred to as the restrained beam test.

Three forms of test pieces were used in the punching tests,—
1. plain concrete plate; 2. recessed concrete block; 3. reinforced recessed concrete block. As was to be expected, the plain concrete plate failure indicated that induced tensile stresses contributed to the failure, and the other test pieces were contrived in an attempt to overcome this defect. A cylindrical die  $5\frac{\pi}{8}$  in. in diameter was used in the punching tests. Fig. 5 (a) shows the dimensions of the plain concrete plate. In the recessed block, shown at (b),




Fig. 5. Forms of Shear Test Piece. (a) Plain Concrete Plate. (b) Recessed Block. (c) and (d) Reinforced Recessed Blocks.

the shearing area is the same, and the hollow space at the bottom is given a draft in order to facilitate drawing the form. This test piece is better fitted to withstand the tensile stresses developed during the punching operation. Fig. 5 (c) and (d) show the reinforced recessed blocks. A reinforcement of steel was embedded in the concrete. In two specimens tested in 1905 four bent bars,  $\frac{7}{16} \times 1\frac{2}{5}$ -in., were placed as shown in Fig. 5 (c), and in two specimens, eight bent rods,  $\frac{1}{4}$ -in. square and twisted, were similarly placed.

In making the tests, the test specimens were placed on a bed plate 1 inch thick, having an opening 6 inches in diameter in the center. The load was applied through a spherical bearing block, and a die 5½ inches in diameter placed on the test specimen formed the punching tool. Plaster of paris coatings were used on all bearing surfaces.

The test piece for the restrained beam test (Fig. 6) was  $4 \times 4$  in. in cross section and 13 inches long. The cast-iron bed plate was faced above and below, as were the two plates at the top.




Fig. 6. Restrained Beam Shear Test Piece.

TABLE 4.\*

Compressive Strength of 6-inch Cubes.

1905 Tests. 1-3-6 Concrete.

Concrete as in	Method of Storing	Age days	Compression Area sq. in.	Ultimate Load pounds	Compressive Strength lb. per sq. in.
Beam No. 35	Air Air	66 66	36 36	48000 47980	1330 1330
	Air	66	36	57400	1590
Beam No. 44	Air Air	67 67	36 36	38400 39800	1065 1105
Deam No. 44	Air	67	36	29400	816
~	Air	59	36	47200	1310
Beam No. 65	Air	59	36	41600	1156
	Air	59	36	48850	1355
A verage					1230

<sup>\*</sup> Taken from Bulletin No. 4, p. 32.

The bolts clamped the beam tightly on the bed plate. Plaster of paris coatings were used on all bearing surfaces. Fig. 10 shows the apparatus in testing machine.

TABLE 5.

Compressive Strength of 6-inch Cubes.

1906 Tests. 1-3-6 Concrete.

Ref.	Method of	Age	res- Area n.	Load in	Compressive Strength b. per sq. in.	
No.	Storing	days	Compression Are sq. in.	At First Crack	Ulti- mate	Compressi Strength Ib. per sq. i
1	Damp sand Damp sand Damp sand	60 60 60	$37.9 \\ 37.5 \\ 36.4$	70000 72000 73500	73200 73500 74500	1930 1958 2045
• 2	Damp sand Damp sand Damp sand	60 60 60	37.9 37.2 36.4	58000 67000 48000	86200 79500 75600	$\begin{array}{c} 2274 \\ 2135 \\ 2072 \end{array}$
3	Damp sand Damp sand Damp sand	61 61 61	$37.5 \\ 37.1 \\ 37.1$	92000 92000 78000	100700 113600 109200	2685 3060 2945
4	Damp sand Damp sand Damp sand	59 59 59	$\frac{37.1}{37.1}$ $\frac{37.1}{37.9}$	70400 84000 74000	101000 101800 97400	2722 2740 2568
Average .						2428
5	Damp sand Damp sand Damp sand	60 60 60	$37.1 \\ 37.1 \\ 36.8$	59600 53100 50100	65800 66500 58900	1773 1791 1600
\verage .						1721

Compressive Strength of Concrete.—An effort was made to find the compressive strength of concrete in order that comparisons with the shearing strength might be made. The method of making and storing the test pieces was not altogether satisfactory, and for this reason a comparison of strength can not be considered entirely trustworthy. All the cubes tested were 6-in, cubes. In the 1905 tests the concrete cubes were stored in air in a steam heated room where the temperature ranged from 60° to 70° F. Table 4 gives the compressive strength of 1-3-6 cubes of the 1905 tests. In the 1906 tests the concrete cubes were stored in sand

which was kept moist during the period of storage. The results of the test are given in Tables 5 and 6. It will be seen that the values found are very high. In fact, these results are so much higher than other tests of concrete cubes made in this laboratory that the difficulty of comparing the tests with tests made at other times is increased. The cause of these variations is somewhat obscure; the manner of storing is probably only one of the elements

TABLE 6.

Compressive Strength of 6-inch Cubes.

1906 Tests. 1-2-4 Concrete.

Ref. No.	Method of Storing	$\Lambda { m ge} \ { m days}$	Compression Area sq. in.	Load in At First Crack	pounds Ulti- mate	Compressive Strength Ib. per sq.in.
6	Damp sand	59	37.1	109500	128500	3463
	Damp sand	59	37.1	110000	129000	3480
	Damp sand	59	37.8	73400	121400	3212
7	Damp sand Damp sand Damp sand	59 59 59	$\frac{35.6}{36.8}$ $\frac{37.1}{37.1}$	96300 104000 100600	$\begin{array}{c} 108000 \\ 117600 \\ 120900 \end{array}$	3030 3193 3259
8	Damp sand	58	37.5	63400	124700	3322
	Damp sand	58	37.8	99900	143100	3790
	Damp sand	58	37.8	86800	138000	3650
9	Damp sand	59	36.8	79500	91900	2492
	Damp sand	59	36.4	98000	113700	3120
	Damp sand	59	37.1	69300	99300	2675
10	Damp sand	57	37.1	64000	111200	2998
	Damp sand	57	37.5	59100	98600	2630
	Damp sand	57	37.5	84300	106500	3840

of difference. Tables 7 and 8 give results of the compression tests made on cylinders 8 inches in diameter and 16 inches long. These specimens were of the same material as the 1906 cubes and were stored in the same manner. It will be seen that the compressive strength determined from the cylinder is materially less than that obtained with the cubes. In all compression tests, a spherical bearing block was used, and a coating of plaster of paris was used on the bearing faces.

TABLE 7. Compressive Strength of  $8\,x\,16$ -inch Cylinders. 1906 Tests. 1–3–6 Concrete.

Ref. No.	Method of Storing	Age days	Compression Area sq. in.	Ultimate Load pounds	Compressive Strength Ib. per sq. in.
$\frac{1}{\frac{2}{3}}$ $\frac{4}{5}$	Damp sand Damp sand Damp sand Damp sand Damp sand	60 60 60 61 59	49.6 49.6 49.6 49.3 49.4	60500 60000 60000 80400 66200	1220 1210 1210 1630 1340
Average 6	Damp sand	60	49.8	57800	1322 1160

Ref. No.	Method of Storing	$\Lambda { m ge} \ { m days}$	Compression Area sq. in.	Ultimate Load pounds	Compressive Strength Ib. per sq. in.
7 8 9 10 Average	Damp sand Damp sand Damp sand Damp sand	59 58 59 57	49.6 49.6 49.6 49.6	132000 126000 114000 110000	2660 2540 2300 2220 2430

Discussion.—The behavior of the plain concrete plates and of the unreinforced recessed blocks during the test indicates that tensile stresses were the primary cause of failure with these forms of test specimens. This tension may be likened to the bursting stress developed in a cylinder subjected to internal pressure. At a load of one-third to one-half of the ultimate load, hair cracks would appear at the bottom and middle of the exterior of the specimen. As the load was increased the crack extended upward and increased in width until at the ultimate load it attained a width of 15 inch at the bottom and extended to the top of the specimen. The specimen could then be broken apart with the hands, giving four exterior pieces and the punched central core. The appearance of the crack is shown in Fig. 8. The broken specimens are shown in Fig. 7. The core which was punched out always showed cracks on the bottom and these generally extended one-half to two-thirds the distance to the top. In some cases the specimen broke into two parts as a beam fails, and in others the corners rose a small distance much as a metal plate does during a punching operation. In every case tension failure at the lateral faces occurred before shearing took place, and it was evident that the final, or ultimate, failure was much influenced by this condition and that ultimate failure could not be said to be due to simple shear. The recessed specimens were better in this respect than the plain plates, and the shearing stresses were evidently more nearly uniformly distributed throughout the depth with this form.

The reinforced recessed blocks failed in a manner quite similar to the unreinforced recessed blocks except that the cracks appeared relatively later and did not open up when the ultimate load was reached. The shearing loads were higher than for the unreinforced specimens and the conditions were more favorable for developing the shearing strength of the material. This is especially true where hoops were used for the reinforcement. An objection which still remains in this form of specimen is that the manner of applying the load at the top of the piece does not give an even distribution of the shear throughout the vertical section.

The manner of failure of the restrained beam form of specimen was as follows: In specimens No. 1 to 5 (1-3-6 concrete) and No.6 (1-2-4 concrete) the first sign of failure was the appearance of cracks at the top as sketched in Fig 11 (a) at a load three-fourths to nine-tenths of the ultimate. These cracks seemed to be caused by a cutting action of the bearing plate or to tension due to beam action. As the load increased these cracks gradually lengthened and widened, as shown in Fig. 11 (b) until they finally reached a




Fig. 11. Manner of Failure in Restrained Beam Shear TEST PIECE.

TABLE 9. SHEARING STRENGTH OF PLAIN PLATES. 1905 Tests. 1-3-6 Concrete.

Ref.	Method of	Age	Shearing Area	Load in	pounds	Shearing Strength . per sq. in.
No.	Storing	days	sq. in.	At First Crack	Ultimate	Shea Stre Ib. per
39 40 41 42 43 44 45 46 47	Air Air Air Air Air Air Air Air	60 60 61 61 61 61 61 61	55.4 56.5 56.5 56.5 56.5 55.4 56.5 56.5	12000 18000 15000 28000 16000 14000 17000 18000 19000	37000 35000 39000 43500 36000 35000 42000 39500 36000	668 620 691 770 638 632 744 700 650
31 32 33 34 35 36 37 Average	Water Water Water Water Water Water Water	69 69 69 61 61 61 61	56.5 54.2 54.2 54.2 55.4 56.5 55.4	8000 15000 14000 12000 20000 13000 17000	36000 41500 38400 36200 47500 40000 42	637 765 708 667 857 709 758




Fig. 7. View Showing Recessed Blocks After Failure.



Fig. 8. View Showing Punching Test.




FIG. 9. VIEW SHOWING TEST PIECES.



Fig. 10. View Showing Restrained Beam Shear Test.

TABLE 10.
SHEARING STRENGTH OF PLAIN PLATES.
1906 TESTS. 1-3-6 CONCRETE.

Ref. No.	Method of Storing	Age days	Shearing Area sq. in.		Shearing Strength 1b. per sq. in.
1 2 3 4 Average	Damp sand Damp sand Damp sand Damp sand	60 60 61 59	57.8 61.0 58.9 60.1	18000 64 58000 60	0800 533 0500 1058 0500 1028 0200 1018 0909
จั	Damp sand	60	61.0	39500 + 59	968

TABLE 11.

SHEARING STRENGTH OF PLAIN PLATES.
1906 TESTS. 1-2-4 CONCRETE.

Ref. No.	Method of Storing	Age days	Sbearing Area sq. in.	Load in At First Crack	Ulti- mate	Shearing Strength lb. per sq. in.
6 7 8 9 10 Average	Damp sand Damp sand Damp sand Damp sand Damp sand	59 59 58 59 57	61.0 60.1 58.9 60.1 61.0	24200 22000 16600 12800 41800	81000 86800 64500 48000 79400	1330 1443 1095 799 1300

maximum width, of, say,  $\frac{1}{3}$  inch at the top. In specimens No. 7 to 10 (1-2-4 concrete) the first sign of failure was a tension crack as shown in Fig. 11 (c), which appeared at a load of one-third to four-fifths of the ultimate and gradually lengthened and widened as the load increased. Later cracks would appear at the top as shown in Fig. 11 (d). After the maximum load was reached, the lower crack gradually closed up and the upper cracks increased in width. The final shearing action occurred at a load less than the maximum and evidently took place over a much smaller shearing

TABLE 12.
SHEARING STRENGTH OF RECESSED BLOCKS.
1905 TESTS. 1-3-6 CONCRETE.

Ref.	Method of	Age	Shearing Area	Load in	pounds	Shearing Strength o. per. sq. in.
No.	Storing	days	sq. in.	At First Crack	Ultimate	Shea Stren lb. per.
14	Air	60	56.5	23000	51000	903
15	Air	60	56.5	23000	36700	650
16	Air	60	55.4	30000	52500	947
17	Air	60	54.2	21000	34800	642
18	Air	61	56.5		39000	691
19	Air	61	55.4	24000	49500	894
20 21 22 23	Air	61	54.2	22000	52500	968
21	Air	61	55.4	26000	49000	894
22	Air	60	56.5	19000	47000	832
23	Air	60	56.5		37000	655
24	Air	60	56.5	23000	51500	911
25	Air	60	56.5	19000	41000	725
26	Air	60	54.2	14000	32500	600
27 28	Air	61	56.5	17500	45500	805
28	Air	61	56.5	18000	40500	717
29 30	Air	61	56.5	24000	50000	885
30	Air	61	55.4	22000	45500	811
verage						796
1*	Water	69	55.4	25000	39500	713
2*	Water	69	54.2 54.2	24000	33000	609
3*	Water	69	54.2	25000	36000	664
4*	Water	69	55.4	19500	43000	775
6*	Water	63	55.4	25000	37100	670
8*	Water	61	55.4		40000	722
verage						692
9	Water	61	54.2	20000	52500	968
10	Water	61	56.5	21000	47200	886
11	Water	61	56.5	24000	50000	885
12	Water	61	55.4	24000	53300	961
13	Water	61	54.2	22000	37700	695
verage						879
rerage						01

<sup>\*</sup>These specimens were injured in removing the forms.

area than the full section of the beam. At the final failure of these beam specimens cracks formed as shown in Fig. 11 (e) through a portion of the depth. This portion of the vertical section evidently took the full shear.

## TABLE 13.

# Shearing Strength of Recessed Blocks. 1906 Tests. 1-3-6 Concrete.

Ref. No.	Method of Storing	Age days	Shearing Area sq. in.	Load in  At First  Crack	pounds Ulti- mate	Shearing Strength 1b. per sq. in.
$\begin{array}{c} 1\\2\\3\\4 \end{array}$	Damp sand Damp sand Damp sand Damp sand	60 60 61 59	$58.8 \\ 58.8 \\ 57.8 \\ 60.1$	54000 69400 63300 28000	66300 69800 69300 63300	1126 1187 1198 1052
Average 5	Damp sand	60	60.1	42000	54700	910

# ·TABLE 14. SHEARING STRENGTH OF RECESSED BLOCKS. 1906 Tests. 1-2-4 Concrete.

Ref. No.	Method of Storing	Age days	Shearing Area sq. in.	Load in  At First Crack	pounds Ulti- mate	Shearing Strength 1b. per sq. in.
6 7 8 9 10	Damp sand Damp sand Damp sand Damp sand Damp sand	59 59 58 59 57	60.1 56.5 57.8 58.8 57.8	39300 45600 41100 26200 19200	66200 82700 86500 74400 55900	1100 1463 1495 1262 967
Average						1257

TABLE 15.

SHEARING STRENGTH OF REINFORCED RECESSED BLOCKS.

1905 TESTS. 1-3-6 CONCRETE.

Ref. No.	Method of Storing	Age days	earing Area 4. in.	Load in	aring ength r sq. in.	
110.		cat, s	She A sq	At First Crack	Ulti- mate	She Str Ib. pe
48 49 50 51	Air Air Air Air	59 59 59 59	56.5 56.5 55.4 56.4	28000 36000 50000 52000	47000 65800 59000 64500	831 1165 1065 1142
Average .						1051

TABLE 16.

SHEARING STRENGTH OF REINFORCED RECESSED BLOCKS.

1906 Tests. 1-3-6 Concrete.

Ref.	Method of	Age	ring ea in.	Load in	pounds	ring ngth sq. in.
No.	Storing	days	Sheari Area Sq. in	At First Crack	Ulti- mate	Shea Stree lb. per
1 2 3 4	Damp sand Damp sand Damp sand Damp sand	60 60 61 59	58.5 57.8 57.8 57.8	73000 98000 100000 62300	89500 105500 108000 119100	1529 1825 1869 2060
Average .						1821
.5	Damp sand	60	58.8	58200	91500	1555

#### EXPERIMENTAL DATA AND DISCUSSION.

Data.—Tables 9, 10 and 11 give the results for the form of test piece called plain concrete plates. Tables 12, 13 and 14 give the results for recessed concrete blocks. Tables 15, 16 and 17 give the results for reinforced recessed concrete blocks. Tables 18 and 19 give the results for form of test piece called restrained concrete beam.

TABLE 17.

SHEARING STRENGTH OF REINFORCED RECESSED BLOCKS.

1906 TESTS. 1-2-4 CONCRETE.

Ref. No.	Method of Storing	Age days	Shearing Area sq. in.	Load in  At First Crack	pounds Ulti- mate	Shearing Strength 1b. per sq. in.
6 7 8 9 10 Average .	Damp sand Damp sand Damp sand Damp sand Damp sand	59 59 58 59 57	60.1 55.2 57.8 58.8 58.8	85300 37700 64300 56700 39300	145500 115500 160000 118000 84600	2420 2091 2767 2008 1440

Discussion.—Table 20 gives a summary of the shear tests, together with a comparison with the results of the compression tests. In considering the resistance of concrete to shearing action, as shown by these results, it will be well to take up the effect of the form of specimen upon the phenomena of failure, to consider the values obtained for ultimate failure and the elements which affect the shearing strength of concrete, and to compare shearing strength with compressive strength.

The tests bring out the difficulties of making shear tests. Even the best forms of test piece used proved not fully satisfactory for determining the strength of concrete in simple shear, and in particular their action does not conform exactly to the phenomenon as it exists in beam action. The tests throw light on the subject, and we may expect to be able to form a judgment on the shearing strength of concrete. In the plain plate test specimen the failure in tension caused by the bursting action evidently

TABLE 18.

# SHEARING STRENGTH OF RESTRAINED BEAMS. 1906 TESTS. 1-3-6 CONCRETE.

Ref. No.	Method of Storing	Λge days	Shearing Area sq. in.	Load in  At First Crack	vilti- mate	Shearing Strength 1b. per sq. in.
1 2 3 4	Damp sand Damp sand Damp sand Damp sand	60 60 61 59	34.0 35.0 34.0 34.0	41200 46000 33300	40500 48000 46500 45000	1190 1371 1368 1324
Average 5	Damp sand	60	34.0	34000	34700	1313 1020

TABLE 19.

SHEARING STRENGTH OF RESTRAINED BEAMS.
1906 TESTS. 1-2-4 CONCRETE.

Ref. No.	Method of Storing	Age days	Shearing Area sq. in.	Load in At First Crack	pounds Ulti- mate	Shearing Strength 1b. per sq. in.
6 7 8 9 10A 10B	Damp sand Damp sand Damp sand Damp sand Damp sand Damp sand	59 59 58 59 57 57	35.0 34.0 34.0 34.0 34.5 34.5	31500 46400 33400 29800 27000	54000 44000 58400 49300 45800 40500	1543 1295 1718 1450 1327 1175
Average						1418

weakened the piece to resist shear, and the results are lower than the real shearing strength of the concrete. In the recessed blocks the bursting effect is distributed over a greater area. The reinforced recessed blocks resisted the bursting pressure even better. The 1906 test pieces reinforced with hoops showed the exterior cracks at a load well up to the ultimate load and these cracks did not open up when the ultimate load was reached. This form is the best of those used in the punching tests. Objection may be made to the punching test that the specimen does not have full opportunity to expand laterally, but a greater objection is that the shearing stress is not distributed uniformly over the shearing area. It is possible that in the specimen reinforced with a hoop the restraint interfered with shear action. The phenomena are further complicated by the compression put upon the test piece and its distribution. In the restrained beam form of test specimen, tension and cutting cracks decreased the effective shearing area. Besides, the application of the load at the level of the top of the beam does not permit an even distribution of the shear throughout the given vertical section. It seems evident that the real shearing strength of concrete will be greater than this form of specimen will give.

In discussing the results given in Table 20, the diverse nature of the materials, the methods of storage, and the form of specimen must be borne in mind. The stone used in the 1906 tests was harder than in the 1905 tests, and the concrete was much stronger. The air-stored specimens were weaker than those not exposed to drying out. The richer mixture does not give proportionally higher strengths than the leaner one. This is to be expected, since the strength of the stone must exert a considerable influence upon the shearing strength and may limit the resistance to shear. The higher values found in the tests made at the Massachusetts Institute of Technology in 1905, as compared with the 1904 results referred to in Taylor and Thompson's Concrete. are explained as due to the better quality of stone used. The quality of the cements used may have had something to do with the difference. It must be remembered that these tests are not entirely comparable. However, it would seem that the results of all these tests may be interpreted to mean that the shearing resistance of concrete is as high as, and probably higher than, the

 $\begin{tabular}{ll} TABLE\ 20. \\ \begin{tabular}{ll} SUMMARY\ OF\ SHEAR\ TESTS. \\ \end{tabular}$ 

=				ests		trengt per sq			of Shear pression
Form of Specimen	Year	Kind of Concrete	Method of Storing	Number of Tests	Shear	Cube		Cube	Cylinder
Plain plate	1905 1905 1906 1906 1906	1-3-6	Air Water Damp sand Damp sand Damp sand	9 7 4 1 5	679 729 905 968 1193	1230 1230 2428 1721 3210	1322 1160 2430	.55 .59 .37 .56	.68 .83 .49
Recessed block	1905 1905 1906 1906		Air Water Water Damp sand Damp sand Damp sand	17 6 5 4 1 5	796 692* 879 1141 910 1257	1230 1230 1230 2428 1721 3210	1322 1160 2430	.65 .56 .71 .47 .53 .39	.86 .78 .52
Reinforced recessed block	1905 1906 1906 1906	1-3-6	Air Damp sand Damp sand Damp sand	4 4 1 5	1051 1821 1555 2145	1230 2428 1721 3210	1322 1160 2430	.86 .75 .90 .67	1.38 1.39 .88
Restrained beam	1906 1906 1906	1-3-6	Damp sand Damp sand Damp sand	4 1 6	1313 1020 1418	2428 1721 3210	1322 1160 2430	.54 .59 .44	1.00 .88 .58

<sup>\*</sup> Specimens injured in removing the forms.

values found with the recessed blocks in the punching tests and with the restrained beam test. The shearing strength of this limestone concrete at 60 days, as determined by these methods, may then range from 800 to 1100 lb. per sq. in. for the stone used in 1905 and from 1100 to 1300 lb. per sq. in. for the stone used in 1906, both for 1-3-6 mixtures. For the 1-2-4 mixture with the stone used in 1906, the range is from 1250 to 1400 lb. per sq. in. These agree fairly well with the results obtained at the Massachusetts Institute of Technology in 1905. The reinforced recessed blocks of Table 17 give averages of 1768 and 2145 lb., so that the shearing strength may be higher than the results given above.

It seems evident that the shearing strength is far greater than the tensile strength and comparison of these two properties is not advisable. It does not seem profitable to compare shearing strength with compressive strength, since the former is more largely influenced by the strength of the stone and the latter by the strength of the mortar. The tests made with the recessed blocks, the reinforced recessed blocks, and the restrained beam test specimens indicate that the shearing strength is at least 50% as much as the compressive strength, except that the high results of the 1906 concrete cube tests bring some of the figures below this. These cube tests are much higher than any other of the same mixture made in the laboratory. Comparison with other cube tests and with the cylinders indicates that shearing strength may run well up toward compressive strength. A range which is thought to cover much of the concrete used is 50% to 75%. conclusion would not disagree with the Massachusetts Institute tests nor with the conclusions of Feret.

Summary.—The following summary is offered:

- 1. It is difficult to devise a form of test specimen and a method of testing which will satisfactorily determine the resistance of concrete to shear. The difficulties lie in the inability to secure an even distribution of the shear over the shear section, in the high cutting and bearing stresses developed, and in the complications formed by the compressive, tensile, and bulging and bursting stresses developed. The forms of test specimen here used are not fully satisfactory, but information concerning the shearing resistance of concrete may be drawn from the tests as a whole, and tentative values selected. A test specimen in the form of a beam and in which the load is applied evenly over the depth of the beam instead of on the top is suggested.
- 2. The resistance of concrete to shear is dependent upon the strength of the stone as well as upon the strength of the mortar, and for the richer mixtures the strength of the stone probably exercises the greater influence. With hard limestone and 1-3-6 concrete 60 days old the shearing strength may be expected to reach 1100 lb. per sq. in., and with the 1-2-4 mixture 1300 lb. per sq. in. It seems very probable that the resistance to simple shear is considerably higher than this, and that tests made with the load applied evenly over the shearing section will verify this.

3. Since the compressive strength of concrete is influenced largely by the strength of the cement and the shearing strength is much more influenced by the strength of the aggregate, it does not seem proper to express the shearing strength in terms of the compressive strength. However, this is frequently done and is of advantage in gaining a conception of their relative action. It appears that the shearing strength is, in general, at least 50 % of the compressive strength, and that it may exceed 75 %. The apparent exception to this is explained by the high values obtained in the 1906 compression tests. These conclusions agree in a general way with the statement of Feret and others that the shearing strength is as much as two-thirds of the compressive strength. Evidently the shearing strength of concrete is several times its tensile strength.

#### H. BOND.

The tests of bond between steel and concrete, or tests of the resistance to a pulling force on the bars, were made in the manner usually followed in such tests. The concrete test piece was made small and short. The tests include the bond resistance of rods having smooth surface and uniform section, like cold rolled shafting, the effect of richness of concrete and of the depth the bar is embedded, and the resistance of flat bars. The work was done by Todd Kirk, a civil engineering student. Mr. Kirk had the misfortune to have the test specimens he made in 1905 injured in the accident mentioned in Bulletin No. 4. The experience gained gives greater reliability to the 1906 tests.

Materials.—The broken stone, sand and cement used were the same as hereinbefore described for the 1906 shear tests. Four different kinds of steel were used:  $\frac{1}{2}$ -in. and  $\frac{2}{5}$ -in. round mild steel rods having an elastic limit of about 38 000 lb. per sq. in.;  $\frac{1}{2}$ -in and 1-in. cold rolled shafting having an elastic limit of about 87 000 lb. per sq. in.;  $\frac{2}{3}$ -in. round tool steel having an elastic limit of about 53 000 lb. per sq. in.;  $\frac{2}{3}$ -in. flat bars with an elastic limit of about 45 000 lb. per sq. in.

TABLE 21.

#### BOND BETWEEN STEEL AND CONCRETE.

1904 Tests.

Test No.	Type of Rod	· Maximum Load	Area sq. in.	Lb. per sq. in. of Net Section	Lb. per sq. in. of Net Surface	Elastic Limit of Steel	Remarks
1 2 3 27 4 30 26 5 31 32 29 33 34 13 35 36 18 14 8 9 10 15 11 12 16 17 21 22 23 28 7 6	½-in. Johnson  "" *	14990 14210 12605 15335 17175 11755 16330 9515 8960 10435 4780 5850 6810 6910 4100 5560 11606 11850 7910 6400 3255 3860 6905 6905 6900 4785 6000 4580 6540 6000 4580 6540 6000 4580 6540 6000 4580 6540 6650 6650 6650 6650 6650 6650 665	.20	74950 71050 71050 63000 76650 47050 32200 38300 448800 26050 24500 29900 29900 42800 36550 42600 25600 223700 28800 34200 43150 41800 29320 41800 29320 41800 29320 41800	625 593 525 639 573 392 466 545 317 298 348 250 357 365 214 290 322 329 329 329 329 329 329 329 329 329	60000 58300 45000 35000 42500 45000 45000	Concrete split.  """  Cylinder broke. Concrete split.  """  """  Rod slipped.  """  """  """  """  """  """  """

<sup>\*</sup> Struck 6 quarter-swing blows with a 10-lb, sledge.

<sup>+</sup> Embedded for a length of 24 in.

Test Pieces.—Two forms of test piece were used, one a cylinder 6 inches in diameter and 6 inches long, and the other 6 inches in diameter and 12 inches long. In Fig. 9 one of the vertical pieces is a bond test piece. The bars were embedded the full length of the cylinders, one end being left flush with an end of the cylinder and the other end projecting far enough to furnish a grip for the pulling head of the testing machine. The 6-in, length of encasement was used to make sure that the stress in the steel would be far below the elastic limit. It was planned that the stress in the steel in the 12-in, encasement should closely approach the elastic limit. In order to determine the effect of the quality of concrete, two mixtures, 1 cement—3 sand— $5\frac{1}{2}$  stone, and 1 cement—2 sand—4 stone were used, all by loose measure. The 1905 tests were with a 1-3-6 mixture.

TABLE 22.

BOND TESTS.

PLAIN ROUND RODS.
1-3-5½ CONCRETE.

	ter ss	ed Th	in inct				ress Develo b. per sq. i	
Ref. No.	Diameter inches	Ength Length inches	Surface i Contact sq. in.	Maximum Load pounds	Running Frietion pounds	Bond	Running Friction	In Steel
1 2 3 4 5 6		6 6 6 6 6	9.42 9.42 9.42 9.42 9.42 9.42	3400 3360 3510 3355 2640 3530	1850 1900 1950 2000 2150 2050	360 356 372 377 386 375	196 201 207 212 228 218	17300 17100 17900 18100 18500 18000
7 8 9 10 11 12	व्यंत्र स्रोच कल व्यंत्र व्यंत्र व्यंत्र	6 6 6 6 6	11.77 11.77 11.77 11.77 11.77 11.77	4300 4195 4250 4150 4075 4050	3000 2600 2500 2650 2500 2500 2950	365 358 361 352 346 342	258 221 212 225 212 251	14000 13650 13850 13520 13300 13200
16 17 18	12 12	12 12 12	18.81 18.84 18.84	-7130 7475 6500	5400 5300 4500	378 397 345	286 281 239	36400 38100 33100
19 20 21	מוֹם מבים מוֹם	12 12 12	23.54 23.54 23.54	10000 9500 8875	5500 6000 5000	425 404 377	234 255 212	32700 30950 28950

Method of Testing and Age of Test Specimen.—The free end of the bar to be tested was run through the movable head and held in the upper grips of the testing machine. The load was then applied with the movable head. In order that the pressure on the concrete might be uniformly distributed, a bearing plate bedded in plaster of paris was placed between the concrete and the movable head of the machine, the plaster of paris being allowed to set under a small load. The age of test piece when tested was 60 days.

TABLE 23.

BOND TESTS.

PLAIN ROUND RODS.
1-2-4 CONCRETE.

	ter	ed th	et et 1.	um ds	ng on ds	St	ress Devel lb. per sq	
Ref. No.	Diameter inches	Ength Length inches	Surface in Contact sq. in.	Maximum Load pounds	Running Frietion pounds	Bond	Run- ning Frie- tion	In
42 43 44 45 46 47	12 12 12 12 12	() () () () () () ()	9,42 9,42 9,42 9,42 9,42 9,42	4000 4490 4060 3840 3650 3340	2470 2600 2400 1900 1700 1740	425 477 428 408 388 355	263 276 254 202 181 184	20400 22900 20600 19600 18600 17000
34 35 36 37	ගේපා ගල්පා ගල්පා	6 6 6	11.77 11.77 11.77 11.77	5580 5510 5260 5530	3400 3390 3600 3550	475 468 448 471	289 288 306 302	18200 18000 17150 18000
13 14 38 39	122 122 122	12 12 12 12 12	18.84 18.84 18.84 18.84	8200 6820 7500 7900	5500 5200 4500 4730	436 362 398 418	292 276 239 251	41800 34800 24400 25700
15 40 41	raka raka raka	12 12 12	23,54 23,54 23,54	41200 9040 9000	7500 4740 4000	476 384 382	318 202 170	36500 29450 29350

1904 Tests.—Table 21 is reprinted from Bulletin No. 1 and gives the results of bond tests made by Mr. Davis in 1904. The concrete used was a 1-3-6 mixture. In making comparisons the values with rods embedded more than 12 inches should not be used, since there is evidently an uneven distribution of bond stress over the length of the bar.

1905 and 1906 Tests.—Tables 22, 23 and 24 give the results of Mr. Kirk's tests. In Table 25 the results are summarized.

Results.—The condition of the concrete caused by the method of testing bond resistance here used, may be considered to differ from the condition of the concrete in a beam when bond stress is developed. In these tests the concrete specimen is subjected to compression, and this compression produces lateral expansion; this lateral expansion may increase the pressure on the surface of

TABLE 24.

BOND TESTS.\*

VARIOUS TYPES OF BARS.

		SS	of	ct.	um H	ng on ds		s Develop per sq. in	
Ref. No.	Kind of Steel	Size of Bar inches	Kind of Concrete	Surface in Contact sq. in.	Maximum Load pounds	Running Friction pounds	Bond	Run- ning Fric- tion	In Steel
18 19 20	Tool steel	§ round § round § round	1-3-6 1-3-6 1-3-6	14.13 14.13 14.13	2060 2180 1993		147 154 141		4650 4940 4510
22 23 24	Cold rolled shafting	1 round	1-3-5½	18.84 18.84 18.84	2700 2200 2810	1500 1000 1270	143 117 150	80 53 67	3440 2800 3580
25 26 27	do.	½ round	6 6 6 6	9.42 9.14 9.42	1425 1610 1395	550 450 400	151 170 147	58 48 43	7250 8220 7130
28 29 30	Mild steel	$^{3}_{16} \times 1^{\frac{1}{2}}_{}$	 	$\begin{array}{c} 20.25 \\ 20.25 \\ 20.25 \end{array}$	2260 2550 2800	1440 1700 2000	111 126 138	71 83 98	8050 9070 9960

<sup>\*</sup> In these tests the steel was encased to a length of 6 inches.

the steel and thus increase the resistance. On the other hand the low compressive stress developed, a maximum of 500 lb. per sq. in. at the top and 0 at the bottom, indicates that the effect of this can not be large.

TABLE 25.
SUMMARY OF BOND TESTS.

lests	Rod	ž.	of te	ength ss Con- in.		d lb.	nd sq. in.	Running Friction		of Run- Friction nd
No. of Tests	Type of Rod	Size inches	Kind of Concrete	Encased Length inches	Surface in Contact sq. in.	Max. Load lb.	Bond Ib. per sq	Max. lb.	lb. per sq. in.	Ratio of I ning Frid to Bond
6	Plain round	1 2	$1-3-5\frac{1}{2}$	6	9.42	3498	372	1983	210	57.0
6	do.	1/2	1-2-4	6	9.42	3893	412	2135	227	55.2
6	do.	58	$1-3-5\frac{1}{2}$	6	11.77	4170	355	2700	227	64.0
4	do.	žą.	1-2-4	6	11.77	5376	465	3485	297	64.0
3,	do.	$\frac{1}{2}$	$1-3-5\frac{1}{2}$	12	18.84	7035	373	5066	268	72.0
4	do.	$\frac{1}{2}$	1-2-4	12	18.84	7605	404	4982	266	65.5
3	do.	<u>5</u> .	$1-3-5\frac{1}{2}$	12	23.54	9458	402	5366	228	56.8
3	do.	<u>5</u>	1-2-4	12	23.54	9736	414	5284	223	54.0
3	Cold rolled shafting	1	1-3-51	6	18.84	2570	136	1256	67	49.2
3	do.	$\frac{1}{2}$	$1-3-5\frac{1}{2}$	6	9.42	1476	157	466	50	31.8
3	Mild steel	$\frac{3}{16} \times 1\frac{1}{2}$	$1-3-5\frac{1}{2}$	6	20.25	2536	125	1713	84	67.1
3	Round tool steel	8.	1-3-6	6	14.13	2077	147			

The following is given as an interpretation of the results of the testson | - Steel bar in compression |

1. Little difference is found in the bond resistance per square inch of surface of bar in contact with the concrete whether the bar is embedded 6 inches or 12 inches. Evidently a length may be found beyond which the stretch of the steel would cause uneven distribution of the bond stress along the length of the bar and cause failure to begin at the point of greatest stress in the steel and thus give results not representative of the real bond resistance. This limitation applies to length for use in experimental tests of bond. In simple beams the bond stresses are applied along the length of the bar, and stretch and bond exist together.

2. The richer mixture of concrete gives somewhat higher bond resistance than the leaner—the values for the 1-2-4 concrete averaging, say, 10% to 15% higher than the 1-3- $5\frac{1}{2}$  concrete. For plain round mild steel rods, the average for the bond resistance ranges from 350 to 450 lb. per sq. in. of contact surface.

3. The flat bars gave much lower resistance than round bars. Only three tests were made with flat bars, and these may not be representative. It may be noted that the results with flat bars are much lower than tests made elsewhere. It should also be noted that for a bond stress of 125 lb. per sq. in., the tensile stress developed in the bar was only 9000 lb. per sq. in.

4. The value of bond resistance will depend upon the smoothness of the surface of the bar, the uniformity of its diameter and section, the adhesive strength of the concrete, and the shrinkage grip developed in setting. The effect of smoothness of surface and uniformity of diameter and section is seen in the tests made with cold rolled shafting and tool steel. The average bond developed with cold rolled shafting and tool steel was 147 lb. per sq. in. of contact surface, as compared with about 400 lb. per sq. in, for ordinary plain, round, mild steel rods. It should be stated that not only was there a very noticeable difference in the smoothness and finish of the surface of the rods, but the section of the cold rolled shafting and tool steel was very uniform, the diameter not varying more than .0001 or .0002 in. at 1-in. intervals throughout the length, while mild steel rods will vary as much as .0015 in. It is to be expected that the smoothness and uniformity of section of drawn steel wire will operate to give low values of bond resistance, though, of course, as the section of wire is small compared

with the circumference, the bond stresses developed when wire is used are relatively small. Attention is called to the fact that in the reinforced concrete beams described in Bulletin No. 4 the bond stresses developed in beams failing by tension of the steel, diagonal tension of the concrete or other similar methods amounted to from 73 to 193 lb. per sq in. Even at the breaking load, then, the bond stress developed in the mild steel rods was far below the bond resistance found in these tests.

5. In these tests the bars began to slip when the maximum load was reached. After slipping began, the resistance to motion was still considerable. This running friction, taken when the bar had moved about \(\frac{1}{4}\) in., amounted to 54% to 72% of the bond developed in the case of mild steel bars and to 32% to 49% in the case of the cold rolled shafting.

### PUBLICATIONS OF THE ENGINEERING EXPERIMENT STATION

Bulletin No. 1. Tests of Reinforced Concrete Beams, by Arthur N. Talbot. 1904.

Circular No. 1. High-Speed Tool Steels, by L. P. Breckenridge. 1905.

Bulletin No. 2. Tests of High-Speed Tool Steels on Cast Iron, by L. P. Breckenridge and Henry B. Dirks. 1905.

Circular No. 2. Drainage of Earth Roads, by Ira O. Baker. 1906.

Bulletin No. 3. The Engineering Experiment Station of the University of Illinois, by L. P. Breckenridge. 1906.

Bulletin No. 4. Tests of Reinforced Concrete Beams, Series of 1905, by Arthur N. Talbot. 1906.

Bulletin No. 5. Resistance of Tubes to Collapse, by Albert P. Carman. 1906.

Bulletin No. 6. Holding Power of Railroad Spikes, by Roy I. Webber. 1906.

Bulletin No. 7. Fuel Tests with Illinois Coals, by L. P. Breckenridge, S. W. Parr and Henry B. Dirks. 1906.

Bulletin No. 8. Tests of Concrete: I. Shear; H. Bond, by Arthur N. Talbot. 1906.





## UNIVERSITY OF ILLINOIS ENGINEERING EXPERIMENT STATION

BULLETIN No. 9

REVISED EDITION

NOVEMBER, 1912

## AN EXTENSION OF THE DEWEY DECIMAL SYSTEM OF CLASSIFICATION APPLIED TO THE ENGINEERING INDUSTRIES

by

L. P. Breckenridge\*, Professor of Mechanical Engineering and

G. A. GOODENOUGH!, ASSOCIATE PROFESSOR OF MECHANICAL ENGINEERING

#### INTRODUCTION

			PAGE
	1.	Preliminary	2
	2.	Explanation of the Decimal System	2
	3.	Relative Index	3
	4.	Uses and Advantages of the Classification and	
		Index	4
	5.	Variations and Modification	5
	6.	Acknowledgments	7
	7.	Illustrations	8
II	TABI	LE OF CLASS NUMBERS	9
TTT	14A	ATIVE INDEX	0.4

<sup>2547/12</sup> \*University of Illinois, 1894-1909: Yale University, 1909-date. ‡Recently appointed Professor of Thermodynamics.

#### I. Introduction.

I. Preliminary.—The decimal system of classification was devised and elaborated by Mr. Melvil Dewey, formerly director of the New York State Library. This system was intended primarily for the use of librarians in the classification and arrangement of books and pamphlets, but it was soon found that the system furnished also a simple and effective means of classifying, indexing and filing literary matter of all kinds. Engineers have found it useful for indexing technical data and information, catalogs, reports, card systems, drawings, etc., and it has been found equally useful by manufacturing and business concerns.

Recognizing the value of the decimal system as a means of classifying and indexing technical literature, the department of mechanical engineering of the University of Illinois prepared several years ago an extension of that part of the Dewey classification which relates to mechanical engineering. The first edition was a small pamphlet of six pages. The demand for the extension was so great that within a year a second edition was printed, and this has been followed by the third and fourth editions. In each successive edition the extension has been carried somewhat further, and such slight changes and modifications have been made as would add to the clearness and consistency of the system as a whole. In the third edition was incorporated with slight modifications the extensions for railroads and railroad engineering adopted by the International Railway Congress.

In the fourth edition are included the extensions to mechanical and railway engineering already worked out; an extension for electrical engineering made by Mr. J. M. Bryant of the electrical engineering department; and more or less complete extensions for other branches of engineering. The whole will be, it is hoped, a self-contained classification which will cover with fair com-

pleteness the entire ground of engineering industry.

2. Explanation of the Decimal System.—The essential characteristic of the Dewey system is its method of division and subdivision. The entire field of knowledge is divided into nine chief classes numbered by the digits from 1 to 9. Matter of too general a nature to be included in any of these classes is put into a tenth class and indicated by 0. The following are the primary classes of the Dewey system:

- o General Works
- 1 Philosophy
- 2 Religion

- 3 Sociology
- 4 Philology
  - 5 Natural Science
  - 6 Useful Arts
  - 7 Fine Arts
  - 8 Literature
  - 9 History

Each of these classes is again divided into nine divisions, with a tenth division for general matter, and each division is separated into nine sections. The sections are again sub-divided and the process may be carried as far as desired.

To show clearly the working of the system the divisions of class 6 (useful arts) and the sections of division 2 of this class

(engineering) are given.

600	Useful Arts	620	Engineering
610	Medicine	621	Mechanical
620	Engineering	622	Mining
630	Agriculture	623	Military
640	Domestic Economy	624	Bridge and Roof
650	Communication and	625	Road and Railroad
	Commerce	_	·
660	Chemical Technology	626	Canal
670	Manufactures	627	River and Harbor
680	Mechanic Trades	628	Sanitary: Water Works
690	Building	629	Other Branches

It will be seen that the first digit gives the class; the second, the division; and the third, the section. Thus 625 indicates section 5 (railroad engineering) of division 2 (engineering) of class 6 (useful arts). For convenience a decimal point is inserted after the section digit. Further sub-division is indicated by digits following the decimal point. For example 625.2 is the number indicating rolling stock; 625.23 passenger cars; 625.24 freight cars, etc.

3. Relative Index.—Following the classification is the relative index, in which the items of the classification are arranged alphabetically, each with its proper class number. The index is necessarily incomplete, as it is manifestly impossible to include every

subject that might arise in engineering practice.

In a highly specialized industry, as for example, the electrical industry, there are thousands of technical terms indicative of materials and processes and to include these would alone require

a volume. It is believed that the index is sufficiently complete that the user may without difficulty assign the proper number

to almost any topic that may arise.

In some cases, the same item has two numbers. For example, "Telephones" has the numbers 537.82 and 654.6. Reference to the classification shows that the former number is used when the telephone is considered as an application of the electric current, while the latter is used when the telephone is looked upon as a means of communication. In any case, reference to the classification will show which number is appropriate to the item under consideration.

4. Uses and Advantages of the Classification and Index.—The decimal classification may be used to advantage in the indexing and filing of notes and memoranda, clippings, general information, articles in technical journals, drawings, catalogs or books. For this purpose, the decimal system possesses certain important advantages over the alphabetical system.

(1) It groups allied subjects. For example, suppose the alphabetical arrangement to be applied to a case of catalogs. The catalogs of the various machine tools, as planers, lathes, drills, hammers, etc., would be scattered throughout the case. With the decimal system, on the other hand all these catalogs would be grouped together under the class number 621.9.

(2) Unless an elaborate system of cross reference is used, the alphabetical scheme is ambiguous; in many cases there is doubt as to what letter should be given a subject. For example, take the item "Automatic pneumatic block signals." This might almost equally well be indexed under A, P, B or S. With the

decimal system this item has its one number 656.256.4.

(3) The decimal system has the advantage of flexibility and an indefinite capacity for extension. For the indexing of books and catalogs only the main division and sections will, in general, be found necessary; but for card indexes of technical literature the most minute subdivisions must ordinarily be used. In individual cases, the user may find that still further division is required. An extension may then be made by adding another decimal place, and if still further subdivision is required still another digit may be used.

The average engineer, for example, can easily index all matter relating to traveling cranes under the single class number 621.872. The designer or builder of cranes may, however, have so much matter relating to this special subject that further subdivision is needed. By the addition of a digit, this matter may

be divided into nine groups designated by 621.872.1, 621.872.2, etc.; and, if necessary, each of these may be divided into nine

new groups.

The effectiveness of the Dewey system has been severely tested in the Engineering College of the University. The mechanical engineering department has a card index of current periodical literature which now contain 20,000 cards. These are indexed by the Dewey system. The classification is first made by students, and is then revised by one competent person. It seldom occurs that there is any doubt as to the proper class number for a given card. For the guidance of those who may wish to use the classification in connection with a card index a sample card is shown on page 8. The class number 621.63 serves to locate the card in the case and the remaining notes in the margin indicate the periodical, volume, page and date. Thus the article in question appeared in the Proceedings of the Institution of Civil Engineers, Vol. 123, page 272, December, 1895; it occupies 55 pages and has 31 illustrations.

Blue prints received from manufacturers; all catalogs, of which there is a large number; clippings, photographs and illustrative class room material; all these are indexed and filed by the decimal system. In every case the system has been found

thoroughly satisfactory.

5. Variations and Modifications.—In the working out of the extension of the various subjects the main divisions and sections as published by Mr. Dewey have been retained unchanged. It cannot be denied that there are many glaring inconsistencies in the arrangement of engineering subjects. For example, no engineer of to-day would put electrical engineering as a division under mechanical engineering (621.3) coordinate with blowing and pumping engines (621.6); nor would he relegate concrete to an unimportant place under building materials. There is no doubt that a committee of competent engineers could vastly improve the logical arrangement of the class numbers for engineering subjects. However, the system as it is, with its faults, has been in use several years and has become more or less universal. It is used in libraries and by many business concerns and individuals. It has become a sort of a standard like the Sellers system of screw threads. For this reason alone, radical changes would be inadvisable. The inexperienced user will be likely to see room for improvement and will be tempted to make changes in the system for his individual Such changes can only lead to confusion. It is far better to accept the system merely as an arbitrary set of numbers corresponding to certain topics and resolutely dismiss rigid ideas of

logical sequence and consistency.

There are certain permissible modifications, however, which may be made without violating the integrity of the system. To avoid the writing of long numbers a single letter may be used for the first three or four digits. Thus an electrical engineer would naturally have most of his material under 621.3 (electrical engineering), and for this number he could substitute the single letter E. Likewise, a railroad man might use R for 625 (railroad engineering).

Another modification consists in the use of an alphabetical arrangement for certain sub-sections combined with the decimal arrangement of main sections. This is sometimes useful in minute subdivisions. For example, under 621.728, material and supplies for the foundry, these various materials may be arranged

in alphabetical order.

The use of form divisions is a modification that may often be employed to advantage. There are certain set forms that are used throughout the whole range of the Dewey classification. These are:

or Philosophy or theory

02 Compends, text books, etc.

03 Cyclopedias, dictionaries

04 Essays, addresses

05 Periodicals

o6 Societies

07 Education, teaching schools, colleges, universities

o8 Tables, calculations miscellanies

og History progress and development

These forms may be further extended; thus:

o64 Exhibits, etc. (under societies)

072 Laboratories (under universities)

Other form divisions which apply particularly to engineering are the following:

ooi Statistics

002 Quantities and costs

003 Contracts and specifications

004 Designs and drawings

005 Executive

oob Working and maintenance

Laws 007

008 Patents

000 Reports

These form divisions may be enclosed in parentheses and annexed directly to the usual class number. Thus 62 (07) indicates engineering education; 621.32 (09), progress of electric lighting; 621.57 (008), patents on ice-making machinery, etc. The object of this parenthesis separation of the form divisions is convenience in cross-references. For example if one is interested in patents he may write his class numbers as follow:

(008)62 Patents—Engineering

(008)66 Patents—Chemical technology (008)69 Patents—Building

In this way all cards on patents are grouped together.

Other modifications will suggest themselves to the user as he becomes more familiar with the system.

6. Acknowledgments.—The authors are much indebted to Mr. J. M. Bryant for his work on the extension of electrical engineering and to Mr A. L. Voge, Washington, D. C., for valuable criticisms and suggestions.

### Sample Card from Card Index

621.63 Proc. F. G. E. V. 123 Jr. 272 Dec. '95	The Design and Testing of Various Types of Centrifugal Frans (55 ft. 34i) H. Heenan and W. Silbert Sives results of elaborate experiments on the efficiency of fans, and deduces characteristic curves that may be employed in the design of a fan with maximum efficiency for a given duty.
---	--

#### Abbreviations Used on Index Cards

pages
diagrams, sketches, etcd
curves, plots, or groups of samec
illustrations, photographs, etci
tables of data, etct
wordsw
volumev

# **TABLE**

## OF

# CLASS NUMBERS

330	Political Economy
331	Capital Labor and Wages
.1	Relations of Capital to Labor
.2	Wages Profit sharing Compulsory insurance
.3	Labor of children
.4	Labor of women
.5	Convict labor Prison contracts
.6	Pauper labor Cheap foreign labor
.7	Skilled and unskilled labor
.8	Laboring classes
.81	Hours of labor
.82	Places of labor Dangers
.83	Food Clothes Shelter
.84	Morals and habits
.85	Helps Lectures, libraries, reading rooms, etc.
.86	Training Apprenticeship
.87	Organization of labor
.88	Trades unions
.89	Strikes
370	Education
380	Commerce Communication
385	Railways from the Economic and Financial
	Point of View
	-

385.0	General works (Compends, Essays, Periodicals, Societies, Reports, Statistics, History)
.1	Railways from the financial point of view
.2	Competition of railway and steamship lines
.3	State control of railways
.4	Administrative organization of railways
<b>-</b> 5	Personnel (Relations of railroads to employes, etc.)
.6	International agreements relative to railroads
.7	Interstate commerce commission
386	Canals and Highways from an Economic Aspect
387	River and Ocean Transportation
388	Rapid Transit in Cities
389	Weights and Measures
510	Mathematics 511 Arithmetic 512 Algebra 513 Geometry 514 Trigonometry 515 Descriptive Geometry and Projection 516 Analytical Geometry 517 Calculus 519 Probabilities
520	Astronomy
530	Physics
531	Mechanics
.1	Pure motion Kinematics
.2	Statics Graphic statics
.21	Force and its measure (Traction dynamometers, weighing scales, etc.)
.3	Dynamics Kinetics
.4	Work Friction (Friction brakes Transmission and absorption dynamometers)
.5	Gravity
.6	Conservation of energy
.7	
.8	Machines Transmission of force

531.9	Tables Problems Questions
532	Liquids Hydrostatics Hydraulics
.5	Liquids in motion Flow in pipes, channels. etc.
533	Gases Pneumatics Air
.1	Properties of gases and vapors
.2	Laws of compressibility
.3	Atmosphere
.6	Aeronautics
.7	Kinetic theory of gases
534	Sound Acoustics
535	Light Optics
536	Heat
.1	Theory Nature
.2	Communication
.3	Action of bodies on heat (Reflection, refraction, radiation, absorption)
.4	Effects Action of heat on bodies
.46	Combustion
.5	Temperature Measurement of, etc.
.51	Thermometry
.52	Pyrometry
.53	Electric methods of measuring
.6	Calorimetry
.7	Thermodynamics
.71	The perfect gases
.72	The vapors
.73	Thermodynamics of the steam engine and other
	heat motors
.74	Flow of fluids
.8	Applications
.9	Tables Problems Questions

537	Electricity
.1	Theory Nature
.2	Statical
.3	
.4	Atmospheric Lightning rods
.5	Dynamical
.6	Electrodynamics
.7	Electrical measurements
.8	Applications (See 621.3 etc.)
.81	Telegraph (See 654)
.82	Telephone Microphone (See 631.35)
.83	Dynamos Electric lighting (See 621.31)
.84	Transmission of power Storage (See 621.34)
.85	Electro-metallurgy
.86	Galvanometers
.87	Medicine .
.88	Electric signals
538	Magnetism
539	Molecular Physics
.1	Theory Molecular structure
.2	Properties of Solids
.3	Elasticity Torsion
.4	Strength of materials  (See also 620.1. General theory should go under 539.4; tests and results of tests, under 620.1)
540	Chemistry
549	Mineralogy
550	Geology
	<u> </u>
553	Economic Geology
.1	Ore deposits

553.2	Carbon series
.21	Peat .
.22	Lignite and jet
.23	Cannel coal Bituminous shale
.24	Bituminous and semi-bituminous coals
.25	Anthracite and graphitic anthracite coals
.28	Petroleum Natural gas
.3	Ores of iron
.4	Ores of metals other than iron
.5	Building stones
.51	Marbles and limestones
.52	Granites and syenites
.53	Sandstones
.54	Slates
.57	Trap
.6	Earthy economic materials
.61	Fire and brick clays
.62	Sands
.65	Emery
.68	Limes and mineral cement
20	Engineering
62(00	
62 (00 62 (07	~ ~ ~
620.1	,
.11	Applied mechanics Engineering materials
.112	Strength of materials General theory  Tests Factors affecting strength
.1	General: influence of temperature, selection of test pieces, etc.
.2	Corrosion Weathering Protection against deteriorat- ing influences
.3	Elastic limit tests: plasticity, fatigue deformation
.4 .41	Tension, compression, torsion, flexure, shearing Tensile tests
.42	
42	Torsion tosts

620.112.44	Flexure (transverse) tests
.45	Shearing tests
.46	Repeated stress tests
.5	Impact Repeated shock tests
	Crystallization and formation of cleavage planes
.6	Hardness tests
.7	Special tests
	Varying for different materials
.8	Tests on special shapes and forms
.82	Plates and structural shapes
	Bars, rods, angles, beams: T, bulb, I, and channel
	beams
.83	Columns, built columns tubes, pipes, cylinders
.84	Rollers Spheres, solid or hollow Ball bearings
.85	Springs
.86	Hooks Chains Hoops Rings
.87	Rivets Bolts Screws Nails Riveted joints of plates
.88	Wire Wire rope Cables Hawsers
.89	Other forms
.9	Other tests
.12	Tests of timber
.13	Tests of Stone Cement Concrete
.132	Stone
.135	Cement
.136	Concrete
.137	Reinforced concrete
.139	Other: artificial stone
.14	Brick, tile, etc.
.15	Masonry adhesives
	Cement, mortar, plaster of paris, etc.
.17	Iron and steel Testing machines
.18	Other metals
.19	Other materials
.195	Mineral: asbestos, mineral wool
.196	Asphalt Tar
.197	Vegetable: paper, hemp, etc.
.198	Animal: hair, hide, bone, etc.
.199	
.2	Compends Handbooks
.3	Dictionaries, cyclopedias
.4	Essays

620	.5	Periodicals
,	.6	Societies
	.7	Study and teaching Instruments
	.8	Tables and calculations
	.9	History of engineering
	•7	
521		Wechanical Engineering (The same form divisions apply to 621 as to 62 above)
,	.1	Steam engineering
	.101	Applied thermodynamics
•	.11	Mechanism of steam engine Design of engine parts
	.111	General
	.112	Types of engines
	.12	Marine engines
	.121	General
	.122	Types of marine engines
	.123	Marine steam turbines
	.13	Locomotives
	.131	Theory of the locomotive
	.1	Adhesion Tractive force Horsepower
	.2	The second secon
	.3	Tests
	.132	Types of locomotives
•	.133	Locomotive boilers Production of steam
	.1 .2	Combustion Fuels Petroleum Fuel consumption
	.2	Grate and ash pit Firebox Stays Shell and tubes
		Smokebox and stack
	.5	Exhaust pipe
	.6	Dome and throttle
	.7	Boiler feeding Pumps, injectors Purification of
		water Scale prevention
	.9	Miscellaneous fittings Gage cocks, safety valves, etc.
	134	Engine of the locomotive
	.1	Driving mechanism Cylinders, pistons, rods, cranked axles, etc.
	.2	Steam distribution Slide valves
	.22	Special types of valves and valve gears
	.4	The compound principle Distribution in compound
		locomotives

621.134.5	Lubrication of locomotive
.135	Running gear
.1	Frames Frame plates Transverse bracing, attachments to boiler, etc.
.2	Wheels, boxes, and axles Disturbances Counter- balancing
.3	Suspension Springs, saddles, equalizing levers, etc.
.4	Trucks Bissell trucks, four-wheel trucks, etc.
.5	Locomotive brakes
.136	Tenders
.1	Design of, weight of, brakes, etc.
.2	Coupling arrangements
.3	Taking water without stopping; track tanks; water scoops
.137	Management of locomotive Engineer's and fireman's duties Assignment of crews, etc.
.138	Maintenance and repair of locomotives
.1	Round houses
.5	Locomotive repair shops
.139	Supplies Materials
.14	Traction engines (agricultural, road roller, etc.)
.146	Agricultural: tractors, etc.
.15	Portable engines
.156	Agricultural: threshers, etc.
.16	Stationary engines
.164	Types
.2	Throttling engines
.3	Automatic shaft governor engines
.4	Releasing gear engines (Corliss, etc.)
.5	Single acting engines of Westinghouse or Williams type
.165	Steam turbines
.1	Theory
.11	Methods of calculation
.12	Vanes and buckets
.13	Guide vanes and nozzles
.14	Stresses in rotor or disc
.15	Windage
.2	Types
.21	Velocity turbines
.22	Pressure turbines
.23	Combined velocity and pressure turbines
.3	Construction Details of design
	(.32 Vanes, buckets; .33 guide vanes, nozzles; .34 rotor, discs; .35 valves, governors, safety devices; .36 thrust balancing; .37 mass balancing; .38 casing, etc.; .39 bearings, etc.)
.166	Rotary engines

621.167	Hoisting engines, hauling engines, dredge engines, and other special types
.18	Steam generation and transmission
	Fuels, furnaces, boilers, piping, power plants
	For steam heating see 697.5
101	<u> </u>
.181	General Fuels Combustion
.182	Fuels Combustion Fuels for boiler heating
.22	Solid fuels: coal, lignite, wood, sawdust, peat
.23	Liquid fuels: tar, petroleum, alcohol
.24	Gaseous fuels: gas from blast furnaces, coke ovens,
****	natural gas
.25	Composite fuels: city refuse, coal dust, trash
.3	Fuel consumption
	Practical experiments with a single fuel
.4	Comparative consumption
	Practical experiments with various fuels
.183	Furnaces Draft
.1	General
	Heating and grate surfaces
.2	Types of furnaces
,3	
.4	
.5	Furnace parts and construction details
.52	Grates
.53	Stationary grates
.54 .55	Shaking, dumping and step grates
.57	Ashpits Furnace doors Burners for liquid fuel
.6	Mechanical stokers
.62	With traveling grate
.63	With rocking grate
.64	With step grate (Roney grate)
.65	With plunger
.66	With screw
.7	Other appliances
.77	Pulverized fuel appliances
.78	Fuel and ash conveyors Ash removers
.8	Chimneys Stacks Draft appliances Smoke con-
.S2	Natural draft Dampers Uptakes
.84	Induced draft
.85	Forced draft
.184	Boilers
.1	General

621,184.13	Boiler economy Tests Feedwater
.2	Types
.22	Marine
.23	Locomotive, traction, portable
.24	Stationary
.25	Firetube boilers (tubular)
.252	Internally fired
.253	Externally fired
.26	Water-tube boilers (tubulous)
.27	Flash generators Instantaneous vaporizing boilers
.5	Boiler construction Setting Parts
.52	Shell Heads Tubesheets Domes Drums Riveted joints, staying and bracing
.53	Tubes Ferules Rings
.54	Casing
.53	Inspection and cleaning parts: man and hand holes, cleanouts, covers
.56	Setting and hanging
.57	Foundations: masonry, flues, etc.
.7	Boiler accessories
.72	Water gauges, floaters, gauge glasses, warning whis- tles
.73	Pressure gauges, manometers, safety valves
.79	Other: air cocks and blowout valves, zincs, steam collectors
.185	Steam transmission and distribution. Piping
.1	General: laws of flow, condensation, friction
.2	
.3	Connections: mains, auxiliary piping
.4	Valves
	Stop, safety, reducing Pressure regulators
.5	Drains and traps Reeivers and distributing valves
.6	Covering Insulators  Nonconductors for high, low and medium temperatures
.7	Joints and cements Expansion joints
.8	Utilization of exhaust steam
19	Steam boiler and power plants. Central stations
.191	General
.192	Arrangement and housing of apparatus
.5	Provision for enlargement
.193	Care and management of steam apparatus
.194	Boilers

621.194.1	Firing
.2	Feeding .
.3	Treatment of feed water: purification, softening
.4	Scale prevention Incrustation
.7	Inspection Hydraulic tests Rating
.195	Engines: oiling, packing, adjusting
.196	Duration Wear
.5	Corrosion
.197	Steam plant accessories Economic appurtenances
.2	Feedwater appliances  Tanks, heaters economizers, filters, purifiers, reg-
	ulators
.3	Pumps Injectors Return traps
.4	Separators
.5	Superheaters
.6	Condensers and cooling towers
.62	Surface condensers
.63	Jet condensers
.64	Cooling towers
.67	Condenser accessories
.7	Instruments
	Indicators, tachometers, gauges, dynamometers,
	thermometers, pyrometers, lubricators, etc.
.2	Hydraulic engines or motors  General theory of hydraulics (See 532)
.21	Water wheels
.22	Overshot and breast wheel
.23	Undershot wheel
.24	Turbines
.241	General: parts (buckets, guides, regulators)
.242	Reaction or pressure turbines
.247	Impulse turbines
.25	Water pressure engines Accumulators
.252	Hydraulic pumps *
.253	Piping for high pressure
.254	Accumulators
.26	Hydraulic machinery and appliances Hydraulic
	presses
	For theory see 532.81
.262	Funicular engines Hydraulic tackle
.263	Hoists Elevators Cranes
-	
.264	Special handling and lifting machinery for steel works,

621.266	Presses Forging and stamping machines
.267	Accessories: injection pumps
.269	Mining, tunneling and other hydraulic appliances
	Hydraulic giant, Brandt's hydraulic gun
.27	Hydraulic rams
	For theory see physics 532.83
.272	Lifting rams Montgolfier ram, Bolle ram, etc.
.273	Pumping rams Leblanc ram
,,,,,	See also 621.64 Pumps
.274	Compressing rams Sommelier ram
20	
.29	Flood gates Dams Mill sluices Head and tail
	races
2 1	Electrical Engineering
.3 I	Electrical Engineering
.3137 H	Heavy Current Engineering
.31	Generation of electricity Dynamoelectric ma-
.01	chinery Transformers
.311	General Central stations
.312 . .312(001)	Generalities, statistics, data, etc.
(002)	Economics, costs, current prices, etc.
(002)	Specifications
(004)	Designs, drawings, etc.
(005)	Management
(006)	Working and maintenance
(0064)	Operation and running
(0065)	Regulation and control
(0069)	Repairs and renewal
(007)	Testing of power plants
(008)	
.1	General
.2	Stations for lighting only Steam driven
,22 ,23	Gas driven
.23	Hydraulic
.25	Composite
.3	Stations for traction only
.32	Steam driven
,33	Gas driven
.35	Composite
.4	Stations for power transmission
.42	Steam driven
.43	Gas driven
.44	Hydraulic
.5	Combined stations

621.312.52	Steam driven
.53	Gas driven
.54	Hydraulic
.6	Substations
.63	Transformer substations
.64	Converter substations
.65	Accumulator substations
.313	Dynamo electric machines
(001)	General, statistics, data
(002)	Costs
(003)	Specifications for D.E.M.
(004)	Designs, drawings, specifications
(005)	Construction, installation
(0051)	General details and parts
(0052)	Electrical details
(00522)	Armature windings
(00523)	Field windings
(0053)	Magnetic details
(00532)	Armature cores
(00533)	Field cores
(00534)	Yokes
(0054)	General details
(00542)	Frame, bed plate, etc.
(00543)	Bearings
(00544)	Shafts, pulleys, etc.
(006)	Working, regulation, operation
(0064)	Operation, running
(0065)	Faults, diseases, etc.
(007)	Tests and testing work
(008)	Accessories
(0082)	Commutators
(0083)	Collector rings
(0084)	Brushes
(0085)	Brush holders
.1	General; construction, installation
.2	Direct or continuous current machinery
.21	Theory
.22	General types
.23	Continuous current generators
.24	Continuous current motors
.245	Constant speed motors
.246	Multispeed motors
.247 .248	Adjustable speed motors
.248	Varying speed motors (railway motors)
.≈5 .26	Continuous current converters
.27	Dynamotors
.61	Compensators or balancers

621,313.28	Continuous current boosters
.29	Other
.291	Acyclic or homopolar machines
.3	Alternating current machinery
.32	General types
.321	Single phase
.322	Two phase
.323	Three phase
.4	Synchronous machines
.41	Theory
.42	General types
.43	Alternating current generators
.44	Synchronous motors
.5	Alternating current converters
.51	Theory
.52	General types Description
.53	Synchronous converters
.54	Phase converters
.55	Frequency changers
.56	Double current generators
57	Motor converters
.6	Asynchronous machines
.61	Theory
.62	
.63	Induction generators
.64	Induction motors
.65	Scries alternating current motors
.66	Repulsion motors
.67	Frequency converters
.68	Phase converters
.7	Rectifying apparatus
.72	Mechanical rectifiers
.73	Arc rectifiers
.74	Electrolytic rectifiers
.314	Stationary induction apparatus
.1	Theory
	General types and description
.3	Transformers
.32	Constant current transformers
.33	Constant potential transformers
.34	Phase changing transformers
.38	Meter transformers
.4	Auto transformers
.5	Potential regulators
.51	Compensator potential regulators
.52	Induction potential regulators
- 59	Magnete potential regulators

691 214 6	Reactors or choke coils
621.314.6	Induction coils
.315	Electrostatic apparatus
.3	Condensers
.316	Details of electric machinery, parts
.317	Switchboards and control devices, central station wiring
.1	General
.2	Panels
.22	Generator panels
.23	Motor panels
.24	Feeder panels
.25	Transformer panels
.26	Converter panels
.27	Arc light panels
.28	Accumulator panels
.3	Switches
.31	General
.32	Knife switches
.33	Dial switches
.34	Plug switches
.35	Oil switches
.36	Circuit breakers
.4	Rheostats and control devices
.5	Signal devices
.6	Meters and indicating devices
.7	Barriers and compartments
.8	Protective devices (fuses, etc.)
.318	Manufacturing processes
.319	Transmission of electric energy
	Limited to transmission of current from central to sub-stations (stepdown transformers) and to
	questions common to all lines.
.1	General
.12	Systems
.122	Direct or continuous current systems
.122.1	2-wire systems
.122.2	3-wire (or Edison) and other
.122.9	Other direct current systems
.123	Alternating current systems
.123.1	Single-phase systems
.123.2	2-phase (or quarter phase) systems
.123.23	3-wire system
.123.24	4-wire system
.123.3	3-phase systems
.123.32	Delta or mesh connections
.123.33	Star or Y connections
.123.9	Other polyphase systems

404 040 407	Comparis a stance
621.319.125	Composite systems  Direct and alternating current combined
.2	Lines and conductors
.21	General
. to I	Interaction of parallel lines, heat losses.
.22	Overhead or aerial lines
.222	Systems
.223	Poles: foundations, guys, etc.
.224	Cross arms Pins
.225	Towers
.23	Underground lines
.232	Systems
.233	Conduits
.234	Manholes
.3	Cables and conductors Insulating materials
.32	Uninsulated conductors Bare wire
.33	Insulated conductors Wire and cable
.34	Cables
.37	Insulating materials
	Leakage Influence of chemic composition
.4	Insulators
.8	Protective devices
.82	Line lightning arresters
	For protection of central stations see 621.317.8
.32	Electric lighting
.321	Illumination
.1	General
.2	Interior illumination
.21	Domestic
.22	Large halls
.23	Theatre
.24	Shops, warehouses, drafting rooms, etc.
.3	Exterior illumination
.32	Streets
.33	Parks and open places
.4	Decorative illumination
.44	Electric signs
.325	Arc lighting
.1	General
.2	Continuous current open
.3	Continuous current enclosed
.4 .5	Alternating current open Alternating current enclosed
.6	Flaming arc
.7	Search lights, etc.
	Scarcii fights, ctc.
.326	Incandescent lighting

621.326.1	General: efficiency, cost, etc.
.2	Systems
.3	Carbon filament lamps
.31	Metalized filament
.32	Other carbon filaments
.4	Metal filament lamps
.41	Platinum filaments
.42	Tantalum filaments
.43	Tungsten filaments
.44	Osmium filaments
.45	Other metal filaments
.5	Glowers of other materials
.53	Nernst lamps
.327	Incandescent vapor lighting and lamps Other elec- tric lighting
.3	Vacuum or incandescent vapor lamps
.4	Mercury vapor lamps
.5	Carbon vapor lamps Moore lamp
.7	Vacuum lamps for special radiations: Crookes tubes,
	etc.
.328	Apparatus at service end of line
.1	Underwriters' requirements
	National electric code
.2	House wiring
.3	Panels
.4	Fuses
.5	Insulators, etc.
.6	Meters
.7	Switches
.8	
.9	Other apparatus
.33	Electric traction
.331	General
.2	Systems
.3	Systems according to service
.32	Trunk lines
.33	Interurban
.34	Local
.342	Surface
.343	Elevated
.344	Subway
.4	Systems according to current
.42	Direct current
.43	Alternating current
.431	Single-phase
.432	2-phase

621.331.433	3-phase
.439	Others
.5	Systems according to delivery of power
.52	Trolley systems
.53	Overhead trolley
.54	Underground trolley
.56	Third rail systems
.562	Unprotected third rail
.564	Protected third rail
.332	The line (including track)
.552	General
.17	Feeders and return systems
.2	Overhead wire Trolley lines
.23	Catenary suspension
.25	Trackless trolley
.23	Third rail
.5	Underground conductor or contact
.6	Oliderground conductor of contact
.7	Accessories
.9	Other types of line
.333	Track
.1	General
.16	
.167	Deteriorating influences
.2	Electrolysis Leakage Rails
.4 .334	Bonding Rolling stock
.334	Locomotives
.3	Motor cars
.4	Accessories and parts Control systems
.4	Motor, controller, current collecting devices, etc.
	Multiple unit control
.5	Locomotive and car wiring
.7	
•16	Running gear and other non-electric details
.35	Chemic electricity Voltaic cells and generators
.00	Primary and secondary
.351	General
.001	E.m.f., counter e.m.f., polarization, weight, capacity;
	efficiency, life, crumbling, deterioration and det-
	rimental influences; residues
.352	Parts and accessories of cells and accumulators
.1	Containers: jars, troughs, vats, etc.
.2	Electrodes and their accessories: positive and nega-
	tive plates or elements. Grids, supporting frames,
	insulating rods, etc.

621.352.3	Diaphragms and partitions
.4	Electrolytes Depolarizers Packing
.5	Circulators · Conduits and piping
.6	Connections Terminals Binding posts
.7	Regulating apparatus
.8	
.9	Other apparatus
.353	Primary cells
	See also 537.5 Voltaic electricity; 541.37 Electro-
	chemistry
.1	General
.3	Single fluid
.4	Double fluid Heavy current cells
.5	Open circuit or non-depolarized
.6	Closed circuit or depolarized
.7	Accessories and parts
.8	Classification according to use or operating methods
.354	Accumulators or storage batteries
	Secondary cells and batteries
.1	General
.18	Care and handling of accumulators
.2	Construction of
.3	Operation of
.4	Application of
.7	Accessories and parts
.355	Lead accumulators
,1	General
.18	Care and handling
.2	Naturally formed: Planté type
.3	Artificially formed: Faure type
.4	Combined Planté-Faure types
.5	Other lead accumulators
.52	Complex oxid types
.55	Lead element accumulators
.56	Copper lead accumulators
.57	Zinc lead accumulators
.58	Cadmium lead accumulators
.356	Alkaline accumulators
.357	Other types of accumulators
	Thalium, gas, etc.
.37	Electric measurements, meters and testing
.371	General General
.372	Standards Calibration of instruments
.373	Meters General types
.010	Recording meters See also special meters, 621,384
	prepayment meters
.374	Special meters and measurements
.2	Resistance meters: inductance, capacity
	motor of management,

Wheatstone bridges, ohmmeters, resistance boxes

621.374.3	Potential meters: voltage
	voltmeters, electrometers, standard cells
.4	Intensity meters: current
	Galvanometers, ammeters, coulometers, Ampére-hour meters
.5	Quantity or work meters Watt-hour meters
.6	Power meters Watt meters
.7	Frequency meters Oscillographs
.9	Other meters and measurements
.91	Phase meters Power-factor meters Synchronizers
.379	Other electric measuring instruments
	For other than electric measurements: e. g., electric thermometers
	WEAK CURRENT ENGINEERING
.38	Electric communication: telegraphy, telephony,
	wireless For overhead or underground
	lines, see 621.3192
.381	General
.382	Telegraphy Systems
.302	Codes
.152	Morse
.153	Continental
.154	Phillips (press code)
.2	A B C, dial, needle telegraph, etc.
.21	Early experimental forms
.22	A B C
.23	Dial
.24	Needle
.25	Pointer
.29	Other
.3	Hand operated code telegraphy
.31	Simplex
.311	Open circuit
.312	Closed circuit
.32	Duplex
.321	Differential duplex systems
.322	Stearns duplex
.323	Polar duplex
.325	Bridge duplex systems
.34	Quadruplex
.35	Multiplex
.36	Synchronous multiplex: Delany
.37	Harmonic multiplex: Gray
.4	Automatic code telegraphy High speed systems

Ink recording or embossing

.44

621.382.45	Wheatstone
.46	Pollak-Virag
.47	Telepost (Delany)
.5	Printing telegraphy
.51	Tape printing: stock tickers
.53	Other tape printing: Hughes
.55	Page printing: Buckingham, Murray, Baudot
.57	Multiple page printing: Rowland
.6	Writing telegraphy
	Transmitting and recording characters while being
	written Gray's telautograph
.7	Facsimile telegraphy
.8	Submarine cable telegraphy
.9	Other wire systems
.94	Induction telegraphy: from moving trains, etc.
.95	Combined telegraphy and telephony Phantom cir
	cuits
.383	Telegraph instruments
.1	Transmitting: keys, senders. etc.
.2	Intermediate and accessory: relays, repeaters,
	switches
.21	Relays
.22	Differential relays
.23	Polarized relays
.24	Repeaters, for simplex: Milliken, Ghegan, Toye, etc
.25	Repeaters for duplex or quadruplex
.26	Half repeaters
.27	Switches and distributing apparatus
.28	Protective apparatus
.29	Miscellaneous telegraph accessories
.3	Receiving instruments
	Sounders, recorders, etc. Subdivided, if wished,
	like 621.3824-8
.384	Wireless electric communication: telegraphy telephony
.1	General
.2	Wireless telegraphy Systems
.21	Spark telegraphy; by free oscillations
.25	Continuous-train telegraphy; by forced oscillations
.3	Instruments
.31	Sending apparatus
.35	Antennae, aerials, and their substitutes
.36	Receiving instruments and apparatus
.4	Applications, adaptations, specific installations
.5	Wireless telephony systems
.6 *	Apparatus
.61	Sending apparatus
.65	Aerials, etc.

621,384.66	Receiving apparatus
.7	Applications, adaptations, specific installations
.385	Telephony Systems
.1	
.2	General
.22	Series
.23	Bridging
.24	Selective
.3	Intercommunicating systems
	Without central switchboard
.32	Common return systems; selective at each station
.34	Radial common return systems; selective at one
	station only
.36	2-wife systems; separate returns
.4	Central switchboard systems
	Manual
.42	Local battery or magneto systems
.46	Common battery or central energy systems
.5	Multiple switchboard systems
.6	Trunking Transfer systems
.61	Trunking
.63	Transfer systems
.7	Semiautomatic and automatic systems
.72	Semiautomatic
.75	Automatic
.76	Strowger system (Automatic Electric Co.)
.8	Private exchanges
.386	Telephone instruments
	Terminal; subscriber's instruments
.2	Transmitters
.3	Receivers
.4	Induction coils
.5	Condensers
.6	Hook or other switches
.7	Call receiving apparatus
.8	Call sending apparatus
.9	Miscellaneous accessories
.92	Coin collecting devices
.94	Protective devices
.96	Current supply (local batteries)
.387	Central switchboards and other station equipment
.1	General
.2	Switchboards, manual
.22	Local battery or magneto
.26	Common battery
.3	Multiple switchboards
.35	Divided multiple

621.387.4	Trunks Transfer boards
.41	Trunks and trunking
.43	A boards
.45	B boards
.47	Multiple plug transfer
.5	Switchboard parts and accessories
.6	Power plant equipment and accessories
.62	Accumulators
.63	Charging generators
.64	Ringing
.7	Automatic and semiautomatic switchboards Including accessories Subdivided like 621.3857
.8	Telephone transmission
.81	
.82	Long distance
.83	Transposition
.84	Telephone cable construction
.85	Loading
.86	Pupin coils
.9	Other central station accessories
.92	Distributing frames and racks; main
.93	Distributing frames and racks; intermediate or secondary
.94	Protective devices
.96	Meters and counters  See also 621.3286 Electric light meters
.389	Other electric communication
.39	Other application of electricity
.4	Air and Gas Engines and other motors
.41	Hot air engines
.42	Compressed (or rarefied) air engines
.43	Internal combustion engines
.431	General theory of internal combustion engines
.2	Thermodynamics of internal combustion
.3	Mechanics Balancing, etc.
.432	Cycles and systems of operation
.1	Four-cycle systems
9	1, explosion motors 2, constant pressure burning
.2	Two-cycle systems 1, explosion type 2, constant pressure type
.3	Modified cycles or systems
.433	Gas turbines
.434	Internal combustion engines (or engine plants) classi-
	fied according to fuels

621.434.1	Engines (or plants) for gaseous fuels
.11	Natural gas
.12	Illuminating gas
.13	Blast furnace gas
.14	Producer gas
	For gas producers see 665.8
.15	Acetylene gas
.2	Engines (or plants) for liquid fuels
.21	Gasoline
.22	Kerosene
.23	Other petroleum oils
.24 .3	Alcohol
	Engines for solid fuels Special engines or motors
.436 .437	Parts and accessories of internal combustion engines
.401	
	<ol> <li>Reciprocating parts;</li> <li>Shafts, Journals and Bearings;</li> <li>Flywheels;</li> <li>Governors;</li> <li>Valves and valve gears;</li> <li>Carburetors and mixing valves;</li> <li>Ignition Systems;</li> <li>Oils and other accessories.</li> </ol>
.438	Special applications
.3	Self-propelled machinery Farm machinery, road roll- ers, etc.
.4	Self-propelled vehicles
.5	Motors for small boats
.6	Internal combustion engines in marine service
.7	Airship motors
.44	Dinagra wanas anginas
	Binary vapor engines
.45	Windmills
.46	Animal motors Tread mills
.47	Solar engines
.48	
.49	
.5	Air compression Ice machines Refrigerators
.51	Air compressors
.515	Dry air compressors
.517	Wet air compressors
.58	Compressed air transmission and distribution
	General
.531 .532	Details of transmission Piping, mains, gages, etc.
,366,	Designs of transmissions
.533	Records of tests on air compressors and transmissions
.534	Theory of air compression (thermodynamics of) Loss of pressure in pipes, etc. Efficiency of compressions: Reheating etc.

621.54	Application of compressed air
.541	Air motors
.542	Pneumatic tools; drills, hammers, etc.
.543	
.544	Special applications in railroad service
.545	Compressed air locomotives
.546	Pumping by compressed air
.549	Miscellaneous applications
.55	Rarefied air and vacuum appliances (Vacuum
	cleaner, etc.)
.56	Refrigerators
.564	Refrigerating fluids
.565	Refrigerating systems and plants
.1	Brine system
.2	Direct expansion system
.566	Design of refrigerating systems Calculation of piping,
	refrigerating surface, etc.
.57	Refrigerating machines
.572	Ammonia compression machines
.573	Ammonia absorption machines
.574	Carbonic acid machines
.575	Miscellaneous types: Air machines, vacuum machines, etc.
.58	Ice making
.581	Can system
.582	Plate system
.6	Blowing and pumping engines
.61	Piston blowers Blast furnace blowing engines, etc.
.62	Rotary blowers
.63	Centrifugal blowers
.64	Steam pumps and pumping engines
.641	General theory Design and construction
.642	Tests of pumps and pumping engines
.65	Direct-acting pumps
.66	Rotary pumps
.67	Centrifugal pumps
.68	Fire engines
.69	Other blowing and pumping devices
-	and pumping devices

621.7	Manufactories Engineering works (See also 670)
.701	Location, shipping facilities, etc.
.702	Arrangements of shops Shop buildings
.703	
.704	Organization and administration
.705	Employees Wages and salaries Payment of labor
	(Conveniences for workmen; hours of work; piece work; premium plan; profit-sharing; labor unions; strikes and lockouts)
.706	Accounting Cost-keeping Estimates
.707	
.708	
.709	
.71	Drafting room
.711	
.712	Arrangement
.713	Equipment Desks, drawing boards, etc.
.714	Materials and supplies
.715	Methods and processes employed in making drawings
.716	Blue-printing processes
.717	Classification and storage of drawings
.719	Miscellaneous
.72	Woodworking shop Pattern shop
.721	Arrangement of shop
.722	Equipment
.723	Woodworking methods and processes
.724	Pattern making
.725	
.726	
.727	Preservation and storage of patterns
.728	Materials and supplies
.729	Miscellaneous
.73	Forge shop
.731	Arrangement of forge shop
.732	Equipment Forges, blowers, anvils, etc.
.733	Forging processes
.734	Drop forging
.735	
.736	
.737	
738	Materials Supplies
.739	Miscellaneous
.74	Foundry
.740	Generalities (.740.5 Periodicals .740.6 Societies: .740.9 Historical)

621.741	General arrangement of foundry
.742	Equipment of foundry
.743	Molding processes Green sand, dry sand, loam, etc.
.744	Machine molding
.745	Cupola practice Mixtures of iron Chemistry of foundry irons
.746	
.747	
.748	Materials and supplies
.749	Miscellaneous
.75	Machine shop
.750	Generalities
.751	Arrangement of machine shop Location of shafting and machines
.752	Equipment (752.1 Machine tools; 752.2 Small tools)
.753	Machine work Methods and processes
.754	Bench work
.755	Erecting
.756	Toolmaking Construction of dies, jigs, etc.
.757	
.758	Supplies Materials and stock
.759	Miscellaneous
.76	Blast furnace
.77	Rolling and drawing mills
.78	
	· ·
.79	Other shops and departments
.792	Boiler and sheet metal shops
.794	Special process shops
	Galvanizing, plating, etc.
.795	Finishing shop
.796	Storehouses
.8	Millwork and machinery of transmission Design of machine parts
.81	Principles of mechanism
.82	Journals, shafting, etc.
.821	Journals
.822	Bearings Ball and roller bearings Bearing metals
.823	Shop shafting
.824	Engine and propeller shafts
.825	Clutches and couplings Friction clutches
.826	Brakes

621.S3	Toothed wheels and cams		
.831	Forms of teeth; tooth curves; general theory		
.832	Efficiency of gears Tests Friction of gears		
.833			
.1	Spur gears		
.2	Bevel and skew bevel gears		
.3	Worm and spiral gears		
.834	Construction: cutting and casting of gears		
.835	Chain gearing		
.837	Ratchet gearing		
.838	Cams		
.84	Valve motions and gears		
.85	Machinery and mill gearing		
.852	Belt gearing		
.853	Hemp rope transmission		
.854	Wire rope transmission		
.858	Friction gearing		
.86	Hoisting and conveying machinery		
.862	Hoists		
.863	Blocks, tackle, etc.		
.864	Winches Capstans Windlasses		
.865	Power shovels		
.866	Dredges		
.867	Conveyors Telferage		
.4	Belt or bucket conveyors		
.868	Telfers		
.87	Cranes and elevators		
.872	Derricks		
.873	Revolving cranes		
.874	Travelling cranes		
.875	Locomotive cranes		
.88	Fastenings		
.882	Screws and bolts Systems of screw threads Screws for transmitting motion		
.883	Keys and cotters		
.884	Rivets Design of riveted joints		
.89	Lubricants Friction *		
.9	Machine tools		
.90	Generalities		
.901	Design of machine tools		
.902	Power required to drive machine tools		

621.91	Planing and milling machines	
.912	Metal planers, shapers, and slotters	
.913	Wood planing machinery	
.92	Grinding and filing	
.922	Cylinder and surface grinding machines (Lapping machines)	
.923	Emery wheels	
.924	Filing machines	
.93	Cutting and sawing	
.932	Metal sawing and cutting machinery	
.933	Wood sawing machinery	
.94	Turning	
.942	Metal turning lathes	
.943	Wood turning lathes	
.944	Pipe threading machines	
.945	Boring mills	
.95	Perforating machinery Drills	
.952	Drilling machinery	
.953	Wood boring machinery	
.954	Reamers	
.955	Tapping machines	
.96	Punching and shearing machinery	
.97	Hammers Nail and rivet machinery	
.98	Bending, straightening, and shaping	
.982	Bending machinery	
.983	Straightening machinery	
.984	Flanging and die press machinery	
.99	Screw machines Bolt and nut machinery, etc.	
622	Mining Engineering	
.1	Exploration and Prospecting	
.11	Theory, applied geology, etc.	
.12		
	Prospecting	
.121 .122	Surface indications	
.122	Prospect trenches, shafts and tunnels Sec 622.2	
.123	Booming and other washing methods  Boring methods See 622.24	
.129	Unreliable methods, including divining rods, fortune	
.1100	tellers ate	

622.13	Surface surveying Surveying mineral claims	
.132 .133	Topographical surveying  Geological surveying	
.14	Mining surveying	
.15	Magnetic surveying	
.16	Faults See 551.87 and 553.19	
.17	Models	
.18	Examination of mineral properties	
.181	Principles	
.182	Sampling	
.183	Estimation of quantity of mineral	
.184	Valuation	
.19	Mining prospectuses See 553	
.2	Practical Mining	
.21	Excavation of loose ground See 622.32	
.211	Pick and shovel	
.212	Plow and scraper	
.213	Cableways and grab buckets	
.214	Mechanical shovels	
.215	Water	
.216	Dredges	
.22	Quarrying dimension stone	
.221	Plug and feathers	
.222	Broaches	
.223	Channelers	
.224	Blasting systems	
.23	Breaking solid ground	
.231	Fire-setting	
.232	Thawing	
.233	Undercutting	
.1	Hand undercutting	
.2	Machine undercutting	
.21	Punchers	
.22	Cutters	
.221	Chain machines	
.222	Disk machines	
.223	Cutter-bar machines	
.234	Wedging without drill holes	

```
Hand drilling
622.235.1
                     Churn drills
      .11
                     Hammer drills
      .12
                     Auger drills
       .13
      .2
                   Machine drilling
      .21
                     Piston drills
      .22
                     Air hammer drills
                     Auger drills
      .23
                 Breaking from drill holes without explosives ·
   .236
                   Wedges
      .1
       .2
                   Freezing water
                   Wetting wooden plugs
      .3
                   Compressed air cartridges
      .4
                   Hydraulic cartridges and direct hydraulic pressure
      .5
      .6
                   Lime cartridges
   .237
                 Explosives
                   Theory
      .1
       .2
                   Low explosives
      .3
                   High explosives
                   Permissible explosives
      .4
      .8
                   Testing
      .9
                   Handling and storage
                                            See 622,932
   .238
                 Blasting
      .1
                   Theory
      .2
                   Methods
      .3
                   Loading
      .4
                   Firing
      .9
                   Testing blasting appliances
   .24
               Boring
                          See 622.124, 622.235 and 622.523
   .241
                 Hand boring
      .1
                   Churn borers
                                   Spring poles
      .2
                   Rotary borers
       .21
                     Augers
      .22
                     Diamond drills
       .23
                     Shot drills
   .242
                 Machine boring
                   Churn borers
      .1
                     Cable drills
      .11
      .12
                     Rod drills
      .13
                     Hollow rod drills
      .131
                       Suction
      .132
                       Jettings
      .2
                   Rotary borers
      .21
                    Non-coring drills
      .211
                       Straight bit drills
```

Auger drills

.212

622.242.22	Core drills		
.221	Serrated ring drills		
.222	Diamond drills		
.223	Shot drills		
.25	Shaft sinking See 622.122 and 622.552		
.251	Plant		
.252	Sinking through firm earth		
.253	Forepoling		
.254	Sinking open caissons		
.255	Shield methods		
.256	Pneumatic methods		
.257	Freezing methods		
.258	Boring methods		
.259	Drilling and blasting methods		
.26	Tunnelling and drifting See 622.122 and 622.524		
.261	Plant		
,262	Preliminary operations		
.263	Forepoling		
.264	Forcing forward metal linings		
.265	Shield methods		
.266	Pneumatic methods		
.267	Boring methods		
.268	Drilling and blasting methods		
.27	Stoping See 622.34		
.28	Supporting ground		
.281	Timber		
.282	Iron and steel		
.283	Masonry		
.284	Concrete		
.29			
•3	Working of mines Exploitation		
.31	Open workings		
.311	Open cut working		
.312	Stripping		
.313	Milling		
.32	Placer workings See 622.21		
.321	Small scale working with pan, cradle and long tom		
.322	Sluicing		
,323	Hydraulicking		
.324	Dredging		
295	Cableway methods		

622.326 .327	Mechanical shovel methods  Dry placer methods
.33	Methods used mainly in coal mining
.331	Longwall methods
.332	Room and pillar methods, including panel method
.34	Methods used mainly in metal mining
.341	Overhand stoping
.342	Underhand stoping
.35	Working thick deposits
.351	Caving method
.352	Filling method
.353	Square set method
,354	Square work method
.36	Working soluble deposits
.361	Salt
.362	Copper sulphate
.37	Working fusible deposits
.371	Sulphur
.38	Working liquid and gaseous deposits
.381	Water
.382	Petroleum
.383	Natural gas
.384	Volcanic emanations
.39	
.4	Ventilation, lighting and signaling
.41	Theory of ventilation
.411	Mine atmospheres
.1	Gases See 622.811
.2 .3	Dust See 622.812 Humidity
.4	Temperature
.412	Resistance to circulation of air
.413	Splitting currents of air
.42	Natural ventilation
.43	Mechanical ventilation without fans or blowers
.431	Cowls
.432	Furnaces
.433	Steam jets
.434	Waterfalls

622.44 .	Fans and blowers See 623 95
.441	Fans
.1	Disk fans
.2	Centrifugal fans See 621.63
.442	Blowers
.1	Rotary blowers See 621.62
.2	Piston blowers See 621.61
.45	Airways, stoppings, regulators
.46	Lighting, safety lamps, etc. See 622.975
.48	Signaling
.5	Drainage
.51	Theory of infiltration of water
.511	Surface water
.512	Ground water
.513	Deep water
.52	Drainage without raising water
.521	Natural drainage
.522	Gutters
.523	Bore holes See 622.24
.524	Tunnels See 622.26
.53	Pumps actuated by surface motors
.531	Rod lift pumps
.1	For mines
.2	For deep wells
.532	Cornish pumps
.533	Bull pumps
.54	Pumps actuated by underground motors
.541	Reciprocating pumps
.1	Station pumps
.11	Steam
.12	Air
.13	Electric
.14	Hydraulic
.2	Sinking pumps
.21	Steam
.22 .23	Air Electric
.23 .542	Centrifugal pumps
.042	Station State Stat
.2	Sinking
.543	Direct displacement pumps

622.543.1 .11 .12 .2 .21 .22	Steam Pulsometers Steam jets Air Exhausting air-pressure pumps Return-air pumps Air lifts
.55 .551 .552	Hoisting of water See 622.65 and 622.67 Water buckets and tanks Water shafts See 622.25
.56 .57 .571 .572	Dams and water tight linings see 622.254 and 622.264 Handling special waters Acid waters Hot waters
.58 .59	Hand pumps Siphons
.6	Extraction, hoisting and transportation
.61 .611 .612	Handling mineral in working place By hand By machine
.62 .63 .64 .641 .642 .643	Underground roads Cars, trams, etc. Transportation by gravity Chutes Batteries Gravity planes Retarding conveyors
.65 .651 .1 .2 .3 .652 .1	Haulage and hoisting by men and beasts Haulage Wheeling in barrows Tramming Animal haulage Hoisting Windlasses Whims
.66 .661 .1	Mechanical haulage Rope haulage See 622.673 and 622.674 Theory Haulage engines

622,661.3	Engine planes
.4	Endless-rope haulage
.5	Tail-rope haulage
.662	Locomotive haulage
.1	Theory
.2	Steam locomotives
.3	Compressed air locomotives
.4	Oil locomotives
,5	Electric locomotives
.67	Mechanical hoisting
.671	Theory
.672	Hoisting engines
.1	Steam hoists
.2	Compressed air hoists
.3	Oil hoists
.4	Electric hoists
.673	Drums, reels, clutches and brakes
.674	Ropes and chains
.1	Manila ropes
.2	Wire ropes
.3	Chains
.675	Head frames
.1	Timber
.2	Steel
.676	Hoisting systems
.1	Unbalanced hoisting Balanced hoisting
.3	Koepe system
.4	Whiting system
.68	Cages, skips, buckets, slope carriages
.69	Surface transportation including mineral roads,
	wire ropeways, transhipment, loading and
	unloading. (See 622 99)
.691	Wagon roads
.692	Railways
.693	Aerial tramways
.694	Telphers
.698	Loaders
.699	Unloaders, dumps, etc.
.7	Mechanical preparation Ore dressing
.71	Theory Preliminary operations
179	Hand dressing See 622.781

000 M0	Currelain or	
622.73	Crushing See 622.782	
.731	Theory .	
.732	Hand breaking	
.733	Mechanical breaking	
.1	Jaw breakers	
.2	Spindle breakers	
.734	Crushing	
.1	Rolls	
.2	Roller mills	•
.3	Stamps	
.4	Impact pulverizers	
.5	Ball mills and tube mills	
.6	Arrastras and grinding pans	
.74	Screening See 622.783	
.741	Theory	
.742	Perforated metal and wire cloth	
.743	Grizzlies	
.744	Shaking screens	
.745	Pulsating screens	
.746	Trommels	
.747	Belt screens	
.75	Wet concentrating machines	Ore concentrators
	See 622.77 and 622.784	
.751	Theory	
.752	Disintegrators	
.1	Trough washers	
.2	Log washers	
.3	Wash trommels	
.4	Washing pans	
.753	Hydraulic classifiers	
.1	Free-settling classifiers	
.11	Carrying-current classifiers	
.111	Buddles	
.112	Riffles, canvas tables, etc.	
.113	Box classifiers	
.114	Settling boxes and ponds	
.12	Hydraulic-current classifiers	
.121	Trough	
.122	Pocket	
.123	Tubular	
.2	Hindered-settling classifiers	
.21	Wolf-tongue classifiers	
.22	Pulsator classifiers	
.754	Jigs	
.1	Hand	

622,754.2	Power
.21	Pan
.22	Piston
.23	Pulsator
.755	Tables
.1	Agitation sizing tables
.11	Bumping
.12	Jerking
.2	Film sizing tables
.21	Fixed
.22	Moving
.756	Vanners
.1	Side-shake End-shake
2	End-snake
.76	Slime treatment see 622.75
.77	Concentration by other means than wet concen-
	tration
.771	Pneumatic concentration See 682.785
.772	Oil concentration
.773	Flotation
.774	Magnetic separation
.775	Electrosctatic separation
.776	Disintegration and screening See 622.78
.78	Preparation of coal see 622.71
.781	Picking See 622.72
.1	Hand
.2	Mechanical
.782	Crushing See 622.73
.1	Jaw breakers
.11	Sauerman
.12	Roll and jaw
.3	Rotary crushers Rolls
.3	Toothed
.32	Corrugated
.33	Smooth
.4	Impact pulverizers
.41	Hammer
.42	Disintegrator
.783	Screening See 622.74
.1	Trade sizes
.2	Bar screens
.3	Shaking screens
.4	Revolving screens
.784	Washing See 622 75

622.784.1	Hyraulic classifiers		
.11	Carrying-current classifiers .		
.111	Grading boxes		
.112	Trough washers		
.12	Hydraulic-current classifiers Tub washers		
.2	Jigs		
.21	Pan		
.22	Piston		
.23	Compartment		
.3	Tables		
.32	Bumping		
.33	Jerking		
.785	Pneumatic concentration See, 622,771		
.786	Concentration by crushing and screening Bradford		
	pulverizers See 622.776		
.787	Coking See 644.22, 622.7 and 669.8		
.1	Theory		
.2	Open pits		
.3	Beehive ovens		
.4	Longitudinal ovens		
.5	Gas retorts		
.6	By-product ovens		
.788	Briquetting		
.1	Peat		
.2	Lignite		
.3	Bituminous coal		
.4	Anthracite		
.5	Coke		
.780	Coal preparation plants See 622.79		
.1	Tipples		
.2	Breakers		
.3	Washeries		
.4	Coking plants		
.5	Briquetting plants		
.79	Mineral preparation plants see 622.789		
.791	Rock houses, shaft houses		
.792	Patios		
.793	Concentrating mills		
(22.0			
622.8	Dangers and accidents		
.81	Explosions, see 622.82		
.811	Marsh gas explosions		
.1	Theory		
.2	Causes		
.3	Actual cases		
.4	Preventive measures		
.812	Coal dust explosions		

622.812.1	Theory
.2	Causes
.3	Actual cases
.4	Preventive measures
.82	Mine fires See 622.81
.821	Timber fires
.1	Theory
.2	Causes
.3	Actual cases
.4	Methods of extinguishment
.5	Preventive measures
.822	Gob fires
.1	Theory
.2	Causes
.3	Actual cases
.4	Methods of extinguishing
.5	Preventive measures
.823	Fires in coal
.1	Theory
.2	Causes
.3	Actual cases
.4	Method of extinguishment Preventive measures
.5 .824	Fires in sulphide ore
.0.4	Theory
.2	Causes
.3	Actual cases
.4	Methods of extinguishment
.5	Preventive measures
.83	Crushing and falls of ground
.84	Flooding of mines
.85	Accidents to miners
.851	Accidents due to falls of ground See 622.83
.852	Accidents due to explosives and blasting
.853	Haulage accidents
.854	Hoisting accidents
.855	Accidents due to machinery
.856	Electric shocks
.857	Falling down shafts, chutes, etc.
.858	Accidents due to explosions and fires See 622.81 and 622.82
.859	Miscellaneous accidents
.86	Rescue and relief
.861	Mine rescue
.1	Apparatus
.2	Systems

622.861	
.3	Actual cases
.862	First aid .
.1	Outfits
.2	Methods
.3	First aid teams
.867	Doctors
.868	Hospitals See 622 975
.869	Miners' insurance and compensation
.87	Sicknesses of miners
.9	Surface plants See 622.789 and 622.79
.91	Offices
.911	General offices
.912	Mine offices
.92	Storehouses and yards
.921	General storehouses
.922	Powder houses
.923	Tool houses
.924	Oil houses
.925	Lamp houses .
.936	Yards for lumber and other combustibles
.937	Yards for steel and other non-combustibles
.93	Shops
.931	Blacksmith shops
.932	Machine shops and foundries
.933	Carpenter shops and sawmills
.94	Power plants
.941	Steam plants
.942	Compressed air plants
.943	Electric plants
.95	Fan houses
.96	Stables
.97	Buildings for employees
.971	Change houses, wash houses, dry houses, shift houses
.972	Club houses
.973	Dwellings
.974	Stores
.975	Hospitals

.028

IL	LINOIS ENGINEERING EXPERIMENT STATION
622.98	Fire protection
.99	Arrangement of surface plants See 622.69
623	Military and Naval Engineering
.8	Naval architecture
624	Bridge engineering Arches
	Construction in wood, stone, and metal This classification includes whatever concerns the methods and principles of construction, so that the computations and technical conditions may be established, or the way the movable parts act of each other. For architectural features see 72 Architecture
624.0	General
	Subdivisions of 624.0 may be combined with the following subdivisions, 624.1—624.9, for specifyin details of construction under consideration
.01	Classification of bridges according to the charac
	acter of the material used
.011	Wooden bridges
	(1 Wooden pile bridges; 2 bridges on stone piers; 3 bridges covere with iron)
.012	Masonry bridges
	(1 Stone bridges; 2 brick bridges; 3 bridges of concrete, plain an reinforced)
.013	Metal bridges on stone piers
	(1 Cast iron bridges; 2 iron and steel bridges)
.014	Bridges entirely of metal
	(1 Bridges of cast iron; 2 bridges of iron and steel)
.02	Classification of bridges according to purpose
.021	Bridge sidewalks for foot passengers
.022	Road bridges (1 Carriage bridges; 2 railway bridges; 3 bridges with more that one track; 4 bridges with more than one story)
.023	Viaducts
.024	Canal and aqueduct bridges
.025	Tunnel bridges
.026	Sluice and toll bridges
.027	Movable and turning bridges

(1 Wooden emergency bridges; 2 trestle 'bridges; 3 pontoon bridges; 4 portable metallic bridges)

Classification of bridges according to outline or .03 type

Military and temporary bridges

624.031	Right bridges
.032	Skew bridges
.033	Curved bridges
.034	Single span bridges
.035	Bridges of multiple independent spans
.036	Bridges of continuous spans
.04	Determination and computation of component
	parts of bridges
	See also 620.1—Resistance of materials
.041	Establishment of the general outline Working drawing
.042	Computation of loads, dead and alive
	Permanent loads, accidental loads, trial loads, wind
	loads, temperature stresses
.043	Computation of the dimensions
.1	Dimensions of arches
	(11 Curve of pressure; 12 diagram of stability)
.2	Dimensions of timber work
	(21 Main timters; 22 accessory members; 23 wind bracing)
.3	Dimensions of piles and abutments
.044	Computation of deformation Flexure, curve of deforation
.045	Computation of weight and cost
	(1 Weight of Parts; 2 net price)
.05	General conditions of location Methods of
	construction
.051	Determination of site Study of soil
.052	Location of approaches
.053	Choice of type Fixing the principal dimensions Height Width
.054	Determination of the waterway Estimating the flow
	Computation of eddies
.055	Organization of work yards Excavation and removals
.056	Preparation of component parts Assemblage Stone cutting
.057	Erecting, scaffolds, launching
.058	Trials, tests
.06	Masonry vaults and arches Various types
.061	Names according to rise or direction Right arches
•001	Skew arches Descending arches Full centered
	arches Flat arches Ascending arches
.062	Cylindrical arches Vaulted arches Names according
	to profile Circuean arches Basket handled or
	oval arches Elliptical or parabolic arches Pointed
	arches

624.063	Penetrating arches Vaulted arches with lunettes Grom arches cloistered arches Cloistered arches with
0.04	plastered covering
.064	Ring arches, vaulted or descending
.065	Spherical vaults Simple domes Domes of cupola lights Partly cylindrical niches Overhanging arches Back-covering
.07	Constituent parts Methods of construction
.071	Intrados, Estrados, Soffit, Spandell
.072	Voussoir, or keystone Height or rise Keys Counter keys Bed joints Rising joints Bearings or springers
.073	Supports Upright pillars or props Drums Pen-
.074	Construction of arches, centering and scaffolding Masonry work Dressing and laying stone Striking the centers Complementary work Coping Spandrel Filling up
.075	Computation and diagrams of arches
.1	Computation of weight and loads
.2	Diagrams of arches (21 Curve of the intrados; 21 depth of the keystone)
.3	Thickness of piers
.4	Equilibrium polygon
.5	Weight diagram
.6	Computation of weights
.08	Trussed girders Component parts and computations
.081	Parts of trusses in ordinary wood Principal rafters, ties, struts, tie-beams, braces False tie-beams Hammer beams Purlins Brackets Wallplates Ridge-pole Luths
.082	Special parts of trusses of jointed wood, curved, or of great span
.083	Parts of metal trusses
.084	Parts of composite trusses
.085	Computation of loads and reactions
.086	Computation of dimensions of parts
.087	Computation of weight
.1	Piers and abutments Foundation work
.11	Foundations Generalities Nature of the soil See also 721.1, Foundations in general
-111	Dry foundations
.112	Foundations by draining

624.113 ·114 .1 .2 .3 .115 .1 .2 .3	Sunk concrete Cribs and frame foundations in general Foundations on piling In river beds Platforms and open caissons Foundations in soft earth Metal piers Foundations by compressed air Tubular caisson foundation in river beds Foundations in ground Movable caissons Montaigue system
.12	Abutments
.121 .122 .1 .2 .3 .4	Abutments for wooden bridges Abutments for masonry bridges Dressing the abutments Abutments of loose stones Wing walls Curved walls Hollow abutments Abutments of metal bridges
.13	Wooden piles Stakes
.14 .141 .142 .143 .144	Masonry piles Piles of uniform strength Cut-waters Preparation of the piles Hollow piles Piles for floors Piles for bridges
.15 .151 .152 .153	Metal piles With four uprights With more than four uprights Piles of uniform strength
.2	Beams Floors of bridges Shapes and arrangement
.21	Wooden bridges
.211	Primitive arrangements Simple beams Without beams
.212	Floors of beams
.213	Trussed beams and spliced beams For arch bridges
.214	American lattice bridges Towne's system
.215	American like St. Andrews cross Howe system
.22	Bridges of metal construction Iron and steel beams American trusses
-221	Simple metal trusses
.1	Trusses with rigid joints
.2	Trusses with solid core

624.221.3	Lattice trusses
.4	Side pieces and crosses of St. Andrew
.222	Trusses of concrete and reinforced concrete
.223	American trusses with jointed connections
.1	Simple American trusses
0	(11 The Warren triangular system; 12 the Howe system; 13 the Pratt and Whipple systems; 14 protected trusses)
.2	Composite American trusses
	(21 Warren multiple system; 22 Linville system; 23 Poat system; 24 the Bollman system)
.3	Compound American truss
	(31 The Warren system; 32 the Pratt or Pettit system; 33 the Howe system; 34 the Funk system)
.3	Metal lattice bridges Different kinds
.31	With trusses of constant height Ordinary lattice
.32	With variable height or bowstring
.33	Cantilevers
.34	
	With joints or crane bridges
.4	Metal tubular bridges
.5	Suspension bridges Different kinds parts
.51	General arrangement Different types
.511	Bridges with flexible hangers
	(1 With single panel; 2 with several panels; 3 with auxillary trusses; 4 with stays)
.512	
.512	Bridges with rigid hangers  With parabolic cable and straight beams
.2	With cable and parabolic beams
.3	With parabolic cable and horizontal stringers
.52	Suspension chains and cables
.521	Main cables
.522	Reserve cables
.523	Anchorage cables
524	Suspension chains and rods
.53	Floors
.54	Piers Towers
.55	Abutments Anchorages
.6	Arch bridges Different kinds
.61	Wooden bridges of one or more spans
.62	Masonry bridges of one or more spans
.621	Stone bridges
.622	Brick bridges
.623	Plain and reinforced concrete bridges

624.63	Cast iron bridges on masonry piers, with one o
.64	Bridges entirely of cast iron
.65	Steel and iron bridges on masonry piers
.651	Single span bridges
.652	Independent span bridges
.653	Continuous bridges
.66	Steel and iron bridges on metal piers
.661	Single span bridges
.662	Independent span bridges
.663	Continuous bridges
.67	Bridges with elevated arch
.7	Bridges of composite construction
. 71	Bridges of unlike spans in masonry and metal
.72	Bridges and viaducts with superimposed spans
.73	Metal bridges with several types of span
.74	Bridges with floor raised with lifts
.8	Movable and shifting bridges Methods of operation
.81	Draw bridges (pont-levis)
.82	Swing bridges
.83	Bascule bridges
.84	Trunion bridges
.85	Rolling bridges
.86	Bridges shifting in the air
.87	Jack-knife bridges
.88	Agencies for operating movable bridges
.881	Movement by hand
.882	Movement by hydraulic power
.883	Movement by steam
.884	Movement by electricity
.9	Roofs and framing Vaults
	Construction adapted to considerable spans See also 605. coverings and 721.5 dwellings
.91	Types of roofs
.911	Roofs of trusses
.912	Mansard roofs
.913	Roofs of curved beams

624.914	Roofs of great span (1 With wooden trusses; 2 with metal trusses; 3 with Combined wood and metal trusses)
.92	Vaulted edifices of masonry
.921	· · · · · · · · · · · · · · · · · · ·
.922	Buildings of one nave Buildings with coupled naves Aisles
,922	Buildings with coupled haves Aisles
.93	Buildings of great width in masonry and in metal Public halls, etc.
.94	Buildings entirely of metal Halls Markets Exposition buildings
.95	Various metal construction Scaffolding Towers
625	Railway and road engineering
.1	Railways Roadbed and work of construction
.11	The survey and location
.111	Preliminary studies Plans Special features of drawings (stations, branches, stonework, crossings
	on a level, tunnels)
.112	Extent of the road
.113	Longitudinal profile Grades Curves
.114	Cross-sections Computation of earthwork
.12	Sub-grade
.121	Acquisition of land
.122	Buildings and consolidating the embankments
.123	Drainage of the foundation bed
.13	Stone work, bridges and tunnels Ventilation of tunnels
.14	The track
.141	Ballast
.142	Supports (ties, etc.)
.1	General principles Longitudinal and tranverse solitary supports Comparison
.2	Supports of wood
.3	Supports of metal
.4	Supports of reinforced concrete
.5	Supports of stone
.143	Rails and rail attachments
.1	Forms of rails Weight of rails
.2	Quality of metal in rails Conditions of manufacture Tests
.3	Wear and breakage of rails
.4	Joints of rails Fish joints
.5	Attachment of rails to supports Creeping

625.144	Laying the track
.1	Width and position of joints Length of rails
	Spacing the cross bars
.2	Excess gauge and superelevation (bending) Laying track on curves
.3	Splices
.4	Operation of track laying
.15	Equipment of the track
.151	Branches (switches. frogs, switch blocks)
.152	Crossings
.153	Junction-crossings
.154	Turntables and swing bridges
.155	Car rollers or shifters
.156	Various accessory appliances (buffers, cyclometers, etc.)
.16	Secondary installations
.161	Sheds and watchman's houses Section houses
.162	Right-of-way fences and bars at grade crossings Set-
	ting land marks
.163	Cultivation and planting
.164	Snow screens
.165	Approaches
.17	Care of the road Maintenance and renewals
.171	Inspection Control
172.	Current maintenance Condition of the road Dudley
	dynamometer Maintaining the joints Dyna-
	mometer cars
.173	Repairs and renewals
.174	Clearing away snow
.175	Velocipedes for track inspection
.176	Changing the alignment
.18	Stores Road materials Accounts
.19	
.10	
.2	Rolling stock (For locomotives, see 621.13) .205 Periodicals; .206 Societies; (Am. Assu. of Master Car Builders)
.21	Cars and carriages, principal parts of
.211	Frames
.212	Axles Wheels Tires Balancing of wheels
.213	Suspension
.214	Provisions for lubricating Lubricants
.215	Trucks Radial and convergent axles
.216	Couplers and buffers Draft gears

625 22	Cross section of cars Clearance of bridges and
	tunnels Influence of length of cars on
	curves
.23	Passenger cars
,23	Types and comparison of types Seating capacity Weight
.231	Compartment cars
.232	Corridor or vestibuled cars Parlor cars Sleeping cars Dining cars, etc.
.233	Lighting of cars
.234	Heating and ventilation of cars Sanitation
.24	Freight cars
.24	Generalities Capacity Weight
.241	Flat cars
.242	Hopper and dumping cars
.243	Closed and covered cars
.244	Refrigerator cars
.245	Special cars Dynamometer cars (See 656.221.7)
.246 .247	Details of construction Use of steel in construction Carunloaders Miscellaneous unloading and dumping
.247	devices devices devices
.25	Brakes Hand, automatic, continuous, etc. Air
	brakes
.26	Car repair shops
.27	Supplies Materials
.3	Inclined and mountain railways
.4	Elevated and underground railways Subways
.5	Cable roads
.6	Tributary railways or feeders Street railways
.61	Tributary railways from a technical standpoint
	.611 Traffic; taxes; .612 administration and operation; .613 sub grade; .614 track and track equipment; .615 stations; .616 motive power; .617 rolling stock
.62	Street railways Tramways
.63	Traction systems
.7	Roads and highways Country roads and city streets
.71	Varieties of ordinary roads, according to the im-
	portance or purpose
.711	Rural roads, wide or narrow
.712	Town roads
	(1 Thoroughfares, avenues, boulevards; 2 narrow streets, alleys: 3 covered ways; 4 squares; 5 promenades and public gardens)

625.72 .721 .722 .723 .724 .725 .726	Surveys and maps of routes  Drafting Staking out the line Longitudinal profile Curve notes Leveling Computation of excavation and embankment
.73	Various features of the route Roadbed Cross- sections  (1 Cross-sections: 2 carriage ruts, crowning, inclines; 3 equip- ment; 4 sidewalks; 5 drains; 6 slopes; 7 retaining walls;
	ment; 4 sidewalks; 5 drains; 6 slopes; 7 retaining walls; 8 parapets)
.74	Method of road construction Construction equipment
.741	General questions  Flag stones Stone pavements Wooden pavements  Macadam roads Monolithic roads Cement, as-
77.40	phalt, gavel and earth roads
.742	Equipment earth roads, macadam roads, paved roads
.743	Sidewalks, macadam, paved, flagging, brick, tiling, sand- stone, asphalt, wood
17.4.4	* *
.744	Curbing
.745	Accessory construction
	(1 Bridges and culverts: 2 aqueducts; 3 manholes; 4 drains; 5 protection stones; 6 mile stones, sign posts; 7 cultivation; 8 lighting, lamp posts; 9 other features)
.75	Construction work
.751	Substructure Embankment Haul Shaping the
	cross-section
.752	Roadway Work of cosolidation
.753	Accessory work
	•
.76	Maintenance of way
.761	Maintenance of paved streets Replacing worn stones
.762	Maintenance of macadam roads
.1	The continuous repair method Closing to travel Ex-
	cessive sweeping Method of making repairs
	Use of material, of concrete
.2	Periodical ballasting Various methods
.3	Rolling
.4	Tarring or oiling the road
.763 .764	Maintenance of wooden roads
.765	Maintenance of monolithic or concrete roads
.766	Maintenance of asphalt roads
.767	Maintenance of foot paths  Maintenance of cycle tracks

625.768	Current minor details of maintenance
.1	Sweeping Use of brooms Wheel sweepers
.2	Scraping and removing wash water
.3	Removal of filth
.4	Removal of dead leaves and other debris
.5 .6	Removal of snow Cleaning by salt
.7	Sanding and ice removal  Sprinkling Use of sprinklers, hose, water columns,
.,	sprinkling costs
.S	Lighting
.9	Other maintenance work
.77	Planting trees and shrubs along the roads
.771	Conditions to be observed Ways of planting Single,
	double or multiple rows Spacing the trees
.772	Choice of species Species used
.773	Operation of planting Trenches Transplanting Nur- series
.774	Maintenance and protection of vegetation
.78	Sanitation applied to streets and roads
.79	Other work connected with roads
.8	Paving stone, paving Macadamizing and other methods of consolidating roads
.81	Paving stone
.811	Stones used Different kinds Granite, limestone, mar- ble, etc.
.812	Splitting and dressing paving stone
.813	Putting in place
.82	Stone pavements
.821	Stone used Granite Sandstone Porphyry Other hard stone
.822	Preparing the stone
.823	Making the stone pavement
.1	The sand foundation
.2	Layers of stones Curbs Old pavements
.3	Setting the stone
.4	Crossings
.83	Wooden pavements
.831	Wood used Pine Hardwood
.832	Preparation of the pavement
.833	Making the pavement
	Staking out Fixing the profile of the concrete foundations Concrete foundations Laying the

525.84	Concrete roads
.85	Asphalt roads
.86	Stone covered roads
.861	Materials used Crushed stone Limestone Flint
	Quartz Sandstone, granite Hornblend Por-
	phyry Trap, basalt and lava Waste from pot- teries
.862	Preparation of materials Crushing the stone Crush-
	ing by hammers Crushers Storing
.863	Applying the metal covering  Method of Tressaquet
.1	Macadamizing
.3	Method of Poloncease
.4	Metal on foundations
.5 .6	Metal without foundation Diagonal waterways Catchbasins
.7	Rolling Rollers, hand, horse, steam
.87	Metallic roads Roads of vitreous stone Roads
.01	of reinforced stone
.88	Establishment of side walks, curbing, flagging
.89	Other work connected with paving
	• ~ ~
.9	Other means of transportation on land
.91	Ship railways
.92	Transportation by aerial cables
26	Canal engineering
27	River, harbor and general hydraulic engineering
.1	Rivers Force of water Discharge Bars
.2	Harbors Breakwaters
.3	Docks, piers and quays Shipping facilities
.4	Dikes and levies Embankments
.5	Other protection and reclamation of land from tides and waves Drainage
.6	Jetties
.7	Dredging Dredging machinery
8.	Dams
.9	Light-houses Buoys

628	Sanitary engineering Waterworks Use same form divisions as under 620
.1	Water supply of towns (For isolated water supply see 628 7)
.11	Sources of water supply: lakes, rivers, springs, wells and pumping
.12	Pumping vs. gravitation systems: pump-well, stand-pipe high service Holly system
.13	Storage and service reservoirs
.14	Conduits Aqueducts Tunnels
.15	Mains and service pipes Freezing Iron Lead
.16	Impurities and their removal Filter-basins, etc.
.17	Public (sprinkling, fire, flushing), manufactur- ing, and domestic use and waste Meters
.2	Sewerage works
.21	Sewerage systems
.211	Combined system
.212	Separate system
.213	Liernur system
.214	Shone systems
.215 .216	Berlier system Other systems
.217	The outfall
.218	Depth and alignment
.219	Grade and velocity
.22	Shape and size of sewers
	(1 storm water flow; 2 ordinary flow; 3 circular section; 4 ordinary; egg-shape; 5 other egg-shapes; 6 other forms; 8 formulas for size)
.23	Ventilation of sewers
	(1 openings in streets; 2 lamp posts; 3 flues in houses; 4 pipes on houses; 5 house drains; 6 chimneys and; furnaces; 7 charcoal and chemicals to deodorize sewerage gas; 8 special mechanism; 9 special construction)
.24	Design and construction of sewers
.25	Sewer appurtenances
	(1 junctions; 2 house connections; 3 manholes, and lampholes; 4 flushing shafts and fixtures; 5 catch basius and inlets; 6 traps and ventilators; 7 valves and penstocks; 8 overflows and regulators; 9 miscellaneous)
.26	River crossings
.27	Intercepting and outfall sewers
.28	Reservoirs and tank sewers
2.9	Pumping stations

628.3	Disposal of Sewage
.31	Physical properties of sewage
.32	Deodorization and disinfection of solids and
	liquids (See 628.237)
.33	Subsidence
.34	Precipitation
	(1 precipitation tanks; 2 mixing machinery; 3 filter presses; 4 precipitation by salts of alumina; 5 by lime; 6 by salts of iron; 7 by other methods; 8 disposal of sludge; 9 miscellaneous)
.35	Filtration
.36	Irrigation
	(1 broad irrigation; 2 ridge and furrow irrigation; 3 fiat bed irrigation; 4 sub-suface irrigation; 5 intermittent downward filtration; 6 carriers and appurtenances; 7 drains and drainage on sewage farms; 8 filtration areas; 9 miscellaneous)
.37	Sewage farming Required modifications of or
	dinary methods
.38	Sewage manures
.39	Discharge into sea, etc.
.4	Sanitation of towns
.41	Middens and privies
.42	Pail system
.43	Earth closet systems
.44	Domestic ashes and garbage
.45	Public urinals and latrines
.46	Street cleaning and sprinkling
.47	Pavements and subways
.48	Trees in streets and squares
.49	Manufacture of fertilizers from town waste
628.5	Industrial sanitation
.51	Factories and trades
	(1 prevention of dust and fumes; 2 protection of throat and eyes; 3 protection against infection; 9 special trades)
.52	Effluvium nuisances
	(1 situation of works; 2 use of high chimneys; 3 condensation in water; 4 combustion in furnaces; 9 special trades)
.53	Smoke nuisance
	(8 From steam generators; 9 From special industries)
.54	Disposal of solid and liquid wastes
	(1 discharge into streams; 2 absorbing wells and burial; 3 clarification by subsidence; 4 chemical treatment; 5 filtration; 6 purification by the soil; 9 special methods and special trades)

628.6	House drainage
.7	Rural water supply Villages and country houses
.8	Ventilation and heating (See 697, 628.23)  This head is chiefly for ventilation. Most matter on heating goes in 697
.9	Lighting (See 021.32, 537.83)
650	Communication Commerce
651	Office equipment and methods
652	Writing Materials Typewriters
653	Stenography
654	Telegraphy (For telegraph and telephone engineering see 621.38)
.6	Telephones
655	Printing and publishing
656 T	ransportation Operation of railways
.1	Transportation on roads and highways
.2	Transportation by railways
.21	Railway terminals and stations
.211	Arangement of passenger stations
.212	Arrangement of freight and terminal stations
.213 .214	Stations for special purposes (coal, live stock, etc.) . Union stations Division of expenses
.215	Heating and lighting of stations
.22	Trains
.221	Train resistance
.1	Resistance of freight trains
.2	Resistance of passenger trains
.3 .4	Resitance o fengines Resistance on electric roads
.5	Resistance of foreign rolling stock
.6	Air resistance
.7	Dynamometer cars (See 625.245)
.222	Running of trains Schedules
.223	Use of and distribution of rolling stock
	(1 Passenger cars; 2 Freight cars; Return of empty cars; Interchange of cars)
.224	Passenger train service Postal service
.225 226	Freight service Making up trains Tonnage rating
.220	Daygage Service

656.227	Transportation of dangerous and perishable freight
.228	200
.229	Military transportation
.23	Traffic and rates
.231	Transportation tolls and rates in general
	(Revision of rates Basing rates Differential rates Zone tariffs, etc;)
.232	Cost of transportation
.233	Competition of railways Division of traffic Pools, agreements, etc.
.234	Passenger rates Rates for baggage, dogs, etc. Passes and reduced fares
.235	Freight rates Classification of freight
.236	Rates for transportation other than by railway
	Rates of porterage and drayage Steamer rates Street railway rates
.237	Accounting and auditing Supervision of receipts and expenses
.24	Damage Delays Claims Responsibility
.25	Safety appliances
.25	General rules
.251	Signals in general Forms Colors Sounds Daltonism
.252	Hand signals Train signals
.253	Fixed track and station signals
.254	Apparatus for long distance communication Bells and special warning signals Telegraph Telephone Communication between stations and running trains Various operating systems Train dispatching Protection of trains in distress
.255	Staff and ticket system of controlling trains
.256	Block systems
.1	Simple manual block signals
.2	Electrically controlled manual block signals
.3	Automatic electric block signals
.4	Automatic pneumatic block signals
.257	Centralization of operation of switch and signal systems
	Interlocking switch and signal apparatus
.258	Electro-pneumatic interlocking devices Indirect blocking systems Electric slot Ring and
.208	key Locking of draw-bridges
.259	Other safety devices
	(Apparatus placed in trains Communication between cars and with locomotive Speed indicators on trains or along the track)
.26	Accessories to railway service Dray and cab
	service Buffets, restaurants and hotels

656.27	Operation of line with light traffic and of local and tributary railways
.28	Accidents
.280	Statistics General questions
.281	Derailments
.282	Broken couplings Runaway cars
.283	Collisions
.284	Other accidents
.285	Accidents to railway employees
.296	Accidents to the public upon railway property
.29	Miscellaneous questions relative to railway trans- portation
	*
.3	Transportation by horseless vehicles
.30	
.31	
.32	Automobiles
.321	Types
.1	Pleasure vehicles
.2	Commercial vehicles
.322	Agricultural vehicles  Motive powers
.1	Internal combustion motors
.2	Steam motors
.3	Electric motors
.323	Principal parts (excluding motors)
	(1 frames, springs, etc.; 2 clutches, brakes; 3 gear; 4 axles, differentials; 6 wheels, rims, tires; 7 steering gear; 8 journals)
.324	Design and construction
.325	Testing
.329	Maintenance, operation, laws, etc.
657	Book-keeping Accounting
660	Chemical technology
661	Chemicals (1 chemical elements: 2 acids: 3 alkalies: 4 salts)
662	Pyrotechnics Explosives
665	Oils Gases

665.2	Animal oils and fats
.3	Vegetable oils and fats
.4	Mineral oils Paraffin Asphaltum
.7	Illuminating gases
.8	Other gases
666	Ceramics Glass, etc.  (1 Glass; 2 Enamel: 3 Ceramics: 4 Clay; 5 Porcelain; 6 Stonewar and earthenware)
666.7	Bricks Tiles
.8	Artificial stone
.9	Cements Limes Mortars
067	Bleaching, dyeing, etc.
668	Other organic chemical industries
069	Metallurgy and assaying
669.1	Iron and steel
.11	Economic factors
.111	Sources
.112	Production
.113	Costs
.114	Prices
.115	Uses
.12	Nature and properties
.121	Composition Analyses
.122	Constitution
.1	Thermal examinations Diagrams
.123	Metallography  The sixty of the
.123	Physical properties Tests Chemical properties Corrosion
.13	Alloys
.131	Nickel
.132	Manganese
133	Chrome
.134	Tungsten
.135	Molybdenum
.136	Vanadium

669.137	Silicon
.138	Titanium
.139	Other alloys
.14	Extraction
.141	Direct processes
.142	Blast furnace process
.143	Electric furnace process
.15	Purification
.151	Puddling processes
.152	Open hearth processes
.1	Acid
.2	Basic
.153	Bessemer processes
.1	Acid
.2	Basic
.154	Electric furnace processes
.16	Carburization
.161	Cementation process
.162	Crucible process
.17	Founding
.171	Melting
.172	Molding
.18	Treatment
.181	Heat treatment
.1	Hardening
.2	Tempering
.3	Annealing
.182	Case hardening
.183	Malleable cast iron process
.184	Mechanical treatment Forging
.1 .2	Rolling
.2	Wire drawing
.4	Pressing
.5	Machining
.185	Finishing
.1	Sand blasting
.2	Pickling
.3	Painting
.4	Galvanizing
.5	Plating
.6	Oxidized coating Enameling
.7	Епатения

669.19	Plants
669.2	Gold and silver
.21	Gold alone
.211	Economic factors
.1	Sources
.2	Production
.3	Costs
.4	Purchasing power
.5	Uses
.212	Properties
.213	Alloys
.218	Chlorination
.1	Theory
.2	Vat chlorination process
.3	Barrel chlorination process
.219	Plants
.22	Silver alone
.221	Economic factors
.1	Sources
.2	Production
.3	Costs
.4	Prices
.5	Uses
.222	Properties
.223	Alloys
.228	Leaching
.1 .2	Hot water leaching Ziervogel process Brine leaching Augustin process
.2 .3	Hyposerlphite leaching
.31	Theory
.32	Patera process
.33	Russell process
.229	Plants
.23	Gold and silver
.231	Amalgamation
.1	Theory
.2	Plate amalgamation process
.3	Pan amalgamation process
.235	Smelting
.237	Refining and parting See 669.373, 669.473 and 669.573
.238	Cyanidation
.239	Plants
669.3	Copper
.31	Economic factors

669.311	Sources
.312	Production
.313	Costs
.314	Prices
.315	Uses
.32	Properties
.33	Alloys
.34	Roasting
.35	Matte smelting
.351	Reverberatory furnace process
.352	Blast furnace processes
.1	Smelting roasted ore
.2	Pyritic smelting
.36	Copper smelting
.361	Reverberatory furnace process for blister copper
.362	Blast furnace process for black copper
.363	Converting
.37	Refining
.371	Reverberatory furnace process
.372	
.373	Electrolytic process
.38	Leaching
.381	Rio Jinto process
.382	Hunt and Douglas processes
.383	Neill process
.384	Henderson process
.39	Plants
669.4	Lead
.41	Economic factors
.411	Sources
.412	Production
.413	Costs
.414	Prices
.415	Uses
.42	Properties
.43	Alloys
.44	Roasting
.45	Smelting
.451	Ore hearth process
.452	Reverberatory furnace process

Blast furnace process

.453

669.46	
.47	Refining .
.471	Pattinson process
.472	Parkes process
.473	Electrolytic process
.48	Leaching
.49	Plants
669.5	Zinc
.51	Economic factors
.511	Sources
.512	Production
.513	Costs
.514	Prices
.515	Uses
.52	Properties
.53	Alloys
.54	Roasting
.55	Smelting
.56	
.57	Refining
.571	Reverberating furnaces process
.572	
.573	Electrolytic process
.58	Leaching
.59	Plants
.6	Tin
.7	Mercury and other metals
.8	General factors of roasting, smelting, refining
.81	Fuels
.811	Theory of combustion
.812	Solid fuels
.1	Wood
.2	Charcoal
.3	Peat
.4	Lignite
.5	Bituminous coal
.6	Coke
.7	Anthracite
.813	Liquid fuels
.814	Gaseous fuels

000.0111	NT-1
669.814.1	Natural gas
***	Producer gas
.3	Water gas
.4	Coal gas
.5	Blast furnace gas
.82	Refractories
.821	Theory
.S22	Siliceous refractories
.1	Sand
.2	Gannister
.3	Silica brick
.4	Carborundum and siloxicon
.823	Argillaceous refractories
.1	Fire clay
.2	Common clay
.824	Aluminaceous refractories
.1	Bauxite
.2	Fused alumina
.825	Carbonaceous refractories
.1	Graphite
.2	Čarbon brick
.826	Chromitic refractories
.827	Alkaline earth refractories
.1	Magnesia
.2	Dolomite
.3	Lime
.828	Rare earth refractories
.7	Zirconia
.2	Tungsten
.829	Application and maintenance
.1	Cements
.2	Tamping implements
.9	Repair materials and methods
••	Tepan materials and memors
.83	Furnaces
.831	Roasting and calcining furnaces
.1	Theory of roasting and calcining
.2	Heaps
.3	Stalls
.4	Kilns
.5	Reverberatory furnaces
.51	Hand
.52	Mechanical
.521	With plane hearths
.522	With conical hearths
.523	With cylindrical hearths
.6	Muffles

669.831.7	Blast roasting furnaces
.71	With intermittent discharge Pots
.72	With continuous discharge
.832	Smelting furnaces
.1	Theory of smelting
.2	Hearths
.3	Reverberatory furnaces  Direct fired
.31 .32	Regenerative
.4	Blast furnaces
.5	Converters
.6	Electric furnaces
.833	Liquation furnaces
.834	Distillation furnaces Retorts
.835	Sublimation furnaces
.836	Refining furnaces
.837	Melting furnaces
.84	Pyrometry
.85	Flue gases and dusts
.86	Slags
.87	Mattes and speisses
.88	Metals and alloys
.89	Metallography
669.9	Sampling, assaying, preliminary operations
.91	Sampling
.911	Sampling ores and fluxes
.1	Theory
.2	Taking samples
.3	Preparing samples
.9	Sampling works
.912	Sampling metals
.1	Theory
.2	Methods
.913	Sampling gases
.913 .1	Sampling gases Theory
.913	Sampling gases
.913 .1 .2	Sampling gases Theory Methods Assaying
.913 .1 .2 .92	Sampling gases Theory Methods Assaying Fire assaying
.913 .1 .2 .92 .921 .922	Sampling gases Theory Methods Assaying Fire assaying Wet assaying
.913 .1 .2 .92 .921 .922 .923	Sampling gases Theory Methods Assaying Fire assaying Wet assaying Electrolytic assaying
.913 .1 .2 .92 .921 .922 .923 .924	Sampling gases Theory Methods Assaying Fire assaying Wet assaying Electrolytic assaying Coal analysis
.913 .1 .2 .92 .921 .922 .923	Sampling gases Theory Methods Assaying Fire assaying Wet assaying Electrolytic assaying

669 93	Drying
.94	Crushing
.95	Briquetting See 622.783 and 622.789.5
670	Manufactures  (In this division may be placed items that do not properly belong under 621; such as items relating to textile mills or machinery, the manu-
	facture of shoes, etc.)
680	Mechanic Trades
690	Building
69 (001)	Statistics
(002)	Quantities and costs Prices, etc.
(003)	Contracts and specifications
(01)	Theories of construction
(02) (07)	Compends, treatises, text books, etc. Education, teaching, etc.
(01)	(See form divisions pp. 7 and 8)
691	Materials Processes Preservatives For Strength of materials, see 620.1 For Uses of prepared materials, see 693 to 699
.1	Woods
.18	Preservation of woods
691.2	Natural stone Protection
.211	Limestone
.221	Granite
.231 .24	Sandstone, ordinary Slate
.29	Preservation
.3	Artificial stone Concrete
.31	Beton coigniet
.32	Ransome
.33	Hollow block
.34	Selenitic
.35	Lime concrete
.36	Cement concrete
.37	
.39	Aggregate
.4	Bricks Tiles Ceramic products
.46	Tiles
.47	Tiles, hollow structural

691.471	Floor	
.472	Roof and ceiling.	
.48	Terra cotta	
.49	Sewer tiles	
.5	Lime Cement Plaster	
.51	Lime, ordinary	
.52	Lime, hydraulic	
.53	Lime, selenitic	
.54	Cement, natural	
.55	Cement, portland or artificial	
.56	Plaster of paris	
.57	Keene's cement	
.6	Glass	
•7	Iron Steel Anti-rust processes	
.71	Cast iron	
.72	Malleable cast iron	
.73	Wrought iron	
.74	Steel, blister or tool	
.75	Steel, crucible	
.76	Bessemer steel	
.77	Open hearth steel	
.78		
.79	Protection of iron and steel	
.791	Painting	
.792 .793	Tinning Galvanizing (Zincking)	
.794	Electroplating	
.8	Other metals	
.9	Other materials	
.91	Mineral wool	
.92	Hair	
.93	Paper	
.95	Asbestos	
.96	Asphalt Tar	
92	Plans Specifications, etc.	
.1	General drawings	

692.2	Detail drawings	
.3	Specifications	
.4	Contracts Agreements Bids Advertisements	
.5	Estimates Quantities Cost	
.6	Superintendence	
.7	Supervision of Accounts	
.8	Professional services Fees Commissions	
.9	Building laws Liabilities of architects, owners and contractors	
.91	State or general laws	
.92	City ordinances	
.93	Town or village ordinances	
.94	Trade rules	
.95	Liabilities of architects	
.96	Liabilities of owners	
.97	Liabilities of contractors	
.98	Lien laws	
693	Masonry Plastering Fire-proofing	
.1	Stone construction	
.2	Brick construction	
.3	Terra cotta construction	
.4	Hollow tiles and porous terra cotta	
.5	Concrete and beton construction	
.51	Massive	
.52	Layers	
.53	Hollow block	
.54	Sidewalks	
.55	Ornamental	
.6	Plastering	
.7	Reinforced concrete	
.71	Systems	
.711	Ordinary	
.712	Ransome's	

693.713	Unit	
.714	Hennebique	
.715 .72	Roebling	
.73	Forms and centers	
.74	Testing and inspection  Data from experiments	
.75	Formulas	
.76	Special applications	
.8	Fire-proofing	
.81	Systems	
.82	Walls and partitions	
.83	Flors	
.84	Roofs	
.85	Columns	
.86	Girders	
.87	Trusses	
.88	Vaults	
594	Carpentry Joinery Stairbuilding	
595	Roofing	
695.1	Shingle	
.2	Slate	
.3	Tile	
.4	Metal	
.5	Iron and steel	
.6	Asphalt, tar, etc.	
.7	Felt and gravel	
.8	Cloth	
.9	Thatch, etc.	
596	Plumbing Gas and steam fitting	
.1	Plumbing	
.2	Gas-fitting	
.3	Steam-fitting	
.4	Rivets and riveted joints	

696.5	Screws and screw joints		
.6	Rust and caulked joints		
.7	Anchors Bond irons		
.8	Other branches		
.9	Plumbing laws		
697	Heating and ventilating		
.1	Fireplaces		
.2	Stoves		
.3	Furnaces, hot air		
.4	Hot water		
.41	High pressure		
.42	Low pressure		
.43	Low pressure with steam mains		
.5	Steam		
.51	High pressure		
.52	Low pressure		
.53	Exhaust steam		
.54	Vacuum		
.6	Gas		
.61	Illuminating		
.62	Fuel		
.63	Natural		
.64	Acetylene		
.7	Electric and other methods		
.8	Smoke flues and chimneys		
.9	Ventilation Ducts Fans		
.91	Natural system		
.92	Plenum		
.93	Exhaust		
.94	Fresh air ducts		
.95	Foul air ducts		
.96	Treatment of air		
.97	Regulation of air supply		
.98	Fans		

698	Painting Glazing Paperhanging		
699	Car and shipbuilding		
720	Architecture		
721	Architectural construction		
.1	Foundations		
.2	Walls		
.3	Piers Columns		
.4	Arched constructions		
.5	Roofs		
.6	Floors and flooring		
.7	Ceilings		
.8	Doors Gates Grilles Windows		
.9	Iron and composite structures		
722	Ancient and oriental architecture		
723	Mediaeval architecture		
724	Modern architecture		
725	Public buildings		
.1	Administrative Governmental		
.2	Business and commercial		
.3	Transportation and storage		
.31	Railway passenger stations		
.32	Railway freight stations		
.99	Railway shops, roundhouses, car houses		
.34	Dock buildings		
.35	Ware houses Cold storage		
.36	Grain elevators		
.38	Garages		
.4	Manufactories		
.41	Textile factories or mills		
.42	Breweries Distilleries		

Foundries Machine shops Iron and stee
Wood-working mills
Carriage and car factories
Hospitals and asylums
Prisons and reformatories
Refreshment Baths Parks
Recreation
Other public buildings
Ecclesiastical and religious
Educational and scientific
Colleges and universities
Professional and technical schools
Laboratories
Residences
Architectural design and decoration
Drawing Decorations Design
Freehand
Perspective
Mathematical and scientific
Engraving
Photography

A		Tests of Wet	621.533
Absorption dynamometers	531.4	Air engines	621.517 621.4
Absorption of heat	536.3	motors	621.541
Abutments for bridges 624.1		pressure gages	621.532
Accidents, in mines	622.8	refrigerating machines	621.565
Railway	656.28	resistance (railway trains)	
Statistics of railway	656.28	supply, Regulation of (ver	
to railway employees	656.285	lation)	697.97
to public upon railway prop-	000,,000	Alcohol engines	621.434.24
erty	656.296	Algebra	512
Accounting	657	Alkalies (chemistry)	661.3
Railway	656.237	Alkaline accumulators	621.356
Shops, manufactories and en-	000.501	Alloys of iron and steel (S	
gineering works	621.706	Steel)	669.13
Accounts, Supervision of	0.51.100	Alternating current, convert-	
(Building)	692.7	ors entreme, convert-	621.313.5
Accumulators, Electric (See	002.1	generators	621.313.43
Storage batt.)	621.354	machinery	621.313.3
Alkaline	621.356	transmission systems	621.319.123
Lead (See Lead accumula-	5,000	Aluminaceous refractories	669.824
tors)	621,355	Amalgamation of gold and s	
Other types of	621,357	ver	669.231
Accumulators, Water	621,254	Ammeters	621.374.4
Acids (chemistry)	661.2	Ammonia, absorption machin	
Acoustics	534	compression machines	621.572
Acyclic machines 621	.313,291	Analyses, of iron and steel	669,121
Adhesion of locomotives	31.131.1	of coal	669.924
Administration of manufactories	621.704	of gas	669,926
Administrative buildings	725.1	of oil	669,925
Aeronautics	533.6	Analytical geometry	516
Agillaceous refractories	669.823	Anchorage (suspension bridg	
Air	533	Anchors (plumbing)	696.7
Flow of, in pipes	621,534	Arcient architecture	722
Air brakes	625.25	Animal haulage (mines)	622,651,3
Air compression	621.5	Animal materials, Tests of	620.198
Theory of	621,534	Animal motors	621.46
Thermodynamics of	621.534	Animal oils	665.2
Air compressors, Dry	621.515	Annealing (steel)	669.181.3
Efficiency of	621.534	Anthracite coal	553,25

Aqueducts 628.14	Braking devices for 656.323
Arch bridges 624.6	Clutches for 656.323.2
Arched constructions (archi-	Design and construction of 656.324
tecture) 721.4	Frames for 656.323.1
Arches 624	Gears for 656.323.3
Architects, Liabilities of 692.9	Journals for 656.323.8
Architectural construction 721	Laws for 656.329
Architectural design and deco-	Motive power of 656.322
ration 729	Motors for 656.322
Architecture 720	Principal parts of 656.323
Ancient and oriental 722	Operation of 656.329
Mediaeval 723	Stearing gears for 656.323.7
Modern 724	Tires for 656.323.6
Naval 623.8	Types of 656.321
Arc lamps 621.325	Wheels for 656.323.6
Alternating current enclosed 621.325.5	Auto-transformers 621.314.4
Alternating current open 621.325.4	Axles, Car 625.212
Continuous current enclosed 621.325.3	Locomotive 621.134.1
Continuous current open 621.325.2	Radial and convergent 625.215
Arc lighting 621.325	
Arc rectifiers 621.313.73	В
Arithmetic 511	Baggage rates 656.234
Artificial cement 691.55	service 656.226
Artificial stone (see Stone, Ar-	Balancers (electric) 621.313.27
tificial) 691.3 620.139	Balancing of car wheels 625.212
Asbestos for building 691.95	Ball bearings 621.822
Ash conveyors 621.183.78	Ballast (railways) 625.141
Ash pits (locomotives) 621.133.2	Bascule bridges 624.83
(stationary boilers) 621.183.55	Basins, Filter 628.16
Asphalt (building material) 691.96	Baths, Public 725.7
roads 625.85	Batteries, Primary 621.353
roofing 695.6	Storage (See Storage bat-
Asphaltum 620.196 665.4	teries) 621,354
Assaying 669 669.92	Beams (bridges) 624.2
Astronomy 520	Bearings 621.822
Asylums (architecture) 725.5	Ball and roller 621.822
Asynchronous machines 621.313.6	Metals for 621.822
Atmosphere 533.3	Bell signals 656.254
Atmospheric electricity 537.4	Belt gearing 621.852
Auditing, Railway 656,237	Bending machinery 621.982
Automatic, electric block sig-	Berlier system of sewerage 628.215
nals 656.256.3	Besemer process for steel 669.153
shaft governor engines 621,164.3	Acid 669,153.1
telephone systems 621.385.75	Basic 669.153.2
Automobiles 656.32	Beton coigniet (artificial stone) 691.31
Axles for 656,323.4	construction (building) 693.5

Bevel gears	621.833.2	manometers	621,184,73
Bids (building construction)	692.4	masonry	621.184.57
Binary vapor engines	621.44	plants	621.19
Bissell trucks	621.135.4	pressure gages	621.184.73
Bituminous coal	553.24	rating	621.194.7
shale	553.23	rings	621.184.53
Blast furnaces	621.76	riveted joints	621.184.52
Blowing engines for	621.61	safety valves	621.184.73
Blasting	622.238	shell setting	621.184.56
Bleaching (chemical technological		shops	621.792
Blocking systems, Indirect	656.258	steam collectors	621.184.79
Block systems, Indirect	. 656.256	tests	621.184.13
	656.256.3	hydraulic	621.194.7
Automatic electric		•	
Automatic pneumatic	656,256,4	tubes	621.184.53
Electrically controlled man		tubesheets	621.184.52
ual	656,256.2	types	621.184.2
Simple manual	656,256,1	water gages	621.184.72
Blocks and tackles	621.863	whistles, warning	621.184.72
Blowers (forge shop)	621.732	zincs	621.184.79
Centrifugal	621.63		184 621,194
Piston	621.61	Bracing of	621,184.52
Rotary	621.62	Corrosion of	621,196.5
Blowing engines	621.6	Firetube (tubular)	621.184.25
Blue printing processes	621.716	Flash generators	621.184.27
Boiler, accessories	621.184.7	Instantaneous vaporizing	621.184.27
casing	621.184.54	Locomotive 621.133	621.184.23
construction	621.184.5	Management of	621,193
domes	621.184.52	Marine	621.184.22
drums	621.184.52	Portable	621.184.23
economy	621.184.13	Scale prevention in	621.194.4
feeding (locomotive)	621,133.7	Setting and hanging of	621.184.56
(stationary)	621.194.2	Stationary	621,184,24
feedwater	621.184.13	Staying of	621.184.52
Treatment of	621,194.3	Traction	621,184.23
ferules	621,184,53	Water tube	621.184.26
firing	621.194.1	Wear and duration of	621.194.196
floaters	621.184.72	Bolt and nut machinery	621.99
flues	621.184.57	Bolts	621.882
foundations	621.184.57	Borers, Churn (hand)	622,241.1
furnaces	621.183	(machine)	622,242.1
gage glasses	621.184.72	Rotary (hand)	622,241,2
hand holes	621.184.55	(machine)	622.242.2
heads	621.184.52	Bonding of rails	621.333.4
incrustation	621.194.4	Bond irons (plumbing)	696.7
inspection	621.194.7	Book-keeping	657
manholes	621.184.55	Boosters, Continuous curren	t 621.313.28

Mine         622.24t Hand         Bow string         624.32 Gantilever         624.32 Gantilever         624.33 Gantilever         624.33 Gantilever         624.32 Gantilever         624.33 Gantilever         624.33 Gantilever         624.32 Gantilever         624.34 Gantilever         624.33 Gantilever         624.34 Gantilever         624.34 Gantilever         624.34 Gantilever         624.34 Gantilever         624.34 Gantilever         624.35 Gantilever         624.07 Gantilever         624.05 Gantilever         Methods of construction         624.07 Gantilever         624.05 Gantilever         Methods of construction         624.05 Gantilever         624.05 Gantilever         Methods of construction         624.05 Gantilever	Boring, mills	621.945	Ordinary lattice	624.31
Hand         622,241         Cantilever         624,33           Machine         622,342         Crane         624,34           Bowstring bridges         624,32         Methods of construction           Brakes (in mills)         621,826         Methods of construction           Brakes, Air         625,25         Movable and shifting         624,83           Friction         531,4         Bascule         624,83           Hand, automatic, continuous         625,25         Draw         624,81           Locomotive         621,135,5         Jack knife         624,87           on tenders         621,136,1         Operating mechanism for         624,85           Braking devices for automobiles 656,323         Rolling         624,85           Breakwaters         621,222         Shifting in the air         624,85           Breakwaters Architecture of         725,42         Shifting in the air         624,85           Breweries, Architecture of 25,43         Suspension         624,85           Brick (building material)         691,4         Suspension         624,55           construction         693,2         Floors for         624,55           dors         620,14         Piers for         624,54	0,	622,24	-	624.32
Machine         622,242         Crane         624,32           Bowstring bridges         624,322         Methods of construction           Brakes (in mills)         621,826         624,07         624,07         624,07         624,07         624,07         624,07         624,07         624,07         624,07         624,07         624,07         624,07         624,07         624,07         624,07         624,07         624,08         624,83         Brakes, Air         625,25         Movable and shifting         624,83         624,83         Draw         624,83         624,83         Rolling         624,83         624,83         Rolling         624,82         Shifting in the air         624,88         624,82         Shifting in the air         624,82         624,82         Shifting in the air         624,82         624,83         Abutments for         624,52         624,52         Abutments for         624,52         624,52			9	624.33
Bowstring bridges         624.32         Methods of construction         624.07         624.05           Brakes (in mills)         621.826         625.25         624.07         624.05           Brakes (in mills)         625.25         Movable and shifting         624.83           Friction         531.4         Bascule         624.83           Hand, automatic, continuous         625.25         Draw         624.81           Locomotive         621.135.5         Jack knife         624.81           on tenders         621.136.1         Jack knife         624.83           Braking devices for automobiles 656.323         Rolling         624.85           Breakers, Circuit         621.317.36         Swing         624.85           Breakwaters         621.22         Trunion         624.85           Breakwater-wheels         621.22         Trunion         624.82           Breweries, Architecture of         725.42         Railway         625.13           Brick (building material)         691.4         Suspension         624.52           clays         553.61         Anchorages for         624.55           Bridge beams         624.2         Piers for         624.52           Bridge beams         624.2		622,242	Crane	624.34
Brakes (in mills)         621.826         Movable and shifting         624.07         624.05           Brakes, Air         625.25         Movable and shifting         624.83           Friction         531.4         Bascule         624.83           Hand, automatic, continuous         625.25         Draw         624.81           Locomotive         621.131.5         Jack knife         624.87           on tenders         621.136.1         Operating mechanism for         624.82           Braking devices for automobiles 656.323         Rolling         624.82           Breakers. Circuit         621.22         Swing         624.82           Breakwaters         627.2         Shifting in the air         624.82           Breast water-wheels         621.22         Trunion         624.82           Break water-wheels         621.22         Trunion         624.82           Brick (building material)         691.4         Suspension         624.82           Brick (building material)         691.4         Anthorages for         624.53           clays         533.61         Anchorages for         624.53           Bridge beams         624.2         Suspension chains and carbinotocatana         624.52           Bridge beams		624.32	Methods of construction	
Brakes, Air         625.25         Movable and shifting         624.8           Friction         531.4         Bascule         624.81           Hand, automatic, continuous         625.25         Draw         624.81           Locomotive         621.135.5         Jack knife         624.87           on tenders         621.136.1         Operating mechanism for         624.88           Braking devices for automobiles 666.323         Rolling         624.81           Breakers, Circuit         621.317.36         Swing         624.82           Breakwaters         627.2         Shifting in the air         624.82           Breast water-wheels         621.22         Trunion         624.82           Breick (building material)         691.2         Railway         625.15           (chem, tech.)         666.7         Abutments for         624.55           clays         533.61         Anchorages for         624.55           construction         693.2         Floors for         624.55           Bridge beams         624.2         Suspension chains and carbinations and car		621.826	624.07	624.05
Friction         531.4         Bascule         624.83           Hand, automatic, continuous         625.25         Draw         624.81           Locomotive         621.135.5         Jack knife         624.87           on tenders         621.136.1         Operating mechanism for         624.88           Braking devices for automobiles         656.323         Rolling         624.88           Breakers. Circuit         621.317.36         Swing         624.82           Breast water-wheels         621.22         Shifting in the air         624.82           Breweries. Architecture of         725.42         Railway         625.13           Brick (building material)         691.4         Suspension         624.55           Clays         553.61         Anchorages for         624.55           construction         693.2         Floors for         624.55           ostruction         693.2         Floors for         624.55           Bridge beams         624.2         Suspension chains and calloge beams         624.2         Bulker         624.54           Bridges         624.2         Towers for         624.55           Bridges         624.2         Tubular         624.65           Cast iron, masonry pier		625,25	Movable and shifting	624.8
Hand, antomatic, continuous   625.25   Care		531.4	9	624.83
Locomotive on tenders   621.135.5   Jack knife   624.87     Operating mechanism for   624.88     Braking devices for automobiles   656.323   Rolling   624.85     Breakers, Circuit   621.317.36   Swing   624.85     Breakwaters   627.2   Shifting in the air   624.86     Breast water-wheels   621.22   Trunion   624.84     Breweries, Architecture of   725.42   Railway   625.13     Brick (building material)   691.4   Suspension   624.55     Chem, tech.   666.7   Abutments for   624.55     Clays   553.61   Anchorages for   624.55     Clays   553.61   Anchorages for   624.55     Clays   693.2   Floors for   624.55     Bridge beams   624.2   Suspension chains and calfloors   624.2     Bridge beams   624.2   Suspension chains and calfloors   624.54     Bridge beams   624.2   Suspension chains and calfloors   624.54     Bridges   624   Tubular   624.64     Cast iron, masonry piers   624.63   Cast iron complete   624.64     Elevated (arch)   624.67   Masonry   624.62     Steel and iron, metal piers   624.62     Steel and iron, metal piers   624.62     Steel and iron, metal piers   624.62     Classification of, according to materials   according to type   624.03     Classification of purpose   according to type   624.03     Classification of parts of   624.04     Composite construction   624.07     Composite construction   624.07     Conditions of location   624.07     Conditions of lo		625.25	Draw	624.81
on tenders         621.136.1         Operating mechanism for captured by the staking devices for automobiles captured by the staking devices for staking devices for automobiles captured by the captured by the staking devices for automobiles captured by the staking devices for			Jack knife	624.87
Braking devices for automobiles 656.323         Rolling         624.85           Breakers, Circuit         621.317.36         Swing         624.82           Breakwaters         627.2         Shifting in the air         624.86           Breast water-wheels         621.22         Trunion         624.84           Breweries, Architecture of (chem. tech.)         666.7         Railway         625.13           Brick (building material)         691.4         Suspension         624.5           (chem. tech.)         666.7         Abutments for         624.5           clays         553.61         Anchorages for         624.55           construction         693.2         Floors for         624.55           Tests of         620.14         Piers for         624.55           Bridge beams         624.2         Suspension chains and cables for         624.54           Bridge beams         624.2         Towers for         624.54           Bridges         624.2         Types of         624.51           Bridges         624.2         Types of         624.51           Bridges         624.62         Tubular         624.04           Arch         624.63         Bridge for quarrying         622.785		621.136.1	Operating mechanism for	624.88
Breakers, Circuit         621.317.36         Swing         624.82           Breakwaters         627.2         Shifting in the air         624.86           Breast water-wheels         621.22         Trunion         624.86           Breweries, Architecture of Brick (building material)         691.4         Suspension         624.51           Brick (building material)         691.4         Suspension         624.55           (chem. tech.)         666.7         Abutments for         624.55           clays         553.61         Anchorages for         624.55           construction         693.2         Floors for         624.53           Bridge beams         624.2         Suspension chains and calles for         624.54           Bridge beams         624.2         Suspension chains and calles for         624.54           Bridges         624.2         Towers for         624.52           Bridges         624.2         Types of         624.54           Arch         624.6         Tubular         624.6           Cast iron, masonry piers         624.61         Briquetting of coal         624.01           Masonry         624.62         Briquetting of coal         622.52           Steel and iron, metal piers <t< td=""><td></td><td>es 656,323</td><td></td><td>624.85</td></t<>		es 656,323		624.85
Breakwaters         627.2         Shifting in the air         624.86           Breast water-wheels         621.22         Trunion         624.84           Breweries, Architecture of         725.42         Railway         625.13           Brick (building material)         691.4         Suspension         624.55           (chem, tech.)         666.7         Abutments for         624.55           clays         553.61         Anchorages for         624.55           construction         693.2         Floors for         624.55           construction         693.2         Floors for         624.55           bridge beams         624.2         Suspension chains and cables for         624.54           Bridge beams         624.2         Suspension chains and cables for         624.52           engineering         624.2         Towers for         624.54           shapes         624.2         Types of         624.54           shapes         624.2         Types of         624.54           Arch         624.6         Vaults and arches for         624.6           Cast iron, masonry piers         624.61         Briquetting of coal         622.788           Bride and iron, metal piers         624.62         Br			Swing	624.82
Breast water-wheels         621.22         Trunion         624.84           Breweries, Architecture of         725.42         Railway         625.13           Brick (building material)         691.4         Suspension         624.55           (chem. tech.)         666.7         Abutments for         624.55           clays         553.61         Anchorages for         624.55           construction         693.2         Floors for         624.55           Tests of         620.14         Piers for         624.55           Bridge beams         624.2         Suspension chains and cables for         624.52           floors         624.2         bles for         624.54           shapes         624.2         Towers for         624.55           Bridges         624.2         Types of         624.51           Bridges         624.2         Types of         624.51           Arch         624.6         Vaults and arches for         624.0           Cast iron complete         624.61         Briquetting of coal         622.788           Elevated (arch)         624.62         Brine system of refrigeration 621.565.1           Broaches (for quarrying)         622.22           Budtest for mine hoisting <td></td> <td>627.2</td> <td>Shifting in the air</td> <td>624.86</td>		627.2	Shifting in the air	624.86
Brick (building material)         691.4 (chem. tech.)         Suspension         624.55           (chem. tech.)         666.7 (chem. tech.)         Abutments for         624.55           clays         553.61 (chem. tech.)         Anchorages for         624.55           clays         553.61 (chem. tech.)         Anchorages for         624.55           construction         693.2 (chem. tech.)         Floors for         624.53           Tests of         620.14 (chem. tech.)         Piers for         624.53           Bridge beams         624.2 (chem. tech.)         Suspension chains and callots for         624.54           Bridge beams         624.2 (chem. tech.)         bles for chem. tech.         624.52           engineering         624.2 (chem.)         bles for chem. tech.         624.52           engineering         624.2 (chem.)         Towers for chem. this and callots for chem.         624.52           Bridges         624.2 (chem.)         Tubular (chem.)         624.54           Arch         624.61 (chem.)         Keled.         Vaults and arches for chem.         624.04           Cast iron complete         624.63 (chem.)         Briquetting of coal chem.         622.78           Building system of refrigeration of coal.         622.68         Broaches (for quarrying)		621.22		624.84
Brick (building material)         691.4 (chem. tech.)         Suspension         624.55           (clays         553.61 (clays)         Abutments for         624.55           construction         693.2 (clays)         Floors for         624.55           construction         693.2 (clays)         Floors for         624.53           Tests of         620.14 (clays)         Piers for         624.53           Bridge beams         624.2 (clays)         Suspension chains and cables for         624.54           floors         624.2 (clays)         Dies for         624.54           shapes         624.2 (clays)         Towers for         624.54           shapes         624.2 (clays)         Types of         624.54           Bridges         624.6 (clays)         Vaults and arches for         624.64           Cast iron masonry piers         624.63 (clays)         Wooden, Beams and floors for         624.04           Cast iron complete         624.61 (clays)         Briquetting of coal (clays)         622.788           Elevated (arch)         624.62 (clays)         Brine system of refrigeration of clays for mine hoisting         622.68           Steel and iron, masonry piers         624.61 (clays)         Buckets for mine hoisting         622.68           Building	Breweries. Architecture of	725.42	Railway	625.13
(chem. tech.)         666.7         Abutments for clays         624.55 construction         693.2 construction         553.61 construction         Anchorages for clay.55 construction         694.55 construction         693.2 construction         Floors for clay.53 construction         624.53 construction         624.53 construction         624.53 construction         624.54 construction         624.54 construction         624.54 construction         624.54 construction         624.54 construction         624.52 construction         624.53 construction         624.52 construction         625.21 construction         625.22 construction         624.03 construction         624.03 construction		691.4	Suspension	624.5
clays         553.61         Anchorages for construction         624.55           construction         693.2         Floors for         624.53           Tests of         620.14         Piers for         624.54           Bridge beams         624.2         Suspension chains and cales for         624.52           engineering         624.2         Towers for         624.52           shapes         624.2         Types of         624.54           Bridges         624.2         Tubular         624.51           Arch         624.6         Vaults and arches for         624.06           Cast iron, masonry piers         624.63         wooden, Beams and floors for         624.06           Cast iron complete         624.64         Brine system of refrigeration         621.565.1           Masonry         624.67         Brine system of refrigeration         621.565.1           Masonry         624.67         Broaches (for quarrying)         622.222           Steel and iron, metal piers         624.61         Buckets for mine hoisting         622.68           Steel and iron, metal piers         624.61         Buffers (railway cars)         625.216           Classification of, according to materials         624.01         Building         690 </td <td></td> <td>666.7</td> <td>Abutments for</td> <td>624.55</td>		666.7	Abutments for	624.55
construction         693.2         Floors for         624.53           Tests of         620.14         Piers for         624.54           Bridge beams         624.2         Suspension chains and callosts         624.52           floors         624.2         bles for         624.52           engineering         624         Towers for         624.54           shapes         624.2         Types of         624.54           Bridges         624         Tubular         624.64           Arch         624.6         Vaults and arches for         624.04           Cast iron, masonry piers         624.63         wooden, Beams and floors for         624.04           Cast iron complete         624.64         Brine system of refrigeration         621.565.1           Masonry         624.67         Brine system of refrigeration         621.565.1           Buckets and iron, masonry piers         624.62         Buckets for mine hoisting         622.68           Steel and iron, metal piers         624.61         Buckets of steam turbines         621.165.12           Buckets of steam turbines         621.165.12         Buffers (railway service)         625.216           Classification of, according to materials         624.01         Building         690 <td>,</td> <td>553,61</td> <td>Anchorages for</td> <td>624.55</td>	,	553,61	Anchorages for	624.55
Tests of 620.14 Piers for 624.54 Bridge beams 624.2 Suspension chains and cafloors 624.2 bles for 624.52 engineering 624 Towers for 624.54 shapes 624.2 Types of 624.51 Bridges 624 Tubular 624.64 Arch 624.63 wooden, Beams and floors for 624.06 Cast iron, masonry piers 624.63 wooden, Beams and floors for 624.21 Cast iron complete 624.64 Briquetting of coal 622.788 Elevated (arch) 624.65 Brine system of refrigeration 621.565.1 Broaches (for quarrying) 622.222 Steel and iron, masonry piers 624.65 Steel and iron, metal piers 624.65 Steel and iron, metal piers 624.61 Cantilever 624.33 Classification of, according to materials 624.01 according to purpose according to type 624.02 according to type 624.03 Clearance of 625.22 Building construction, Cost of 692.5 Computation of parts of 624.04 Building material 691 Composite construction of 624.07 Artificial stone 691.95 Foundations for 624.21 Asphalt 691.4	•	693.2	Floors for	624.53
Bridge beams624.2Suspension chains and calbles for624.52engineering624Towers for624.54shapes624.2Types of624.51Bridges624Tubular624.64Arch624.6Vaults and arches for624.06Cast iron, masonry piers624.63wooden, Beams and floors for624.06Cast iron complete624.64Briquetting of coal622.788Elevated (arch)624.67Brine system of refrigeration621.565.1Masonry624.62Broaches (for quarrying)622.222Steel and iron, masonry piers624.65Buckets for mine hoisting622.68Steel and iron, metal piers624.61Buffers (railway cars)621.165.12Wooden624.61Buffers (railway cars)625.216Cantilever624.01Building690Classification of, according to materials624.01Building690according to purpose according to type624.02Superintendence of692.5Clearance of Computation of parts of Composite construction of Conditions of location624.04Building material691.0Conditions of location metal, Beams and floors for624.01Asbestos691.95Foundations for metal, Beams and floors for624.22Brick, tiles691.4		620.14	Piers for	624.54
floors 624.52 engineering 624 shapes 624.2  Bridges 624  Arch 624.6  Cast iron, masonry piers 624.63  Elevated (arch) 624.67  Masonry 624.62  Steel and iron, masonry piers 624.65  Steel and iron, metal piers 624.61  Cantilever 624.61  Cantilever 624.61  Cassification of, according to materials according to purpose according to type 624.03  Clearance of 625.22  Computation of parts of 624.04  Conditions of location 624.05  Foundations for 624.11  Arch 624.2  Tubular 624.4  Vaults and arches for 624.06  Wooden, Beams and floors for 624.21  Briquetting of coal 622.788  Briquetting of coal 622.788  Brine system of refrigeration 621.565.1  Broaches (for quarrying) 622.222  Buckets for mine hoisting 622.68  Buckets of steam turbines 621.165.12  Buffers (railway cars) 625.216  Building 690  Building construction, Cost of 692.5  Superintendence of 692.5  Building material 691  Conditions of location 624.05  Asbestos 691.95  Foundations for 624.22  Brick, tiles 691.4		624.2	Suspension chains and ca-	
engineering 624.2 Towers for 624.54 shapes 624.21 Bridges 624. Tubular 624.4 Arch 624.6 Vaults and arches for 624.06 Cast iron, masonry piers 624.63 wooden, Beams and floors for 624.21 Cast iron complete 624.64 Briquetting of coal 622.788 Elevated (arch) 624.67 Brine system of refrigeration 621.565.1 Masonry 624.62 Broaches (for quarrying) 622.222 Steel and iron, masonry piers 624.65 Buckets for mine hoisting 622.68 Steel and iron, metal piers 624.66 Buckets for mine hoisting 622.68 Steel and iron, metal piers 624.61 Buffers (railway cars) 625.216 Cantilever 624.33 Buffets (railway service) 656.26 Classification of, according to materials 624.01 according to purpose 624.02 according to type 624.03 Clearance of 625.22 Building laws 692.9 Computation of parts of 624.04 Building material 691 Composite construction of 624.7 Artificial stone 691.3 Conditions of location 624.05 Asbestos 691.95 Foundations for 624.22 Brick, tiles 691.4	9	624.2	1 -	624.52
shapes 624.2 Types of 624.51  Bridges 624 Tubular 624.4  Arch 624.6 Vaults and arches for 624.06  Cast iron, masonry piers 624.63 wooden, Beams and floors for 624.21  Cast iron complete 624.64 Briquetting of coal 622.788  Elevated (arch) 624.67 Brine system of refrigeration 621.565.1  Masonry 624.62 Broaches (for quarrying) 622.222  Steel and iron, masonry piers 624.65 Steel and iron, metal piers 624.66 Wooden 624.61  Cantilever 624.33 Classification of, according to materials 624.01 according to purpose 624.02 according to type 624.03 Clearance of 625.22 Computation of parts of 624.04 Composite construction of 624.7 Artificial stone 691.3 Conditions of location 624.05 Asbestos 691.95 Foundations for 624.21 Brick, tiles 691.4		624	Towers for	624.54
Bridges 624 Tubular 624.4  Arch 624.6 Vaults and arches for 624.06  Cast iron, masonry piers 624.63 wooden, Beams and floors for 624.21  Cast iron complete 624.64 Briquetting of coal 622.788  Elevated (arch) 624.67 Brine system of refrigeration 621.565.1  Masonry 624.62 Broaches (for quarrying) 622.222  Steel and iron, masonry piers 624.65 Steel and iron, metal piers 624.66 Wooden 624.61  Cantilever 624.33 Classification of, according to materials 624.01 according to purpose 624.02 according to type 624.03 Clearance of 625.22 Computation of parts of 624.04 Composite construction of 624.7 Artificial stone 691.3 Conditions of location 624.05 Foundations for 624.22 Brick, tiles 691.4	<u> </u>	624.2	Types of	624.51
Arch Cast iron, masonry piers 624.63 wooden, Beams and floors for 624.21 Cast iron complete 624.64 Briquetting of coal 622.788 Elevated (arch) 624.67 Brine system of refrigeration 621.565.1 Masonry 624.62 Broaches (for quarrying) 622.222 Steel and iron, masonry piers 624.65 Steel and iron, metal piers 624.66 Wooden 624.61 Cantilever 624.33 Classification of, according to materials according to purpose 624.02 according to type 624.03 Clearance of 625.22 Computation of parts of 624.04 Composite construction of 624.04 Conditions of location 624.05 Foundations for 624.11 Asphalt 691.96 metal, Beams and floors for 624.22 Brick, tiles 624.04 Briquetting of coal 622.788 wooden, Beams and floors for 624.64 Briquetting of coal 622.788 Briquetting of coal 622.78	*	624	* *	624.4
Cast iron complete 624.64 Elevated (arch) 624.67 Masonry 624.62 Steel and iron, masonry piers 624.65 Wooden 624.61 Cantilever 624.33 Classification of, according to materials according to type 624.03 Clearance of 625.22 Clearance of 625.22 Computation of parts of 624.04 Composite construction of 624.07 Conditions of location 624.05 Conditions of location 624.05 Conditions for 624.11 Cast iron complete 624.64 Briquetting of coal 622.788 Briquetting of coal 622.788 Brine system of refrigeration 621.565.1 Broaches (for quarrying) 622.222 Buckets for mine hoisting 622.68 Buckets of steam turbines 621.165.12 Buffers (railway cars) 625.216 Building construction, Cost of 692.5 Superintendence of 692.5 Building laws 692.9 Building material 691 Conditions of location 624.05 Conditions of location 624.05 Foundations for 624.11 Asphalt 691.96 Brick, tiles 691.44		624.6	Vaults and arches for	624.06
Cast iron complete 624.64 Elevated (arch) 624.67 Masonry 624.62 Steel and iron, masonry piers 624.65 Wooden 624.61 Cantilever 624.33 Classification of, according to materials according to type 624.03 Clearance of 625.22 Clearance of 625.22 Computation of parts of 624.04 Composite construction of 624.07 Conditions of location 624.05 Conditions of location 624.05 Conditions for 624.11 Cast iron complete 624.64 Briquetting of coal 622.788 Briquetting of coal 622.788 Brine system of refrigeration 621.565.1 Broaches (for quarrying) 622.222 Buckets for mine hoisting 622.68 Buckets of steam turbines 621.165.12 Buffers (railway cars) 625.216 Building construction, Cost of 692.5 Superintendence of 692.5 Building laws 692.9 Building material 691 Conditions of location 624.05 Conditions of location 624.05 Foundations for 624.11 Asphalt 691.96 Brick, tiles 691.44	Cast iron, masonry piers	624.63	wooden, Beams and floors for	624.21
Elevated (arch) 624.67 Masonry 624.62 Steel and iron, masonry piers 624.65 Steel and iron, metal piers 624.66 Wooden 624.61 Cantilever 624.33 Classification of, according to materials according to purpose according to type 624.03 Clearance of 625.22 Clearance of 625.22 Computation of parts of 624.04 Composite construction of 624.07 Conditions of location 624.05 Conditions of location 624.05 Foundations for 624.11 Masonry 624.62 Brine system of refrigeration 621.565.1 Broaches (for quarrying) 622.222 Buckets for mine hoisting 622.68 Buckets of steam turbines 621.165.12 Buffers (railway cars) 625.216 Building Construction, Cost of 692.52 Superintendence of 692.5 Building laws 692.9 Building material 691 Artificial stone 691.3 Conditions of location 624.05 Foundations for 624.11 Asphalt 691.96 metal, Beams and floors for 624.22 Brick, tiles 691.44	,	624.64		
Masonry Steel and iron, masonry piers 624.65 Steel and iron, metal piers 624.66 Wooden 624.61 Cantilever 624.33 Classification of, according to materials according to purpose 624.02 according to type 624.03 Clearance of 625.22 Computation of parts of 624.04 Composite construction of 624.7 Conditions of location 624.05 Conditions for 624.11 Conditions for 624.22 Steel and iron, masonry piers 624.65 Buckets for mine hoisting 622.68 Buckets of steam turbines 621.165.12 Buffers (railway cars) 625.216 Building construction, Cost of 692.5 Superintendence of 692.5 Building laws 692.9 Building material 691 Conditions of location 624.05 Conditions of location 624.05 Conditions for 624.11 Asphalt 691.96 Broaches (for quarrying) 622.222 Buckets for mine hoisting 622.68 Buckets of steam turbines 621.165.12 Buffers (railway service) 656.26 Building construction, Cost of 692.5 Superintendence of 692.5 Building material 691 Asphalt 691.96 Broaches (for quarrying) 622.68 Buckets for mine hoisting 622.68 Buckets for mine hoisting 622.68 Buckets for mine hoisting 622.68 Buckets of steam turbines 621.165.12 Buffers (railway service) 656.26 Building construction, Cost of 692.5 Asperton for 692.5 Superintendence of 692.6 Building laws 692.9 Building material 691.3 Conditions of location 624.05 Asbestos 691.95 Foundations for 624.11 Asphalt 691.96 Broaches (for quarrying)	-	624.67	_	
Steel and iron, masonry piers 624.65 Steel and iron, metal piers 624.66 Wooden 624.61 Cantilever 624.33 Classification of, according to materials according to type 624.03 Clearance of 625.22 Computation of parts of 624.04 Composite construction of 624.7 Conditions of location 624.05 Conditions of location 624.05 Foundations for 624.11 Steel and iron, masonry piers 624.65 Buckets of steam turbines 621.165.12 Buffers (railway service) 656.26 Building construction, Cost of 692.5 Superintendence of 692.5 Building laws 692.9 Building material 691 Composite construction of 624.7 Artificial stone 691.3 Conditions of location 624.05 Foundations for 624.11 Asphalt 691.96 Brick, tiles 691.4	Masonry	624.62		
Steel and iron, metal piers Wooden 624.61 Cantilever 624.33 Classification of, according to materials according to type 624.03 Clearance of 625.22 Computation of parts of 624.04 Composite construction of 624.05 Conditions of location 624.05 Conditions of location 624.05 Conditions for 624.11 Conditions for 624.22 Clearance of 624.23 Clearance of 624.24 Composite construction of 624.7 Conditions of location 624.05 Conditions of location 624.05 Conditions of location 624.05 Conditions of location 624.05 Conditions of location 624.22 Clearance of 624.22 Clearance of 624.23 Clearance of 624.24 Composite construction of 624.7 Conditions of location 624.05 Conditions of loc	Steel and iron, masonry pi	ers 624.65		
Wooden Cantilever Classification of, according to materials according to purpose according to type Clearance of Computation of parts of Composite construction of Conditions of location Conditions for Conditions for Cantilever 624.03 Buffers (railway cars) Buffets (railway service) 656.26 Building Construction, Cost of 692.5 Superintendence of 692.6 Building laws 692.9 Building material 691.3 Conditions of location 624.7 Conditions of location 624.05 Conditions for 624.11 Asphalt 691.96 Buffers (railway cars) 625.216 Building 690 Building construction, Cost of 692.5 Superintendence of 692.6 Congulation for 624.7 Artificial stone 691.3 Conditions of location 624.05 Asbestos 691.95 Foundations for 624.11 Asphalt 691.4				
Cantilever Classification of, according to materials according to purpose according to type Clearance of Computation of parts of Composite construction of Conditions of location Conditions of location Foundations for metal, Beams and floors for  Classification of, according to Building Building construction, Cost of Building construction, Cost of G92.5 Superintendence of Building laws Superintendence of G92.6 Artificial stone G91.3 Conditions of location G94.05 Asbestos G91.95 Brick, tiles G96.26 Building according to G92.5 Superintendence of G92.6 Asteroidal Superintendence of G92.6 Building material G91.8 G91.8 G92.9 Building material G91.8 G91.8 G91.9 G92.6 Building beaution G92.9 Building material G91.8 G91.9 G92.6 Building material G91.8 G91.9 G92.6 Building beaution G92.6 G92.6 G92.6 Building beaution G92.7 Artificial stone G91.9 G92.6 G92.6 G92.6 G92.6 G92.6 G92.6 G92.6 G92.6 G92.6 Building beaution G92.7 Artificial stone G91.3 G91.8 G92.6 G92.6 G92.6 G92.6 G92.6 G92.6 G92.6 G92.6 Building beaution G91.8 G91.8 G91.9 G91.8 G92.6	Wooden	624.61		
Classification of, according to materials 624.01  according to purpose 624.02  according to type 624.03  Clearance of 625.22  Computation of parts of 624.04  Composite construction of 624.7  Conditions of location 624.05  Foundations for 624.11  Mailding construction, Cost of 692.5  Superintendence of 692.6  Building laws 692.9  Building material 691.3  Conficial stone 691.3  Conditions of location 624.05  Foundations for 624.11  Asphalt 691.96  metal, Beams and floors for 624.22  Brick, tiles 691.4	Cantilever	624.33		
materials according to purpose according to type 624.03 Superintendence of 692.5 Superintendence of 692.6 Clearance of 625.22 Building laws 692.9 Computation of parts of 624.04 Building material 691 Composite construction of 624.7 Artificial stone 691.3 Conditions of location 624.05 Asbestos 691.95 Foundations for 624.11 Asphalt 691.96 metal, Beams and floors for 624.22 Brick, tiles 691.4	Classification of, according to	0		
according to purpose according to type 624.02 Superintendence of 692.6 Clearance of 625.22 Building laws 692.9 Computation of parts of 624.04 Building material 691 Composite construction of 624.7 Artificial stone 691.3 Conditions of location 624.05 Asbestos 691.95 Foundations for 624.11 Asphalt 691.96 metal, Beams and floors for 624.22 Brick, tiles 691.4	materials	624.01		
Clearance of 625.22 Building laws 692.9 Computation of parts of 624.04 Building material 691 Composite construction of 624.7 Artificial stone 691.3 Conditions of location 624.05 Asbestos 691.95 Foundations for 624.11 Asphalt 691.96 metal, Beams and floors for 624.22 Brick, tiles 691.4	according to purpose	624.02		
Computation of parts of 624.04 Building material 691 Composite construction of 624.7 Artificial stone 691.3 Conditions of location 624.05 Asbestos 691.95 Foundations for 624.11 Asphalt 691.96 metal, Beams and floors for 624.22 Brick, tiles 691.4	according to type	624.03	_	
Composite construction of 624.7 Artificial stone 691.3 Conditions of location 624.05 Asbestos 691.95 Foundations for 624.11 Asphalt 691.96 metal, Beams and floors for 624.22 Brick, tiles 691.4		625.22		
Conditions of location 624.05 Asbestos 691.95 Foundations for 624.11 Asphalt 691.96 metal, Beams and floors for 624.22 Brick, tiles 691.4	Computation of parts of	624.04	_	
Foundations for 624.11 Asphalt 691.96 metal, Beams and floors for 624.22 Brick, tiles 691.4	Composite construction of	624.7	Artificial stone	
metal, Beams and floors for 624,22 Brick, tiles 691.4	Conditions of location	624.05		
	Foundations for	624.11		
Metal lattice 624.3 Cement 691.5	metal, Beams and floors for	624,22		
	Metal lattice	624.3	Cement	691.5

Building Material.—Continued.		Cables, aerial, Transportation	n
Concrete	691.3	. by	625.92
Glass	691.6	Cables (elec. trans.)	621.319.34
Granite	691.221	Telephone and telegraph	621.319.34
Hair	691.92	Cages (mining)	622.68
Iron and steel	691.7	Calcining furnaces	669,831
Lime	691.5	Calculus	517
Limestone	691.211	Calorimetry	536.6
Mineral wool	691.91	Cams .	621.83
Paper	691.93	Design of	621.838
Plaster of Paris	691.56	Canal engineering	626
Preservatives for	691	Canals from economic aspect	386
Sandstone	691,231	Cannel coal	553.23
Slate	691.24	Can system of ice making	621.581
Stone (natural)	691.2	Cantilever bridges (see Bridge	
Tar	691.96	Cantilever)	624.33
Terra cotta	691.48	Trusses	624.22
Woods	691.1	Capital	331
Building plans (specifications,	00111	Relation of, to labor	331.1
etc.)	692	Capstans	621.864
Building processes	691	Car axles	625.212
Building stones	553.5	Carbonic acid refrigerating ma	
for building	691.2	chines	621.574
Buildings, Administrative	725.1	Carbon filament incandescent	0.21,014
Business and commercial		lamps	621.326.3
Cast iron in	725.2	Carbon series (econ. geology)	
Dock	691.71	Carbon vapor lamps	621.327.5
Ecclesiastical	725.34	Car, building	699
Educational	726	factories	
	727	frames	725.45
Exposition	624.94	houses	625.211
Governmental	725.1		725.33
Masonry	624,93	repair shops unloaders	625.26
Metal	624.94		625.247
Public	725	wheels	625.212
Recreation	725.8	Carburization of steel	669.16
Religious	726	Cementation process	669.161
Scientific	727	Crucible process	669,162
Shop	621.702	Carpentry	694
Storage	725.3	Carriage factories	725.45
Transportation	725.3	Carriages (mine hoisting)	622,68
Buoys	627.9	Carriages, railway, Principal	20
		parts of	625.21
С		Cars, Closed and covered	625.243
Cab service (transportation)	050.00	Compartment	625,231
Cable roads	656.26	Corridor or Vestibule, Parlor	*
Cable Toads	625.5	Sleeping	625.232

Cars.—Continued.		Ceramic products (building m	ıa-
Cross section of	625.22	terials)	691.4
Dining	625.232	Ceramics (chem. tech.)	666
Dynamometer	656.221.7	Chain gearing	621.835
Dynamometer and special	625.245	Channelers (for quarrying)	622.223
Electric	621.334.3	Chains, Hoisting	622.674
Flat	625.241	Chemical elements	661.1
Freight	625.24	technology	660
Heating of	625.234	Chemical deodorization of se-	wer
Hooper and dumping	625.242	gas	628,237
Interchange of	656.223.2	Chemistry	540
Lighting of	625.233	of foundry irons	621.745
Mine	622.63	Children, Labor of	331,3
Passenger	625.23	Chimneys (boiler plants)	621,183.8
Principal parts of	625.21	(heating and ventilation)	697.S
Refrigerator	625.244	(sanitation)	628.236
Sanitation of	625.234	Choke coils	621.314.6
Suspension of	625,213	Chrome steel	669.133
Ventilation of	625.234	Circuit breakers	621.317.36
Cast iron (in buildings)	691.71	Circulating pumps	621.197.3
Case hardening of	669.182	Claims (transportation)	656.24
Manufacture of	669.17	Classification of freight	856,235
Catch basins for sewers	628.255	drawings	621.717
Cattle-guards	625,162	Clay	666.4
Caulked joints (plumbing)	696.6	Fire and brick	553.61
Ceilings (architecture)	721.7	Clearance of bridges and tun	nels 625.22
Ceiling tile	691.472	Cloth roofing	695.8
Cells, Primary	621,353	Clutches	621.825
Secondary	621.354	Friction	621.825
Cement, Building	691.5	Coal and ash conveyors	621.183.78
concrete	691.36	Coal, Anthracite and graphic	c
· Keene's	691.57	anthracite	553.25
Natural	691.54	Bituminous and semi-bitum	in-
Portland or artificial	691.55	ous	553.24
	0.13 620.15	Briquetting of	622.788
Cements (chem. tech.)	666.9	Cannel	553,23
Cements, Mineral	553.68	Coking of	622,787
Central power stations (stea		Concentration of, by crushin	
end of)	621.19	and screening	622.786
Central stations	621,312	Crushing of	622.782
Combined	621.312.5	Mining of (methods)	622.33
for lighting only	621.312.2	Picking of	622,781
for power transmission	621.312.4	Plants for preparation of	622,789
for traction only	621.312.3	Pneumatic concentration of	
Centrifugal blowers	621.63	Preparation of	622.78
pumps	621.67	Screening of	622,783
PP0	0.21.01	Serecining of	01010,100

Coal.—Continued.		Concentrators, Coal 622.78	5 622.786
Trasming of	2.784	Ore	622.75
Cocks, Air 621.1	84.79	Concrete (building constructi	on) 693.5
Coking of coal 65	2.787	(building material)	691.3
Cold storage 65	1.565	Cement	691.36
Cold storage warehouses 7	25.35	construction, Hollow block	693.53
Colleges (buildings)	727.3	Lime	691.35
Collisions (railway) 65	6.283	Reinforced (See Reinforced	1
Columns, Architecture of	720.3	concrete)	693.7
Fireproofing of	93.85	Tests of	620.13
Combustion 621.182 5	36.46	Condensation in steam pipes	621.185.1
in locomotive boilers 621.	133.1	of effluvia in water	628,523
of effluvia in furnaces 62	8.524	Condensers (electric)	621.315.3
of fuel 62	1.182	Tet	621.197.63
Commerce 380	650	V	621.197.6
commission, Interstate	385.7	Steam	
· · · · · · · · · · · · · · · · · · ·	725.2	Surface	621.197.62
Communication 380	650	Telephone	621.386.5
Communication between stations		Conductors (electric) 621.319.5	
	6.254	Insulated	621.319.33
Communication, Long-distance		Uninsulated	621.319.32
	6.254	Conduits, Compressed air	621.532
	536.2	for water	628.14
	5.231	Underground transmission	621.319.23
	620.2	Conservation of energy	531.6
Compensators 621.3		Continuous current	
*	6.233	boosters	621.313.28
of railways and steamship lines		compensators or balancers	621.313.27
_	134.4	convertors	621.313.25
	134.4	dynamotors	621.313.26
Compressed air, Applications of 6		generators	621.313.23
Applications of, in railway ser-	.JI.UT	machinery	621.313.2
	1.544	motors	621.313.24
	1.532	transmission systems	521.319.122
		Contractors, Liabilities of	692.9
	T.O IN	Contracts (building)	692.4
	1.545	Engineering	62(003)
	1.532	Prison	331.5
		Control devices (electric)	621.317.4
		Convergent axles (cars)	625.215
		Convertor substations	621.312.64
transmission and distribution of 6			0.21.31.04
Compressibility of gases	21.53 C 633.2	Convertors, Continuous cur-	601 212 05
		rent	621.313.25
TD1	621.5	Alternating current	621.313.5
C	1.534	Frequency Motor	621.313.67
Compressors, Alf	21.51	MOIOL	621.313.57

	G 5
Convertors.—Continued.	Cutting of gears 621.834
Phase 621.313.68 621.313.54	Cutting machinery (metal) 621.932
Synchronous 621.313.53	Cylinders, Locomotive 621.134.1
Conveying machinery 621.86	
Conveyors, Ash 621.183.78	_
Fuel 621.183.78	D
Cooling towers 621.197.64	Daltonism 656.251
Copper, Alloys of 669.33	
Smelting of 669.36	Damage in transportation 656.24
Economic factors concerning 669.31	Dams 621.29 627.8
Leaching of 669.38	Dangerous freight, Transporta-
Matte smelting of 669.35	tion of 656,227
Metallurgy of 669.3	Dangers (mining) 622.81
Plants for the production of 669.39	Decoration 740
	Architectural 729
Properties of 669.32	Decorative illumination by elec-
Refining of 669.37	tricity 621,321,4
Roasting of 669.34	Delays in transportation 656.24
Corridor cars 625.232	Deodorization of solids and
Corrosion of boilers 621.196.5	liquids 628.32
Cost-keeping in manufacturing 621.706	•
Cost of building construction 692.5	
of transportation 656.232	Derricks 621.872
Costs in engineering 62 (002)	Descriptive geometry 515
Cotters 621.883	Design 740
Country roads 625.7	Architectural 729
Counter balancing of locomo-	of automobiles 656.324
tives 621.135.2	of cams 621.838
Couplers and buffers 625.216	of engine parts 621.11
Coupling arrangements for ten-	of gears 621.833
ders 621.136.2	of machine parts 621.8
Couplings (mech. tech.) 621,825	of refrigerating systems 621.566
Covering for steam piping 621.185.6	of riveted joints 621,884
Crane bridges 624.34	of sewers 628,24
Cranes 621.87	of steam turbines 621.165.3
Hydraulic 621.263	of tenders 621.136.1
Locomotive 621.875	Designs, Engineering 62(004)
Revolving 621.873	Detail drawings 692.2
	Dial switches (electric) 621.317.33
	Dictionaries, Engineering 620.3
Cranked axles (locomotives) 621.134.1	
Crookes tubes 621.327.7	
Crossarms for overhead lines 621.319.224	Dies, jigs, etc. 621.756
Crossings (railway) 625.152	Differential rates 656.231
Cross-ties for track 625.142	Dikes 627.4
Crushing (mining) 622.73	Dining cars 625.232
Coal 622.782	Direct current machinery 621.313.2
Cupola practice 621.745	Direct current trans. sys. 621.319.122
Curves (railway) 625.113	Direct expansion refrigeration 621.565.2

Disinfection of solids and liquids 628.32 Disposal of sewage 628.3	Drifting, Tunnelling (mining) 622.26 Drill holes, Breaking from,
Disposal of solids and liquid	without explosives 622.236
wastes 628.54	Drilling (mining) 622.235
Distilleries, Architecture of 725.42	Drilling machinery 621.952
Distribution of compressed air	Drills 621.95
(See Compressed air) 621.53	Pneumatic 621.542
Distribution and use of freight	Driving mechanism of locomo-
cars 656.223.2	tives . 621.134.1
Dock buildings 725.34	Drop forging 621.734
Docks 627.3	Drop forging processes 621.733
Domes, Locomotive 621.133.6	
Boiler 621.184.52	Drums, Boiler 621.184.52 Hoisting 622.673
Doors (architecture) 721.8	
	Dry sand molding 621.743 Ducts, Foul air 697.95
Double current generators 621.313.56	
Draft appliances (boiler fur-	Fresh air 697.94
naces) 621.183.8	Dumping cars 625.242
Draft gears (rolling stock) 625.216 Drafting rooms 621.71	Dust, Prevention of 628.511
	Dyeing (chemical technology) 667
Arrangement of 621.712	Dynamical electricity 537.5
Equipment of 621.713	Dynamics 531.3
Materials and supplies for 621.714	Dynamoelectric machinery 621.313
Drainage, House 628.6	Manufacturing processes for 621.318
of land 627.5	Tests of 621.313(007)
of mines (see Mines, Drainage	Dynamometer cars 625.245 656.221.7
of) 622.5	Dynamometers 531.21 531.4 621.197.7
of railway road bed 625.123	Dynamos 537.38 621.313
of sewage farms 628.367	General details of 621.313(0051)
Drains for steam piping 621.185.5	Operation of 621.313 (0064)
Draw-bridges 624.81	Tests of 621.313 (007)
Locking of 656.258	Dynamotors 621.313.26
Drawing 740	
Freehand 741	F
Mathematical 744	E
Mathematical 744 Methods and processes of 621.753	Earth closet systems 628,43
Mathematical 744 Methods and processes of 621.753 Perspective 742	<del></del>
Mathematical 744 Methods and processes of 621.753 Perspective 742 Drawings (building) 692.1	Earth closet systems 628.43
Mathematical 744 Methods and processes of 621.753 Perspective 742 Drawings (building) 692.1 Classification and storage of 621.717	Earth closet systems 628.43 Earthwork, Computation of 625.114
Mathematical 744 Methods and processes of 621.753 Perspective 742 Drawings (building) 692.1 Classification and storage of 621.717 Engineering 62 (004)	Earth closet systems 628.43 Earthwork, Computation of 625.114 Earthy economic materials 553.6
Mathematical 744  Methods and processes of 621.753  Perspective 742  Drawings (building) 692.1  Classification and storage of 621.717  Engineering 62 (004)  Dray and cab service 656.26	Earth closet systems 628.43 Earthwork, Computation of 625.114 Earthy economic materials 553.6 Ecclesiastical buildings 726
Mathematical 744 Methods and processes of 621.753 Perspective 742 Drawings (building) 692.1 Classification and storage of 621.717 Engineering 62 (004) Dray and cab service 656.26 Dredge engines 621.167	Earth closet systems 628.43 Earthwork, Computation of 625.114 Earthy economic materials 553.6 Ecclesiastical buildings 726 Economic aspects of canals and highways 386 Economic geology 553
Mathematical 744 Methods and processes of 621.753 Perspective 742 Drawings (building) 692.1 Classification and storage of 621.717 Engineering 62(004) Dray and cab service 656.26 Dredge engines 621.167 Dredges 621.866	Earth closet systems 628.43 Earthwork, Computation of 625.114 Earthy economic materials 553.6 Ecclesiastical buildings 726 Economic aspects of canals and highways 386 Economic geology 553 Economizers, Fuel 621.197.2
Mathematical 744 Methods and processes of 621.753 Perspective 749 Drawings (building) 692.1 Classification and storage of 621.717 Engineering 62(004) Dray and cab service 656.26 Dredge engines 621.866 Mining 622.216	Earth closet systems 628.43 Earthwork, Computation of 625.114 Earthy economic materials 553.6 Ecclesiastical buildings 726 Economic aspects of canals and highways 386 Economic geology 553
Mathematical 744 Methods and processes of 621.753 Perspective 742 Drawings (building) 692.1 Classification and storage of 621.717 Engineering 62(004) Dray and cab service 656.26 Dredge engines 621.866 Mining 622.216 Dredging 627.7	Earth closet systems 628.43 Earthwork, Computation of 625.114 Earthy economic materials 553.6 Ecclesiastical buildings 726 Economic aspects of canals and highways 386 Economic geology 553 Economizers, Fuel 621.197.2
Mathematical 744 Methods and processes of 621.753 Perspective 742 Drawings (building) 692.1 Classification and storage of 621.717 Engineering 62(004) Dray and cab service 656.26 Dredge engines 621.167 Dredges 621.866 Mining 622.216	Earth closet systems 628.43 Earthwork, Computation of 625.114 Earthy economic materials 553.6 Ecclesiastical buildings 726 Economic aspects of canals and highways 386 Economic geology 553 Economizers, Fuel 621.197.2 Economy, of boilers 621.184.13

Education	370	systems according to delivery	
Engineering	620.7	of power 62	1.331.5
Educational and scientific but	ild-	overhead trolley 621	.331.53
ings	727	third rail 621	.331.56
Effluvia, Combustion of, in fu	ır-	underground trolley 621	.331.54
naces	628.524	systems according to service 62	1.331.3
Condensation of, in water	628.523		,331.33
Effluvium nuisances	628.52	trunk 621	.331.32
Egg-shaped sewers	628,224	Third rail for 62	1.332.3
Elastic limit	620.112.3	Track for	621.333
Elasticity ,	539.3	Trackless 621	.332.25
Electric		Trolley lines for 62	1.332.2
block signals	656.256.3	Underground conductor for 62	1.332.5
cars	621.334.3		1.334.5
energy, Transmission of	621.319	Electrical engineering	621.3
lighting 53	37,83, 621.3		1.3137
locomotives	, 621.334.2	Weak current	621.38
methods of measuring ter	n-	Electrical instruments & meters	621.37
peratures	536.53	measurements 621.37	, 537.7
railways (interurban)	621.331.33	Electrically controlled manual	
power plants	621.312	block signals 65	6.256.2
Combined	621.312.5	Electricity (physics)	537
for lighting	621.312.2	Application of 621.39,	537.8
for power transmission	621.312.4	applied to medicine	537.87
for railways	621.312.3	Atmospheric	537.4
roads, Resistance on	656,221.4	Dynamical	537.5
signs	621.321.44	Generation of	621.31
slot	656,258	Heating by	697.7
testing	621.37	Miscellaneous applications of	621.39
Electric traction	621.33	Nature of	537.1
Accessories for	621.332.7	Statical	537.2
Bonding for	621.333.4	Theory of	537.1
· Catenary suspension for	621.332.23	Transmission of	621.319
Control system for	621.334.4	Electrodes for voltaic cells 62	21.352.2
Feeders for	621.332.17	Electrodynamics	537.6
Leakage & electrolysis in	621.333,167	Electrolysis 62	21.352.4
Locomotives for	621.334.2		333.167
Motor cars for	621,334.3	Electrolytic rectifiers 621	.313.74
Rails for	621.333.2	Electrolytes for voltaic cells 62	21.352.4
Rolling stock for	621.334	Electro-metallurgy	537.85
Running gear for	621.334.7	Electrometers 62	1.374.3
Street railways	621.331,342	Electroplating for protection	691.794
systems	621.331.2	Electro-pneumatic interlocking	
systems according to curren	t 621,331.4		656.257
alternating	621,331,43		621.315
direct	621.331.42	Electro-therapeutics	537.87

Elements, Chemical	661.1	Statistics of	62 (001)
Elevated railways	625.4	. Steam	621.1
Electric	621.331.343	Steam marine	621.12
Elevators	621.87	societies	620,6
Grain	725,36	Study and teaching of	620.7
Hydraulic	621,263	tables and calculations	620.8
Embankments (levees, etc.)	627.4	Telegraph and telephone	621.38
Emery	553,65	works	621.7
Emery wheels	621.923	Engines, Automatic shaft go	
Employees (shops and manu	1-	ernor	621.164.3
factories)	621,705	Alcohol	621.434,24
Accidents to railway	656.285	Binary vapor	621.44
Enamel	666.2	Blast furnace blowing	621.61
Enameling iron and steel	669.185.7	Blowing	621.6
Energy, Conservation of	531.6	Compressed air	621.42
Engine, of locomotives	621,134	Dredge	621.167
parts, Design of	621.11	Fire	621.68
shafts	621.824	Funicular	621.262
Engineering	620	Gas (see Gas engines)	621.43
Bridge	624	Gasoline	621.434.21
Canal	626	Hauling	621.167
compends	620.2	Heat	621.4
contracts and specifications		Hoisting	621.167
costs	62(002)	Hoisting (mining)	622.672
dictionaries, etc.	620.3	Hot air	621.41
drawings and designs	62 (004)	Hydraulic	621.2
education	620.7	Kerosene	621.434.22
Electrical	621.3	Locomotive	621.134
Heavy current	621.3137	Marine	621.134
Weak current	621.38	Portable	621.15
essays	620.4	Pumping	621.13
handbooks	620.2	Releasing gear (Corliss, etc	
History of	620.9	Resistance of (locomotive)	
Hydraulic	621.2	Rotary	621.166
instruments	620.7	Single acting	621.164.5
materials	620.1	Solar	
Mechanical	621	Special types of	621.47
Military	623	Stationary	621.167
Mining	622	Throttling	621.16
Naval	623	Traction	621.164.2
periodicals	620,5		621.14
quantities and costs		Types of engines	621.112
Railroad and road	62 (002) 625	vapor, Binary	621.44
reports	62 (009)	Water pressure Wind	621,25
River, harbor, hydraulic	627		621.45
Sanitary	628	Engraving	760
Camear y	628	Equalizing levers, Locomotive	621,135.3

D 1		7314	
Equipment of drafting room		Filters, Feed water	621.197.2
of forge shop	621.732	Filtration of sewage	628.35
of foundry	621.742	Fire box of locomotives	621.133.2
of machine shop	621.752	Fire clays	553.61
Erecting (machinery)	621.755	Fire engines	621.68
Essays, Engineering	620.4	Fireplaces, Heating by	697.1
Estimates (building construct		Fire-proofing (building cons	struc-
Estimates (shops and manufa		tion)	693.8
tories)	621.706	of columns	693.85
Excavation (mining)	622.21	of floors	693.83
Exhaust pipe, Locomotive	621.133.5	of girders	693.86
Exhaust steam, Heating by	697.53	of partitions	693.82
Exhausters	621.62	of roofs	693.84
Exploitation of mines	622.3	of trusses	693.87
Exploration (mining)	622.1	of vaults	693.88
Explosions in mines (see Min	ies) 622.81	of walls	693.82
Explosives (chemical tech.)	662	Systems of	693.81
for mining	622.237	Fire tube boilers	621.184.25
Exposition buildings	624.94		
Exterior illumination by elec	:-	Flaming arc lighting	621.325.6
tricity	621.321.3	Flanging machinery	621.984
Extraction (mining)	622.6	Flash generators	621.184.27
		Flat cars	625,241
		T1	001 104 70
Ŧ		Floaters (boiler)	621.184.72
F		Flood gates	621.29
Factories, Sanitation of	628.51	Flood gates Floor tiles	621.29 691.471
-		Flood gates	621.29 691.471 cture) 721.6
Factories, Sanitation of		Flood gates Floor tiles	621.29 691.471
Factories, Sanitation of Carriage and car (architectu	ıre) 725.45	Floor tiles Floors and flooring (architec	621.29 691.471 cture) 721.6
Factories, Sanitation of Carriage and car (architecture) Textile (architecture) Fan blowers and exhausters Fans (ventilation)	re) 725.45 725.41	Floor tiles Floors and flooring (architector of bridges	621.29 691.471 cture) 721.6 624.2
Factories, Sanitation of Carriage and car (architecture) Textile (architecture) Fan blowers and exhausters	725.45 725.41 621.62	Flood gates Floor tiles Floors and flooring (architector of bridges Floors, Fireproofing of	621.29 691.471 cture) 721.6 624.2 693.83
Factories, Sanitation of Carriage and car (architecture) Textile (architecture) Fan blowers and exhausters Fans (ventilation)	725.45 725.41 621.62 697.98	Flood gates Floor tiles Floors and flooring (architector of bridges Floors, Fireproofing of Flow of air in pipes	621.29 691.471 cture) 721.6 624.2 693.83 621.534
Factories, Sanitation of Carriage and car (architecture) Fan blowers and exhausters Fans (ventilation) Fastenings (machine design) Fatigue of metals Faults (mining)	725.45 725.41 621.62 697.98 621.88	Flood gates Floor tiles Floors and flooring (architector of bridges Floors, Fireproofing of Flow of air in pipes of fluids	621.29 691.471 cture) 721.6 624.2 693.83 621.534 536.74
Factories, Sanitation of Carriage and car (architecture) Fan blowers and exhausters Fans (ventilation) Fastenings (machine design) Fatigue of metals	725.45 725.41 621.62 697.98 621.88 620.112.3	Flood gates Floor tiles Floors and flooring (architector of bridges Floors, Fireproofing of Flow of air in pipes of fluids of liquids	621.29 691.471 cture) 721.6 624.2 693.83 621.534 536.74 532.5
Factories, Sanitation of Carriage and car (architecture) Fan blowers and exhausters Fans (ventilation) Fastenings (machine design) Fatigue of metals Faults (mining)	725.45 725.41 621.62 697.98 621.88 620.112.3 622.16	Flood gates Floor tiles Floors and flooring (architector of bridges Floors, Fireproofing of Flow of air in pipes of fluids of liquids of rivers	621.29 691.471 cture) 721.6 624.2 693.83 621.534 536.74 532.5
Factories, Sanitation of Carriage and car (architecture) Fan blowers and exhausters Fans (ventilation) Fastenings (machine design) Fatigue of metals Faults (mining) Feed water, appliances	725.45 725.41 621.62 697.98 621.88 620.112.3 622.16 621.197.2	Flood gates Floor tiles Floors and flooring (architector of bridges Floors, Fireproofing of Flow of air in pipes of fluids of liquids of rivers of steam	621.29 691.471 cture) 721.6 624.2 693.83 621.534 536.74 532.5 532.5
Factories, Sanitation of Carriage and car (architecture) Fan blowers and exhausters Fans (ventilation) Fastenings (machine design) Fatigue of metals Faults (mining) Feed water, appliances Boiler	725.45 725.41 621.62 697.98 621.88 620.112.3 622.16 621.197.2 621.184.13	Flood gates Floor tiles Floors and flooring (architector of bridges Floors, Fireproofing of Flow of air in pipes of fluids of liquids of rivers of steam of water in pipes	621.29 691.471 cture) 721.6 624.2 693.83 621.534 536.74 532.5 621.185.1 532.5
Factories, Sanitation of Carriage and car (architecture) Fan blowers and exhausters Fans (ventilation) Fastenings (machine design) Fatigue of metals Faults (mining) Feed water, appliances Boiler filters, etc.	725.45 725.41 621.62 697.98 621.88 620.112.3 622.16 621.197.2 621.184.13 621.197.2	Flood gates Floor tiles Floors and flooring (architector of bridges Floors, Fireproofing of Flow of air in pipes of fluids of liquids of rivers of steam of water in pipes Flue gases and dusts	621.29 691.471 cture) 721.6 624.2 693.83 621.534 536.74 532.5 532.5 621.185.1 532.5 669.85
Factories, Sanitation of Carriage and car (architecture) Fan blowers and exhausters Fans (ventilation) Fastenings (machine design) Fatigue of metals Faults (mining) Feed water, appliances Boiler filters, etc. heaters purifiers Treatment of	725.45 725.41 621.62 697.98 621.88 620.112.3 622.16 621.197.2 621.184.13 621.197.2 621.197.2	Flood gates Floor tiles Floors and flooring (architect of bridges Floors, Fireproofing of Flow of air in pipes of fluids of liquids of rivers of steam of water in pipes Flue gases and dusts Flues (sewer ventilation) Boiler Fluids, Flow of	621.29 691.471 cture) 721.6 624.2 693.83 621.534 536.74 532.5 621.185.1 532.5 629.85 628.233 621.184.57
Factories, Sanitation of Carriage and car (architecture) Fan blowers and exhausters Fans (ventilation) Fastenings (machine design) Fatigue of metals Faults (mining) Feed water, appliances Boiler filters, etc. heaters purifiers	725.45 725.41 621.62 697.98 621.88 620.112.3 622.16 621.197.2 621.184.13 621.197.2 621.197.2	Flood gates Floor tiles Floors and flooring (architect of bridges Floors, Fireproofing of Flow of air in pipes of fluids of liquids of rivers of steam of water in pipes Flue gases and dusts Flues (sewer ventilation) Boiler	621.29 691.471 cture) 721.6 624.2 693.83 621.534 536.74 532.5 621.185.1 532.5 629.85 628.233 621.184.57
Factories, Sanitation of Carriage and car (architecture) Fan blowers and exhausters Fans (ventilation) Fastenings (machine design) Fatigue of metals Faults (mining) Feed water, appliances Boiler filters, etc. heaters purifiers Treatment of	725.45 725.41 621.62 697.98 621.88 620.112.3 622.16 621.107.2 621.184.13 621.197.2 621.197.2 621.194.3	Flood gates Floor tiles Floors and flooring (architect of bridges Floors, Fireproofing of Flow of air in pipes of fluids of liquids of rivers of steam of water in pipes Flue gases and dusts Flues (sewer ventilation) Boiler Fluids, Flow of	621.29 691.471 cture) 721.6 624.2 693.83 621.534 536.74 532.5 621.185.1 532.5 629.85 628.233 621.184.57
Factories, Sanitation of Carriage and car (architecture) Fan blowers and exhausters Fans (ventilation) Fastenings (machine design) Fatigue of metals Faults (mining) Feed water, appliances Boiler filters, etc. heaters purifiers Treatment of Feeders (electric traction)	725.45 725.41 621.62 697.98 621.88 620.112.3 622.16 621.197.2 621.197.2 621.197.2 621.194.3 621.332.17	Flood gates Floor tiles Floors and flooring (architect of bridges Floors, Fireproofing of Flow of air in pipes of fluids of liquids of rivers of steam of water in pipes Flue gases and dusts Flues (sewer ventilation) Boiler Fluids, Flow of Flushing shafts and fixtures	621.29 691.471 cture) 721.6 624.2 693.83 621.534 536.74 532.5 621.185.1 532.5 629.85 628.233 621.184.57 536.74
Factories, Sanitation of Carriage and car (architecture) Fan blowers and exhausters Fans (ventilation) Fastenings (machine design) Fatigue of metals Faults (mining) Feed water, appliances Boiler filters, etc. heaters purifiers Treatment of Feeders (electric traction) Felt roofing	621.197.2 621.197.2 621.197.2 621.197.2 621.197.2 621.197.2 621.197.2 621.197.2 621.332.17 695.7 625.162	Flood gates Floor tiles Floors and flooring (architect of bridges Floors, Fireproofing of Flow of air in pipes of fluids of liquids of rivers of steam of water in pipes Flue gases and dusts Flues (sewer ventilation) Boiler Fluids, Flow of Flushing shafts and fixtures (sewers)	621.29 691.471 cture) 721.6 624.2 693.83 621.534 536.74 532.5 621.185.1 532.5 629.85 628.233 621.184.57 536.74
Factories, Sanitation of Carriage and car (architecture) Fan blowers and exhausters Fans (ventilation) Fastenings (machine design) Fatigue of metals Faults (mining) Feed water, appliances Boiler filters, etc. heaters purifiers Treatment of Feeders (electric traction) Felt roofing Fences (railway or road)	621.197.2 621.197.2 621.197.2 621.197.2 621.197.2 621.197.2 621.197.2 621.197.2 621.332.17 695.7 625.162	Flood gates Floor tiles Floors and flooring (architect of bridges Floors, Fireproofing of Flow of air in pipes of fluids of liquids of rivers of steam of water in pipes Flue gases and dusts Flues (sewer ventilation) Boiler Fluids, Flow of Flushing shafts and fixtures (sewers) Force and its measure	621.29 691.471 cture) 721.6 624.2 693.83 621.534 536.74 532.5 621.185.1 532.5 629.85 628.233 621.184.57 536.74
Factories, Sanitation of Carriage and car (architecture) Fan blowers and exhausters Fans (ventilation) Fastenings (machine design) Fatigue of metals Faults (mining) Feed water, appliances Boiler filters, etc. heaters purifiers Treatment of Feeders (electric traction) Felt roofing Fences (railway or road) Fertilizers made from town wa	11re) 725.45 725.41 621.62 697.98 621.88 620.112.3 622.16 621.197.2 621.197.2 621.197.2 621.194.3 621.332.17 695.7 625.162 estes 628.49	Flood gates Floor tiles Floors and flooring (architect of bridges Floors, Fireproofing of Flow of air in pipes of fluids of liquids of rivers of steam of water in pipes Flue gases and dusts Flues (sewer ventilation) Boiler Fluids, Flow of Flushing shafts and fixtures (sewers) Force and its measure Forced draught	621.29 691.471 cture) 721.6 624.2 693.83 621.534 536.74 532.5 621.185.1 532.5 629.85 628.233 621.184.57 536.74
Factories, Sanitation of Carriage and car (architecture) Fan blowers and exhausters Fans (ventilation) Fastenings (machine design) Fatigue of metals Faults (mining) Feed water, appliances Boiler filters, etc. heaters purifiers Treatment of Feeders (electric traction) Felt roofing Fences (railway or road) Fertilizers made from town was Filing machines	11re) 725.45 725.41 621.62 697.98 621.88 620.112.3 622.16 621.197.2 621.197.2 621.197.2 621.194.3 621.332.17 695.7 625.162 4stes 628.49 621.92	Flood gates Floor tiles Floors and flooring (architect of bridges Floors, Fireproofing of Flow of air in pipes of fluids of liquids of rivers of steam of water in pipes Flue gases and dusts Flues (sewer ventilation) Boiler Fluids, Flow of Flushing shafts and fixtures (sewers) Force and its measure Forced draught Force, Tractive, of locomo-	621.29 691.471 cture) 721.6 624.2 693.83 621.534 536.74 532.5 621.185.1 532.5 669.85 628.233 621.184.57 536.74 628.254 531.21 621.183.85

Forge shop	621.73	clutches	621.825
Arrangement of	621.731	of gears	621.832
Equipment of	621,732	of steam in pipes	621.185.1
Materials, and supplies for	621.738	Theory of	531.4
Forging, Drop	621.734	Fuel, consumption	621,182,3
Iron and steel	669.184.1	of locomotives	621.133.1
machines, Hydraulic	621.266	conveyors	621.183.78
processes	621,733	economizers	621.197.2
Forms and centers for reinfor	rced	for locomotives	621.133.1
concrete	693.72	gas, Heating by	697.62
Foul air ducts (ventilation)	697.95	Fuels, Comparative consump-	-
Foundations (architecture)	721.1	tion of	621,182.4
Boiler	621.184.57	for boiler heating	621.182.2
Founding of iron and steel	669.17	Fumes, Prevention of	628.511
Foundries (architecture)	725,43	Funicular engines	621,262
Foundry	621.74	Furnace appliances (boiler)	621.183.7
Arrangement of	621,741	fittings	621.183.5
Cupola practice	621.745	grates	621.183.52
Equipment of	621.742	Furnaces (boiler)	621.183
irons, Chemistry of	621.745	Blast roasting	669,831,7
Materials and supplies for	621,748	Distillation	669.834
Four-cycle gas engines	621,432.1	Hot air	697.3
Frame plates, Locomotive	621,135.1	Liquation	669,833
Frames, Car	625.211	Melting	669.837
Hoisting	622,675	Metallurgical	669.83
Locomotive	621.135.1	parts, Construction and de	
Freehand drawing	741	of	621.183.5
Freezing of mains	628.15	Smelting	669,832
Freight-and terminal stations	s 656.212	Sublimation	669,835
Freight cars	625,24	Types of	621.183.2
Details of construction of	625.246	<i>2</i> 1	
Use and distribution of	656.223,2	G	
Weight and capacity of	625,24	G	
Freight, Classification of	656.235	Gage cocks (locomotive)	621.133.9
dangerous and perishable,		glasses (boiler)	621.184.72
Transportation of	656.227	Gages, Compressed air	621.532
rates	656,235	Boiler water	621.184.72
service	656.225	Steam	621.197.7
stations (railway)	725.32	Steam pressure	621.184.73
trains, Resistance of	656.221.1	Galvanizing (protection of	
Frequency changers	621,313,55	iron) 691.79	3, 669.185.4
convertors	621.313.67	Galvanometers 537.80	6, 621.374.4
indicators or meters	621.374.7	Garages	725.38
Fresh air ducts (ventilation	697.94	Garbage	628.44
F 1 4	1.4, 621.89	Gas and steam fitting	696
brakes	531.4	Gas engine power plants	621.434.1

Gas engines	621.43	Design of	621.833
Applications of	621,438	Draft	625.216
to air ships	621.438.7	Efficiency of	621.832
to automobiles	621.438.4	Friction of	621.832
to farm machinery	621.438.3	Spur	621.833.1
to marine service	621.438.6	Tests of	621.832
to motor boats	621.438.5	Valve	621,84
Four-cycle	621.432.1	Worm and spiral	621.833.3
Parts and accessories of	621.437	Generation of electricity	621.31
Theory of	621.431	of steam	621.18
Two-cycle	621.432.2	Generators, Alternating cur	-
using blast furnace gas	621.434.13	rent	621.313.43
using acetylene	621.434.15	Continuous current	621.313.23
using alcohol	621.434.24	Double current	621.313.56
using gasoline	621.434.21	Flash	621.184.27
using illuminating gas	621,434.12	Induction	621.313.63
using kerosene	621,434.22	Geology	550
using natural gas	621.434.11	Applied (mining)	622.11
using producer gas	621.434.14	Economic	553
using solid fuels	621,434,3	Geometry	513
Gas, Heating by	697.6	Analytical	516
illuminating	665.7	Descriptive	515
Natural	553.28	Girders, Fireproofing of	693.86
producers	621.434.14	for bridges, Trussed	624.08
turbines	621,433	Lattice (metal)	624.3
Gases	533	Glass	666.1
(chem. tech.)	665	Glass (building material)	691.6
Flue	669,85	Glazing	698
Kinetic theory of	533.7	Gold, Metallurgy of	669.2
Laws of compressibility of	533.2	Alloys of	669.213
Physical theory of	533	Chlorination of	669.218
Properties of	533.1	Economic factors concern	ing 669.211
Sampling of	669.913	Properties of	669.212
Thermodynamics of	536.71	Plants for the prod. of	669.219
Gasoline engines	621.434.21	Governmental buildings	725.1
Gates, Architecture of	720,8	Grades and curves (railway	s) 625.113
Flood	621.29	Grain elevators	725.36
Gearing, Belt	621.852	Granite (building material)	691.221
Chain	621.835	Granites (geology)	553.52
Friction	621.858	Graphic statics	531.2
Machinery and mill	621.85	Graphitic anthracite coals	553.25
Ratchet	621.837	Grates, Furnace	621.183.52
Gears	621.83	Locomotive	621.133.2
Bevel and skew bevel	621.833.2	Gravel roofing	695.7
Construction of	621.834	Gravity	531.5
Cutting and casting of	621,834	Green sand molding	621.743

Grilles, Architecture of	720.8	Hennebique system (reinforc	
Grinding machinery	621.92		693.714
Grinding machines (cylinde	r and	Highways	625.7
surface)	621.922	from economic aspect	386
Guide vanes (steam turbines	s) 621,165.13	History of engineering	620.9
Guys for overhead lines	621,319,223	Hoisting engines	621.167
		in mines (see Mines)	622.6
		machinery	621.86
H		Hoists .	621.862
		Hydraulic	621,263
Hair for building	691.92	Hollow concrete blocks	693.53
Hammers, Power	621.97	Hollow tile for building co	
Pneumatic	621.542	struction	693.4
Hand books, Engineering	620.2	*	621.313.291
Hand signals	656,252	Hopper cars	625.242
Hanging of boilers	621.184.56	Horseless vehicles, Transport	ta-
Harbor engineering	627	tion by	656.3
Harbors	627.2	Horsepower of locomotives	
Shipping facilities of	627.3	Hospitals	725.5
Hardness of materials	620.112.6	Hot air engines	621.41
Haulage in mines (see Min-	es) 622.6	Furnaces	697.3
Hauling engines	621.167	Hotels (railway service)	656.26
Head and tail races	621.29	Hot water heating	697.4
Heat	536	High pressure .	697.41
Applications of	536.8	Low pressure	697.42
combustion	536.46	Low pressure with steam	
Communication of	536.2	mains	697.43
Effects of	536.4	House drainage	628.6
engines	621.41	House drains (ventilation)	628,235
motors, Thermodynamics	of 536.73	House wiring	621.328.2
Reflection, refraction, radi	ation,	Hydraulic cranes	621.263
and absorption of	536.3	devices used in steel works	621.264
tables, problems, and ques	stions 536.9	elevators	621.263
Theory and nature of	536.1	engineering	627
Heaters, Feed water	621.197.2	engines and motors	621.2
Heating and ventilation	628.8, 697	forging	621,733
by fireplaces	697.1	machines	621.266
by gas (acetylene, fuel, na	tural,	hoists	621.263
illuminating)	697.6	lime	691.52
by hot air furnaces	697.3	machinery and appliances	621.26
by hot water	697.4	for steel works	621.264
by steam	697.5	mining appliances	621.269
by stoves	697.2	presses	621.266
of cars	625.234	pumps	621.252
of railway stations	656.215	injection	621.267
Hemp rope transmission	621.853	rams	621.27

Hydraulic, rams.—Continued.		Inlets for sewers 628.255
compressing	621.274	Inspection of boilers 621,184.55
lifting	621,272	of reinforced concrete 693.73
pumping	621.273	Instruments, Engineering 620.7
stamping machines	621.266	for boiler tests 621.197.7
tackle	621,262	for engine tests 621.197.7
tunneling devices	621,269	Insulating materials 621,319,37
Hydraulics (general theory)	532	Insulators 621.328.5, 621.319.4
Hydrostatics	532	Pins for 621.319.224
1		Insurance, Compulsory 331.2
I		Intercepting sewers 628.27
Ice machines	621.5	Interior illumination by elec-
making	621.58	tricity 621.321.2
Can system of	621.581	Interior wiring 621,328,2
Plate system of	621.582	Interlocking devices,
Illuminating gas	665.7	Electro-pneumatic 656.257
Illumination by electricity	621.321	Interlocking switch and signal
Decorative	621.321.4	apparatus 656.257
Exterior	621.321.3	International agreements relative
Interior	621.321.2	to railways 385.6
Impact tests	620.112.5	Interstate commerce commission 385.7
Impurities in water	628.16	Interurban electric railways 621,331,33
Incandescent lamps	621.326	Iron, Alloys of 669.13
Carbon filament	621.326.3	Analyses and tests of 669.121
Metal filament	621.326.4	Bessemer process for refining
Metallized filament	621.326.31	of 669.153
Osmium filament	621.326.44	Acid 669.153.1
Platinum filament	621.326.41	Basic 669.153.2
Tantalum filament	621.326.42	Chemical properties of 669.124
Tungsten filament	621.326.43	Economic factors concerning 669.11
Vapor lighting	621.327	Electric furnaces for refining
Incandescent lighting	621.326	of 669.154
Inclined railways	625.3	Extraction of 669.14
Incrustation of boilers	621.194.4	Blast furnace process for 669.142
Indicators, Frequency	621.374.7	Direct process for 669.141
Steam engine	621.197.7	Electric furnace process for 669.143
Indirect blocking systems	656.258	Forging, etc. of 669.184.1
Induction, apparatus, Station-	on.	Founding of 669.17
ary	621.314	Galvanizing of 669.185.4
coils	621.314.7	in building construction 691.7
generators	621.313.63	mains and service pipes 628.15
motors	621.313.64	Manufacture of 669.14
Industrial sanitation	628.5	Melting of 669.171
Injection pumps, Hydraulic	621.267	Metallurgy of 669.1
Injectors (boiler plants)	621,197,3	Mixtures of (foundry) 621.745
Injectors (locomotive)	621.133.7	Moulding of 669.172

Iron.—Continued.		L	
Nature and properties of	669.12	T 1 -/ ' / t' / \	
Open hearth process for refin		· Laboratories (architecture)	727.5
ing of	669,152	Labor and wages	331
Acid	669.152.1	Labor, Cheap foreign	331.6
Basic	669.152.2	Child	331.3
ore	553.3	Convict	331.5
Painting of (protection)	691.791	Hours of	331.81
Physical properties of	669.123	Organization of	331.87
Protection of	691.79	Payment of	621,705
Puddling process for refining	g	Pauper	331.6
of	. 669,151	Places of danger for	331.82
Purification of	669.15	Premium system of paying	
roofing	695.5	Relation of, to capital	331.1
Structure and composition	of 669.12	Skilled	331.7
structures (architecture)	721.9	strikes	331.89
Tests of	620.17	trade unions	331.88
Working, manipulation and		unions	621,705
treatment of 669.	17, 669.18	Unskilled	331.7
Irons, founding, Chemistry of	621.745	Women	331.4
Irrigation by sewage	628.36	Laboring classes	331.8
		Food, clothes, shelter for	331.83
T		Helps, lectures, libraries an	ıd
)		reading rooms for	331.85
Jack knife bridges	624,87	Morals and habits of	331.84
Jet	553,22	Training and apprenticeship	for 331.86
Jet condensers	621.197.63	Lamp posts as ventilators	628.232
Jetties (river engineering)	627.6	Lamps, Arc (See Arc light-	
Jigs, Construction of	621.756	ing)	621.325
Joinery	694	Incandescent (See Incandes	S-
Joints, Screw	696,5	cent lighting)	621.326
Riveted	696.4	Nernst	621.326.53
Rust and caulked	696.6	Land, Drainage of	627.5
Journals	621.821	Land, Reclamation of, from t	ides
Junctions (railway)	625,153	and waves	627.5
		Lapping machines	621.922
		Lathes, Metal turning	621.942
K		Wood turning	621.943
TZ 1		Latrines	628.45
Keene's cement	691.57	Lattice bridges, Metal	624,3
Keys	621.883	Laws, Building	692.9
	621.434.22	Engineering	62(007)
Kinematics, General theory of		of compressibility	533.2
Kinetic theory of gases	533.7	Plumbing	696.9
Kinetics	531.3	Lead accumulators	621,355
Knife switches (electric)	621.317.32	Cadmium lead types	621.355.58

Lead accumulators.—Continued.	L	imestone (building material)	691,211
Care and handling of 621.	355.18 L	imestone (geology)	553.51
Combined Planté Faure		ines, Electric	621.319.2
types 621		iquids	532
Complex Oxid types 621.		iquids, Flow of	532.5
Copper lead types 621.		oam molding	621.743
Faure types 621			
Lead element of 621.	355.55	ocation and survey (railways of manufactories	
Planté types 621	.355.2		621.701
Zinc lead types 621.	355.57	of shafting and machines	621,751
Lead, Alloys of	009.43	ocking of draw-bridges	656.258
Economic factors conc.	669.41 <sup>L</sup>	ocomotive	621.13
Leaching of	569.47	ash pit	621.133.2
Metallurgy of	669.4	axles	621.135.2
Plants for prod. of	669.49	boiler, Attachments to	621.135.1
Properties of	369,42	boilers	621,133
Refining of	669.47	bracing, transverse	621.135.1
Roasting of	569.44	brakes	621.135.5
Smelting of	369.45	boxes	621.135.2
Lead mains and service pipes	528.15	cranes	621.875
Levees (river engineering)	627.4	cylinders	621.134.1
Liabilities of architects	692,9	dome	621.133.6
of contractors	692.9	Engine of the	621.134
of owners	692.9	exhaust pipe	621.133.5
Lien laws (building construc-		firebox	621.133.2
	592.98	frame plates	621.135.1
Liernur system of sewerage 69	28.213	frames	621.135.1
Light	535	fuel consumption	621.133.1
Lights, Search 621	.325.7	fuels	621,133,1
Lighthouses	627.9	gage cocks	621.133.9
Lighting	628.9	grates	621.133.2
Arc 65	21.325	injectors	621.133.7
- Electric	321.32	pistons and rods	621.134.1
Incandescent 65	21,326	pumps	621.133.7
of cars 69	25.233	repair shops	621.138.5
of mines	522.46	running gear	621.135
of railway stations 68	6.215	safety valves	621.133.9
Lightning arrestors 621.3	319.82	shell	621.133.3
rods	537.4	slide valves	621.134.2
Lignite	53,22	smokebox and stack	621.133.4
Lime concrete	91.35	springs, saddles, equalizing lev	·-
Lime for building	691.5	ers	621.135.3
9	591.52	stays	621.133.2
	391.51	tenders (See Tenders)	621.136
Selenitic 6	391.53	Theory of the	621.131
	53,68		621.133.6
Limes (chemical technology)	666.9	trucks	621.135.4

Locomotive.—Continued.		Dredging	627.7
tubes	621.133.3	Drilling	621.952
valves	621.134.2	Flanging and die press	621.984
wheels, boxes, and axles	621.135.2	Hoisting and conveying	621.86
Locomotives, Adhesion of	621.131.1	Metal sawing	621.932
Combustion of fuel in	621.133.1	Nail and rivet	621.97
Compound	621.134.4	of transmission	621.8
Counterbalancing of	621.135.2	Perforating	621.95
Driving mechanism of	621.134.1	Punching and shearing	621.96
Electric	621.334.2	Wood boring	621.953
Horsepower of	621.131.1	Wood planing	621,913
Lubrication of	621.134.5	Wood sawing	621.933
Maintenance and repair of	621.138	Machines, Grinding and filing	621.92
Management of	621.137	Pipe threading	621.944
Mine	622.662	Planing	621.91
Production of steam in	621.133	Refrigerating	621.57
Scale prevention in	621.133.7	Screw	621.99
Steam distribution in	621.134.2	Tapping	621.955
Supplies and materials for	621.139	Theory of	531.8
Suspension of	621,135,3	Machining iron and steel	669.184.5
Tests of	621,131.3	Magnetic surveys	622.15
Tractive force of	621,131.1	Magnetism	538
Types of	621.132	Mains, Compressed air	621.532
Longwall methods (mining)	622.331	Freezing of	628.15
Long distance communication	656.254	Water	628.15
Lubricants	621.89	Maintenance of locomotives	621.138
Lubricants (railway cars)	625.214	Maintenance of way	625,17
Lubrication of locomotives	621.134.5	Malleable cast iron (in build	i-
M		ings)	691.72
		Malleable cast iron, Manufac-	
Macadamizing of roads	625.8	ture of	669.183
Machine molding	621.744	Management of locomotives	621.137
parts, Designs of	621.8	Manganese steel	669.132
shops	621.75		621.184.55
Architecture of	725.43	for sewers	628.253
Arrangement of	621.751	for underground transmis-	
Equipment of	621.752		21.319.234
Supplies and materials fo			621.184.73
Tool making for	621.756	Manual block signals, Electric	<del>-</del>
tools	621.9	ally controlled	656.256.2
Design of	621.901	Manufactories	621.7
Power required for	621.902	Architecture of	725.4
(shop equipment)	621.752.1	Location of	621.701
Machinery and mill gearing	621.85	Organization and administra	l-
Bending	621.982	tion of	621.704
Bolt and nut	621,99	Shipping facilities of	621.701

Manufactures (miscellaneous) 670 Metal filament incandescent	
Manures, Sewage 628.38 lamps 6	21.326.4
Marbles (geology) 553.51 Metalized filament incandes-	
Marine boilers 621.184.22 cent lamps 62	1.326.31
engines 621.12 Metallography	669.89
Markets (buildings) 624.94 Metal mining, Methods of	622.34
Masonry (building construction) 693 planers, shapers, slotters	$621\ 912$
Adhesive tests of 620.15 roofing	695.4
Boiler 621.184.57 sawing and cutting machinery	621.932
Materials, Strength of 539.4 620.1 turning lathes	621.942
Building 691 Metals, and alloys of	669.88
Mathematics 510 Fatigue of 6	20.112.3
Mathematical drawing 744 Sampling of	669.912
Measurements, Electric 621.37 537.7 Meter transformers 62	1.314.38
Measures, Weights and 389 Meters, Electric 621.373, 6	21.328.6
Mechanical concentration (misc.) 622.77 Ampere hour 6	21.374.4
concentration (wet) 622.75 Calibration of	621.372
crushing 622.73 Current 6	21.374.4
engineering 621 Electromotive force 6	21.374.3
naurage (mmmg)	21.374.7
preparation of coal (See Coal) 622.78 General types of	621.371
preparation of mine products 622.7 Phase and power factor 62	1.374.91
screening 622.74 Potential 6	21.374.3
slime treatment 622.76 Power 6	21.374.6
stokers 621.183.6 Recording	621.373
Mechanic trades 680 Resistance, inductance, capac-	
Mechanics 531 ity 6	21.374.2
Applied 620.1 Special	621.374
Tables, problems, questions re- Standards for	621.372
Tatting to	21.317.6
Mechanism of steam engine 621.11 Water	628.17
Mechanism, Principles of 621.81 Watt hour 6	21.374.5
Mediaeval architecture 723 Watt meters 6	21,374.6
Medicine, Application of elec- Middens	628.41
tricity to 537.87 Military engineering	623
Mercury, Metallurgy of 669.7 transportation	656.229
Mercury vapor lamps 621,327.4 Mill dams	621.29
Metallurgical furnaces 669.83 gearing	621.85
Metallurgy 669 sluices	621.29
of copper 669.3 Milling machines	621.91
of gold and silver 669.2 Mills, Architecture of	725.41
of iron 669.1 Rolling and drawing	621.77
of lead 669.4 Wind	621.45
of mercury 669.7 Millwork	621.8
of tin 669.6 Mine, accidents	622.8
of zinc 669.5 First aid in	622.862

	Mines.—Continued.	
622.63	· Hoisting engines in	622.672
622.867	Hoisting in	622.6
622.97	by men and beasts	622.65
622.21	Mechanical	622.67
622.215	Hoisting of water in	622.55
622.868	Lighting of	622.46
622.19	Liquid and gaseous deposits	in 622.38
622.86	Locomotives for ·	622.662
622.14	Models of	622.17
553,63	Offices for	622.91
620.195	Open working of	622.31
665.4	Placer working of	622.32
622.79	Power plants for	622.94
622,18	Shops for	622.93
622,131	Signaling in	622.48
691.91	Siphon for drainage of	622.59
549	Soluble deposits	622,36
622.85	Special waters in, Handling	of 622.57
622.869	Stables for	622.96
622.87	Store houses and yards for	622,92
622,24	Surface plants of	622.9
622.23	Arrangement of	622.99
	Fire protection for	622.98
622.213	*	of 622.53
		622.51
	•	622.35
	-	622.6
		622.64
		622.692
		622.69
		622,693
		622,54
		622.62
622.6	e e e e e e e e e e e e e e e e e e e	622.4
622.95		622,45
622.82	* ' '	622.44
622.823		622,42
622.822		
622.824	· ·	622,43
622.84	•	622,41
622.37		622.3
622.61		
622.58	Coal (methods of)	622.33
622.6	,	622
622.65	faults	622.16
622.66	Metal	622.34
	622.867 622.97 622.21 622.213 622.868 622.14 553.63 620.195 665.4 622.79 622.18 622.86 622.131 691.91 549 622.85 622.80 622.21 622.21 622.21 622.21 622.81 622.82	622.63 Hoisting engines in 622.867 By men and beasts 622.21 Mechanical 622.215 Hoisting of water in 622.868 Lighting of 622.19 Liquid and gaseous deposits 622.86 Locomotives for 622.14 Models of 622.15 Open working of 622.15 Open working of 622.16 Placer working of 622.79 Power plants for 622.18 Shops for 622.18 Shops for 622.18 Signaling in 691.91 Siphon for drainage of 622.85 Special waters in, Handling of 622.86 Stables for 622.87 Store houses and yards for 622.87 Store houses and yards for 622.24 Surface plants of 622.23 Arrangement of 622.24 Fire protection for 622.21 Surface pumps for drainage 622.56 Fire protection in 622.52 Surface pumps for drainage 622.51 Theory of drainage of 622.52 Transportation in 622.52 Surface 622.53 Surface 622.54 Transway (aerial) 622.65 Underground pumps in 622.66 Underground roads in 622.81 Underground roads in 622.82 Ventilation of 622.82 Fans and blowers for 622.82 Fans and blowers for 622.82 Theory of 622.83 Mining, Appliances, Hydraulic 622.64 Mining, Appliances, Hydraulic 622.65 Gal (methods of) 622.66 engineering 622.65 faults

Mining.—Continued.		0	
Placer	622.32		
Practical	622.2	Ocean transportation	387
Mixing machinery (sewerag	e) 628.342	Office equipment methods	651
Mixtures of iron (foundry)	621.745	Ohm meters	651 621,374,2
Modern architecture	724	Oils (chemical technology)	665
Molding machines	621.744	Animal	665.2
processes	621.743	Mineral	665.4
Molecular physics	539	Vegetable	665.3
structure	539.1	Oil switches, Electric	621.317.35
Molybdenum steel	669.135	Open hearth processes	669.152
Moore lamp	621.327.5	Acid	669.152.1
Mortars (chemical technolo	gy) 666.9	Basic	669.152.2
Motor cars (for electric tra-	c-´	Operating systems (transport	ta-
tion)	621.334.3	tion)	656,254
Motor-convertors	621.313.57	Operation of tributary railwa	ays 656.27
Motors, Air	621.541	of railway lines with light	
Animal	621.46	traffic	656.27
Automobile	656.322	of railways	656
Constant speed	621.313.245	of signal systems	656.257
Continuous current	621.313.24	of street railways	625.612
Hydraulic	621.2	of switch signals	656.257
Induction	621.313.64	Optics	535
Repulsion	621.313.66	Ore concentrators	622.75
Series A. C.	621.313.65	deposits	553.1
Synchronous	621,313,44	dressing Ores of iron	622.7
Mountain railways	625.3	of metals other than iron	553.3 553.4
Movable bridges (see Bridges		Sampling of	669.911
Movable)	624.8	Organization of manufactorie	
Muffles	669.831.6	and shops	621.704
Multiplex telegraphy	621,382,35	Oriental architecture	722
		Oscillographs	621.374.7
N		Osmium filament incandescen	
37-11 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1		lamps	621.326.44
Nail and rivet machinery	621.97	Outfall (sewerage)	628.217
Natural, cement	691.54	Outfall sewers	628.27
gas	553.28	Overshot water wheels	621.22
Heating by	697.63	Owners, Liabilities of	692.9
Naval architecture	623.S		
engineering	623	P	
Nernst lamps Nickel steel	621.326.53	De alaineae Char	001.101
Nozzles (steam turbine)	669.131 621.165.13	Packings, Steam	621.185
Not machinery	621.99	Painting Painting iron and steel	698
The machinery	021.99	ranting from and steel	691.791

Panels for interior wiring	621,328.3	Discourse 1	000 100
Panels, Switchboard	621.317.2	Physical properties of iron Physical properties of sewage	669,123
Paper for building	691.93	Physical theory of gases	628.31
Paperhanging	698	Physics Physics	533 530
Paraffin	665.4	Physics, Molecular	539
Parks, Public	725.7	Pickling (iron and steel)	
Parlor cars	625,232	Piece work	669.185.2 621.705
Partitions, Fireproofing of	693.82	Piers (architecture)	721.3
Passenger cars	625.23	(harbor engineering)	627.3
Types of	625.23	for bridges	624.1
Use and distribution of	656.223.1	for suspension bridges	624.54
Weight of	625,23	Pig iron, Manufacture of	669.14
rates	656.234	Piles, Masonry	624.14
	656.211	Metal	
stations, Arrangement of Lighting of	656.215		624.15
Railway	725.31	Wooden, for bridge foundati Pins, Insulator 6	
train service	656.224		21.319.224
train service trains, Resistance of	656.221.2	Pipe coverings	621.185.6
Passes and reduced fares	656.234	fittings, Compressed air threading machines	621.532
	62(008)		621.944
Patents (engineering)	621.724	Piping, Compressed air	621.532
Pattern making	621.72	connections for steam piping	
Pattern shops		Joints in	621.185.7
Arrangement of	621.721	of refrigerating systems	621.566
Equipment of	621.722 621.728	Steam	621.185
Materials and supplies for		water, High pressure	621.253
Patterns, Preservation and sto	621.727	Piston blowers	621.61
age of	628.47	Pistons, Locomotive	621.134.1
Pavements, Sanitation of Stone	625.82	Placer workings	622.32
Wooden	625.83	Planers (for metals)	621.912
	625.8	Planing machines	621.91
Paving of roads and streets stone	625.81	for wood	621.913
Peat	553.21	Plans for buildings	692
Penstocks	621.29	Plastering (building constructi	
for sewers	628.257	Plaster of Paris (building ma	
	621.95	terial)	691.56
Perforating machinery Periodicals, Engineering	620.5	Tests of	620.15
Perishable freight, Transport		Plate system for ice making	201 #20
tion of	a- 656,227	plants	621.582
Perspective drawing	742	Platinum filament incandescent	
Petroleum	553,28		621.326.41
for locomotives	621,133,1	Plenum system of ventilation	697.92
Phase convertors	021,155,1	Plug & feathers (for quarrying	
621.313.68	621,313,54	Plug switches, Electric	622,221
indicators	621.374.91	Plumbing	621.317.34
Photography	770	Plumbing laws	696
Thotographiv	110	ramoing taws	696.9

Pneumatic block signals	656.256.4	Single liquids	621.353.3
Drills	621.542	Principles of mechanism	621.81
Hammers	621.542	Printing	655
Tools	621.542	Prison contracts	331.5
Pneumatics	533	Prisons (architecture)	725.6
Poles for overhead lines	621.319,223	Privies -	628.41
Foundations for	621.319.223	Probabilities, Theory of	519
Political economy	330	Processes, Building	691
Pools, agreements (transp	orta-	Professional and technical	
tion)	656.233	schools	727.4
Porcelain	666.5	Profiles of railways	625.113
Portable boilers	621.184.23	Profit-sharing	331.2
engines	621.15	Projection	515
Portland cement	691.55	Propeller shafts	621.824
Postal service	656,224	Properties of gases and vapors	s 533.1
Potential regulators (see l	Regu-	of iron and steel	669.12
lators)	621.314.5	of metals (magnetic, electric	с,
Power factor indicators	621.374.91	etc.)	669
Power hammers	621.97	of refrigerating fluids	621.564
Power plants	621.312	of stone, concrete, cement,	
Mining	622.94	etc.	620.13
Steam end of	621.19	of solids	539.2
Testing of	621.312(007)	Prospecting	622.12
Power transmission, Comp	ressed	Protection against infection fro	om
air	621.53	dust	628,513
Precipitation of sewage	628.34	of iron and steel	691.79
by lime	628.345	of stone	691.2
by salts of alumina	628.344	of throat and eyes from dus	
by salts of iron	628.346	and fumes	628.512
Precipitation tanks (sewe		of trains in distress	656.254
Premium system of paying		Protective devices, Switchboar	
Preparation of coal	622.78		621.317.8
.Preservation of patterns	621.727	Transmission lines	621.319.8
of stone	691.29	Public buildings (architecture)	
Preservatives (building m	ateri-	Public halls (masonry construc	
als)	691	tion)	624.93
Presses, Hydraulic	621.266	(metal)	624.94
Pressure gages, Air	621.532	Public parks	725.7
Steam	621.184.73	Publishing	655
Pressure regulators (steam	,	Puddling processes (see Iron)	669.151
Pressure steam turbines	621.165.22	Pumping, by compressed air	621.546
Prevention of dust and fu		engines	621.64
Primary cells	621.353	Tests of	621.642
Closed circuit	621,353.6	stations (sewerage)	628.29
Double fluid	621.353.4	vs. gravitation systems (wa	
Open circuit	621.353.5	ter supply)	628.12

Pumps, Centrifugal Circulating, for steam plan	621.67	Road bed (see Road bed) rolling stock (see Rolling	625.1
gramma, rer eream plan	621.197.3	stock)	625.2
Direct acting	621.65	service, Accessories to	656.26
Design and construction of	621.64	shops, roundhouses, car house	
General theory of	621.641	terminals and stations	656.21
Hydraulic Hydraulic	621.252	track (see Roadbed)	625.14
Locomotive	621.133.7	tunnels	625.13
	622.53—.54	Railways, Administrative	0.50,10
Piston		* /	385.4
	621.65	organization of	
Rotary	621.66	Competition of	656.233
Steam	621.64	with steampship lines	385.2
Tests of	621,642	Economic and financial aspects	
Punching and shearing machin		of	385,1
Purification of iron	669.15	Elevated and underground	625.4
of water for locomotives	621.133.7	Essays on, history of	385.0
Purifiers, Feed water	621.197.2	Inclined	625.3
Pyrometers, (steam plant)	621.197.7	International agreements rela-	•
	.52 669.84	tive to	385.6
Phyrotechnics (chemical tech	nol-	Interstate commerce commission	on 385.7
ogy)	662	Mountain	625.3
0		Operation of	656
Q		Personnel of	385.5
Quantities and costs, Enginee	r-	Report of, statistics of, etc.	385.0
ing	62(002)	Safety appliances of	656.25
Quarrying dimension stone	622.22	Ship	625.91
Blasting systems for	622.224	State control of	385.3
Quays	627.3	Street	625.6
R		Survey and location of	625.11
10		Transportation by	656.2
Ratchet gearing	621.837	Tributary	625.6
Radial axles	625,215	Rams, Hydraulic	621.27
Radiation of heat	536.3	Compressing	621.274
Rail bonding	621.333.4	Lifting	621.272
Rails (electric railways)	621.333.2	Pumping	621.273
and attachments	625.143	Ransome's artificial stone	691.32
Railway, bridges	625.13	system of reinforced concrete	
cars (see Rolling stock)	625.2	Rapid transit in cities	388
cross ties	625.142	Rates, Basing and differential	656.231
crossings	625,152	for baggage, dogs, etc.	656.234
engineering	625	for transportation	656.231
fences	625.162	Freight	656.235
freight stations	725.32	of porterage and drayage	
junctions	625,153	Passenger	656.236
passenger stations	025,155 725,31	Revision of	656,234
Lighting of	656.215	Steamer	656.231
Enting Of	050.215	Steamer	656,236

Rates.—Continued.		Potential	621.314.5
Street railway	656.236	Pressure (compr. air)	621.532
Reactors	621.314.6	Steam pressure	621.185.4
Reamers	621.954	Reheating of compressed air	621.534
Receivers, Telephone	621.386.3	Reinforced concrete 693.7	7 620.137
Reclamation from tides and w	aves 627.5	Experimental data for	693.74
Recording pressure gages, (ai	r) 621.532	Forms and centers for	693.72
Steam	621.184.73	Formulas for	693.75
Recreation buildings	725.8	Hennebique system of	693.714
Rectifiers, Arc	621.313.73	Ordinary system of	693.711
Electrolytic	621.313.74	Ransome's system of	693.712
Mechanical	621.313.72	Roebling system of	693.715
Rectifying apparatus (elect.)	621.313.7	Special applications of	693.76
Refining of iron and steel	669.15	systems	693.71
Refining of ore	669.8	testing and inspection	693.73
Reflection of heat	536.3	Unit system of	693.713
Reformatories	725.6	Relations of Capital to Labor	331.1
Refraction of heat	536.3	Releasing gear engines (Corlise	s,
Refractories	669.82	etc.)	621.164.4
Alkaline earth	669.827	Religious buildings	726
Aluminaceous	669.824	Removal of impurities from wa	ter 628.16
Application and maintenance	of 669.829	Repair of locomotives	621.138
Argillaceous	669.823	Repair shops, Car	625.26
Carbonaceous	669,825	Locomotive	621.138.5
Chromitic	669,826	Repairs and renewals of railw	ay
Rare earth	669.828	track	625.173
Siliceous	669.822	Repulsion motors	621,313.66
Refreshment buildings	725.7	Reservoirs and tank sewers	628.28
Refrigerating fluids	621.564	Reservoirs (water supply)	628.13
Refrigerating machines	621.57	Residences	728
Ammonia	621.572	Resistance of air to trains	656.221.6
Carbonic acid	621.574	of engines	656.221.3
Miscellaneous types	621.575	of foreign rolling stock	656.221.5
Refrigerating plants	621.565	of freight trains	656.221.1
Refrigerating systems	621.565	of passenger trains	656.221.2
Briņe	621.565.1	on electric roads	656.221.4
Design of	621.566	Resistance boxes	621.374.2
Direct expansion	621,565,2	meters	621.374.2
Piping for	621.566	Restaurants (railway service)	656.26
Refrigerator cars	625,244	Reverberatory furnaces	669.831.5
Refrigerators	621.56	Rheostats	621.317.4
Regulators, Air pressure	621.532	Ring and key (railway blocking	
Compensator	621,314.51	systems)	656.258
for sewers	628,258	River and ocean transportation	
Induction	621.314.52	crossings (sewers)	628.26
Magneto	621.314.53	engineering	627

Rivers, Discharge of, etc.	627.1	Sanitation of	625.78
Flow of	532.5		625.86
Rivet machinery	621.97	Surveys and maps of routes f	
Riveted joints	696.4	Trees and shrubs along	625.77
Design of	621.884	Vitreous stone for	625.87
Rivets	621.884	Roasting of ore	669.8
Roadbed and track (railway)	625.1	Roasting furnaces	669.831
approaches	625.165	Fuels for	669.81
Ballast for	625.141	Rock drills (compressed air)	621,542
bridges	625.13	Rods, Lightning	537.4
crossings	625.152	Locomotive	621,134.1
Drainage of	625.123	Roebling system (reinforced cor	
Fences, etc., for	626.162	crete)	693.715
Maintenance of	625.17	Roller bearings	621.822
Materials for	625.18	Rolling bridges	624.85
Rails and rail attachments for		Rolling, Iron & steel	669.184.2
Section houses for	625.161	mills	621.77
Snow screens for	625.164	Rolling stock, Electric traction	621.334
Stone work for	625.13	Railway	625.2
Subgrade of	625.12	Axles	625.212
Switches, etc., for	625.151	Brakes	625,25
Ties for	625.142	Clearance of bridges and	
Track	625.14	tunnels	625.22
Equipment of	625.15	Couplers and buffers	625,216
Laying of	625.144	Draft gears	625.216
Tunnels	625.13	Frames	625.211
Ventilation of	625.13	Freight cars	625.24
Turntables	625.154	Capacity of	625.24
Road engineering	625	Closed and covered	625.243
Road machines, Steam	621.14	Dynamometer	625.245
Roads	625.7	Flat cars	625.241
Cable	625.5	Hopper and dumping	625.242
Country	625.7	Refrigerator	625.244
Underground (mines)	622,62	Unloaders for	625.247
Roads and highways	625.7	Weight of	625.24
Asphalt	625.85	Lubricants for	625.214
Concrete	625.84	Passenger cars	625.23
Construction of	625.74	Compartment cars	625.231
Construction work of	625.75	Dining cars	625.232
Cross section of	625.73	Heating and ventilation of	of 625.234
Equipment for construction of	625.74	Lighting of	625,233
Maintenance of way of	625.76	Parlor cars	625.232
Metallic	625.87	Sleeping cars	625.232
Paving of	625.8	Types of	625.23
Roadbed of	625.73	Weight of	625,23
Reinforced stone for	625.87	Repair shops for	625.26

Rolling stock.—Continued.		of cars	625,234
Supplies and materials for	625.27	of factories	628.51
Suspension of	625,213	of streets and roads	625.78
Tires for	625.212	of towns	628.4
Trucks for	625,215	Sawing machinery	621.93
Wheels for	625,213	Metal	621.932
Street railway	625.617	Wood	621,933
Use of, and distribution of	656,223	Scaffolding	624.95
Roof and ceiling tile	691,472	Scale prevention in locomotive	es 621.133.7
Roofs, Fireproofing of	693.84	in stationary boilers	621.194.4
Roofing	695	Scales, Weighing	531.21
Asphalt	695.6	Schedules of trains	656.222
Cloth	695.8	Scientific buildings	727
Felt	695.7	Screening (mines)	622.74
Gravel	695.7	Coal Coal	622,783
Metal	695,4	Screw machines	621.99
Iron and steel	695.5	threads, Systems of	621.882
Shingle	695,1	Screws 696	6.5 621.882
Slate	695.2	for transmitting motion	621.882
Thatch	695.9	Searchlights	621.325.7
Tile	695.3	Secondary cells	621,354
Roofs (architectural)	721.5	Section-houses (railway)	625,161
Rope transmission	621.853	Selenitic artificial stone	691.34
Ropes, Hoisting	622.674	Selenitic lime	691.53
Rotary blowers	621.62	Semi-bituminous coal	553.24
pumps	621.66	Separators, Steam	621.197.4
steam engines	621.166	Series, A. C. motors	621.313.65
Round houses 725.33	621,138.1	Service pipes, Water supply	628.15
Running gear, Locomotive	621.135	Service reservoirs	628.13
Rural water supply	628.7	Sewerage, Discharge of, into	sea 628.39
		Deodorization and disinfec	tion
S		of	628.32
9		Disposal of	628.3
Saddles, Locomotive	621.135.3	farming	628.37
Safety appliances (railways)	656.25	Filtration of	628.35
Safety devices (railways)	656.259	irrigation	628.36
Safety valves	621.133.9	manures	628.38
Locomotive	621.133.9	Physical properties of	628.31
Sampling (metallurgy)	669.91	Precipitation of	628.34
Sandblasting	669.185.1	Subsidence of	628.33
Sands (econ. geology)	553.62	Sewer appurtenances	628.25
Sandstone (building material)	691,231	inlets	628,255
Sandstone (geol.)	553.53	tiles (building)	691.49
Sanitary engineering	628	Sewerage systems	628.21
Sanitation, Industrial	628.5	works	628.2
in trades	628.51	pumping stations for	628.29

Sewers, Design and construction		Signal apparatus, Interlockir	
of	628.24	Signal devices (electric trans	
Intercepting and outfall	628.27	sion)	621.317.5
Reservoirs for	628.28	systems, Centralization of	656.257
River crossings for	628.26	Signaling in mines	622.48
Shape and size of	628.22	Signals, Bell (railways)	656.254
Tank	628.28	Block	656.256
Ventilation of	628.23	block, Automatic electric	656.256.3
Shaft governor engines, Auto-	-	Electric	537.88
matic	621.164.3	Electrically controlled many	ual
Shaft sinking (mines)	622,25	block .	656.256.2
Shafting, Shop	621.823	Forms, colors, sounds of	656.251
Location of	621.751	Hand and train	656.252
Shafts, Engine and propeller	621.824	in train operation	656.251
Shale, Bituminous	553.23	Station	656.253
Shapers	621.912	Pneumatic block	656,256.4
Shearing machinery	621.96	Simple manual block	656.256.1
Shell, Boiler	621.184.52	Signs, Electric	621.321.44
Locomotive	621.133.3	Siliceous refractories	669.822
Shifting bridges	624.8	Silicon steel	669.137
Ship building	699	Silver, Metallurgy of	669.2
railways	625.91	alloys	669.223
Shipping facilities (manufac-		amalgamation with gold	669.231
tories)	621.701	Economic factors conc.	669.221
Shone system of sewerage	628.214	Leaching of	669,228
Shop buildings	621.702	Plants for the prod. of	669,229
shafting	621.823	Properties of	669.222
Shops, Arrangement of	621.702	Simplex telegraphy	621.382.31
Boiler and sheet metal	621,792	Single acting engines	621.164.5
Car repair	625.26	Skew bevel gears	621.833.2
Finishing	621.795	Skips (mine hoisting)	622.68
Forge	621.73	Slags from metals	669.86
for special processes	621.794	Slate (building material)	691.24
Machine	621.75	roofing	695.2
Mining	622.93	Slates (geol.)	553.54
Organization and administra	L-	Sleeping cars	625.232
tion of	621.704	Slide valves, Locomotive	621.134.2
Pattern	621.72	Slot, Electric	656,258
Railway	725.33	Slotters	621.912
Shovels, Mechanical (mining)	622.214	Sludge, Disposal of	628.348
Power	621.865	Sluices	621.29
Steam	621.167	Smelting of ore	669.8
Sidewalks, Concrete	693,54	Fuels for	669.81
Curbing for	625.88	Smoke box, Locomotive	621.133.4
Establishment of	625.88	Smoke, consumers	621,183.8
Flagging of	625.88	flues and chimneys	697.8

Smoke.—Continued.		Steam, collectors	621.184.79
from special industries	628,539	condensation in pipes	621.185.1
from steam generators	628.538	distribution in locomotives	621.134.2
nuisance	628.53	dredges	621.167
Snow screens (railway)	625.164	engine, dynamometers	621.197.7
Societies, Engineering	620.6	indicators	621.197.7
Solar engines	621.47	lubricators	621.197.7
Solids, Properties of	539.2	mechanism	621.11
Sound	534	tachometers	621.197.7
Specifications, Building	692.3	engineering	621.1
Engineering	62(003)	engines, Care and manage-	0.21.1
Speisses (metallurgy)	669.87	ment of	621.195
Spiral gears	621.833.3	Rotary	621.166
Springs, Locomotive	621.135.3	Stationary	621.16
Springs, Strength of	620.112.85	Thermodynamics of	536.73
Sprinkling of streets	628,46	Traction	621.14
Spur gears	621.833.1	fitting	
Stacks (boiler plants)	621.183.8	Flow of, in pipes	696
Locomotive	621,133,4	furnaces	621,185.1
Stamping machines, Hydrauli	c 621.266		621.183
Standard cells	621.374.3	gages 621.184.73	621.197.7
Stairbuilding	694	generation	621.18
Stand-pipes (water supply)	628.12	heating	697.5
State control of railways	385.3	Exhaust	697.53
Static electricity	537.2	High pressure	697.51
Statics	531.2	Low pressure	697.52
Graphic	531.2	Vacuum	697.54
Station signals	656,253	piping	621,185
Stationary boilers	621.184.24	plant	621.19
Stationary steam engines	621.16	accessories	621.197
Stations, Central	621.312	instruments	621.197.7
for lighting	621.312.2	pressure gages	621.184.73
for power	621,312.4	pressure regulators	621.185.4
for railways	621.312.3	Production of, in locomotiv	es 621.133
Stations, Railway	656.21	pumps and pumping engines	3
for special purposes (coal,	000,112	(see Pumps)	621.64
live stock, etc.)	656,213	road machines	621.14
freight, Arrangement of	656,212	separators	621.197.4
Heating and lighting of	656.215	shovels	621.167
passenger, Arrangement of	656,211	superheaters	621.197.5
Union	656.214	Transmission and distributio	11
Statistics, Engineering	62(001)	of	621.185
of railways	385.0	traps	621.185.5
Staying of boilers	621.184.52	Steamship lines, Competition of	
Stays (locomotive boilers)	621.133.2	with railways	385,2
m	4 621.184	Steam turbine	621.165
Steam boilers and power plan			621.165.12
power plan	0.01,10	- Carreto	0.1.100.1a

Steam turbine.—Continued.		Pressing of	669.184.4
calculations	621,165.11	Properties and constants o	
discs, Stresses in	621,165,14	Protection of	691.79
guide vanes and nozzles	621.165.13	Purification of (see Iron)	669.15
theory	621.165.1	Rolling of	669.184.2
vanes and buckets	621.165.12	roofing	695.5
Steam turbines	621.165	Sand blasting of	669.185.1
Combined velocity and press		Structure and composition	
comanied verselly and press	621.165.23	Tempering of	669.181.2
Construction of	621,165,3	. 0	.123 620.17
Design of	621.165.3	Treatment of	669.18
Pressure type	621.165,22	Uses of	669.115
Stresses in	621.165.14	Steel works (architecture)	725.43
Types of	621.165.2	Steels, Special	669.139
Velocity type	621.165.21	Stenography	653
Windage in	621.165.15	Stokers, Mechanical	621.183.6
Steam valves	621.185.4	Stone, Artificial	691.3 666.8
Steel	669.1	Beton coigniet	691.31
Alloys of	669.13	Ransome	691,32
Chrome	669,133	Selenitic	691.34
Manganese	669.132	Tests of	620.139
Molybdenum	669.135	as building material	691.2
Nickel	669,131	construction	693.1
Silicon	669.137	Preservation of	691.29
Titanium	669.138	Protection of	691.2
Vanadium	669.136	Tests of (appl. mech.)	620.13
Annealing of	669.181.3	Stones, Building	553.5
Carburization of	669.16	Stoneware	666.6
Cementation process for	669.161	Stoping (mining)	622.27
Crucible process for	669,162	Overhand	622,341
Case hardening of	669,182	Underhand	622.342
Chemical properties of	669.124	Storage and service reservoir	rs 628.13
Economic factors conc.	669.11	Storage batteries	621.354
Finishing of	669.185	Application of	621.354.4
forging	669.184.1	Care and handling of	621.354.18
founding	669.17	Construction of	621.354.2
Hardening of	669.181.1	Operation of	621.354.3
in buildings	691.7	Storage buildings	725.3
Machining of	669.184.5	Storage of electricity	537.84
Metallurgy of	669.1	Storage of drawings	621.717
Melting of	669.171	Storage of patterns	621.727
Moulding of	669.172	Storage reservoirs	628.13
Nature and properties of	669.12	Store houses, (manufactories	
Painting of	669.185.3	Storm-water flow	628.221
(for protection)	691.791	Stoves, Heating by	697.2
Physical properties of pickling	669.123 669.185.2	Straightening machinery	621.983
picking	009.185,2	Straightening machinery	0.56.1.50

Street cleaning and sprinkling 628.46	panels 621.317.2
Street railways 625.6	protective devices 621.317.8
Electric (see Electric trac-	Switchboards 621.317
tion) 621.331.34	Telephone (see Telephone) 621.387
Elevated 621.331.343	Automatic 621.387.7
Subways 621.331.344	Switches, Electric 621.317.3 621.328.7
Surface 621.331.342	Dial 621.317.33
Streets, City 625.7	Knife 621.317.32
Sanitation of 625.78	Oil 621.317.35
Sprinkling and cleaning of 628.46	Plug 621,317.34
Strength of materials 620.11 539.4	Switches, Railway 625.151
Tests of 620.112	Syenites (geol.) 553.52
Strength of springs 620.112.85	Synchronizers 621.374.91
Strikes and lockouts 621.705	Synchronous commutating ma-
Study and teaching of engineer-	chines 621.313.4
ing 620.7	convertors 621.313.53
Subgrade (railways) 625.12	machines 621.313.4
(street railways) 625.613	motors 621.313.44
Submarine cable telegraphy 621.382.8	telegraphy 621.382.36
Subsidence (sewerage) 628.33	
Substations, Electric 621.312.6	Т
Subways 621.331.344 625.4	•
Superheaters, Steam 621.197.5	Tachometers 621.197.7
Superintendence of building con-	Tackle 621.863
struction 692.6	Hydraulic 621.262
Supporting ground (mining) 622.28	Tables and calculations, Engi-
Surface, condensers 621.197.62	neering 620.8
grinding machines 621.922	Tail races 621.29
lines (street railways) 621.331.342	Tank sewers 628.28
transportation (mines) 622.69	Tanks, Precipitation (sewerage) 628.341
Survey of railway routes 625.11	Track 621.136.3
Preliminary 625.111	Tapping machinery 621,955
Surveying, Mine 622.14	Tar (building material) 691.96
· Surface (mining) 622.13	Taxes (street railway) 625.611
Surveys, Magnetic 622.15	Technology, Chemical 660
Mineral 622.131	Telegraph 654 537.81
Suspension, bridges (see Bridges) 624.5	codes 621.382.15
chains and cables 624.52	engineering 621.38
of locomotives 621.135.3	instruments 621.383
of railway cars 625.213	Intermediate 621.383.2
Swing bridges 624.82	Receiving 621.383.3
Switch and signal apparatus, In-	Transmitting 621.383.1
terlocking 656.257	systems 621.382
Switchboard meters and indi-	Automatic code 621.382.4
cating devices 621,317.6	Duplex 621.382.32


Telegraph, systemsContinu	ed.	Semi-Automatic	621.385.72
Fac-simile telegraphy	621.382.7	Uses of, in transportatio	n 656.254
Multiplex	621.382.35	transmission	621.387.8
Multiplex harmonic	621.382.37	. Cable construction for	621.387.84
Multiplex synchronous	621.382.36	Long distance	621.387.82
Printing telegraphy	621.382.5	Pupin coils	621.387.86
Quadruplex	621.382.34	transposition	621.387.83
Simplex	621.382.31	Telephony (communication)	654.6
Writing telegraphy	621.382.6	(engineering)	621.385
Uses of, in transportation	656.254	Combined telegraphy and	621.382.95
Telegraphy (communication)	654	Wireless .	621.384.5
(engineering)	621.382	Telfers	621.868
Combined telephony and	621.382.95	Temperature, Influence of	
Induction	621.382.94	on metals	620.112.1
Submarine cable	621.382.8	Measurement of	536.5
Wireless	621.384	by electric methods	536.53
Telephone 65	54.6 537.82	regulators, Electric	621.39
(engineering)	621.38	Tempering steel	669.181.2
instruments	621,386	Tender brakes	621.136.1
Batteries	621,386.96	Tenders	621.136
Call receiving apparatus	621.386.7	Couplings for	621.136.2
Call sending apparatus	621.386.8	Design of	621.136.1
Coin collecting devices	621.386.92	Weight of	621.136.1
Condensers	621.386.5	Terminals and stations, Railw	ay 656.21
Distributing frames and		Terra cotta (building)	691.48
racks	621.387.92	construction	693.3
Induction coils	621.386.4	Textile factories (architectur	e) 725.41
Meters and counters	621.387.96	Thatch roofing	695.9
Protective devices	621.386.94	Thermodynamics	536.7
Receivers	621.386.3	Applied	621.101
Transmitters	621.386.2	of air compression	621.534
power plant	621.387.6	of perfect gases	536.71
Accumulators for	621.387.62	of steam engine and heat m	0-
Generators for	621.387.63	tors	536.73
switchboards, Central	621.387	of vapors	536.72
Automatic	621.387.7	Thermometers (steam plant)	621,197.7
Manual	621.387.2	Thermometry	536.51
Multiple	621.387.3	Third-rail for elect, traction	621.332.3
Transfer	621.387.4	Threads, screw, Systems of	621.882
switching devices	621.386.6	Throttle, Locomotive	621,133.6
systems	621.385	Throttling engines	621.164.42
Automatic	621.385.75	Tile (chem. tech.)	666.7
Central switchboard	621.385.4	floors	691,471
Intercommunicating	621.385.3	roofing and ceiling	691.472
Multiple switchboard	621.385.5	roofing	695.3
Private exchange	621,385.8	sewers	
- Continue	0.01,000,0	SCWEIS	691.49

Tile.—Continued.		Trains	656.22
Tests of	620.14	Making up of	656.225
Tiles (building materials)	691.46	Protection of, in distress	656,254
Hollow structural	691.47	Running of	656.222
Timbering of mines	622,281	Tramming (mines)	622.651.2
Timber, Tests of (appl. mech.)	620.12	Trams (mines)	622.63
Tin, Metallurgy of	669.6	Tramways	625,62
Tinning of iron and steel	691.792	Transfer boards (telephone)	621.387.4
Tires, Car	625.212	Transformers	621.314.3
Titanium steel	669,138	Auto.	621,314,4
Tonnage rating	656,225	Constant current	621.314.32
Tool making	621.756	Constant potential	621.314.33
Tools, Machine (see Machine		Meter	621.314.38
tools)	621.9	Phase changing	621.314.34
(shop equipment)	621.752.1	substations	621.312.63
Tools, Pneumatic	621.542	Transmission, Air	621.532
Tooth curves	621.831	dynamometers	531.4
Torsion	539.3	Hemp rope	621.853
Towers	624.95	machinery	621.8
for suspension bridges	624.54	of compressed air (see Co	
	21.319.225	pressed air)	621,53
Towns, Sanitation of	628.4	of electrical energy	621.319
Water supply for	628.1	Lines for	621,319,2
Track (electric traction)	621.333	Overhead	621.319.22
Track (railway) (see Road		Underground	621.319.23
bed)	625.14	Poles and towers for	621.319.225
tanks	621.136.3	Protective devices for	621.319.8
,	621.184.23	Retaining and supporting	
dynamometers	531.21	devices for	621.319.4
engines	621.14	Systems of	621.319.12
Electric (see Electric tractio	*	Alternating current	621.319.123
systems	625.63	Composite	621.319.125
Tractive force of locomotives		Continuous current	621.319.122
Trade rules (building constru		of force	531.8
tion) Trades, Mechanic	692.94	of power	537.84
Traffic (transportation)	680 656,23	of steam	621.185
Traffic, Division of	656,233	Wire rope	621,854
Traffic (street railway)	625,611	Transmitters, Telephone	621,386,2
Train crews, Assignment of		Transportation	656
Train, dispatching	621.137 656.254	buildings	725.3
resistance	656,221	by horseless vehicles	656.3
schedules	656,222	by railways	656.2
service, Passenger	656.224	claims, Damage in, Delays	
Freight	656,225	Cost of	656.232
Baggage	656,226	in mines	622.6
signals	656,252	Military	656,229
51511015	000,202	ATTITUAL Y	000.220

Transportation.—Continued.		Turntables	625.154
of dangerous freight	656.227	Two-cycle engines	621.432.2
of perishable freight	656.227	Typewriters	652
on roads and highways	656.1	-21	
Pools and agreements rela		. []	
ing to	656,233	ğ	
River and ocean	387	Underground railways	625.4
tolls and rates	656,231	roads (mines)	622.62
Trap (geol.)	553.57	transmission lines	621.319.23
Traps for sewers	628.256	Undershot water wheels	621.23
	3 621.185.5	Underwriters requirements f	
Traveling cranes	621.874	electric lighting	621,328.1
Tread mills	621.46	Union stations	656.214
Tributary railways	625.6	Unions, Labor	621.705
Operation of	656.27	Unit system (reinforced co	
Trigonometry	514	crete)	693.713
Trolley lines	621,331,2	Universities	727.3
Trucks, Bissell	621,135.4	Urinals (sanitation)	628,45
Four-wheel	621,135.4		
Locomotive	621,135.4	V	
of railway cars	625.215	Vacuum appliances	621.55
Trunk lines, Electric	621.331.32	lamps for special radiation	621.327.7
Trunnion bridges	624.84	Valve gears	621.84
Truss, Bowstring	624.32	for locomotives	621,134,22
Cantilever	624.33	Valves, for locomotives	621,134,22
Trussed girders for bridges	624.08	Blowout	621.184.79
Trusses, Fireproofing of	693.87	Safety	621,185,4
Tubes, Locomotive	621.133.3	(boiler)	621.184.73
Tubular bridges	624.4	Steam	621.185.4
Tungsten filament incandescer		for sewers	628.257
lamps	621.326.43	Vanadium Steel	669.136
Tunneling and drifting	622,26	Vanes (steam turbines)	621.165.12
Tunneling devices, Hydraulic	621,269	Vapor engines, Binary	621.44
Tunnels (railway)	625.13	lamps for incandescent ligh	
Clearance of	625.22	ing	621.327.3
for telephone cables	621.319.23	Vapors, Properties of	533.1
for water supply	628.14	Thermodynamics of	536.72
Ventilation of	625.13	Vaulted edifices of masonry	624.92
Turbines, Gas	621.433	Vaults	624.9
Steam Steam	621,165	and arches (bridges)	624.06
Buckets for	621,165,12	Fireproofing of	693.88
Vanes for	621,165,12	Vegetable materials, Tests of	
Water	621.24	oils	665.3
Impulse	621.247	Velocity turbines	621.165.21
Reaction or pressure	621.242	-	28.8 697.9
Turning machinery	621.94	by fans	697.98
Tarming machinery	0.01,07	by Tans	001.00

Ventilation.—Continued.		pressure engines	621.25
Exhaust system of	697.93	Purification of, for locon	
Foul air ducts for	697.95	tives	621.133.7
Fresh air ducts for	697.94	scoops for tenders	621.136.3
Natural system of	697.91	Sources of	628.11
of cars	625.234	storage reservoirs	628.13
of mines (see Mines, Ventila		supply for villages and cou	
tion of)	622.4	try houses	628.7
of sewers	628,23	tunnels	628.14
of tunnels	625.13	turbines	621.24
Plenum system of	697.92	Impulse	621.247
Regulation of air supply for	697.97	Reaction or pressure	621.242
Treatment of air for	697.96	Use and waste of	628,17
Vestibule cars	625,232	wheels	621.21
Villages, Water supply for	628.7	Breast	621.22
Voltaic cells and generators	621.35	Overshot	621.22
Containers for	621.352.1	Undershot	621.23
Electrodes for	621,352.2	Water-tube boilers	621.184.26
Electrolytes for	621.352.4	Water-works	628
Voltmeters	621.374.3	Watt-hour meters	621,374.5
		Wattmeters	621.374.6
W		Wear and duration of boiler	
VV		Weathering of materials	620.112.2
Wages	331.2	Weighing scales	531.21
Labor and	331	Weight and capacity of freig	
Walls (architecture)	721.2	cars	625,24
Fireproofing of	693.82	of passenger cars	625.23
Warehouses, Cold storage	725.35	of tenders	621,136,1
Washing of coal	622.784	Weights and measures	389
Wastes, Disposal of	628.54	Wells for water supply	628.11
Discharge of, in streams	628.541	* * *	621.374.2
Filtration of	628.545	Wheatstone bridges	
Purification of by the soil	628.546	Wheels, Car	625.212
Water	532	Balancing of	625.212
accumulators	621.254	Breast Locomotive	621.22
acqueducts	628.14	Overshot	621.135.2 621.22
conduits	628.14	Toothed	621.83
engines	621.2	Undershot	621.23
Filterbasins for	628.16	Water	621.21
Flow of, in pipes	532.5	11 -11 -11	
for towns	628.1	Whistles, Boiler warning Winches	621.184.72 621.864
	21.184.72		
Impurities in, and their re-		Windage in steam turbines	621.165.15
moval	628.16	Wind engines	621.45
Mains and service pipes for	628.15	Windows, Architecture of	721.8
meters	628.17	Windlasses	621.864
motors	621.2	Windmills	621.45

****		*** ***	
Wire drawing	669.184.3	Working of mines	622.3
Wireless telegraphy	621.384.2	Works, Engineering	621.7
Wiring, Central station	621.317	Worm gears	621.833.3
Interior	621.328.2	Writing, Methods of	652
Wire rope transmission	621.854	Wrought iron (in buildings)	691.73
Women, Labor of	331.4	Puddling process for the	
Wood boring machinery	621,953	mfg. of	669,151
planing machinery	621.913	7.	
sawing machinery	621.933		
turning lathes	621.943	Zinc, Metallurgy of	669.5
Woods, Preservation of	691,18	alloys	669.53
used in building	691.1	Economic factors conc.	669.51
		Leaching of	669.58
Woodworking methods and pro		Plants for the prod. of	669.59
cesses	621.723	Properties of	669.52
Woodworking mills (architec-		Refining of	669.57
ture)	725.44	Roasting of	669.54
Woodworking shop	621.72	Smelting of	669,55
Wool, Mineral (for building)	691.91	Zincs (boiler)	621.184.79
Work, Theory of	531.4	Zone tariffs	656.231



### PUBLICATIONS OF THE ENGINEERING EXPERIMENT STATION

\*Bulletin No. 1. Tests of Reinforced Concrete Beams, by Arthur N. Talbot. 1904. None available.

\*Circular No. 1. High-Speed Tool Steels, by L. P. Breckenridge, 1905. None available.

\*Bulletin No. 2. Tests of High-Speed Tool Steels on Cast Iron, by L. P. Breckenridge and Henry B. Dirks. 1905. None available.

\*Circular No. 2. Drainage of Earth Roads, by Ira O. Baker. 1906. None available.

\*Circular No. 3. Fuel Tests with Illinois Coal. (Compiled from tests made by the Technologic Branch of the U. S. G. S., at the St. Louis, Mo., Fuel Testing Plant, 1904-1907, by I. P. Breckenridge and Paul Diserens. 1909. Thirty cents.

\*Bulletin No. 3. The Engineering Experiment Station of the University of Illinois, by L. P. Breckenridge. 1906. None available.

\*Bulletin No. 4. Tests of Reinforced Concrete Beams, Series of 1905, by Arthur N. Talbot. 1906. Forty-five cents.

\*Bulletin No. 5. Resistance of Tubes to Collapse, by Albert P. Carman. 1906. Fifteen Cents.

\*Bulletin No. 6. Holding Power of Railroad Spikes, by Roy I. Webber. 1906. Thirty-five cents.

\*Bulletin No. 7. Fuel Tests with Illinois Coals, by L. P. Breckenridge, S. W. Parr and Henry B. Dirks. 1906. Thirty-five cents.

\*Bulletin No. 8. Tests of Concrete: I. Shear; II. Bond, by Arthur N. Talbot. 1906. None available,

\*Bulletin No. 9. An Extension of the Dewey Decimal System of Classification Applied to the Engineering Industries, by I., P. Breckenridge and G. A. Goodenough. 1906. Revised edition, 1912. Fifty cents.

\*Bulletin No. 10. Tests of Concrete and Reinforced Concrete Columns, Series of 1906, by Arthur N. Talbot. 1907. None available.

\*Bulletin No. 11. The Effect of Scale on the Transmission of Heat through Locomotive Boiler Tubes, by Edward C. Schmidt and John M. Snodgrass. 1907. None available.

\*Bulletin No. 12. Tests of Reinforced Concrete T-beams, Series of 1906, by Arthur N. Talbot. 1907. None available.

\*Bulletin No. 13. An Extension of the Dewey Decimal System of Classification Applied to Architecture and Building, by N. Clifford Ricker. 1907. Fifty cents.

\*Bulletin No. 14. Tests of Reinforced Concrete Beams, Series of 1906, by Arthur N. Talbot. 1907. None available.

bot. 1907. None available.

\*\*Bulletin No. 15. How to Burn Illinois Coal without Smoke, by L. P. Breckenridge. 1908.
Twenty-five cents.

\*Bulletin Na. 16. A Study of Roof Trusses, by N. Clifford Ricker. 1908. Fiftcen cents.

\*Bulletin No. 17. The Weathering of Coal, by S. W. Parr, N. D. Hamilton, and W. F. Wheeler. 1908. Twenty cents.

Bulletin Na. 18. The Strength of Chain Links, by G. A. Goodenough and L. E. Moore. 1908. Forty cents.

\*Bulletin Na. 19. Comparative Tests of Carbon. Metallized Carbon and Tantalum Filament Lamps, by T. H. Amrine. 1908. Twenty-five cents.

\*Bulletin No. 20. Tests of Concrete and Reinforced Concrete Columns, Series of 1907, by Arthur N. Talbot. 1908. Nane available.

Bulletin No. 21. Tests of a Liquid Air Plant, by C. S. Hudson and C. M. Garland. 1908. Fifteen cents.

\*Bulletin No. 22. Tests of Cast-Iron and Reinforced Concrete Culvert Pipe, by Arthur N. Talbot. 1908. Thirty-five cents.

Bulletin No. 23. Voids, Settlement and Weight of Crushed Stone, by Ira O. Baker. 1908. Fifteen cents.

Bulletin No. 24. The Modification of Illinois Coal by Low Temperature Distillation, by S. W. Parr and C. K. Francis. 1908. Thirty cents.

Bulletin No. 25. Lighting Country Homes by Private Electric Plants, by T. H. Amrine. 1908. Twenty cents.

Bulletin No. 26. High Steam-Pressures in Locomotive Service. A Review of a Report to the Carnegie Institution of Washington, by W. F. M. Goss. 1908. Twenty-five cents.

Bulletin No. 27. Tests of Brick Columns and Terra Cotta Block Columns, by Arthur N. Talbot and Duff A. Abrams. 1909. Thirty cents.

Bulletin No. 28. A Test of Three Large Reinforced Concrete Beams, by Arthur N. Talbot. 1909. Fifteen cents.

<sup>\*</sup>Out of print; price attached.

N. B.—A limited supply of bulletins, the titles of which are not starred, is available for gratuitous distribution.

### PUBLICATIONS OF THE ENGINEERING EXPERIMENT STATION

Bulletin No. 29. Tests of Reinforced Concrete Beams: Resistance to Web Stresses. Series of 1907 and 1908, by Arthur N. Talbot. 1909. Forty-five cents.

Bulletin No. 30. On the Rate of Formation of Carbon Monoxide in Gas Producers, by J. K. Clement, L. H. Adams, and C. N. Haskins. 1909. Twenty-five cents.

Bulletin No. 31. Fuel Tests with House-heating Boilers, by J. M. Snodgrass. 1909. Fifty-five cents.

Bulletin No. 32. The Occluded Gases in Coal, by S. W. Parr and Perry Barker. 1909. Fifteen cents,

Bulletin No. 33. Tests of Tungsten Lamps, by T. H. Amrine and A. Guell. 1909. Twenty cents.

Bulletin No. 34. Tests of Two Types of Tile Roof Furnaces under a Water-tube Boiler, by J. M. Snodgrass. 1909. Fifteen cents.

\*Bulletin No. 35. A Study of Base and Bearing Plates for Columns and Beams, by N. Clifford Ricker. 1909. Twenty cents.

Bulletin No. 36. The Thermal Conductivity of Fire-Clay at High Temperatures, by J. K. Clement and W. L. Egy. 1909. Twenty cents.

\*Bulletin No. 37. Unit Coal and the Composition of Coal Ash, by S. W. Parr and W. F. Wheeler. 1909. Thirty-five cents.

Bulletin No. 38. The Weathering of Coal, by S. W. Parr and W. E. Wheeler. 1909.
Twenty-five cents,

Bulletin No. 38. Tests of Washed Crades of Illinois Coal, by C. S. McCounty, 1909.

Bulletin No. 39. Tests of Washed Grades of Illinois Coal, by C. S. McGovney. 1909. Seventy-five cents.

Bulletin No. 40. A Study in Heat Transmission, by J. K. Clement and C. M. Garland. 1910. Ten Cents.

Bulletin No. 41. Tests of Timber Beams, by Arthur N. Talbot. 1910. Twenty cents.

Bulletin No. 42. The Effect of Keyways on the Strength of Shafts, by Herbert F. Moore. 1910.  $Ten\ cents$ .

\*Bulletin No. 43. Freight Train Resistance, by Edward C. Schmidt. 1910. Seventy-five cents.

Bulletin No. 44. An Investigation of Built-up Columns under Load, by Arthur N. Talbot and Herbert F. Moore. 1911. Thirty-five cents.

Bulletin No. 45. The Strength of Oxyacetylene Welds in Steel, by Herbert L. Whittemore. 1911. Thirty-five cents.

Bulletin No. 46. The Spontaneous Combustion of Coal, by S. W. Parr and F. W. Kressmann. 1911. Forty-five cents.

Bulletin No. 47. Magnetic Properties of Heusler Alloys, by Edward B. Stephenson. 1911.

Twenty-five cents.

Bulletin No. 48. Resistance to Flow through Locomotive Water Columns, by Arthur N.

Talbot and Melvin L. Enger. 1911. Forty cents.

Rulletin No. 48. Resistance to Flow through Locomotive Water Columns, by Arthur N. Talbot and Melvin L. Enger. 1911. Forty cents.

Rulletin No. 48. Tests of Niele Steel Riveted Leists by Arthur N. Telbot and Harbort

Bulletin No. 49. Tests of Nickel-Steel Riveted Joints, by Arthur N. Talbot and Herbert F. Moore. 1911. Thirty cents.

Bulletin No. 50. Tests of a Suction Gas Producer, by C. M. Garland and A. P. Kratz. 1912. Fifty cents.

Bulletin No. 51. Street Lighting, by J. M. Bryant and H. G. Hake. 1912. Thirty-five cents.

Bulletin No. 52. An investigation of the Strength of Rolled Zinc, by Herbert F. Moore.
1912. Fifteen cents.

' Bulletin No. 53. Inductance of Coils, by Morgan Brooks and H. M. Turner. 1912. Forty cents.

Bulletin No. 54. Mechanical Stresses in Transmission Lines, by A. Guell. 1912. Twenty cents.

Bullctin No. 55. Starting Currents of Transformers, with Special Reference to Transformers with Silicon Steel Cores, by Trygve D. Yensen. 1912. Twenty cents.

Bulletin No. 56. Tests of Columns: An Investigation of the Value of Concrete as Reinforcment for Structural Steel Columns, by Arthur N. Talbot and Arthur R. Lord. 1912. Twenty-five cents.

Bulletin No. 57. Superheated Steam in Locomotive Service. A Review of Publication No. 127 of the Carnegie Institution of Washington, by W. F. M. Goss. 1912. Forty cents.


Bulletin No. 58. A New Analysis of the Cylinder Performance of Reciprocating Engines, by J. Paul Clayton. 1912. Sixty cents.

Bulletin No. 59. The Effects of Cold Weather upon Train Resistance and Tonnage Rating, by Edward C. Schmidt and F. W. Marquis. 1912. Twenty cents.

Bulletin No. 60. The Coking of Coal at Low Temperatures, with a Preliminary Study of the By-Products, by S. W. Parr and H. L. Olin. 1912. Twenty-five cents.

Bulletin No. 61. Characteristics and Limitations of the Series Transformer, by A. R. Anderson and H.R. Woodrow. 1912. Twenty-five cents. (Ready for distribution about Dec. 15.)





600,000 LB. TESTING MACHINE WITH COLUMN IN PLACE.

## UNIVERSITY OF ILLINOIS

## Engineering Experiment Station

BULLETIN No. 10

February 1907

# TESTS OF CONCRETE AND REINFORCED CONCRETE COLUMNS; SERIES OF 1906

By Arthur N. Talbot, Professor of Municipal and Sanitary Engineering and in Charge of Theoretical and Applied Mechanics

### CONTENTS

### I. INTRODUCTION

		Page
1.	Preliminary	3
2.	Scope of Bulletin	3
3.	Acknowledgment	4
	II. MATERIALS, TEST PIECES AND METHOD OF TESTING	3
4.	Materials	4
5.	Test Specimens	7
6.	Forms for Columns	9
7.	Making of Columns	10
8.	Storage of Columns	10
9.	Summary of Test Pieces	11
10.	Testing Machines Used	11
11.		11
12.	Measuring Devices	12
13.	Application of the Load	15

	III. EXPERIMENTAL DATA AND DISCUSSION	
14.	Column Test Data	1
15.	Phenomena of the Column Tests	1
16.	Cube and Cylinder Test Data	19
17.	Stress-deformation Diagrams	2
18.	The Parabolic Stress-deformation Relation	2
19.	The Stress-deformation Relation Developed in	
	the Columns	28
20.	Strength of the Plain Concrete Columns	3.
21.	Strength of the Reinforced Concrete Columns	33
22.	Watertown Arsenal Column Tests	38
23.	Modulus of Elasticity	38
24.	Discussion of Basis for Working Stresses and	
	Working Factor in Structures	43
25.	Formulas for Plain and Reinforced Concrete	
	Columns	45
26.	Discussion of Columns in Building Construction	50
27.	Summary	5:
	Stress-deformation Diagrams for University of	
	Illinois Column Tests	58
	Stress-deformation Diagrams for Watertown Ar-	
	sonal Mosts	5.0

### I. Introduction

- 1. Preliminary.—Columns form an important element in reinforced concrete building construction. Many tests have been made on cubes and short prisms to determine the compressive strength of concrete. The method of making the test pieces and the conditions entering into the tests, as compared with the fabrication and testing of columns, do not permit the results of such tests to be taken as representative of the strength of concrete columns, the cubes generally having a stronger and more uniform concrete and the restraint of the bearing plates giving a higher relative load. Comparatively few tests have been made on columns, either plain or reinforced, and many of these, because of variation in material or age at test or other elements of strength, do not furnish data for comparison or conclusion. The tests herein recorded were made as a preliminary series, to open up the field for further experimentation here, and hence were not considered to be complete or to give full data or to follow in all respects the most approved methods of design, construction and testing. It is hoped, however, that the data and discussion will contribute somewhat to the knowledge of the strength and behavior of plain and reinforced concrete columns and perhaps serve to warn constructors against the use of high working stresses for columns constructed under ordinary working conditions and with concrete of moderate quality.
- Scope of Bulletin.—Both plain and reinforced columns were The reinforcement consisted of longitudinal rods. For part of the columns ties were carried around the reinforcing rods to hold them in place. Not only was the strength of the columns obtained, but the proportion taken by the concrete and by the steel has been estimated by means of the observed relation between the applied load and the resulting shortening of the column and through the use of the analysis herein given. This stressdeformation relation has also been utilized to determine other properties of the columns. Formulas for reinforced columns are given, and the constants to be used are discussed. As bearing on this, a discussion is made of the basis for factor of safety and working stress for plastic materials such as concrete under the conditions of the distribution and application of load to be found in columns. To permit a comparison to be made with the results

of other tests, a summary of the results of a series of column tests at Watertown Arsenal is included. It is felt that this comparison is a valuable addition.

3. Acknowledgment.—The investigation was made in the Laboratory of Applied Mechanics of the University of Illinois as a part of the work of the University of Illinois Engineering Experiment Station. The work of making the tests on the columns, cubes, and cylinders was done principally as thesis work by Ralph Corson Llewellyn, a senior student in architectural engineering, class of '06. Mr. Llewellyn is entitled to much credit for the intelligent thought and diligent care which he gave to the work, and much of the trustworthiness of the results is due to him. The review of the tests which he gave in the thesis was also quite creditable. Immediate supervision of the work of making the columns and of conducting the tests was given by D. A. Abrams, Assistant in the Engineering Experiment Station, whose aid in this and in interpreting the results has added much to the value of the work. Acknowledgment is also made to W. R. Robinson, Assistant in the Engineering Experiment Station, for valuable aid in the preparation of this bulletin.

The following division of the subject matter of the bulletin has been made: I. Introduction; II. Materials, Test Pieces and Method of Testing; III. Experimental Data and Discussion.

## II. MATERIALS, TEST PIECES AND METHOD OF TESTING

4. Materials.—The materials used in making the columns were similar to the building materials ordinarily used in concrete construction in the middle west. The sand, stone and cement were obtained in the open market.

Stone.—The stone was crushed limestone from Kankakee, Illinois. It was ordered to pass over a \frac{1}{4}-in. screen and through a 1-in. screen. Tests showed 54% voids, as found by pouring the stone slowly into water. The stone was nearly pure limestone, somewhat soft in quality.

Sand.—The sand was of good quality, well graded, sharp and fairly clean. It came from deposits near the Wabash river at Attica, Indiana. An average of five determinations showed it to contain 28% voids. The result of the mechanical analysis is given in Table 1.

TABLE 1.

MECHANICAL ANALYSIS OF SAND.

Sieve No.	Diameter of Mesh inches	Per cent Passing
4	1	100.0
10	.096	73.0
20	.040	36.0
50	.019	16.0
74	.011	5.0
100		2.0

Cement.—Chicago AA portland cement was used for all the tests. It was bought from a local dealer. Table 2 gives the

TABLE 2.

TENSILE STRENGTH OF CEMENT.

Ref.	Ag	re 7 Days	Age 60 Days		
	Neat	1-3 Mortar	Neat	1-3 Mortai	
$\frac{1}{2}$ $\frac{3}{4}$ $\frac{4}{5}$ $\frac{6}{6}$	634 717 732 687 580 731	283 281 275 217 206 189	890 916 840 942 872 885	443 440 442 365 352	
Av.	680	242	892	404	

strength of standard briquettes of neat cement and of 1-3 mortar for age of 7 and 60 days.

Concrete.—Men skilled in mixing concrete were employed, and an effort was made to have the different batches of a uniform quality. All of the concrete was made of the proportions 1 of cement, 2 of sand,  $3\frac{3}{4}$  of stone, measured by loose volume. It was intended to use a 1–2–4 mixture, but the large percentage of voids made it seem desirable to increase the amount of mortar. The concrete will, however, generally be referred to as a 1–2–4 mixture.

The mixing was done with shovels by hand. The sand and cement were first mixed together dry. The stone was then added and the mass turned several times with the shovels. When thoroughly mixed, water was added and the whole mass turned until uniform in appearance. A fairly wet mixture, as indicated further in the description of the making of the columns, was used, as this could be tamped into the forms to better advantage. The average weight of the concrete at the time of testing, figured from the weight of the cubes, was about 147 lb. per cu. ft.

Steel.—The reinforcement used in the columns consisted of plain round mild steel bars. It was furnished by the Illinois Steel Company and was an even grade of open hearth steel. Vertical rods,  $\frac{3}{4}$ -in. in diameter were used in the 12-in. columns and rods  $\frac{5}{4}$ -in. in diameter in the 9-in. columns. All ties were made of  $\frac{1}{4}$ -in. round rods. The yield point of the steel averaged 39,800 lb. per sq. in., the ultimate strength averaged 59,200 lb. per

TABLE 3.

TENSION TESTS OF STEEL USED IN COLUMNS.

Average Values.

. Col. No.	Diam. inches	Per cent Elongation in 8 in.	Yield Point pounds	Maxi- mum Load pounds	Yield Point lb. per sq. in.	Ultimate Strength lb. per sq. in.
1 2 3 6 7 10 11 12 14 16 17	.752 .618 .751 .622 .749 .623 .751 .623 .619 .623	31.2 32.4 30.9 30.1 32.2 31.8 30.6 31.8 29.1 30.6 31.5	17600 11850 18100 11770 17640 12070 18480 12050 11900 11030 12130	26230 17850 27280 17710 25530 17920 26780 17800 18350 17460 17900	39750 39500 40870 38650 40030 30280 41820 37070 39450 39470 39500	59200 59500 62000 58300 58300 58820 60520 58470 60820 58100 58350
Ay.		30.9			39800	59200

sq. in., and the elongation in eight inches averaged 30.9 %. Table 3 shows the results of the tests of steel used in the columns.

- 5. Test Specimens.—In making the test specimens, the effort was made to have the conditions of fabrication as nearly as possible the same in every case. In general two specimens of each kind were made, so that one would act as a check upon the other. Three types of specimens were made,—(a) cubes, (b) cylinders and (c) columns, the concrete for all being of the 1-2-3\frac{3}{4} mixture described above. Data for the test specimens are given in Table 4.
- (a) Cubes.—17 cubes were tested, all of 12-in. edge. They were generally made in pairs, the concrete being taken from the mix used in the columns of corresponding number. The concrete for the cubes was taken from the middle of the batch, and is thought to be representative. In the case of columns mixed in two batches one cube was made from each batch. The concrete




FIG. 1. FORMS FOR COLUMNS AND CYLINDERS.

was well tamped into the forms, and was troweled around the sides with a bricklayer's trowel to insure a good surface on the cubes. The conditions of storage were the same for the cubes as for the columns, the forms being taken off of correspondingly numbered specimens at the same time.

TABLE 4.
LIST OF TEST SPECIMENS.

		Minor Specimens					
			Reinforc	ement			
Col. No.	Size	Area of Cross-		Area		Cubes	Cylinders
3	in.x in.x ft.	section sq. in.	Kind	sq. in.	per cent		
1	12x12x12	147.4	4—3-in. rods	1.77	1.20		
2	9x 9x12	80.6	$4-\frac{5}{8}$ -in. rods	1.23	1.52	Cube $2_1$ Cube $2_2$	
3	12x12x12	146.2	$4-\frac{8}{4}$ -in. rods $12-\frac{1}{4}$ -in. ties	1.77	1.21	Cube 23	
4*	9x 9x12	182.0	Plain	0.	0.	Cube 4	
5	12x12x12	146.4	Plain	0.	0.	Cube $5_1$ Cube $5_2$	Cylinder 5
6	9x 9x12	80.9	4—§-in. rods	1.23	1.52		
7	12x12x12	145.5	4—¾-in. rods	1.77	1.21	Cube 7 <sub>1</sub> Cube 7 <sub>2</sub>	
8	9x 9x12	80.8	Plain	0.	0.		
0	12x12x12	146.6	Plain	Ō.	0.		Cylinder 9
10	9x 9x12	82.0	$4 - \frac{5}{8}$ -in. rods $12 - \frac{1}{4}$ -in. ties	1.23	1.50	Cube $10_1$ Cube $10_2$	Cylinder 10 <sub>1</sub> Cylinder 10 <sub>2</sub>
11	12x12x12	145.2	$4 - \frac{8}{4}$ -in. rods $12 - \frac{1}{4}$ -in. ties	1.77	1.21	Cube 11 <sub>1</sub> Cube 11 <sub>2</sub>	
12	9x 9x 9	82.7	4—§-in. rods 9—‡-in. ties	1.23	1.48		Cylinder 12 <sub>1</sub> Cylinder 12 <sub>2</sub>
13	12x12x12	148.8	Plain	0.	0.		Cylinder 13
14	9x 9x12	82.0	$\frac{4-\frac{5}{8}-in.}{12-\frac{1}{4}-in.}$ rods	1.23	1.50		
15	12x12x 6	148.0	Plain	0.	0.	Cube $15_1$ Cube $15_2$	
16	9x 9x 9	82.5	4-5-in. rods 9-1-in. ties	1.23	1.49	Cube 16 <sub>1</sub> Cube 16 <sub>2</sub>	Cylinder 16 <sub>1</sub> Cylinder 16 <sub>2</sub>
17	9x 9x 6	83.6	4-§-in. rods	1.23	1.47		
18	9x 9x 6	83.6	Plain	0.	0.		

<sup>\*</sup>No. 4 was accidentally shattered in placing in machine and is not further considered.

- (b) Cylinders.—Only 9 cylinders were tested. They were 8 in. in diameter and 16 in. long, and were made in the wrought iron forms shown in Fig. 1. They were made from the same concrete as the columns of corresponding numbers, and were treated in the same manner as the columns and cubes.
- (c) Columns.—Three series of columns were made, one of plain concrete with no reinforcement, one reinforced with vertical rods in the corners only, and one reinforced with vertical rods in the corners tied together by ties of \(\frac{1}{4}\)-in. rods every 12 in. in height. All columns were made square in cross-section, two sizes being used, 9 in. and 12 in. Three lengths of columns were used,—6, 9 and 12 ft. The sizes and arrangement of the steel are shown in Fig. 2.




FIG. 2. ARRANGEMENT OF REINFORCEMENT.

The ties were made by bending  $\frac{1}{4}$ -in. steel rods while cold about a suitable form. The vertical rods were in all cases cut 1 in. shorter than the finished length of the column, it being intended to have  $\frac{1}{2}$  in. of concrete over the rods at each end. In some cases, however, the rods settled before the concrete set until the end was found flush with the bottom of the column.

6. Forms for Columns.—The forms for the columns were made of 2-in. pine plank, planed on both sides. Drawings of the forms

for the 12-in. columns are shown in Fig. 1, which are also typical of the forms for the 9-in. columns. Three sides of the forms were made of continuous pieces for the full height of the column, while the fourth side was made up of 2-ft. lengths. The forms were held together with braces of 2-in. x 4-in. pieces and  $\frac{1}{2}$ -in. bolts. Wedges were used to adjust the form to the correct width and to hold it while the concrete was put in. It will be noticed that all parts of the forms are reversible, so that the sides can be turned over if they become warped through use. Three forms each were made for the 9-in. and the 12-in. columns, this number being sufficient to allow the forms to remain on the columns about two weeks before being needed for other specimens.

- 7. Making of Columns.—The forms were soaked in water for a few days before being set up. This kept the wood from drawing very much water out of the concrete and also decreased the tendency of the forms to warp. For the reinforced columns, the rods were put in place and fastened by temporary wooden blocks before any concrete was put in, the blocks being removed as the concrete was put into the forms. The concrete for the 12-in. x 12-in. x 12-ft. columns was mixed in two batches, care being taken to have both as nearly alike as possible. For all other columns, the concrete was mixed in one batch. The concrete was put in in 6-in. layers, each layer being thoroughly tamped or churned, troweled around the sides to improve the surface, and then tamped again. The consistency of the mixture was such that with a 4-in., 10-lb, tamper, efforts at tamping generally resulted in churning the mass, and water was constantly present on the top. When the column had been built up to the top of the first 2-ft. section of the open face of the form, another 2-ft. section was added, and the process carried on without intermission until the column was complete. In the columns with ties, the ties were placed 12-in. apart, as the concrete was filled in, the first tie being always 6-in. from the bottom of the column.
- 8. Storage of Columns—The forms were allowed in most cases to remain on the columns for a period of 14 days after making. Nothing other than this was done to protect the surface of the columns from drying out too rapidly in the air. The temperature of the laboratory in which the columns were made ranged from 60° F. to 70° F. The forms protected the columns enough to prevent the warmer air at the top of the room from affecting the re-

sults of the tests to any great extent. The columns were not moved from the vertical position in which they were made until they were tested. It was intended to test each specimen at the age of 60 days but owing to a delay in receiving some of the instruments, the general age of the specimens was somewhat greater than this.

- 9. Summary of Test Pieces.—Table 4 gives a list of all the test specimens made, together with the size, and amount and kind of reinforcement. Specimens having corresponding numbers were made from the same batches of concrete. Columns 17 and 18 were not made with the same care as the other test specimens, being intended for 30-day preliminary tests, but finally were used at about the same age as the other columns.
- 10. Testing Machines Used.—The machine used in testing the columns and cubes was a Riehlé vertical screw machine with a capacity of 600,000 pounds. Because of its design, it was admirably adapted to carrying on the tests described here. The vertical screws are 36 inches apart, and a guide frame prevents any lateral movement of the head. The machine has six speeds, of which only the slowest, .05 inches per minute, was used in these tests. The frontispiece shows the machine, the scale case and controlling levers, and also a column in position for testing. The cylinders were tested on a 100,000-lb. Riehlé testing machine. The slowest speed of the machine, 0.1 inches per minute, was used for the tests.
- 11. Method of Setting Specimens in Machine.—Cubes.—The cubes were set in the machine in plaster of paris in a manner similar to that which will be described for the columns. Pieces of building paper were placed between the plaster and the bearing blocks of the machine to protect the latter.

Cylinders.—The cylinders were set in plaster and in addition a bearing block having two spherical surfaces of contact was placed above the specimen.

Columns.—The columns, when ready to be tested, were moved from the place where they were made to the machine by means of a four-legged crane, built especially for moving beams in the laboratory. This crane was high enough so that the columns could be raised vertically off of the floor by a block and tackle at one end of the crane. The tackle was fastened to a rope looped around the column slightly above its center of gravity, the top of the column being steadied by ropes tied to the top of the crane. After

being wheeled to the machine in this almost vertical position, two tackles on the machine were attached to opposite faces of the column near the top. The column could then be swung directly over the bearing block on the weighing table of the machine. A thin layer of rather slow-setting plaster of paris was then spread upon the bearing plate and the column lowered to a bearing in the plaster. Care was taken that the column was directly in the center of the machine and that it was plumb. The column was held in the proper position until the plaster bearing had set, after which the tackles were removed and a layer of plaster applied to the top of the column. The head of the machine was run down on this




FIG. 3. EXTENSOMETER DEVICE.

plaster which was allowed to set under a load of several thousand pounds. A piece of galvanized sheet iron was used between the column and the pulling head of the machine to protect the latter from the plaster. This method of setting the columns in plaster assists in giving a uniform bearing over the entire area of the specimen.

12. Measuring Devices.—The shortenings or longitudinal deformations of the columns were read by means of an extensometer especially devised for these tests. (See Fig. 3). The extensometers were so arranged as to indicate the deformation in the center of each face of the column. The dials were arranged in pairs, those on opposite faces of the column being on the same yoke. The yokes were fastened to the column by means of four contact points, two on each opposite face. These contact points were 9 inches apart for the 12-in. and 6 inches apart for the 9-in. columns and were placed symmetrically with regard to the center line of the column. The two yokes carrying the dials were




FIG. 4. ARRANGEMENT OF APPARATUS.

placed 3 inches apart at the bottom of the column, while the yokes carrying the corresponding extensometer bars were placed in a similar position at the top of the column. The gauged length was usually about 12 inches less than the length of the column. The extensometer bars were made of seasoned maple with steel blades at the ends to make contact with the rollers of the dials, which were so arranged that the blades of the extensometer bars could be held against the rollers by means of rubber bands. The dials, which were  $4\frac{1}{2}$  inches in diameter, read to ten-thousandths

TABLE 5. SUMMARY OF COLUMN TESTS.

	Reinforceme	ent	Maxii	num Load		
Col. No.	Kind	per cent	Total pounds	lb. per sq. in. of Gross Section	Age days	Manner of Failure
1	4-8-in. rods	1.20	234000	1587 .	71	Crushed on one side, 4 ft. from bottom
2	4—5-in. rods	1.52	127000	1577	69	Crushed out near top
3	$4 - \frac{8}{4}$ -in. rods $12 - \frac{1}{4}$ -in. ties	1.21	272000	1862	71	Crushed out I ft. from bottom. Rods final- ly buckled
5	Plain	0.	250200	1710	69	Crushed and sheared diagonally, 1½ ft. below top
6	4—§-in. rods	1.52	129400	1600	70	Crushed out 1 ft. from bottom. Rods finally buckled
7	4—å-in. rods	1.21	269000	1850	65	Crushed and sheared 5 ft. from bottom
8	Plain	0.	162000	2004	64	Top sheared off
9	Plain	0.	236000	1610	65	Crushed and sheared off at top
10	4—5-in. rods 12—1-in. ties	1.50	105000	1280	65	Crushed out 1 ft. from bottom. Rods finally buckled
11	4—\frac{8}{4}-in, rods 12—\frac{1}{4}-in, ties	1.21	281200	1936	65	Crushed 1½ ft. from top
12	$\frac{4-\frac{5}{8}}{9-\frac{1}{4}}$ -in. rods	1.48	193100	2335	66	Crushed 1 ft. below top
13	Plain	0.	254000	1709	61	Crushed in middle of length
14	$\frac{4-\frac{5}{6}-in.}{12-\frac{1}{4}-in.}$ rods	1.50	112000	1367	63	Crushed 1½ ft. below top
15	Plain	0.	176000	1189	63	Crushed 1 ft. from top
16	$4-\frac{5}{8}$ -in. rods $9-\frac{1}{4}$ -in. ties	1.49	132500	1607	59	Crushed at center Rods finally buckled
17	$4-\frac{5}{8}$ -in. rods	1.47	184400	2206	67	Crushed 1 ft. from top. Rods finally buckled
18	Plain	0.	90300	1079	65	Crushed 1 ft. below top

of an inch. A clearer idea of the extensometers and method of using them may be obtained from Fig. 4 and also from the various photographs of the tests. Usually two men were engaged in taking the readings.

The lateral deflections of some of the columns were measured roughly by means of a thread and scale, fastened on the column as shown in Fig. 4. These readings were used only as a check on the way the column was deflecting.

13. Application of the Load.—In testing the columns, the load was applied in increments of about 10,000 pounds, the operator holding the load and the observers taking the readings about 30 seconds after the load was attained. The machine speed was .05 inches per minute. In six columns the load was increased progressively until failure occurred. In ten the load was released at one-third to two-thirds of the ultimate, and then reapplied. In one the load was released twice.

### III. EXPERIMENTAL DATA AND DISCUSSION

- 14. Column Test Data.—Table 5 gives data of the age of test, maximum load on column, and manner of failure. The proportion of the load taken by the concrete and by the steel is considered in a succeeding paragraph.
- 15. Phenomena of the Column Tests.—Most of the columns failed in either the top or bottom third of the length, only three failing at or near the center. Ten failed in the top third and four in the bottom third. The numerous failures near the top may possibly be due to drying out of the top of the columns, or more probably to the naturally greater porosity of the concrete there.

In most cases, little warning in the way of cracks or sounds was given before the maximum load was reached. Five of the columns, all reinforced ones, gave warning by noises or vertical cracks slightly before the concrete sustained the maximum stress. Eight columns, including all the plain ones, showed no sign of failure until the maximum load on the concrete was reached. The remaining four showed first sign of failure after reaching the maximum stress in the concrete but before the maximum load taken by the column as a whole was attained.

The plain columns failed suddenly, an explosive noise sometimes accompanying the crushing. The failure of the reinforced columns was usually first indicated by vertical hair cracks after which the column commenced to bulge at the point of failure. Since in practically every failure the reinforcing rods buckled, it would seem at first thought that the failure was caused by a lateral deflection of the rods, resulting in splitting of the concrete outside the reinforcement, but in the discussion of the observations it will be shown that this buckling occurred after the failure of the concrete.

The following notes show the principal features of the tests of individual columns:

Column No. 1. At about the maximum load fine cracks appeared on one face 4 ft. above the bottom and soon spread to the adjoining face, but no crack appeared on the opposite face. Failure occurred at this point. Fig. 5 shows the appearance of the cracks on the face first showing sign of failure. At the maximum load the column deflected laterally at the middle of its length 0.22 in. in a direction away from the face on which failure first showed. This column gave the greatest lateral deflection measured, the next highest being only one-third as much. At a load of 167,000 lb. (1132 lb. per sq. in.) hair cracks appeared at the top of the column but these did not develop further. With the continued application of the load after the maximum had been reached, the concrete broke out, accompanied finally by buckling of the reinforcing rods.





FIG. 5. TYPICAL FAILURES.

Column No. 2. Failed by crushing at top, the first crack appearing near one corner at the maximum load. Failure occurred immediately. A few cracks had appeared at the bottom of the column but these did not develop further. It would appear that the top end was weaker than the remainder of the column.

Column No. 3. Failed by crushing at a point 12 inches above the bottom at the maximum load. With continued application, all vertical rods buckled between the two ties. Fig. 5 shows the final condition at the point of failure.








FIG. 6. VIEWS SHOWING COLUMN NO. 7 AND 16 AFTER FAILURE.

Column No. 4. This column was accidentally broken in setting it in the machine. It is not considered in this report.

Column No. 5. Failed at maximum load by crushing and shearing off completely on a diagonal line. No warning cracks appeared before maximum load was reached. The shearing plane extended from a point 9 in. below the top on one face to 2 ft. 5 in. on the opposite face.

Column No. 6. In this column the reinforcing rods extended through to the bottom of the concrete and thus had a direct bearing on the bed of the machine. The first crack appeared just before the maximum load taken by the concrete was reached. Failure occurred by compression of the concrete 12 in. above the base, and with continued application of the load the rods buckled at this point.

Column No. 7. Failed by compression of the concrete at a point about 5 ft. above the base, followed a little later by buckling of the rods. With continued application of a load nearly as great, the column finally sheared off diagonally with a loud explosive noise to a point 2 ft. 6 in. above the base. Fig. 6 shows the manner of failure. The greatest lateral deflection was 0.05 in.

Column No. 8. Failed without warning cracks by crushing at the top and shearing diagonally to a point 2 ft. 4 in. below.

Column No. 9. Failed without warning cracks and without noise by crushing diagonally about 18 inches below the top. Fig. 5 shows two faces.

Column No. 10. Failed by crushing out between the bottom two ties, 12 in. from the base. The concrete broke out near the vertical rod on one corner. This rod was found to rest directly upon the bed of the machine at the completion of the test. The lateral deflection was .02 in. Fig. 5 shows one face after failure.

Column No. 11. A corner was knocked off of the top of the column for a distance of  $2\frac{1}{2}$  in. each way while setting it in the machine. Failure occurred by crushing between upper two ties 16 in. below the top after the maximum stress on the concrete had been passed. The lateral deflection was .07 in.

Column No. 12. Failed by crushing between upper two ties 13 in. below the top. First crack appeared at maximum load on the column, after the maximum stress on the concrete had been passed. Crackling sounds were heard at 2,275 lb. per sq. in.

Column No. 13. Failed by crushing nearly squarely across at the center of the height of the column. Vertical cracks extended half the length of the column. No cracks appeared before maximum load was reached.

Column No. 14. Failed by crushing at from 12 to 22 in. below the top. With continued application of the load the rods buckled between the top two ties. Maximum lateral deflection of column was .02 in.

 $\label{table 6.}$  Tests of Cubes and Cylinders.

		Cubes		Cylinders			
No.	Age at Test days	Total pounds	lb. per sq. in.	No.	Age at Test days	Maxir Total pounds	lb. per sq. n.
$\begin{array}{c} \frac{2}{2} \\ \frac{1}{5} \\ \frac{1}{5} \\ \frac{1}{5} \\ \frac{1}{5} \\ \frac{1}{5} \\ \frac{1}{7} \\ \frac{1}{7} \\ \frac{1}{2} \\ \frac{1}{10} \\ \frac{1}{10} \\ \frac{1}{2} \\ \frac{1}{15} \\ \frac{1}{15} \\ \frac{1}{2} \\ \frac{1}{15} \\ \frac{1}{2} \\ \frac{1}{15} \\ \frac{1}{2} \\ 1$	67 67 61 61 69 70 64 76 75 67 67 66 66 39 39	282400 280000 333100 368700 256500 383000 273100 352500 353500 282400 280000 348000 213000 223400	1970 1954 2314 2572 1790 2672 1897 2308 2453 2340 1970 1954 2090 2417 1472 1550	$\begin{array}{c} 5 \\ 9 \\ 10_1 \\ 10_2 \\ 12_1 \\ 12_2 \\ 16_1 \\ 16_2 \end{array}$	68 59 80 80 78 80 69 69	85600 55000 52000 61000 100320 95000 75500 59100	1758 1112 1068 1233 2088 1920 1525 1212
A v.			2100	• • • • •			1490

Column No. 15. Failed by crushing at about 12 in. from the top, vertical cracks appearing on all sides when maximum load was reached. No cracks appeared previously.

Column No. 16. Failed by crushing near the center of the length of the column, the first crack appearing just before the maximum load on the column, and some time after the max-

imum stress in the concrete had been reached. With further application of the load vertical rods buckled between three successive ties.

Column No. 17. Failed by crushing at maximum load 12 in. below the top. Rods finally buckled between top two ties.

Column No. 18. Failed by crushing at maximum load 12 in. below top. This column showed poor concrete.




Fig. 7. Stress-deformation Diagram for Column No. 5.

16. Cube and Cylinder Test Data.—Table 6 gives data of the age at test and of the compressive strength of the cubes and cyl-

inders which were made from the same batches of concrete as the corresponding columns. Reference to the strength of the con-




Fig. 8. Stress-deformation Diagram for Column No. 12. - crete in the columns given in Tables 7 and 8 shows that the cubes

and cylinders correspond to the weaker rather than to the stronger columns.

Stress-deformation Diagrams.—In Fig. 13 to 29, following 17. the text, and in the sample figures (Fig. 7 and Fig. 8) given in the text, the stress-deformation diagrams represent the observed loads and the corresponding deformations or shortenings for the columns tested. The ordinates (vertical distances on the diagram) represent the loads or pressure per square inch on the columns. For the reinforced concrete columns, for convenience of calculation, the unit-loads given on the diagram are based upon the gross area of the column. The bearing of this assumption upon the stresses in the concrete is discussed elsewhere. The abscissas (horizontal distances on the diagram) represent the unit-deformations, or shortenings per unit of length, determined from the observed extensometer readings for the gauged length used. These values are the averages for the readings on the four faces of the In general, the readings on the four faces varied but little from each other, as would be the case if the head of the machine moved parallel with itself and the column deflected laterally but slightly.

In these diagrams the amount of deformation is calculated by using as the zero reading the extensometer reading at the original zero of load or load at which the first reading was taken. In other words, the deformation shown is independent of any set which the load may have produced in the concrete. Whether gross or net (elastic) deformations are to be considered in discussing the results of tests depends, of course, on the use which is to be made of the results. In a discussion of the action and effect of longitudinal reinforcing bars, it would seem that gross or total deformations should be used rather than net or elastic deformations, and this is one reason for choosing to use gross deformations here. Since nothing is known of the shrinkage stresses in the concrete and steel, no consideration of their effect will be made.

The "Line for initial modulus of elasticity" given on the diagrams is the tangent at zero load for a parabola which has been found to fit the stress-deformation curve closely. The analysis and formula for the parabola and the initial tangent are given in a succeeding paragraph. In the choice of parabola for a given stress-deformation curve, the effort has been made to fit the curve fairly closely, but a fair correspondence between the ordinate for

the vertex of the parabola and the ultimate strength of the concrete has been looked for and also an agreement of the vertex with the deformation of the concrete at the maximum load. While some variation may be found in the exercise of the judgment in determining this parabola, yet the range of choice is less than is found when attempting to select a straight-line modulus through the early part of the curve.




Fig. 9. Stress-deformation Diagram for a Reinforced Concrete Column.

The line marked "Line for steel" represents for any given deformation the load per square inch considered distributed over the area of the column which is equivalent to that taken by the steel alone, considering the modulus of elasticity of the steel to be 30,000,000 lb. per sq. in. Thus, for a deformation in the column of .001, the corresponding stress in the steel is 30,000 lb. per sq. in. For a column having steel reinforcement equal to  $1\frac{1}{2}\%$  of its cross section, the load thus taken by the steel is equivalent to 450 lb. per sq. in. distributed over the whole cross section, and the "Line for steel" is drawn through 450 lb. per sq. in. and a unit deformation of .001. For any given deformation, then, the amount of load below this line represents, on this basis, the part taken by

the steel reinforcement, and the amount above this line represents the part taken by the concrete. To illustrate, in Column No. 12 (Fig. 8) for a deformation of .0005 the steel will, by this analysis, be taking the equivalent of 220 lb. per sq. in. distributed over the cross section of the column (15,000 lb. per sq. in. on the steel alone), and the concrete will be taking 1,020 lb. per sq. in.; for a deformation of .001, the steel will be taking the equivalent of 440 lb. per sq. in. (30,000 lb. per sq. in. on the steel alone), and the concrete 1,560 lb. per sq. in. Strictly speaking, the amount so found should be increased by a percentage equal to that occupied by the steel area, since the former calculation assumes that this area is occupied by concrete, but as the effect of this correction is small it has been neglected.

In the case of the plain concrete columns, the maximum load may be expected to occur at or before the vertex of the parabola. Evidently, even if such a curve as the parabola fits the stress-deformation curve fairly well for low and medium loads, it may not be expected to agree so closely near the maximum, and beyond the maximum load such a law of course is not applicable. Fig. 7 shows the stress-deformation curve and points on its parabola for Column No. 5. In this and in Fig. 13 to 18 at the end of the text, several points of the parabola which is taken to express the stress-deformation relation have been calculated for the columns and are shown on the diagrams by points marked by crosses. These are given at deformations equal, respectively, to one-sixth, one-quarter, one-half, and full abscissa of the vertex of the parabola. The last one given is for the vertex of the parabola.

In the case of the columns reinforced with longitudinal rods, (1) a new diagram may be made to express the load taken by the concrete alone, or (2) the stress-deformation line may be considered to be drawn according to a modified system of oblique co-ordinates. In Fig. 9 the line OE represents the stress-deformation relation for the combination of steel and concrete and OC that for the steel. For (1), if the point E be set down to D a distance ED equal to CG, the ordinate GD will represent the stress taken by the concrete alone at this point. If, now, the amounts taken by the concrete alone, found on the above basis, be replatted, using the line OX as an axis, the new line OD marked "Line for concrete alone" will be the stress-deformation diagram for the concrete itself, and will be found to approximate to a parabola as in the

plain concrete columns. The resemblance of this curve and tangent to those for the plain concrete columns is at once apparent. (In Fig. 8, a diagram for the concrete alone is shown for Column No. 12.) The line OB is the tangent for this curve, or line for initial modulus of elasticity. By (2), the representation by a modified system of oblique co-ordinates, the ordinates or loads taken by the concrete are measured from the oblique line marked "Line for steel", and the shortenings of the column are measured horizontally as before. In Fig. 9, CE will represent the stress in the concrete at its maximum load, and the stresses in the concrete for other deformations will be found by measuring upward from the line OC. The separate diagram gives a good expression of the stress in the concrete itself. However, the line OE (Fig. 9) represents this stress-deformation relation as well, if we keep in mind that ordinates are to be measured from OC, and that diagonal distance or spaces are misleading. OA, which will represent the line for the initial modulus of elasticity in this combination or oblique diagram, will be above OB, and any point of it will be as much higher as the vertical distance of the corresponding point on OC is above OX. This line OA, from its distorted position, may not seem to be tangent to the curve OE. The point E on the oblique or combination parabola, directly above the vertex D of the ordinary parabola, must be considered to be the vertex of the oblique parabola, and is the point where the maximum load is taken by the concrete according to this stress-deformation relation, as is shown by the tangent line EF being parallel to OC. Beyond this point, while the column as a whole may sustain a larger load, a greater proportion of the load is taken by the steel, and the concrete has passed its maximum carrying capacity. In general, then, the point at which the concrete carries a maximum amount may be obtained by finding the point (as E) where a line parallel to the . line for steel (OC) is tangent to the stress-deformation curve and then determining the load above the line for steel. represented by CE, may then be considered the maximum load taken by the concrete. The values given in the discussion which follows were calculated on this basis. This analysis, as is shown later, is borne out by the results of the columns tested. Although the oblique or combination diagram may strike the reader strangely, it was not thought necessary to reduce the readings to ordinary rectangular co-ordinates and make a second set of diagrams.

The diagrams given in Fig. 19 to 29, while at first perhaps appearing distorted, will, it is believed, give a comprehensive view of the relation between the loads taken by the concrete and steel for any given deformation or shortening of the column.

18. The Parabolic Stress-deformation Relation.—To begin with, it may be premised that a study and analysis of the relation between the stress or load in pounds per square inch and the unit deformation or shortening of the concrete will be of considerable value in the discussion and interpretation of the phenomena of compression of concrete in plain and reinforced columns. stress-deformation relation has an important bearing upon the strength of columns and on the proportion of load taken by the concrete and by the steel reinforcement in reinforced concrete columns. An analysis based on a curved stress-deformation relation, although not difficult, requires some little explanation. is hoped, therefore, that the reader will go over the discussion fully with the applicability of such an analysis in mind and not hastily conclude that undue weight has been attached to the curved form of the stress-deformation relation. Nor should the reader consider that the use of the parabolic relation in this discussion commits the writer to the position of excluding the straight-line stress-deformation relation (constant modulus of elasticity) from use in any formulas or applications whatever.

In a general way it may be said that concrete does not possess the property of proportionality of stress and deformation for wide ranges of stress as does steel; in other words, the deformation or shortening produced by a load is not proportional to the compres-The relation between stress and deformation is not sive stress. entirely uniform; there are even considerable differences in deformations for the same mixture, but generally the variation from direct proportionality is less for the richer mixtures. curves have been proposed to represent the stress-deformation relation, but the parabola is the most satisfactory general representation. Frequently the parabola expresses the relation almost exactly, especially for mixtures of medium richness, and in nearly every case the parabolic relation will fit the stress-deformation diagram very closely throughout the part which is ordinarily developed in columns, the lack of agreement near the crushing point not being so important. Fig. 7 and Fig. 8 show the close agreement of the observed stress-deformation curve and the parabolic relation for Columns No. 5 and 12.

Modulus of elasticity is a term which has been used very loosely in connection with reinforced concrete. As a general property of materials, it is defined to be the ratio of the unit stress to the unit deformation within the elastic limit of the material. As applied in this way to materials having the property of proportionality of stress and deformation, the modulus of elasticity is a constant. For materials with a variable stress-deformation relation like concrete it may not be considered proper to call the variable ratio the modulus of elasticity, and such a use may lead to misunderstanding. However, it is important that a definite expression for this ratio be found.




Fig. 10. Stress-deformation Diagram for a Plain Concrete Column.

The writer obtains this relation from the initial modulus of elasticity and uses the term "Initial Modulus of Elasticity" to express the relation which would exist between stress and deformation if the concrete compressed uniformly at the rate it compresses when the load is first applied. For the parabolic stress-deformation relation, the line which represents this uniform or constant stress-deformation relation will be tangent to the parabola at the zero point. In Fig. 10 the ordinates represent unit stresses (pounds per square inch) and the abscissas unit deformations (shortenings in inches per inch). The relation between the stresses and the corresponding deformations may be represented by the part of a parabola, OA, which has its vertex at A, AC being its axis. The oblique line is tangent to the parabola at O, and

the tangent of the angle which it makes with the vertical is  $E_c$ , where  $E_c$  is the value of the initial modulus of elasticity. The equation of this line is  $x = E_c y$ , and this equation would give the relation between the compressive stress and the deformation if the stress-deformation relation were constant; or in other words if the modulus of elasticity were a constant.

The equation of the parabola may best be expressed by its relation to this line for initial modulus of elasticity. Let c represent compressive unit-stress for any point, (for the point P the ordinate DP represents c) and c' the maximum compressive stress (ordinate of vertex of parabola, CA). Let  $\epsilon_c$  represent the unit-deformation for the point P (abscissa OD) and  $\epsilon'_c$  the unit-deformation corresponding to the maximum compressive stress (abscissa of the vertex of the parabola, OC). It can be shown that  $c = E_c \epsilon_c$ 

 $\frac{1}{2}\frac{1}{\epsilon_c'}E_c\epsilon_c^2$  may be taken as the equation of the parabola. On this

basis, this equation expresses the relation between the compressive stress and its corresponding deformation. It may be noted that the first term of the second member gives the stress corresponding to a given deformation by the straight-line relation, while the remaining term expresses a correction or reduction which changes the results materially for the higher deformations.

The value of the deformation at the maximum compressive strength of concrete,  $\epsilon'_c$ , (abscissa of the vertex of the parabola), enters into equation (1). For many applications, it is convenient to express the deformation as a part of or in terms of this vertex deformation. Call the ratio of the deformation developed at a

given load to the deformation at the maximum load q (i. e.,  $q=\frac{\epsilon_{\rm c}}{\epsilon_{\rm c}'}$ )

and the foregoing equation becomes

$$c = E_{c}\epsilon_{c} - \frac{1}{2} \frac{1}{\epsilon_{c}} E_{c}\epsilon_{c}^{2} = (1 - \frac{1}{2} q) E_{c}\epsilon_{c} \dots \dots \dots \dots (1)$$

The following relation may also be derived

$$\frac{c}{c'} = (1 - \frac{1}{2} q) 2 q.$$
 ....(2)

When this parabolic relation is used the value c' will refer to the stress for the vertex of the parabola and  $\epsilon'_c$  as its correspond-

ing deformation or abscissa. These may vary somewhat from the maximum compressive strength of the concrete and its corresponding deformation, but not greatly. The two sets of values should not be confused.

In Fig. 10 it may be seen that for the lower ranges of stress the parabola does not vary greatly from the straight line. At the

TABLE 7.
PLAIN CONCRETE COLUMNS.

Col.	Gauged Length	Initial Modulus of Elasticity lb. per sq. in.	Abscissa of Vertex of	Maximum Stress lb. per sq. in.		
No.	inches		Parabola	Parabola	Observed	
5	114	3 150 000	.0011	1730	1722	
8 9	114 114	$2530000 \\ 2500000$	.0016	$\frac{2000}{1620}$	2004 1615	
13	60	2 370 000	.0013	1660	1709	
15	60	$\frac{1}{2}$ 000 000	.0012	1200	1189	
18	60	1 490 000	.00145	1080	1079	
Av.		2 340 000	.00134	1550	1553	

vertex, however, the compressive stress (representing the maximum compressive strength) is one-half of that given by the straight-line relation. At one-half of ultimate deformation  $(q = \frac{1}{2})$  it is three-quarters of that given by the straight-line relation.

The modification of the stress-deformation relation when longitudinal reinforcement is introduced has already been described.

19. The Stress-deformation Relations Developed in the Columns.—
It will be well to discuss the stress-deformation relations found in the columns tested, not so much because of the importance of the relations themselves, but for the reason that the results throw light upon the strength, stiffness, uniformity, and reliability of the columns. The diagrams (Fig. 13 to 18, following the text) contain the stress-deformation curves for the plain concrete columns. As has already been stated, these diagrams are based upon gross or total shortenings and not on net or elastic defor-

mations, since one use of the data will be to permit comparison, in the case of columns having longitudinal reinforcement, of the amount of load taken by the concrete with that taken by the steel, and the use of elastic deformation would involve consideration of stresses left in the steel upon release of load.

An examination of these diagrams shows that the maximum loads on the columns are in agreement with the stress-deformation diagrams, no column failing at a lower load than would be expected from a study of its diagram. The porous nature of Column No. 18 (a column made with less care than was given to the others) is shown by its diagram, (Fig. 15), which early gives indication of the low ultimate strength. The points given on these figures (denoted by crosses) for the parabolic stress-deformation relation agree, in general, fairly closely with the diagrams.

Table 7 gives for the plain concrete columns values for the initial modulus of elasticity, the deformation at the point of maximum strength used (abscissa of vertex of parabola), the maximum stress shown by the parabolic relation and the observed maximum compressive strength of the parabolic relation and the observed maximum compressive strength of the column. Except for Columns No. 5 and 18, both the modulus of elasticity and the abscissas of the vertex of the parabolas have a small range, and even including these the results show as small variation as may be expected in concrete made in this way. The average value for the initial modulus of elasticity, 2,340,000 lb. per sq. in., not only is of interest in its application to columns but it may have a bearing upon the value to be used in beam formulas. It should be noted that these values are for the first application of a load. For a repetition of a load the modulus of elasticity would be somewhat lower than this, the amount of this decrease depending upon the concrete and the number of repetitions. The average value for the abscissa of the vertex of parabola is .00134.

Table 8 gives similar values for the reinforced concrete columns. The amount of load taken by the concrete was found by the method described under Stress-deformation Diagrams, and the initial modulus of elasticity was taken from the derived stress-deformation curve for concrete alone. The abscissa of the vertex was found in a similar way. The maximum stress taken by the concrete was determined from the point on the stress-deformation curve at which a tangent is parallel to the line for the steel.

It will be seen by inspection of the diagrams that the column as a whole takes a load somewhat greater than that which gives the maximum stress on the concrete, the increase coming from the increased stress in the steel, though the amount of this increase

TABLE 8.

REINFORCED CONCRETE COLUMNS.

Col.	Length nes	cent	Initial	Abscissa of lb. pe	in Co		Maximum Stress on
No.	Gauged Ler inches	per cent Reinforcement	Modulus of Elasticity lb.per sq.in.	Vertex of Parabola	Parabola	Ob- served	Gross Area lb. per sq. in.
1	132	1.20	2 570 000	.00095	1220	1220	1587
$\frac{2}{3}$	108	1.52	2330000	.0010	1165	1160	1577
3	132	1.21	2 340 000	.0012	1400	1380	1862
6	132	1.52	2 090 000	.00105	1095	1090	1600
7	132	1.21	2 570 000	.0011	1410	1400	1850
10	132	1.50	1 800 000	.0009	810	775	1280
11	$\frac{132}{95}$	1.21	2430000 $2500000$	.0012	1460 1687	$\frac{1460}{1685}$	1936 2335
12 14	$\frac{95}{132}$	$\frac{1.48}{1.50}$	$\frac{2000000}{2000000}$	.00135	950	955	2555 1367
16	95	1.49	1 900 000	.00095	1000	990	1607
17	60	1.45	1 900 000	.0016	1520	1560	2206
			200000	.0010	1020	2000	
Av.			2 220 000	.00112	1247	1243	1746

averages only 2.2% and the largest increase is only 6.6%. The range of values for the initial modulus of elasticity is not greater than for the plain concrete columns, nor is that for deformation at vertex of parabola.

The last column of Table 8 gives the maximum load taken by the column in lb. per sq. in. of gross area, and hence includes the load taken by the steel.

The average value of the initial modulus of elasticity for the reinforced concrete columns is 2,220,000 lb. per sq. in. The average value of the final unit-deformation is .00112. The average variation from the average modulus of elasticity is 11%. The average variation from the average final deformation is 14%. The average value of the initial modulus of elasticity, 2,220,000 lb.

per sq. in., is very close to that for the plain concrete column, 2,340,000 lb. per sq. in. The final deformation is lower than that for the plain concrete columns. The range of results is smaller than that for the plain concrete columns.

The average modulus of elasticity for both plain and reinforced columns is 2,250,000 lb. per sq in. The average variation from this is 14%. The range covered is 40% above the average and 34% below, the extreme cases both being plain concrete columns.

Table 9 gives the observed and calculated loads for both plain and reinforced columns at four points of the tests. The loads include both the part taken by the concrete and that taken by the steel. The calculated loads are determined from the initial modulus of elasticity and parabola given in Tables 7 and 8. In the table,  $\epsilon'_c$  represents the deformation at the point of maximum stress in the concrete, which agrees with the abscissa of the vertex of the parabola used. The values given in the last column therefore may not be expected to agree with the values given in Table 8 for maximum stress on gross area.

The three other points selected are at deformations of one-sixth  $(q=\frac{1}{6})$ , one-quarter  $(q=\frac{1}{4})$  and one-half  $(q=\frac{1}{2})$  of this deformation. It will be seen that the observed and calculated loads compare very favorably. The calculated loads are also shown in Fig. 13 to 29 (following the text) by points marked by crosses. Values for the Watertown Arsenal column tests, described elsewhere, are included in Table 9.

20. Strength of the Plain Concrete Columns.—Naturally, with the variation in materials and in the conditions attending fabrication and setting, concrete columns may not be expected to have uniform strength and stiffness. The conditions attending the fabrication of test specimens, however, are more nearly constant than those to be found in ordinary building operations and a greater allowance for variation should be made in building design than the variation found in these test columns. No. 18, which was made hastily and somewhat carelessly, with the expectation that it would be used at an early age merely for practice in the use of the instruments and machine, gives not only less stiffness but a very low compressive strength.

TABLE 9.
CALCULATED AND OBSERVED LOADS.

Loads are given in pounds per square inch of the gross section of the column and hence include the load taken by the steel.

Col.	At $\frac{1}{6}$ $\epsilon_{\mathrm{c}}'$		At ¼ €c		At $\frac{1}{2} \epsilon_{\rm c}'$		At $\epsilon_{\mathrm{e}}^{'}$	
No.	Calc.	Obs.	Calc.	Obs.	Calc.	Obs.	Calc.	Obs.
	•		University	y of Illino	ois Colum	ıs.		
$\begin{array}{c} 1 \\ 2 \\ 3 \\ 6 \\ 7 \end{array}$	440 430 505 400 500	435 430 545 415 515	610 625 725 600 720	600 620 745 600 705	1085 1105 1270 1065 1260	1055 1080 1265 1045 1300	1560 1620 1840 1575 1815	1560 1570 1815 1570 1810
10 11 12 14 16	315 520 605 365 380	315 540 630 385 415	440 750 895 525 550	435 750 910 535 555	805 1320 1575 915 980	785 1310 1575 910 960	1210 1900 2290 1370 1450	1205 1895 2290 1375 1450
17 5 8 9 13	595 520 610 495 505	540 520 630 490 505	845 770 875 710 725	820 745 880 690 710	1490 1300 1500 1220 1240	1535 1275 1435 1150 1170	2230 1730 2000 1620 1660	2200 1720 2005 1620 1710
15 18	370 330	385 345	525 475	525 475	900 8 <b>0</b> 5	860 765	1200 1080	1190 1080
Av.	463	473	662	664	1167	1146	1656	1651
			Waterto	wn Arsena	al Column	S		
1579 1580 1581 1582 1584 1585 1583	805 557 640 650 820 675 645	830 555 610 620 820 630 650	1130 755 885 905 1170 930 890	1130 750 880 860 1110 870 890	1920 1260 1480 1500 1980 1600 1450	1920 1280 1475 1450 1930 1550 1420	2800 1820 2080 2110 2870 2460 1800	2800 1830 2060 2110 2870 2460 1800
Av.	685	673	952	927	1598	1575	2277	2275

The average maximum load for the plain concrete columns tested, as shown in Table 7, was 1553 lb. per sq. in. The lowest load, 1079 lb. per sq. in. for Column No. 18, is 30% less than this

average, and the highest load, 2004 lb. per sq. in., is 29% more than this average. The average variation from the average strength is 18%. This range is not large, considering the nature of the material. As has been stated, the stress-deformation diagrams indicate that the maximum loads found correspond with the general behavior of the columns and that the test loads were generally concentrically applied and uniformly distributed. They also show the variation in quality and action. The diagram of No. 18 shows its porous nature and foretells failure at a low load. No general difference in results between 9 x 9-in. and 12 x 12-in. columns is noticeable.

A comparison of the ultimate strength of the cubes tested with the loads carried by the columns made with the same mix shows that the strength of the columns is materially less than the strength of the cubes. As shown in Table 6 the average for the 12-in. cubes is 2205 lb. per sq. in. and that for the columns is 1553 lb. per sq. in., 30% less. It seems probable that the restraining influence of the friction against the bearing plates is a cause for the additional strength in the cubes, as has been shown by some experimenters to be the case, while in the columns this influence does not extend far from the ends. The results with the 8 x 16-in. cylinders given in the same table (average of 1490 lb. per sq. in.) agree very closely with the column tests and corroborate this view.

21. Strength of the Reinforced Concrete Columns.—Two things are noticeable in the results given in Table 8 for the loads taken by the concrete in the columns reinforced with longitudinal rods,—that the maximum stresses taken by the concrete are less than for the plain concrete columns, and that the range of results is greater. Before discussing these apparent characteristics of the tests, it will be well to consider some of the conditions attending the tests and the possible effect of such conditions upon the results.

No effort was made to bring the ends of the reinforcing rods to have a bearing upon the compression or bearing plates of the testing machine. Generally, the rods ended within  $\frac{1}{2}$  in. of the end of the column. In No. 6, the rods rested on the bearing plate; in No. 10, one rod rested on the plate; and in No. 14, the rods extended to the face of the plaster in which the ends of the columns were bedded. Evidently it would be difficult to get an exact and even bearing for all the rods directly against the plates. The

concrete or plaster under the ends of the rods would not be capable of transmitting as great a stress per square inch as is taken by the steel, and part of the load taken by the steel must be carried through the surrounding concrete and be transmitted to the steel by means of the bond between concrete and steel. Fortunately this extra stress on the concrete exists at the ends of the columns where the concrete has the aid of the lateral restraining influence of the bearing plates. The bond developed would cause the stress to be transmitted to the rods within a short distance of the end of the column. Whether this is done before the concrete is beyond the influence of the bearing plates and, whether the bond developed is beyond the bond strength may, perhaps, be determined by a study of the stress-deformation diagrams and the method and point of failure of the individual columns. The vokes of the extensometers were in general within the portion of the length where the rods may be considered to be taking their full stress, and the deformations are the average deformations for the gauged length.

In all of the columns the point of maximum stress on the concrete is well within the point of ultimate failure, the deformation of the columns going on for some time beyond this maximum point. The form of the stress-deformation curve is similar for all the columns, and no difference can be detected for those with different positions of the ends of the reinforcing rods. The method of failure and the position of the failure are not noticeably connected with any end condition, and the distribution of the failures does not differ in any marked degree from that for the plain concrete columns. It would seem, then, that in general the position of the ends of the reinforcing rods has not affected the results in any marked manner, and there is no apparent reason for giving greater or less weight to the strength of any column. An exception to this may possibly be made in the case of No. 10, in which one bar rested on the plate and the failure was due to the breaking of the concrete around this rod at the end of the column. The condition is a severe one, and it is quite possible that the results in this case should be thrown out.

The average stress taken by the concrete, based on the analysis heretofore given, is, as shown in Table 8, for all the reinforced concrete columns 1243 lb. per sq. in. and with No. 10 omit-

ted, 1290 lb. per sq. in. Omitting Column No. 10, the lowest value is 26% below the average, the highest value is 30% above the average, and the average variation is 16%. The average strength of the plain concrete columns is 1553 lb. per sq. in. average strength of the reinforced concrete columns, based on gross area and without allowance for the steel, is 1746 lb, per sq. in. It will be seen that the stress taken by the concrete is, in the case of the reinforced columns, about 15% less than the strength of the plain columns, and that the total strength of the reinforced columns is considerably more than that of the plain columns. These results may not be representative, but at least they indicate that care should be taken not to use too high working stresses in columns reinforced in this way. The fact that the values of the initial modulus of elasticity average for the reinforced columns so closely to the average for the plain columns, is confirmatory of the correctness of the results. It may also be noted that the abscissa of the vertex of the parabola fitted to the reinforced columns is less than that for the plain columns. This fact is possibly connected with the explanation of the lower concrete stresses in the reinforced columns.

The columns having ties around the longitudinal rods show no greater strength than those without ties, and there is no difference apparent in the manner of failure. It is true that buckling of the rods occurred between the ties, but this buckling must have taken place after the concrete reached its maximum stress, judging from the stress-deformation diagrams. In fact, it may not be expected, from ordinary analysis, that ties placed at so great a distance apart will have a beneficial effect upon the strength of the columns.

22. Watertown Arsenal Column Tests.— Not many tests have been made on plain and reinforced concrete columns in a systematic way with a view of determining the relative amount of stress in the steel and concrete while under load. Many occasional or desultory tests have been made, but usually these furnish no basis for comparison. The only series made in the United States, known to the writer, which gives an opportunity for making a comparison with the tests here recorded, is the series made by the United States government at Watertown Arsenal and reported in Tests of Metals for 1904. The well known care and trustworthiness of the Watertown tests make it seem profitable to in-

clude here a summary of such of these tests as may be compared with the University of Illinois columns. The columns selected include all of those made with one grade of 1–2–4 concrete and tested at about the same age and include the numbers from 1579 to 1585. As only one column of plain concrete was tested and a single test may not be at all representative of the characteristics of a concrete, but little comparison between plain and reinforced columns may be made. The number of reinforced columns and the range of the reinforcement are such that the tests give a good opportunity to study the relative stresses taken by steel and concrete.

The concrete was made of one part Vulcanite cement, two parts sand ( $\frac{1}{8}$ -in. sieve), and four parts pebbles ( $\frac{1}{2}$  to  $1\frac{1}{2}$  in. in diameter) by volume. The concrete averaged about 145 lb. per cu. ft. in weight. The reinforcing rods at the corners were placed  $1\frac{1}{8}$  in. from the faces of the column, and where more than four rods were used the remaining rods were placed symmetrically in the interior. A variety of forms of reinforcement was used. The rods were cut to exact length and always had a direct bearing upon the bearing plates of the testing machine. In the test, the load was released several times, generally ten or more, but at progressively increasing amounts, and never more than once from any given load. The age of the columns averaged about  $3\frac{1}{2}$  months at time of test.

TABLE 10.

Data on Watertown Arsenal Columns.

Average length of columns, 94 inches.

Col. No.	Dimensions	Gross	Reinforcement				
	in. x in.	Area sq. in.	Amount and Kind	percent	at Test days		
1579 1580 1581 1582 1584 1585 1583	12.58x12.60 12.60x12.51 12.60x12.67 12.68x12.60 12.63x12.60 12.60x12.50 12.66x12.59	158.5 157.6 159.6 159.8 159.5 157.5 159.4	8-\frac{2}{4}-in. Thacher bars 4-\frac{2}{4}-in. Twisted bars 4-\frac{2}{4}-in. Thacher bars 4-\frac{2}{5}-in. Corrugated bars 8-\frac{2}{5}-in. Corrugated bars 8-\frac{2}{4}-in. Twisted bars None		102 103 104 106 104 105 107		

Stress-deformation diagrams are given in Fig. 30 to 36 at the end of the text. As before, the deformations given are gross and not net or elastic deformations. The line for steel, line for initial modulus of elasticity, and point of maximum stress in concrete are used in the way already given for the University of Illinois tests. Points for the parabolic stress-deformation relation for one-sixth, one-fourth, one-half, and full abscissa are marked by crosses. It will be seen that these diagrams have the same general characteristics as the University of Illinois tests, and that the parabolic curve fits them very closely.

Table 10 gives general information on the amount and nature of the reinforcement and the age of test. Table 11 gives the initial modulus of elasticity, the abscissa of vertex of the stress-deformation parabola, and the maximum stress taken by the concrete alone, the last being based upon the method already used, wherein the steel is considered to take a stress corresponding to

TABLE 11.
WATERTOWN ARSENAL COLUMN TESTS.

Col. No.	Gauged Length inches	sent cement	Initial Modulus of	Abscissa of Vertex of Parabola Calc	Maximu in Cor lb. per		Maximum Stress on Gross Area lb. per sq. in,
		per cent Reinforcement	Elasticity lb.per sq.in.		Calcu- lated	Ob- served	
1579	50	2.09	3 200 000	.0012	1950	1950	2760
1580	50	1.43	2 000 000	.0012	1200	1200	1990
1581	50	1.03	2200000	.0014	1540	1460	1990
1582	50	0.97	2300000	.0014	1600	1540	1250
1584	50	1.94	2800000	.0014	1960	1920	2830
1585	50	2.86	2200000	.0012	1330	1330	3160
1583	50	0.00	2 770 000	.0013	1800	1710	1710
Av.			2 500 000	.0013	1620	1590	2240

its deformation and the concrete the remainder of the load. In Table 9 are given observed stresses at four deformations and also stresses calculated for the same points from the parabolic stressdeformation relation.

The one plain concrete column has a higher modulus of elasticity than the average value found for the reinforced columns,

and its stress-deformation curve does not reach the vertex of the containing parabola. These differences and the variability of stiffness and strength found in the reinforced columns, as well as the well established variability of concrete, go to show that the result of this one test may not be taken as representative of the strength and stiffness of plain concrete columns in comparison with the reinforced columns, and general conclusions may not be drawn. The ultimate strength of this column is, however, somewhat higher than the average maximum stress in the concrete for the reinforced columns as determined from the line for steel.

The average maximum stress in the concrete, for the reinforced columns, determined from the line for steel is fairly uniform, the range being 23% below the average and 24% above. The strength and stiffness of these columns are somewhat higher than given by the University of Illinois tests, as might be expected from the greater age at test and the use of pebbles instead of limestone. The columns are evidently somewhat more uniform in their make-up. The agreement of the observed values with those calculated by the parabolic stress-deformation relation is close. The average maximum compressive stress taken by the concrete, including the result for the one plain column, is 1590 lb. per sq. in. In general, the results of the two series of column tests are quite similar.

A study of the results shows that there is no marked characteristic difference in either stiffness or strength for columns made with any special form of reinforcing bar or with any given amount of reinforcement. For leaner concrete, and hence greater porosity, the difference in the elastic limits of the bars may be expected to have an effect upon the results.

23. Modulus of Elasticity.—As has already been stated, there is a great diversity of usage in reference to modulus of elasticity. Some writers have fallen into the error of using a constant ratio between stress and deformation, and yet of considering the stress-deformation diagram a parabola. Whether the stress-deformation relation should be considered variable, or whether a straight-line relation may be held to serve well enough for the range used, depends upon the particular use or application to which the relation is to be put. In fact, generally the test of the method to be employed lies in the purpose and end to be served in the application. In beams having a small amount of reinforcement the use of a

constant modulus may be permissible. In beams having a large amount of reinforcement and in which the compressive strength of the concrete is the controlling element, a variable modulus may be preferable. In reinforced columns, it would seem that a variable modulus (curved stress-deformation diagram) should be used in discussing the relative loads finally taken by the concrete and by the steel. The same test applies to the use of gross or net (elastic) deformations. If one purpose in the use of the deformation is to determine (a), in the case of a reinforced column, the amount of the deformation in the longitudinal steel reinforcement and from this to calculate the stress in the steel, or (b), in a reinforced beam, the amount of change in a section and from this the position of the neutral axis and the resulting stress in the steel. it seems clear that gross (total) deformation should be used and not net (elastic) deformation, if we consider that a plane section before bending remains a plane section after bending. of elastic deformations must be misleading in these cases.

Again, the method to be used in determining the stress-deformation relation for repetitive loading should be judged in the same way. For example, when a compression test piece (a beam gives a similar phenomenon) has had loads applied in continuously increasing amounts, the stress-deformation line will be a curve. as is shown for example in the diagrams for Columns No. 5 and 12 given in Fig. 7 and 8. If now the load be gradually released. the points found during release will approximate to a straight line running to the set point. If the load is reapplied, the points found on the return line are not far from the straight line, and the second application of the given load shows a deformation somewhat larger than the first. To say, because at the partial loads the values approximate to a straight-line relation, that therefore the corresponding constant modulus of elasticity should be used in calculations on beams and columns, is evidently erroneous reasoning, as will be shown in the succeeding paragraph.

The set indicated in this line of released and reapplied loading does not exist throughout the cross-section of a beam under repeated loadings, as might at first thought seem to be the case. A method of more general applicability is to determine the final deformation after repetition for each loading seriatum. Thus, if the loads are to be applied one hundred times, apply, say, 100 lb. per sq. in. one hundred times and note the final deformation; apply

500 lb. per sq. in. one hundred times and note the final deformation; apply 1,000 lb. per sq. in., etc. Fig. 11 gives some idea how these deformations will change under repetitions, the points obtained for the same number of repetitions being connected together. The final diagram (represented by the lower curve) will resemble the one for the initial application, especially in portions of the curve other than near the ultimate, though the exact position of this will depend upon the number of repetitions, the elas-




Fig. 11. Diagram Illustrating Effect of Repetitive Loading.

ticity of the concrete, etc. Now, the same condition may be expected to exist in a beam that has been loaded one hundred times: at the remotest fiber the deformation is that due to repetition at the unit stress it has been subjected to, say 500 lb. per sq. in.; at a point half way to the neutral axis it is that due to repetition at one-half as great a unit stress, say 250 lb. per sq. in., and not (as would be the case if the results by the first mentioned method of loading were taken) the deformation under the condition that this fiber has been stressed to 500 lb. per sq. in. and then had had its stress reduced to 250 lb. per sq. in. This statement, of course, is approximate, since under the conditions described the position of the neutral axis would change, the stresses themselves would change, and the section itself would distort from a plane section, but nevertheless the illustration holds. The stress-deformation curve for repetitive loading should, then, be made by connecting points obtained under repetition of first one load, then a higher one, then still a higher one, etc. For a column, the deformations at intermediate loads are not so important, but the general character of the stress-deformation diagram is essential.

The use of both gross and elastic deformations contributes to the diversity of values for the modulus of elasticity of concrete given in engineering literature. Elastic deformations naturally give higher values. Caution should be used in accepting high values because they may have been obtained from elastic deformations or because they may have been taken from short specimens affected by the restraint of the bearing plates or because they may represent concrete of a much denser quality than is to be found under the conditions of practical construction. It is also to be seen, as shown in the preceding paragraph, (see also Fig. 11), that with repeated applications of a load the deformations will increase and the abscissa of the vertex of the assumed parabola will be larger. At the same time the maximum load which the concrete will take must be considered to be smaller. Under these two changes, it is evident that the resulting initial modulus of elasticity will be smaller than that for a single application of the load. What the amount of this decrease is will depend upon the nature of the concrete, its age and plasticity, and the number of repetitions of the load. The more plastic and porous the concrete, the greater the effect. The richer the mixture and the older the test piece, the less it will be. At the same time, it must be borne in mind that the concrete grows stiffer with age, and that most tests have been made at an early age, 30 Whether this increase in stiffness with time will counteract the decrease in value just noted, will depend upon the nature of the concrete and the number of applications. A similar effect may be expected in concrete by reason of its plastic nature when a load is applied for a considerable length of time (time effect), but little is known of this phenomenon.

It is noticeable that the values of the initial modulus of elasticity for the two series herein given agree fairly closely, an average of 2,250,000 lb. per sq. in. for 1–2–4 limestone concrete 60 days old tested at the University of Illinois, and an average of 2,500,000 lb. per sq. in. for 1–2–4 pebble concrete 105 days old tested at Watertown Arsenal. These values are based upon gross deformations and, in the main, first loading of the specimen. The combined effect of age and even moderate repetition, if the discussion in the previous paragraph holds, may be a modulus somewhat smaller than that given by these tests. What this modulus will become cannot be told without adequate tests. However, for

1-2-4 concrete of the quality used in the University of Illinois and the Watertown Arsenal columns (limestone in one, pebbles in the other), the initial modulus of elasticity at the age of a year and after a moderate number of applications of the load seems more likely to be below 2,500,000 lb. per sq. in. than above it. Further data on the effect of age of concrete and repetition of load upon modulus of elasticity are necessary before definite conclusions may be reached.

It should be noted that if a straight-line stress-deformation relation is to be used, particularly in the case of columns, the value chosen should be considerably less than that of the initial modulus of elasticity.

Discussion of Basis for Working Stresses and Working Factor in Structures.—The real basis for a working stress or a factor of safety to be used in designing seems not to be generally understood, or at least it is not often properly explained, and expressions sometimes heard indicate that the purpose and use of factor of safety and working stress are misinterpreted. Of course, no engineer will say that for a factor of safety of, say, four (using the term factor of safety as based upon the ultimate strength of the material) the structure will take four times the assumed load without injury. It is understood by engineers that the actual ratio of the load which the structure may properly take under the ordinary conditions of construction to the assumed load used in the calculations made in the design is not large and may, under some circumstances, not be very much above one. Yet the statement is sometimes made, or the inference may be drawn, that because a given working stress is to be used in the calculations there is no advantage in looking into the behavior of the material or the action of the structure at a stress higher than the assumed working Before discussing further the meaning of the tests here recorded, it may be well to consider some of the aspects of working stresses and factors of safety.

Mild steel has a rather definite elastic limit and yield point beyond which the character of its action changes in a marked way. Beyond the yield point the rate of stretch in tension becomes almost at once one hundred or more times as much as it was within the elastic limit. In compression, the ultimate strength of mild steel is not far beyond its elastic limit. It is evident that a structure made up of this material will distort and fail when a load producing stresses not much greater than the elastic limit is placed upon it. The elastic limit of mild steel has a small range, its value running from 50% to 65% of the ultimate strength, depending upon the size of the piece, method of rolling, etc., and the steel is made under such conditions that little risk is taken in choosing a value for a particular size and shape of piece. The modulus of elasticity of steel is also quite uniform. It may be said then, that the properties of this material, with proper inspection, are fairly definitely known. When we base the factor of safety of a structure upon ultimate strength of mild steel, whether we do it consciously or unconsciously we have tacitly assumed that the factor of safety named in the calculations is nearly double the factor which will bring actual failure under the conditions assumed to exist in the structure.

For a plastic material, or a material not having a definite elastic limit, or at any rate one for which the stress varies directly as the deformation for at best only a small part of the ultimate strength of the material, a different consideration must be given. For such materials, the effect of lack of uniformity of the material, the effect of increased deformation, of repetitive loading, of time, and of other factors must be considered.

But there are other considerations which go to confine the working stress, particularly in concrete, to the low value usually assumed. Sometimes the stress is made low to allow for a possibly greater load than that assumed, or for a load applied other than statically. Even if the assumed load has the correct total amount, the following items may be said to influence the choice of a lower working stress: (1) Uneven distribution of load among members; (2) Unconsidered stresses due to settling, variability of the material, etc.; and (3) Variation in the material and in its fabrication.

(1) Even with a load of the amount assumed, the division of this load among the members of the structure may be uneven. Variations in stiffness, differences in quality of adjacent members due to inherent variations or to the variations which arise in such a material as concrete during fabrication and setting, differences due to restraint or lack of restraint at connections,—all go to make the actual distribution of the load different from its assumed division among the members. In a timber trestle bridge, the weaker stringer is generally less stiff than its stronger

neighbor, and hence the poor stringer takes a smaller share of the load and the good one a greater. Even in steel building construction, differences in rigidity of connections, modifications made to overcome lack of exact fit, and variations caused by field riveting act to modify the division of the load. In concrete construction the variations in fabrication and conditions of setting (e. g., in the beams and girders) and the consequent variable effect on stiffness and restraint may have a considerable effect upon the division of the load. This is especially true in the floor, beams, and girders, so that the load transmitted to a particular column may be quite different from that assumed.

- (2) Settling of the foundation of one column more than of another is possible. A variation in the shrinkage of adjacent columns through variation in conditions attending fabrication or to a less extent in porosity or stiffness of column will modify the distribution of the load. Variations in size also affect this distribution. The more nearly uniform the dimensions and physical properties, the more nearly regular the division of load will be and the higher the allowable comparative working stress. In this respect, steel is an advantageous building material.
- (3) The values of physical properties usually quoted are average values. The data were obtained from test pieces, sometimes large, frequently small, and these may be said to have been made and tested under favorable conditions. Since the members of a structure which have the poorest quality may have a controlling influence upon the amount of load to be carried, if average values are used the factor must be greater to allow for this. In other words, in poorly made beams or columns the load or stress which comes on the piece is relatively nearer the point of failure than is indicated by the use of the assumed working stress and an average ultimate value.

Enough has been said to show that the assumed stresses are not the actual stresses coming upon the members of a structure and that the relation between the assumed working stress and the average ultimate strength of the material is a matter which should involve thought and study. It may then be stated that (a) the stress actually brought upon a member of a structure by an assumed loading may be materially higher than the assumed working stress, and (b) the stress actually developed in a member may be much higher comparatively (i. e., with respect to its own ulti-

mate strength) than even this increased amount would indicate. This goes to show that the nature of the action of the material, including its stress-deformation relation, should be studied at points well above the assumed working stress. What point should be fixed upon as a basic point, upon which a working factor covering uneven distribution of load, uncertainty of quality, effect of repetitive loading, etc., may be based, will depend upon the nature of the material and the conditions of the structure. Some discussion of this subject will be given under Formulas for Plain and Reinforced Concrete Columns. No attempt will be made here to discuss what the working factor should be. Its value will depend upon many conditions which it will be impossible to discuss here.

25. Formulas for Plain and Reinforced Concrete Columns.—It seems hardly necessary to advance the idea here that for concrete columns used in ordinary building construction little attention need be given to the relation between length and lateral dimensions after a length of a few diameters has been reached. Text books on reinforced concrete contain long and complicated treatments involving Euler's relation and Rankine's formula. However, columns in buildings do not ordinarily go beyond, say, 12 or 15 diameters, and the ratio is usually much less, especially for the lower stories. Even for 15 diameters we may readily conclude from the calculated results of long column formulas and also from the small lateral deformation found in the columns tested that the difference in strength between a column 15 diameters long and one 5 diameters long is less than the variation among several columns of the same length. The same conclusion may be drawn from the set of tests of columns of varying length made at the Massachusetts Institute of Technology and quoted in Buel and Hill's Reinforced Concrete, page 76. For columns eccentrically loaded, the effect of any eccentricity is generally large in comparison with the lateral deflection used in the Euler analysis, and it may be said to be generally independent of the length of the column. Clearly, for conditions of ordinary design a formula for plain columns or for columns reinforced with longitudinal rods need not include the ratio of length to lateral dimension. In this discussion only concentric loading of columns is considered.

Obviously then, the formula for plain concrete columns is  $P = Ac \dots (3)$ 

where P is the load assumed to be carried, A is the area of the column considered (in practice, part of the area at the outside, sometimes being excluded as a precaution in case of fire) and c is the working stress assumed or determined by other considerations.

In columns with longitudinal reinforcement, if we use P, A, and c as before, and denote by p the ratio which the area of the column bears to the area of the steel reinforcement, and by n the ratio between the stress existing in the steel and that in the concrete, the area of the steel will be pA, the unit-stress in the steel will be nc, and the area of the concrete will be A(1-p). The total compressive stress in the steel will then be pAnc and that in the concrete Ac(1-p). The formula for the strength of the column may then be written

This ratio is used rather than the ratio of the moduli of elasticity, since the latter may be misleading. If we call the area of the steel A, this formula may be put in the form,

It will be necessary to select the value to be used for n in these formulas, and this will involve a discussion of the part of the stress-deformation field from which the basic value of the compressive strength used in the determination of the working strength is to be taken.

Granting that the actual stress in the member of a structure will probably be considerably greater than the stress calculated from the assumed distribution of the load, by reason of such agencies as have been discussed, and also that for members which are weaker than their neighbors the stress deformation point developed will be relatively nearer the point of failure and hence farther up the diagram than the same stress will be in the diagram for an average test piece, and considering further that an additional allowance must be made for contingencies or emergencies, it is apparent that the field for this basic value of the compressive strength will be well along on the stress-deformation diagram. Obviously the extreme variability of concrete near the point of failure rules out values near the ultimate strength, even if other considerations do not. In all the field near the point of failure, too, the deformations are large, and repetition of loading increases them rapidly. The time effect of a permanent load is also large. It would seem that a stress greater than that which

gives a deformation equal to one-half of the ultimate deformation of the concrete,  $(q=\frac{1}{2})$ , is as large as may properly be taken as a basic value, even if the contingency of ever having such a stress in the member is very remote and then only temporary and not to be repeated. The stress corresponding to this deformation point is by the parabolic relation three-fourths of the ultimate strength of the concrete. This is not far from the basis adopted by Captain Sewell, eight-tenths of the ultimate strength, in his admirable paper on Reinforced Concrete Floor Systems in the Transactions of the American Society of Civil Engineers, Vol. 56. For many conditions of fabrication or of application of the load, a lower point in the diagram should be chosen, or the factor of safety increased. If we select the half-way point in the stress-deformation diagram  $(q=\frac{1}{2} \text{ and } c=\frac{3}{4}c')$ , for the basic value, the next step will be to choose the working factor, to cover the effect of repetition of stress, uncertainty of distribution of assumed load, variation in quality of material and construction, and other uncertainties and contingencies. It should be noted that this discussion is more particularly applicable to columns, since in beams with the amount of reinforcement ordinarily used the beam will fail through tension in the steel or by web stresses and not by compression of the concrete.

In the formula for reinforced concrete columns an important factor is the ratio of the stress in the steel to the stress in the concrete, called n in this discussion. This ratio is a variable one, depending upon the amount of deformation developed. To call it the ratio of the moduli of elasticity is indefinite and undesirable. If we assume the parabolic stress-deformation relation, it may be shown that this ratio is

$$n = \frac{1}{1 - \frac{1}{2}q} \quad \frac{E_s}{E_c} \cdot \dots (6)$$

where  $E_s$  is the modulus of elasticity of the steel,  $E_c$  is the initial modulus of elasticity of the concrete, and q is the ratio of the deformation at the load under consideration to the ultimate deformation (vertex of the parabola). For low loads, n will not differ far from the ratio of the two moduli used above. At the four points noted on the stress-deformation diagrams it will be as follows: for  $q = \frac{1}{6}$ ,  $\frac{12}{11}$  times the initial ratio given above; for  $q = \frac{1}{4}$ ,  $\frac{8}{7}$  times the initial ratio; and for

q=1, 2 times the initial ratio. For  $E_c=2.500,000$ , the initial value of n is 12, and it becomes 16 and 24 for the half-way deformation and the ultimate strength, respectively. For  $E_c=2.000,000$ , the values of n for the same points are 15, 20, and 30. It is seen that n rapidly increases at the higher deformations.

Values of n have been determined from the observed deformations, counting the division of stress between the concrete and the steel to be according to the analysis heretofore given, and results for both the University of Illinois tests and the Watertown Arsenal data are given in Table 12.  $\epsilon'_{c}$  represents the unit deform-

TABLE 12.  $\begin{tabular}{ll} \hline & & & & & & \\ Ratio of Stress in Steel to Stress in Concrete. \\ & & & & & \\ Values of n. \\ \hline \end{tabular}$ 

 $\epsilon_c'$  — unit deformation at the maximum compressive stress in the concrete.

Col. No.	At 0	At $\frac{1}{6} \epsilon'_{c}$	At 1 c'	At $\frac{1}{2} \epsilon'_{e}$	At ϵ <sub>c</sub>	Remarks
1	11.7	12.2	13.7	16.0	24.8	U. of 1. tests.  One rod on bearing plate.  Rods on plaster.
2	12.9	13.9	14.9	17.8	25.7	
3	12.8	13.2	14.2	17.4	26.4	
6	14.3	15.5	16.4	19.6	29.0	
7	11.7	13.1	13.7	15.5	23.8	
10	16.7	17.3	18.6	23.0	33.9	
11	12.3	12.3	13.4	16.2	24.7	
12	12.0	12.7	13.3	16.0	24.2	
14	15.0	14.8	16.5	20.0	29.4	
16	15.8	16.0	17.3	21.2	32.2	
17	15.8	20.4	20.0	20.1	27.2	
1579	9.4	9.4	10.8	12.6	18.5	Watertown tests.
1580	15.0	17.5	17.5	19.6	29.2	
1581	13.6	15.4	15.9	18.4	28.1	
1582	13.1	16.0	15.9	17.9	25.6	
1584	10.7	11.4	12.7	14.9	21.4	
1585	13.6	16.5	16.8	19.0	27.1	

ation at the point of maximum stress in the concrete (corresponding to abscissa of vertex of parabola). The same values are given in Fig. 12, the dots representing University of Illinois results and the crosses Watertown Arsenal values. The lines de-

note average values. In both Table 12 and Fig. 12, the value at the initial loading (q=0) is taken from the ratio for the initial modulus of elasticity for the column under consideration. It will be seen that the values range from 11.7 in one case for initial load to 34 in another at ultimate load.

If we assume that a concrete stronger than the average has a modulus of elasticity higher than the average, and that a weaker concrete has a smaller modulus, then the selection of a value of n higher than the average for use in design may be defended, for if a given column is made of concrete poorer than the average the steel by virtue of the low modulus of elasticity of the concrete in which it is embedded will have a greater stress thrown upon it than is indicated by an average value of n, and a column made better than the average will be capable of taking a greater load than that calculated with an average value of n. At least, it would seem logical to choose a value higher than the average




Fig. 12. Values of n.

value rather than a lower value.

If we take the half-way deformation  $(q = \frac{1}{2})$  as the point for determining our basic value for working factor and working stress, the average values of n in Table 12, 18.4 and 17.1, respectively, may serve as a guide for the value to be chosen for equation (4). For concrete of the character used in the tests, it would seem then, that 17 and 18 may be considered average values for n, and that values even higher than these, say, 18 to 21, may properly be selected.

It may be added that the value of n to be used for a given concrete will depend upon its density and stiffness. For a very rich concrete, not only will the initial modulus of elasticity be higher, but the deformation at maximum strength (abscissa of vertex of parabola) will be less. As a consequence of both of these changes the ratio n will be less for very rich concrete than for the test columns here considered. On the contrary, for lean concrete, the initial modulus of elasticity will be lower and the deformation at maximum stress higher, and therefore the ratio n will be higher than the values here given.

26. Discussion of Columns in Building Construction—It may be well to call attention to some of the reasons why columns may be a weak point in reinforced concrete construction and to offer a word of caution concerning their construction. The conditions of column construction as ordinarily carried on in building operations give little chance for efficient inspection, and there is abundant opportunity for great variation in the concrete, since the work is out of sight and the mixture of the material and the tamping or stirring will be far from uniform, much less uniform than in the test columns herein described. Even in test columns the poorer columns carried low ultimate loads. If, in addition to these considerations, the possible uneven distribution of the assumed load due to settlement, shrinkage, and uneven stiffness of the floor system be also taken into account, the need for using low working stresses and careful construction ought to be apparent. Evidently a fairly rich concrete made of a high grade of cement should be used. It is not improbable that in many buildings the working stresses used are too high for the concrete actually put into the columns. Besides, it must always be borne in mind that the strength obtained from test cubes may not be taken as representing the strength of a column. It is probable that many engineers have been misled by high values obtained on test cubes. Again, great caution should be used in the time allowance for removing the forms, particularly in cool weather, for the concrete in the olumns should be fairly well set before much of a load is allowed on it. A method of construction should be selected which will not bring weight upon the columns until the forms are removed, and the concrete is thoroughly set. It is fortunate that the concrete continues to gain in strength for a considerable time, although this advantage is counteracted in a structure to some extent by the injury to the concrete caused by early application of the load.

Both plain and reinforced concrete columns take up considerable room, particularly on the lower floors of a building. A richer concrete will permit a reduction in the area occupied. The large size of the columns makes the effect of eccentricity of loading smaller than it would be otherwise. Columns of hooped concrete have been used as a means of reducing the cross section. It is hoped that the investigation of hooped columns now in progress at the University of Illinois will throw some light on this allied subject.

- 27. Summary.—Parts of this discussion may be summarized as follows:
- 1. In discussions involving the strength and stiffness of concrete, the variability of the concrete must be taken into consideration. Test columns made with care to secure uniformity of conditions show considerable diversity in quality. An even greater variation in character must be expected under the conditions of ordinary building construction.
- 2. Cubes and other small test specimens are made under conditions which give a stronger and denser concrete than is generally found in full-sized pieces in building work. The restraining effect of the bearing plates of the testing machine also influences the results of cube tests. It is evident that the test pieces used in many tests recorded in engineering publications were made with a quality of materials, methods of fabrication, and conditions of setting which are far more favorable to high results than will be found under average conditions of construction. Caution should therefore be used in accepting as a basis for design values obtained from tests without knowing fully all the conditions accompanying the investigation.
- 3. The relative amount of load taken by the concrete and by the steel, in columns with longitudinal reinforcement, may be determined by means of the observed relation between loads and deformations under the assumption that the stress in the steel reinforcement is proportional to the deformation in the column. It is assumed that the bond between the steel and the concrete is adequate. This method forms an efficient means for discussing the relative stresses in steel and concrete.
- 4. By the method of analysis used, the average maximum stress in the concrete for the reinforced columns tested is found to be 15% less than the average for the plain concrete columns.

While this may not be taken as a final or representative conclusion, since it may be merely incidental to the columns used or the method of testing, it is at least an added reason for caution in choosing working stresses for this form of construction. The average total load taken by the reinforced columns, it should be understood, was considerably higher than the average for the unreinforced columns.

- 5. The plotted diagrams representing the loads or stresses in the columns and the corresponding deformations or shortenings, (stress-deformation diagrams), show a variable relation which is well expressed by the parabola. The tangent to the parabola at the point of zero load represents by its slope the initial modulus of elasticity of the concrete, and forms a convenient basis for an expression for the variable relation between stress and deformation. It should not be inferred that this relation is generally applicable to very rich or very lean concrete. The "Line for steel" in the diagrams for reinforced columns is helpful in determining the stress taken by the concrete and by the steel.
- 6. Gross (total) deformations and not net (elastic) deformations are used, since in the application of the stress-deformation relation to columns and beams gross deformations will, under the hypotheses ordinarily accepted, enable the stress in the steel to be determined, and net values will not.
- 7. The fact that during the operation of releasing a load the stress-deformation diagram does not follow the parabola but takes a course which approximates a straight line, is not a valid reason for not accepting the parabolic relation in the analysis of beam and column action. When a beam has been loaded up to a given load, the area of the part of a section above the neutral axis is in compression, and no point of this section has been strained beyond the amount then developed at that point, each point having the highest stress which has come upon it. The effect of repeating a load on a beam in progressively increasing amounts is to increase all the deformations in the section, but the resulting curve will still resemble the parabola, and the resulting initial modulus of elasticity will have a smaller value than that found for the first application of loads.
- 8. The Watertown Arsenal tests of columns of composition similar to the University of Illinois columns are comparable in strength and stiffness and in the form of stress-deformation


diagram and tend to confirm the results and conclusions of the University of Illinois tests. The average maximum compressive stress taken by the concrete in the Watertown Arsenal columns was 1590 lb. per sq. in. In the University of Illinois columns it was 1550 lb. per sq. in. for the plain columns and 1290 lb. per sq. in. for the reinforced columns.

- 9. The average value of the initial modulus of elasticity given for the University of Illinois columns, 2,250,000 lb. per sq. in., and that for the Watertown Arsenal columns, 2,500,000 lb. per sq. in., may be considered tentative values for 1-2-4 concrete of the kind described for use at an age of 60 to 105 days and first application of load. Age will increase the modulus and repetition decrease it. What the combined effect of these two agencies will be is not known, but it will vary with the conditions of materials and number of repetitions and also with the age at which loads are first applied. When a constant modulus of elasticity (straightline relation) is used, the value chosen should be less than that for the initial modulus here given. The high values of modulus of elasticity frequently quoted are doubtless due to shortness of length of test piece, high quality in the test pieces used, use of elastic deformation, etc. The quality of the aggregate, as well as of the cement used in making test pieces, may not always be representative of that used in building operations.
- 10. The proper basis for working factor and working stress for use in designing with any given material and form of construction is of much more importance than is usually given to it. The conditions of loading, of transmission and distribution of load. of variation in fabrication and construction, all act to make the stress actually developed in a member of a structure greater than the assumed working stress. For steel the real basic point is the elastic limit or yield point. For concrete this basic point may well be considerably below its ultimate strength. The choice of a value corresponding to a deformation equal to one-half of the deformation at point of failure is suggested. This, by the parabolic relation, is equal to three-fourths of the ultimate strength. Having selected a basic point, a working factor to obtain the working stress will then be chosen to cover contingencies and emergencies and the variations in distribution of load, quality of materials, method of fabrication, nature of load and its manner of application, etc. The range in the values for the working fac-


tor which may be used under the various conditions of repetition of load, workmanship and material, is of course much greater with concrete than will be necessary with such a material as mild steel.

- 11. The ratio between the amount of stress taken by the steel and that taken by the concrete in columns reinforced with longitudinal rods varies as the load is increased, as may be expected from the variable stress-deformation relation of the concrete. In these tests this ratio varied from 12 at the initial application of the load in one column to 34 at the maximum strength of the concrete in another. For the average initial modulus of elasticity of the concrete, the range is from  $13\frac{1}{3}$  at the zero load to  $26\frac{2}{3}$  at the ultimate. For very rich concrete the effect of the additional stiffness and the lower final deformation is to decrease the ratio n, and for lean concrete the smaller modulus and greater final deformation will make it larger.
- 12. If we choose the half-way deformation for our basic point, the value for the ratio of stress in steel to stress in concrete may, from the two sets of experiments, be taken as 17 to 18 for 1-2-4 concrete of the quality used in the tests. However, this ratio may properly be taken to be even higher than an average value, since for columns weaker than the average column the ratio may be expected to be higher than the average value and hence to fit the conditions of such columns better, while for columns stronger than the average the added strength of the concrete will go to make up for the overestimated stress in the steel. For this assumption, 18 to 21 may be used.
- 13. Under the conditions of building construction, columns may form a weak element in the structure. To overcome this, the working stresses should be kept low and every precaution taken to secure proper materials, workmanlike fabrication, and efficient inspection.


#### DEFORMATION PER UNIT OF LENGTH





500





DEFORMATION PER UNIT OF LENGTH











DEFORMATION PER UNIT OF LENGTH

### PUBLICATIONS OF THE ENGINEERING EXPERIMENT STATION

Bulletin No. 1. Tests of Reinforced Concrete Beams, by Arthur N. Talbot. 1904.

Circular No. 1. High Speed Tool Steels, by L. P. Breckenridge. 1905.

Bulletin No. 2. Tests of High-Speed Tool Steels on Cast Iron, by L. P. Breckenridge and Henry B. Dirks. 1905.

Circular No. 2. Drainage of Earth Roads, by Ira O. Baker. 1906.

Bulletin No. 3. The Engineering Experiment Station of the University of Illinois, by L. P. Breckenridge. 1906.

Bulletin No. 4. Tests of Reinforced Concrete Beams, Series of 1905, by Arthur N. Talbot. 1906.

Bulletin No. 5. Resistance of Tubes to Collapse, by Albert P. Carman. 1906.

Bulletin No. 6. Holding Power of Railroad Spikes, by Roy I. Webber. 1906.

Bulletin No. 7. Fuel Tests with Illinois Coals, by L. P. Breckenridge, S. W. Parr and Henry B. Dirks. 1906.

Bulletin No. 8. Tests of Concrete: I. Shear; II. Bond, by Arthur N. Talbot. 1906.

Bulletin No. 9. An Extension of the Dewey Decimal System of Classification Applied to the Engineering Industries, by L. P. Breckenridge and G. A. Goodenough. 1906.

Bulletin No. 10. Tests of Concrete and Reinforced Concrete Columns, Series of 1906, by Arthur N. Talbot. 1907.

Bulletin No. 11. The Effect of Scale on the Transmission of Heat through Locomotive Boiler Tubes, by Edward C. Schmidt and John M. Snodgrass. 1907. (In press).

Bulletin No. 12. Tests of Reinforced Concrete T-beams, Series of 1906, by Arthur N. Talbot. 1907.







# UNIVERSITY OF ILLINOIS

# Engineering Experiment Station

BULLETIN NO. 11

APRIL 1907

# EFFECT OF SCALE ON THE TRANSMISSION OF HEAT THROUGH LOCOMOTIVE BOILER TUBES

By Edward C. Schmidt, M. E., Associate Professor of Railway Engineering, and John M. Snodgrass, B. S., Instructor in Railway Engineering

During the past twenty or thirty years there has been considerable discussion in railroad circles as to the effect of scale upon the heat-transmitting properties of tube surfaces, and the consequent effect upon the consumption of fuel. Statements as to the extent to which deposits of scale affect the conductivity of a tube or sheet have been made from time to time and have differed widely.

The report continues as follows: "On most western roads incrustations will form to a thickness of from  $\frac{1}{5}$  in. to  $\frac{3}{16}$  in. in the course of one year, and will increase at a still greater ratio as long as the engine is kept in service. Thus after four months' time, there will have accumulated in our engines nearly  $\frac{1}{16}$  in. of scale. If Dr. Rodgers' theory be correct, after one month's service our engines will consume  $3\frac{1}{4}\%$  more fuel than at first; after two months' service  $7\frac{1}{2}\%$  and so on, making an average for the year of over 20% more fuel than they would have consumed if using pure water."

In a report before the same Society in the year 1877 upon "Feed Water" a committee under the sub-heading, "The Effect of Incrustations on the Consumption of Fuel," reports in part as follows: "The increase in the consumption of fuel, on account of incrustations on the heating surfaces of boilers, varies with the thickness and density of the deposit. When porous the water will penetrate it, but when hard and compact it presents a complete barrier to the contact of the water with the heating surfaces. As incrustations are poor conductors of heat, an increased consumption of fuel is inevitable where they exist." The committee then cites a number of cases for which sufficient data were collected to estimate the per cent loss that was occasioned due to scale deposits. A table showing the average miles run to one ton of coal by engines upon the Illinois Central Railroad for three months prior to and for three months after the removal of incrustations, including 120 such cases and extending over a period of three years, showed as a general average an increase of 11% in the consumption of coal for three months prior to the cleaning of the boilers, as compared with the three months immediately succeeding. The result of 11% loss due to scale is, of course, entirely a general result, as individual cases often showed less miles run per ton of coal after cleaning than before. This difference from the general result could in most cases be accounted for by weather differences. A second case is cited for two passenger engines, which were of the same size and pattern, and which were run with the same trains on alternate days. Records were kept for the six months preceding and six months following the cleaning of the boilers. Both engines had previously been cleaned at the same time and had made an average of 34,047 miles before the test began. The tests as run showed a difference in favor of clean heating surfaces of 17.5%. Mr. Wells, the master mechanic making this test, however, concludes, on account of the scaled tubes being run more often during the winter months than the cleaned tubes, that of the 17.5% difference in consumption of fuel between clean and incrusted heating surfaces about 2% was due to temperature and  $15\frac{1}{2}\%$  to the effects of incrustation. Similar tests with two freight engines gave a difference of 26% in favor of clean heating surfaces. A correction of 4% was applied to this on account of different atmospheric temperatures under which the tests were made, "thus giving a net saving of 22% in favor of clean boilers on two freight engines."

Other cases might be mentioned giving results more or less similar, also cases in which little or no loss was found to be occasioned by the presence of scale. Likewise, the opinion has been not uncommonly expressed that there is either no fuel loss due to the presence of scale in the usual amounts or that loss is so small as to be of little practical importance.

During the last few years there have been made by the Railway Engineering department of the University of Illinois four series of experiments to determine the relative conductivities for heat of clean and scale-covered locomotive boiler heating surfaces. A fifth series of tests is now being carried on along the same general lines as the others. It is the purpose of this bulletin to report upon the results of the first four series of these tests.

The tests were planned with the purpose of determining, not only the actual transmission loss due to scale in individual cases, but also the relation of this loss to the scale thickness. The last three series were arranged especially to try to determine whether there is any regularity of variation of heat transmission loss with scale thickness and to study at the same time the effects of chemical composition on this loss.

· It was recognized from the outset that in any series of comparative tests for the purpose of determining the loss in heat transmission due to the presence of scale, practically exact similarity of conditions was essential for trustworthy results. A study of previous work done along this line, such as the cases and results already referred to, also served to emphasize the necessity of such care. In all of the work hereinafter reported the greatest stress has been laid upon this point, i. e. the elimination of variations in conditions except the scale itself. The difficulties

which have been encountered while prosecuting this work have still further emphasized this necessity. The difficulties attending road-testing are well understood both as to exact measurements and similarity of conditions. These considerations were of weight in determining that the tests herein reported should be largely of laboratory character rather than road tests.

The first series\* of tests was made during May and June 1898.

The method employed in making the tests was as follows:—

A Mogul freight locomotive, which had been in service 21 months and which was about to be sent to the shops for repairs and new tubes, was set in the roundhouse and the boiler tested by the standard method. The locomotive was then sent to the shops and the boiler carefully cleaned and retubed. All the scale was removed and samples analyzed from nine different parts of the boiler. It was then sent back and again tested for evaporation under the same conditions as before cleaning. Before making the trials with the clean tubes the locomotive was allowed to make one or two trips on the road so as to insure its being thoroughly clean. The tests were made in the round-house at Champaign, Illinois.

The locomotive was set in the roundhouse over a pit and the tender removed. A car of coal was then run in back of the engine and on this were arranged the scales for weighing the coal. All of the feed water was weighed and then delivered into a tank placed on a platform by the side of the car, and connected with the suction pipe of the injector.

The slide valve on one side of the locomotive was moved back far enough, by disconnecting the valve rod, so that the steam generated could pass directly into the exhaust, and thus out through the nozzle and produce the necessary draft as usual. A 2-in. pipe was also run from the dome to the atmosphere, a valve in the pipe furnishing additional means of disposing of the steam generated. The tests were started by the standard method, i. e., raising steam to the running pressure, drawing the fire and starting with weighed wood.

At the end of the tests the ashes were all weighed. One of the regular road firemen fired for all the tests and the boiler and furnace were operated under the usual road conditions. A series of observations was made during these tests, to determine the re-

<sup>\*</sup>This test constituted the thesis for graduation of Messrs. F. H. Armstrong and J. N. Herwig.




Fig. No. 1 Locomotive No. 420



lation between the blast-pipe pressures and vacuum in smoke box and furnace, as well as the velocity of the gases in the stack at various points along two diameters at right angles to each other. The locomotive upon which the tests were made was a Mogul freight engine made by the Rogers Locomotive Works, and was one of nineteen in use at that time on the Chicago division of the Illinois Central Railroad between Champaign and Centralia, Illinois. Fig. 1 shows the arrangements just described and gives a general view of the locomotive.

No. of Locomotive.....

T .		3 *	
1.69.0	nor	dım	ensions:
13000	4117	CULLI	CINCIONIO.

No. of Locomotive	420
Diameter of cylinder	19 in.
Stroke	26 in.
Diameter of drivers	$56\frac{1}{2}$ in.
Weight on drivers	106,400 lbs.
Weight on trucks	19,600 lbs.
Total weight of engine	126,000 lbs.
Diameter of boiler	62 in.
Number of tubes	236
Diameter of tubes	2 in.
Length of tubes	11 ft. 1 in. over
	tube sheets
Length of firebox	1141 in.
Width of firebox	33§ in.
Depth of firebox, front end	67½ in.
Depth of firebox, back end	$59\frac{7}{8}$ in.
Length of grate	114½ in.
Width of grate	33§ in.
Diameter of dry pipe	8 in. outside
Diameter of steam dome	$29\frac{1}{8}$ in. inside
Height of steam dome	28 in.
Kind of lagging	Magnesia sec-
Governing proportions:	tional
Grate area	26.45 sq. ft.
Total heating surface	1531.6 sq. ft.
Area of draft through tubes	573.5 sq. in.
Ratio of grate to heating surface Fuel used:	57.9
Commercial name	Odin
Commercial size	Mine run
Lumps per cent	75
Small coal per cent	20
Slack per cent	5
Heat units per lb. of dry coal (by calorimeter)	12,240
The results of those tests are exhibited in the	nggomnonying

The results of these tests are exhibited in the accompanying tables.

TABLE 1

Log of Observations Giving Average Values

Locomotive No. 420 Illinois Central Railroad

		Series le in iler	Second Series Cleaned Boiler		
Date of Trial (1898).  Duration of trial, hours.  Steam pressure by gage.  Vacuum in smoke box (in. of water).  Temperature of orundhouse (degrees F.).  Temperature of feed water in tank (degrees F.).  Temperature of escaping gases (degrees F.).  Temperature of steam (degrees F.).  Moisture in coal, per cent  Percentage of ash (from ash pan).  Percentage of moisture in steam.	May 2	May 3	May 31	June	
	8.33	8.17	8.03	8.16	
	143	140	116.40	114	
	2	2	2.9	2.8	
	72	62	79	89	
	57	54	58.5	59.4	
	623	670	621	687	
	362	360	348	346	
	4.0	4.0	4.0	4.0	
	15.6	15 6	16.6	18.7	
	2.25	2.25	2.85	2.85	

### TABLE 2

RESULTS OF EVAPORATION TEST OF LOCOMOTIVE BOILER ENGINE NO. 420, ILLINOIS CENTRAL RAILROAD

First Series: After running 21 months and accumulating a scale deposit  $\frac{1}{32}$  to  $\frac{3}{64}$  inch thick.

Second Series: After cleaning and putting in new tubes.

			rst Serie Scale in Boiler	es	Second Series Clean Boiler			
Evaporative '	Date of Trial (1898)	May 2 lbs. 5.21 6.29 6.17 7.46	May 3 1bs. 5.27 6.39 6.25 7.59	Mean lbs. 5.24 6.34 6.21 7.53	May 31 1bs. 5.81 6.99 6.95 8.36	June 1 lbs. 5.85 7.04 7.16 8.61	Mean 1bs. 5.83 7.01 7.05 8.48	
Rate of Combustion	Dry coal burned per hour per sq. ft. of grate surface	57.45 394.80 .93	58.51 402.10 .95	57.95 398.40 .94	59.80 411.00 .97	60.00 412.80 .98	59.90 411.90 .97	
Rate of Evaporation	Water evaporated per hour from and at 212° F. per sq. ft. of grate surface	361.80 2486.00	374.40 2573.00 6.09	368.10 2529.00 5.99	418.00 2874.00 6.81	416.00 2857.00 6.76	417.00 2865.00 6.79	

The loss due to scale in this boiler was (7.01 minus 6.34) divided by 7.01 or 9.55 %.

The water used in the locomotive tested was taken from tanks at Centralia, Kinmundy, Little Effingham, Neoga, Dorans. Galton and Champaign. From the thickness of scale deposited during the 21 months it is evident that these waters are comparatively good for this section of the country.

The average thickness of the scale on the principal heating surfaces was  $\frac{3}{64}$  in. The total weight of scale removed on cleaning was 485 lbs. The boiler had been in regular service during the 21 months.

The locomotive was cleaned and retubed at the Burnside shops of the Illinois Central Railroad. When the boiler was opened all the scale removed was carefully weighed, the scale on the tubes being determined by weighing the tubes before and after cleaning them. The scale from the shell and firebox sheets that could be removed was carefully collected. The total weight of scale was as follows:—

Weight of scale from flues	360 lbs.
Weight of scale from shell	125 lbs.
Total weight of scale	485 lbs.

At nine different points in the boiler the thickness of the scale was determined by the average of many measurements, and samples were secured for analysis as follows:—

- Point 1. Near injector discharge, hard and soft scale \(\frac{1}{2}\) in, thick.
  - 2. On upper tubes, hard smooth scale uniform thickness  $\frac{1}{32}$  in.
  - 3. On lower tubes, hard scale near middle,  $\frac{1}{16}$  in. thick.
  - 4. Mud covering hard scale at No. 3,  $\frac{3}{32}$  in. thick.
  - 5. Scale from side sheet, flue sheet, and tubes rough and scaly.
  - 6. From bottom of barrel, 4 ft, from flue sheet.
  - 7. On crown stays, 3 in. to 6 in. from crown sheet.
  - 8. On crown sheet, rivet heads and base of stays.
  - 9. From stay bolts at water line. '

The results of the analyses of these scales calculated to compounds are shown in Table 3.

TABLE 3

RESULTS OF THE ANALYSES OF BOILER SCALE FROM ENGINE No. 420
SCALE CONSTITUENTS CALCULATED TO COMPOUNDS AND EXPRESSED
IN PER CENT

Point No.	Silica SiO <sub>2</sub>	Iron and Aluminum Oxides Fe <sub>2</sub> O <sub>3</sub> and Al <sub>2</sub> O <sub>3</sub>	Calcium Sulphate	Calcium Carbonate CaCO <sub>3</sub>	Calcium Oxide CaO	Magesium Carbonate MgCO <sub>3</sub>	Magnesium Oxide MgO	Organic Matter and Undetermined
1 2 3 4 5 6 7 8	7.70 25,20 8.00 7.84 15.89 11,25 18.25 13.05 22.70	3.20 7.10 4.99 3.27 4.30 7.70 6.90 7.85 12.75	10.86 16.45 21.22 4.38 21.38 1.97 1.95 40.03 11.73	65.81 20.92 48.90 61.17 30.36 67.08 45.51 24.33 28.32	1.90  5.69 1.14	3.05 8.14 8.71  5.86	9.55 19.52 4.48 5.47 7.66 9.29 16.77 9.12 18.45	2.78 7.67 10.51 9.73 11.70 2.71 4.93 4.48 0.11

The loss, as found by these trials, due to the presence of scale, was 9.55 % of the fuel.

### EXPERIMENTS WITH SINGLE TUBES

The last three series of experiments to determine the loss due to scale have been laboratory experiments entirely. They were made during the years 1901, 1904 and 1905, and are referred to as the series of 1901, 1904 and 1905 respectively.\*

The locomotive boiler tubes upon which the experiments were made in 1901 were furnished by the Peoria and Eastern division of the Cleveland, Cincinnati, Chicago and St. Louis, the Illinois Central, the Chicago, Burlington and Quincy, and the Chicago, Milwaukee and St. Paul Railways. The tubes used in 1904 and 1905 were furnished by the first two railroad companies mentioned above. Table No. 4 gives information concerning these tubes. Fig. 2 shows some of the tubes tested.

<sup>\*</sup>These experiments were conducted by the following men as theses for graduation: Series of 1901, by F. L. McCune; Series of 1904, by W. A. Miskimen and C. N. Stone; Series of 1905, by H. F. Godeke and A. A. Hale,




Fig. No. 2 Scaled Boiler Tubes




TABLE 4:
THE TRANSMISSION OF HEAT THROUGH SCALE-COVERED BOILER TUBES
RAILWAY ENGINEERING DEPARTMENT—UNIVERSITY OF ILLINOIS

		131101				
Tube Number	Purnished by	No. of Engine from which Tube was taken	REMARKS * General Character of Scale, Etc.			
1	2	3	4	5	6	7
			-		SER	IES OF 1901
1 2 3 4 5 6	I. C. R. R. P. & E. RY. P. & E. RY. C. M. & ST. P. C. M. & ST. P. I. C. R. R. P. & E. RY.	311 526 536 126 1337 820 513	10.5 13.5 5.5  5.5 37.5	2 2 2 2 2 2 2 2	0.06 0.04 0.02 0.03 0.13 0.07 0.04	Even, hard, dense Soft, porous. Removed in places Hard, dense, white Hard, dense, white Hard, dense Mileage during service, 19690 Hard, dense, rough, one end. Soft, porous at the other
9	C. B. & Q.	1179		2	0.11	Hard, porous, gray. Mileage, 50889
11	I. C. R. R.	1107	21.	2	0.09	Soft, porous
14	P. & E. RY.			2		New and clean tube
_				7,	SERI	ES OF 1904
8a	I. C. R. R. I. C. R. ST. I. C. C. & ST. L. C.C.C. & ST. L. C.C.C. & ST. L. C.C.C. R. R. I. C. R. R.	41 41 41 141 141 141 540 540 540 540 440 440 440	16 16 16 15 15 15 	ରୀ ରଧ ଜୀ ଜୀ ରଧ ଜୀ ଜୀ ଜୀ ଜୀ ଜୀ ଜୀ ଜୀ ଜୀ	0.04 0.07 0.08 0.05 0.04 0.06 0.06 0.05 0.04 0.06 0.03 0.09	Hard, gray. In bad condition Loose, gray Loose, gray White, porous. Removed in places White, porous. Removed in places White, soft, irregular White, soft, irregular Hard, white, irregular Hard, white Hard Hard Gray, porous Gray, porous Clean tube
					SERI	ES OF 1905
3 4 8 9 10 11 12 13 14 15 7	I. C. R. R. I. C. R. R. C.C.C. & ST. L. C. C. C. & ST. L. I. C. R. R. C.C.C. & ST. L. I. C. R. R. I. C. R. R. I. C. R. R. I. C. R. R.	Medium Hard Soft Very soft Soft Very soft Hard Hard Hard Medium Very hard Clean tube				

These tests were made as laboratory tests on account of the desire to make comparative tests under entirely similar conditions except in regard to the scale itself and in order that more exact measurements might be made than were found possible with road or roundhouse tests. The apparatus used in all of these tests has been practically the same from year to year. It is shown in Fig. 3, 4, and 5 and consists of a long water chamber through which the tube to be tested was passed, and in which water was circulated. On one end of this water chamber was fastened a combustion chamber, at the forward end of which was This burner was supplied with gas and air. placed a burner. Combustion took place in the chamber, which served the purpose of the firebox. The hot gases passed through the boiler tube to the air. The water entered the water chamber at the right, leaving it at the left as indicated in Fig. 3, at both of which points its temperature was read upon the thermometers there shown. water tank received the water from the city mains. It was provided with an overflow, as shown, and the water was led directly down from the bottom of this tank to the water chamber. was used in order to give a constant pressure at the inlet and thus to avoid variations in the rate of flow of the water. The gas and air tanks were arranged to give constant pressures of gas and air. The inner vessels, open at the bottom, float in water contained in the outer tank and confine the air or gas in the space above the water level. These inner tanks can be weighted at will to give any desired pressure to the air or gas contained within them.

During the tests of 1901 a copper ball pyrometer was employed to obtain the temperatures of the gases entering the tube being tested. For the series of 1904 and 1905 a Le Chatelier pyrometer was employed for this purpose. The location of the pyrometer is shown in Fig. 3. The temperature of the gases as they left the flue was read on the thermometer shown at the end of the tube.

The purpose of the tests was to measure the number of heat units transmitted per hour through the different tubes. This was accomplished by weighing the water which circulated around the tube in the water chamber and measuring its rise in temperature. The attempt was made to maintain a constant furnace temperature at the entrance to the tubes throughout all experiments of each



Average

1659

267 964 66.8

series and thereby have available for transmission the same amount of heat, since the amounts of gas and air supplied to the burner were continually the same.

TABLE 5

THE TRANSMISSION OF HEAT THROUGH SCALE COVERED BOILER TUBES
RAILWAY ENGINEERING DEPARTMENT—UNIVERSITY OF ILLINOIS

			A	verage	Temp Deg	eratu rees	res Du Fahr.	ring T	uring	f Water ige of dump 9	Tube	e Been Trans- Temperature Elan Tubes	Scale	
			Of Fu	rnace	Gases	Of C	Of Circulating Water				re o Rar		Beer empe	e to
Tube Number	Test Number	Duration of Test-Hours	In Combustion Chamber	Of Escaping Gases	Average Temperature of Gases	At The Inlet	At The Outlet	Average Temperature of Water	Rise in Temperature of Water	Weight of Water Used D Test-In Pounds	Difference Between Temperature of Wata and Temperature of Gases—"Range of Temperature"—Column 6 Minus Column	B. T. U. Transmitted Through During Test	B. T. U. Which Would Have Bee mitted Had The Range Of Tenn Been The Same As For Clean	Decrease in Conductivity Due Per Cent Loss
1	2	3	4	5	6	7	8	9	10	11	12	13	14	15

\*0.6 99830 30063 1657 256 957 66.9 112.7 89.8 651.3 867.2 66.8 99463 1702 252 977 112.6 89.7 45.8 643.3 887.3 29021 2.9 12 2233445566779 16 1650 260 955 65.0 113.9 89.5 48.9 526.5 865.5 25746 25999 13.0  $\frac{8.5}{9.7}$ 18 1631 269 950 64.1 110.3 87.2 16.2 584.0 862.8 26981 27331 878 4 875.6 1693 239 966 64.7 110.4 87.6 593.5 27123 26987 1690 238 964 88.4 45.3 600.7 27212 27162 9 1 \*1.4 259 949 89.2 676.0 859.8 29812 30301 20 1639 111.2 1622 252 937 66.8 88.3 42.9 713.5 848.7 30609 31522 \*5.5 1559 248 904 110.6 88.3 583.0 26060 27923 6.5 65.9 44.7 815.7 6 981 63.9 87.1 621.0 28330 27606 22 1702 265 109.3 15.1 685.5 1682 87.9 886.1 30916 30194 265 974 65.3 110.4 45.1 30427 29101 2.6 23 1718 284 1001 63.6 110.7 616.0 913.8 28274 1695 252 67.1 113.3 90.2 46.2 612.0 883.8 27961 6.4 8 971 256 975 66.9 112.0 89.5 45.1 669.5 885.5 30194 29802 0.2 1693 9 249 892 65.3 87.6 546.0 801.4 24351 26459 11.4 1535 109.9 41.6 22776 20.4 1597 252 925 88.4 505.0 836.6 23794 9 15 65.8 110.9 45.1 87.0 27167 262 63,9 16.1 589.3 874 0 27167 9.1 1659 961 11 271 86.8 24 1683 977 64.1 109.5 45.1 590.5 890.2 26809 26321 11.9 11 1 86.7 611.0 814.3 29238 931 61.0 Clean 1595 266 109.4 45.4 30039 Tubes 14 1690 267 979 67.8 68.5 114.0 46.2 650.2 888.1 45.7 \*Increase 91.4 661.0 889.6 30345 981 114.2 1693 268


112.5 89.7


874.0

45.8 652.7

29874

SERIES OF 1901





APPARATUS FOR THE DETERMINATION OF THE EFFECT OF SCALE ON HEAT TRANSMISSION THROUGH TITBES Fig. No. 4




Fig. No. 5 Apparatus for the Depermenation of the Effect of Scale on Heat Transmission Through Tubes



SERIES OF 1904

1 2 3 4 5 6 7a 7b 8a 8b 9 10 11 12	15 16 17 18 19 20 13 14 12 11 10 7 8	1 1 1 1 1 1 1 1 1 1	1432 1439 1436 1418 1438 1439 1437 1443 1414 1423 1431 1415 1426	648 659 667 515 523 511 647 523 623 593 547 517 536 551	1040 1049 1052 967 981 975 1043 980 1033 1004 985 974 976 989	56.8 57.9 58.0 57.7 57.1 58.3 57.0 56.5 57.0 58.9 57.6 59.0	84.7 84.0 83.2 80.4 83.4 82.7 81.9 81.5 89.4 91.3 83.8 84.8 85.1	70,8 71.0 70.6 69.1 70.5 69.5 69.0 73.2 75.1 70.7 72.0 71.0	27.9 26.1 25.2 22.7 26.3 24.4 24.9 25.0 32.4 26.2 25.7 26.3 29.3 29.3	829 850 895 975 814 865 875 803 662 654 767 808 735	969 2 978 0 981 4 897 9 910 7 904 5 973 5 911 0 959 8 928 9 914 3 902 0 918 0	23129 22185 22554 22133 21408 21106 21788 20075 21449 21190 20095 20766 19331 21414	22227 21128 21405 22958 21895 21734 20845 20845 20812 21247 20471 21442 19916 21727	5.1 9.8 8.6 2.0 6.5 7.2 11.0 12.4 19.3 12.6 8.5 15.0 7.2
13a 13b 13e	6 5 4	I 1 1	1441 1439 1440	554 563 569	998 1001 1005	56.5 56.7 56.3	82.5 85.1 82.6	69.5 70.9 69.5	26.0 28.4 26.3	891. 825. 900.	928.5 930.1 935.5	23166 23430 23670	Clean Tubes	
Ave	rage		1440	563	1001	56.5	83.4	70.0	26.9	872.	931 4	23422		
_							SER	IES O	F 190	)5				
3 3 3 3 4 4 4 4 8 8 8 8 8 9 9 9 9 9 10 10 11 11 12 12 13 13 13 14 14 15 15 15 15 15 15 15 15 15 15 15 15 15	48 49 50 46 47 24 25 26 27 28 29 30 31 32 34 35 37 38 39 40 41 41 41 41 41 41 41 41 41 41		1783 1781 1798 1816 1809 1806 1788 1790 1805 1752 1752 1763 1772 1783 1776 1785 1786 1785 1776 1787 1787 1787 1787 1787 1787 1787	873 879 867 733 743 743 743 743 743 759 786 803 804 804 790 740 740 740 740 740 740 740 740 740 74	1328 1330 1333 1275 1266 1267 1277 1277 1278 1285 1288 1291 1291 1290 1288 1253 1212 1292 1292 1298 1292 1292 1292 1292	62.4 62.4 62.2 62.2 63.3 59.7 60.1 60.1 60.9 59.7 67.0 64.0 60.2 64.0 60.2 64.0 60.2 66.3 66.3 66.3 66.3 66.3 66.3 66.3 66	103.6 102.1 99.2 102.6 102.4 102.4 101.7 100.4 101.7 100.6 101.8 101.4 103.1 102.4 103.1 102.1 102.1 102.1 102.1 102.1 102.1 102.1 102.1	83.0 82.3 80.6 82.4 82.6 82.6 82.9 81.7 80.3 80.3 80.3 80.3 80.3 80.3 80.3 80.3	41.2 41.3 41.2 40.4 43.0 40.6 40.9 42.3 43.0 42.3 43.0 42.3 43.0 42.3 43.0 42.3 43.0 42.3 43.0 42.3 43.0 42.3 43.0 44.0	717 753 800 699 692 641 666 682 695 674 663 677 757 721 679 668 695 665 668 674 669 668 674 674 767 721 668 669 660 660 660 660 674 674 674 675 674 675 674 674 675 675 675 675 675 675 675 675 675 675	1245.0 1247.7 1252.4 1192.4 1179.4 1173.1 1182.3 1185.7 1193.1 1191.5 1196.7 1196.7 1196.7 1206.7 1206.7 1206.7 1206.7 1206.7 1206.7 1206.7 1206.7 1206.7 1206.7 1206.7	29540 29894 29760 28240 27482 27057 27563 27918 27290 28140 27690 28426 28443 28509 28383 27612 26656 28087 27470 28099 28645 28109 2809 2809 2810	28722 29002 28764 28063 28155 27920 28502 27688 28009 28727 28718 28646 28449 27717 28674 28176 27598 28190 2822 28588	2.8 1.9 2.7 3.0 4.8 5.6 6.3 3.3 5.2 2.8 6.2 9.8 4.7 6.6 6.2 3.8 1.2 4.4 4.5 6.2 3.8 4.5 6.2 3.8 4.6 6.2 3.8 4.6 6.2 3.8 4.6 6.2 4.6 6.6 6.2 6.2 6.2 6.2 6.2 6.2 6.2 6.2 6
7 7 7	21 22 23	1 1 1	1792 1796 1808	794 787 784	1293 1292 1296	64.5 64.2 63.3	102.1 103.6 101.4	83.3 83.9 82.4	37.6 39.4 38.1	782 754 776	1209.7 1208.1 1213.6	29403 29708 29566	Clean	
Ave	rage		1799	788	1294	64.0	102.4	83.2	38.4	770.7	1210.5	29559		

The method of conducting a test was as follows:

The burner was first lighted and the gas and air pressures adjusted, then the flow of water through the water chamber was regulated and the apparatus allowed to run until all conditions had become uniform. This usually occupied about one hour, at the end of which time the test was started.

At the beginning of a test for the series of 1901 a determination of temperature was made by the copper ball pyrometer and readings were taken on all three thermometers, which readings were also taken at intervals of five minutes throughout the test. At the end another determination was made of the furnace temperature, and the water which had flowed through the chamber was weighed.

Observations for the tests of 1904 and 1905 were taken in a similar manner except that all temperature readings including that of the furnace were taken at regular intervals of 10 minutes.

Table No. 5 gives a summary of the data of the various tests and also the calculated results. The furnace temperature was not maintained quite the same throughout the tests, as an inspection of Table No. 5 will show. It was likewise impossible to maintain the average temperature of the circulating water the same during all the tests. Consequently the range of temperature between the gases in the tube and the water varied somewhat. Since the rate of transmission of heat through the tube varies directly with this range in temperature it is necessary, in order to compare the conductivity of the different tubes, to reduce the actual amounts of heat transmitted to what they would have been for one standard range of temperature. This standard range was assumed the same as the range existing during the test of a new clean tube, such a tube being tested with each series of tests.

These derived figures are given in column 14, Table No. 5, and they show the amounts of heat which would have been transmitted in each case had the difference between the temperature of the gases and the temperature of the water been the same in all tests of that particular series, i. e., the same as during the tests of the clean tube then tested. It is from the figures in this column that the losses due to scale are computed. This loss expressed as a per cent is exhibited in column 15 of Table No. 5.

Table No. 6 gives the chemical analyses of the scale found upon the tubes tested in the series of 1901, 1904 and 1905. The constituents of the scale are calculated to compounds and expressed as per cent. These analyses were made by the Chemical department of the University of Illinois.

TABLE 6 The Transmission of Heat through Scale-covered Boiler Tubes Railway Engineering Department—University of Illinois

	KAILW	AY ENGI	NEERIN	G DEPA	RTMENT	-UNIV	ERSITY	OF ILLI	NOIS
			CHEM	ICAL AN	ALYSES	OF SCAI	E		
		Constitue	ents of Sca	ile		_	Amount	in per ce	ent
	$\mathrm{SiO}_{\scriptscriptstyle 2}$	${ m Fe}_2{ m O}_3$	CaSO <sub>4</sub>	CaCO3	CaO	MgCO3	MgO		
Tube Number	Silica	Oxides of Iron and Aluminum	Calcium Sulphate	Calcium Carbonate	Calcium Oxide	Magnesium Carbonate	Magnesium Oxide	Moisture .	Organic Matter and Alkali
1	2	3	4	5	6	7	8	9	10
				SERIE	es of 19	01			
1 2 3 4 5 6	7.00 5.68 9.24 9.80 10.00 7.42 12.22	8.32 8.98 10.98 15.92 7.00 4.26 5.38	16.78 27.30 2.04 25.86 14.35 16.08 17.70	47.16 22-27 59.75 23.20 50.30 51.44 37.02	10.45 0 62 3.02	1.30  8.40 1.53 0.79	11.20 15.82 10.18 13.16 7.30 11.25 16.76	1.18 1.14 0.64 1.42 0.84 1.19 1.63	7.06 8.34 6.55 7.62 1.81 6.83 8.50
9	12.46	11.24	36.85	21.37		3.13	0.72	1.02	13.21
11	17.82	10.32	5.06	37.50	6.70		13.92	2.25	6.43
				SERIE	es of 19	04			
1 2 3 4 5 6 7a 7b 8a 8b 9 10 11 12	26.04 17.21 15.10 8.99 9.11 12.10 12.93 12.70 12.70 23.52 10.05 9.75 7.98	10.80 8.02 3.95 1.90 2.20 2.60 1.35 1.35 2.33 2.33 7.20 6.47 2.08 4.68	1.36 18.50 21.93 22.81 47.96 54.99 21.83 35.05 6.56 11.71 6.05 8.89	27.50 11.52 10.48 49.11 16.85 10.78 31.14 17.03 17.03 37.56 50.98 54.71 55.61	3.84	15.61 11.06 14.11 2.46 4.63 5.14 5.14 3.99 3.99 3.99	23.07 21.74 25.28 0.50 11.76 9.57 15.94 17.85 17.85 5.59 4.94 6.43 3.75	1	7.39 7.40 2.20 9.66 5.33 1.67 11.05 11.05 16.09 8.52 5.26 7.73
				SERII	es of 19	05			
3 4 8 9 10 11 12 13 14 15	7.09 6.92 6.61 8.44 3.33 7.09 27.72 9,54 16.87 24.03	5.05 3.57 1.34 2.52 1.43 2.30 9.53 10.38 4.73 12.69	17.16 21.57 0.62 12.59 5.82 14.87 12.11 8.41 2.22 1.46	19.45 3.61 74.26 56.80 67.99 58.18 10.05 9.67 40.30 31.37	25.61  1.64  0.24 3.87 6.06 0.35	0.77 0.15 0.33 2.22	34.10 1.85 10.87 11.43 11.11 8.26 29.90 39.09 19.25 20.91	0.58 0.56 0.68 0.87 0.48 0.75 1.07 0.71 0.83 1.45	15.80 36.31 5.47 7.02 8.20 6.33 9.38 18.33 9.74 7.74

Table No. 7 gives a summary of the data and results. In it are given for each tube the corresponding average loss as determined by the several experiments, as well as the thickness and some of the results of analyses. From this table there have been plotted five diagrams—Fig. 6, 7, 8, 9 and 10, which exhibit the loss due to the scale with reference to thickness, hardness and chemical composition. Fig. 6 shows the loss due to scale plotted with reference to its thickness. Fig. 7 is identical with Fig. 6, except that the letters H, S or M have been added at the various points to indicate the scale as being either hard, soft, or medium. In Fig. 8, 9 and 10 the loss due to the scale is plotted with reference to the amount of its chemical constituents; in Fig. 8 with reference to the sum of the percentages of calcium carbonate and magnesium carbonate: in Fig. 9 with reference to the percentage of calcium sulphate; and in Fig. 10 with reference to the percentage of silica.

In the series of 1901 there are a few tests which indicate an increase of conductivity of the scaled tube as compared with the clean tube. These are perhaps to be accounted for by errors in conducting the experiments, although they could not be detected at the time the experiments were made. The apparatus used in 1904 and 1905 was improved in some particulars, the most important change being in the means for the measurement of furnace temperatures. Such discrepancies disappear in the latter series.


When the experiments were planned it was considered probable that the transmission of heat through the scale was principally dependent upon two of its characteristics, namely, its thickness and its mechanical structure and that probably, for such thicknesses as are usually met with, thickness had greater influence than structure. Thickness was therefore carefully determined and structure approximately designated as in Table 4, as hard, soft or medium, no more exact characterization of structure being possible with tubes collected from different sources as these were.


It was hoped that the experiments might develop, if perhaps only approximately, some law of variation of conductivity with thickness. After making allowance for probable errors due to the method of conducting the tests, consideration of Fig. 6 shows perhaps a decrease of conductivity with thickness; but certainly no regularity of variation. In Fig. 7 the loss in heat transmission is again plotted with reference to thickness; and the structure of the scale, in so far as it was determined, is indicated as previously explained. No regularity of variation is observable with respect to hardness or softness.


## TABLE 7 SUMMARY


THE TRANSMISSION OF HEAT THROUGH SCALE-COVERED BOILER TUBES
RAILWAY ENGINEERING DEPARTMENT—UNIVERSITY OF ILLINOIS


_	_			_													
Tube No.	Test No.	Loss per cent	Ave. Loss per cent	Character of Scale	Thickness of Scale	CaCO <sub>3</sub> +MgCO <sub>3</sub> in Scale	Ca SO <sub>4</sub> in Scale	Si O <sub>2</sub> in Seale	Tube No.	Test No.	Loss per cent	Ave. Loss per cent	Character of Scale	Thickness of Scale	CaCO <sub>3</sub> +MgCO <sub>3</sub> in Scale	Ca SO <sub>4</sub> in Scale	Si O <sub>2</sub> in Scale
		S	ERI	ES (	OF 19	01						SEI	RIES	OF I	1905		
1 1 2	11 12 16	*0.6 2.9	1.2	Н	0.06	48.46	16.78	7.00	3 3 4	48 49 50	2.8 1.9 2.7	2 5	М	0.07	20.22	17.16	7.09
1 2 3 3 4 4 5 5 6 6 6 7 9	18 1 2	13.0 8.5 9.7 9.1	9.4	s H	0.06	22 . 27 59 . 75	27.30 2.04	5,68 9.24	4	45 46 47	$\begin{array}{r} 3.0 \\ 4.8 \\ 5.6 \end{array}$	4.5	Н	0.05	3.61	21.57	6.92
4 4 5	20 21 6	*1.4 *5.5 6.5	*3.5	H H	0.0 <b>3</b> 0.13	23.20 58.70	25.86 14.35	9.80	8 8 9	24 25 26 27 28	4.5 3.6 6.3 3.3 5.2 2.8 2.9 3.1	4.8	s	0.03	74.41	0.62	6.61
5 6 6	22 3 23 8	7.6 *2.1 2.6 6.4	0.3	<b>√</b>	0.07	52.97	16.08	7.42	9 9 10	28 29 30	5.2 2.8 2.9	3.8	s	0.09	57.13	12.59	8.44
7 9 9	9 4 15	0.2 11.4 20.4	3.3 15.9	M H	0.04	37.81 24.50	17.70 36.85	12.22 12.46	10 10 11	31 32 34	3.1 3.8 6.2	3,3 8.0	s	0.07	67.99	5.82	3.33
1 1 1 I	7 24	9.1 11.9	10.5 *I	S	0.09 ase	37.50	5.06	17.82	11 12 12	35 37 38	3.8 6.2 9.8 4.7 6.6 2.3 1.3	5.7	Н	0.04	60.40 10.05	14.87 12.11	7.09 27.72
		<u> </u>	Ser	IES	OF 1	.904			13 13 13	39 40 41	1.3	1.6	Н	0.02	9.67	8,41	9.54
1	15	5,1		Н	0.04	97.50	1.36	26.04	14 14	43 44	1.2 4.4 4.3	4.4	M	0.04	40.30	2.22	16,87
1 2 3 4 5 6 7a 7b 8a 8b 9 10 11 12	16 17 18 19 20 13 14 12 11 10 7	9.8 8.6 2.0 6.5 7.2 11.0 12.4 11.1 9.3 12.6 8.5 15.0 7.2		наямамминнням	0.04 0.07 0.08 0.05 0.04 0.08 0.06 0.06 0.05 0.04 0.06 0.06 0.05 0.04	27.50 27.13 21.54 63.22 19.31 15.41 36.28 36.28 21.02 21.02 37.56 58.31 60.43 66.97	1.30 18.50 21.93 22.81 47.96 54.99 21.83 35.05 6.56 6.56 11.71 6.05 8.89	20.04 17.21 15.10 8.99 9.11 12.10 12.93 12.70 12.70 23.52 10.05 9.75 7.98	15 15	51 52	3.8	3.6	Н	0.03	31.37	1.46	24.30











In considering Fig. 6 and 7 it must be borne in mind that the tubes tested were taken from locomotives which had been in service in different parts of the country and that the scale on each tube was made up of the mineral constituents of many different water supplies. What is designated as hard scale in one case may be very different in structure—in porosity, for example—from what is designated as hard scale on another tube. Fig. 7 cannot therefore be considered as providing conclusive evidence concerning variation of conductivity with structure. The results may properly be interpreted as indicating that mechanical structure is at least as important a factor in the change in heat transmission due to scale as is the mere thickness. Such a conclusion is, of course, in accord with the facts concerning other heat insulators.

Fig. 8, 9 and 10, in which the loss in heat transmission is plotted with reference to the principal chemical constituents of the scale, do not warrant the conclusion that its chemical composition has any direct influence on its conductivity.

From the point of view of the physicist the experiments are open to objection as to method. From the engineer's viewpoint it is believed that the possible errors of the experiments do not, by any means, account for all the irregularity in the plotted results, and considering the controversy upon this subject and the comparatively meager information available, it is deemed proper to publish at this time the results as they stand in the hope that they contribute additional information which may be of interest in some quarters.

#### Conclusions:

In so far as generalization is warranted we may sum up the results of the tests in the following conclusions:

- 1. Considering scale of ordinary thickness, say of thicknesses varying up to  $\frac{1}{8}$  inch, the loss in heat transmission due to scale may vary in individual cases from insignificant amounts to as much as 10 or 12 per cent.
  - 2. The loss increases somewhat with the thickness of the scale.
- 3. The mechanical structure of the scale is of as much or more importance than the thickness in producing this loss.
- 4. Chemical composition, except in so far as it affects the structure of the scale, has no direct influence on its heat transmitting qualities.

Publications of The Engineering Experiment Station

Bulletin No. 1. Tests of Reinforced Concrete Beams, by Arthur N. Talbot. 1904.

Circular No. 1. High-Speed Tool Steels, by L. P. Breckenridge. 1905.

Bulletin No. 2. Tests of High-Speed Tool Steels on Cast Iron, by L. P. Breckenridge and Henry B. Dirks. 1905.

Circular No. 2. Drainage of Earth Roads, by Ira O. Baker. 1906.

Bulletin No. 3. The Engineering Experiment Station of the University of Illinois, by L. P. Breckenridge. 1906.

Bulletin No. 4. Tests of Reinforced Concrete Beams, Series of 1905, by Arthur N. Talbot. 1906.

Bulletin No. 5. Resistance of Tubes to Collapse, by Albert P. Carman. 1906.

Bulletin No. 6. Holding Power of Railroad Spikes, by Roy I. Webber. 1906.

Bulletin No. 7. Fuel Tests with Illinois Coals, by L. P. Breckenridge, S. W. Parr and Henry B. Dirks. 1906.

Bulletin No. 8. Tests of Concrete: I. Shear; II. Bond, by Arthur N. Talbot. 1906.

Bulletin No. 9. An Extension of the Dewey Decimal System of Classification Applied to the Engineering Industries, by L. P. Breckenridge and G. A. Goodenough. 1906.

Bulletin No. 10. Tests of Plain and Reinforced Concrete Columns, Series of 1906, by Arthur N. Talbot. 1907.

Bulletin No. 11. The Effect of Scale on the Transmission of Heat through Locomotive Boiler Tubes, by Edward C. Schmidt and John M. Snodgrass. 1907.

Bulletin No. 12. Tests of Reinforced Concrete T-Beams, Series of 1906, by Arthur N. Talbot. 1907.

Bulletin No. 13. An Extension of the Dewey Decimal System of Classification Applied to Architecture and Building, by N. Clifford Ricker. 1907.

#### UNIVERSITY OF ILLINOIS

## Engineering Experiment Station

BULLETIN No. 12.

14.

15.

FEBRUARY 1907

17

18

# TESTS OF REINFORCED CONCRETE T-BEAMS SERIES OF 1906.

By Arthur N. Talbot, Professor of Municipal and Sanitary Engineering and in Charge of Theoretical and Applied Mechanics.

#### CONTENTS.

I. INTRODUCTION.

#### Page. Preliminary 1. 3 Scope of Tests.... 3 3 Acknowledgment 4 II. RESISTANCE OF T-BEAMS TO ELEXURE. 4. General ..... Notation.... 5 Longitudinal, Tensile and Compressive Stresses, and Location of Neutral Axis. - Approximate Solution 6 7. Web Stresses 9 Integrity of Flanges ..... 8. 11 Method of Treatment..... 12 9. Other Formulas for T-beams..... 10. 12 MATERIALS, TEST PIECES, AND METHODS OF TESTING. 11. Materials ..... 13 Test Specimens..... 12. 14 13 Forms ..... 17

Fabrication and Storage .....

Method of Testing .....

#### IV. EXPERIMENTAL DATA AND DISCUSSION.

		rage
16.	Cube and Cylinder Test Data	19
	Deflection Diagrams	
	Phenomena of Tests	20
	Tension in Steel	24
20.	Compression in Concrete	25
	Web Stresses	$2 \vec{0}$
	Beam Deflection	28
	Position of Neutral Axis	28
	Applicability of Results	29
	Summary	30
	Deflection Diagrams	32

#### I. Introduction.

1. Preliminary.—The series of tests on T-beams herein described was undertaken with two objects in view,—to determine whether the width of slab within the limit used in the experiments is a controlling element in the strength of the beam, and to test the efficacy of vertical reinforcing stirrups in resisting web stresses.

When a reinforced concrete floor and its supporting beams are built as one piece, the resulting composite structure forms a system of T-shaped beams. There are differences of opinion on the action of the T-beams so formed, and also differences as to the width of flange or floor which may be considered to contribute to the strength and stiffness of the beam. T-shapes may also be used in the design of bridge girders and other structures for special conditions. The large amount of reinforcement which may be put into a T-beam without encroaching on the compressive strength of the concrete too far and the resulting high web stresses developed in the stem of the T-beam, make the T-beam an advantageous form of test piece for determining the efficacy of various forms and amounts of web reinforcement. It is felt that this feature of T-beam testing is, in itself, sufficient reason for the conduct of tests on T-beams.

2. Scope of Tests.—Three top widths of beam were used. equal, respectively, to two, three, and four times the width of the stem of the beam. The beams were reinforced vertically with U-shaped stirrups. One size and spacing of stirrups was used. To insure that failure would not occur by slipping of the vertical reinforcement in the concrete, the stirrups were made of deformed bars. The amount of longitudinal reinforcement was made proportional to the width of flange of Both mild steel plain round rods and high-carbon Johnson corrugated bars were used for the longitudinal reinforcement, as it was not known whether the point of elastic limit of the metal would control the amount of load or method of failure. As no data on the amount of the web stresses which may be resisted by vertical stirrups were available and as little seemed to be known on the effect of the width of flange or slab, the beams were designed to give considerable latitude in the results The series was considered as preliminary and leading to a set of

tests which should include various forms and amounts of web reinforcement.

3. Acknowledgment.—The investigation was made in the Laboratory of Applied Mechanics of the University of Illinois as a part of the work of the University of Illinois Engineering Experiment Station. Assistance in the tests and in the calculations was given by F. S. Hewes and C. A. Hewes, senior students in civil engineering, class of 1906, who used the results in their thesis. Immediate supervision of the work of making the beams and conducting the tests was given by D. A. Abrams, Assistant in the Engineering Experiment Station. Acknowledgment is also made to W. R. Robinson, Assistant in the Engineering Experiment Station, for aid in the preparation of this bulletin. The stone, sand and cement used in making the beams were furnished by the Joint Committee on Concrete and Reinforced Concrete.

An analysis of some of the elements of flexure of T-beams will be given. This will be followed with a description of the test pieces and method of testing, the experimental data, and a discussion of the results.

#### II. RESISTANCE OF T-BEAMS TO FLEXURE

General.—The analysis of the resistance of T-beams to flexure may be made to follow the general lines of analysis for rectangular beams. If the tensile strength of the concrete be not considered at sections having a maximum bending moment and if the flange or slab extends down to the neutral axis of the beam, the resisting moment may be expected to be the same as that for a rectangular beam of width equal to the width of the flange, provided, of course, that the integrity of the plane section is conserved. If the flange does not extend down to the neutral axis, an examination of the effect of the omission of a part of the compression area must be made to find whether the formula for rectangular beams is still applicable. With relatively shallow flanges some modification of the formulas used in rectangular beams for determining neutral axis, tensile and compressive stresses, and resisting moment may be required. determination of web stresses, a slightly different treatment will be needed on account of the narrowed width of beam through the stem. The stiffness and integrity of the flange next to its junction with the stem will require investigation.

In the treatment here given, the usual assumptions of beam action noted in Bulletin No. 4 will be made. These include the assumptions that a plane section before bending will remain a plane section after bending and that tensile stresses in the concrete at the section of greatest bending moment may be neglected. The stresses developed in the flange to conserve the plane section will be considered separately. The general treatment will follow that given in Bulletin No. 4 of the University of Illinois Engineering Experiment Station, under I. Resistance of Beams to Flexure, and equations from this source will be quoted without demonstration. The term "inclosing rectangle" will be used to denote the rectangle inclosing the flange of the T-beam and the stem down to the centroid of the reinforcing bars.

5. Notation.—The following notation will be used, Fig. 1:

h =thickness of flange or slab of T-beam.

b =breadth of flange or slab of T-beam.

b' =breadth of stem of T-beam.

d = distance from the compressive face to the centroid of the longitudinal reinforcement.

d'= distance from the center of the longitudinal reinforcement to center of gravity of compressive stresses.

A =area of cross section of longitudinal reinforcement.

bd = area of inclosing rectangle (rectangle inclosing flange and stem of T-beam down to center of the longitudinal reinforcement).

 $p = \frac{A}{bd}$  = ratio of area of longitudinal reinforcement to area of inclosing rectangle.

o = circumference or periphery of one reinforcing bar.

m = number of reinforcing bars.

 $E_{\rm s} = {\rm modulus}$  of elasticity of steel.

 $E_{\rm c}$  = initial modulus of elasticity of concrete in compression, a term defined in Bulletin No. 4.

 $n = \frac{E_{\rm s}}{E_{\rm c}} = {
m ratio~of~two~moduli.}$ 

t = tensile stress per unit of area in longitudinal reinforcement.

c = compressive stress per unit of area in most remote fiber of concrete.

c' = compressive stress per unit of area which causes failure by crushing.

 $\epsilon_s = {
m deformation} \ {
m per} \ {
m unit} \ {
m of} \ {
m length} \ {
m in} \ {
m the} \ {
m longitudinal} \ {
m reinforcement}.$ 

 $\varepsilon_c$  = deformation per unit of length in most remote fiber of the concrete.

 $\varepsilon'_c$  = deformation per unit of length when crushing failure occurs; i. e., ultimate or crushing deformation.

 $q=rac{arepsilon_c}{arepsilon_e}={
m ratio}\ {
m of}\ {
m deformation}\ {
m existing}\ {
m in}\ {
m most}\ {
m remote}\ {
m fiber}\ {
m to}\ {
m ultimate}\ {
m or}\ {
m crushing}\ {
m deformation}.$ 

k = ratio of distance between compression face and neutral axis to distance d.

z =distance from compression face to center of gravity of compressive stresses.

M = resisting moment at the given section.

s = horizontal tensile stress per unit of area in the concrete.

t = diagonal tensile stress per unit of area in the concrete.

u =bond stress per unit of area on the surface of the reinforcing bar.

v = vertical shearing stress and horizontal shearing stress per unit of area in the concrete.




Fig. 1. T-BEAM AND INCLOSING RECTANGLE.

6. Longitudinal, Tensile and Compressive Stresses, and Location of Neutral Axis.—Approximate Solution.—Under the assumption that horizontal tensile stresses in the concrete are not to be considered and that a plane section before bending remains a plane section after bending, the formulas for rectangular beams may be made applicable to T-beams with a close degree of approximation by the substitution of the rectangle inclosing the flange and stem down to the centroid of the reinforcing bars (called here the inclosing rectangle) shown in Fig. 1. If the flange of the T-beam were thick enough to extend down to or below the neutral axis, the part of the concrete not included in the inclosing rectangle would, by the assumptions quoted above, not affect the resistance of the beam

to flexure. If the flange does not extend to the neutral axis, a part of the compression area assumed to exist for the inclosing rectangle is not available in the T-beam, but the portion so cut off has, by reason of its proximity to the neutral axis, a comparatively small influence upon the flexural action of the beam. The effect is so little that we may, within certain limits of proportions, substitute the inclosing rectangle for the T-section in determining the position of the neutral axis, the tensile stress in the reinforcement, the compressive stress in the most remote fiber of the concrete, and the resisting moment of the section.

For this approximation, the formulas given in Bulletin No. 4 for the proportional depth of the neutral axis may be repeated:

For a constant modulus of elasticity in the concrete (straightline stress-deformation relation),

$$k = \sqrt{2 pn + p^2 n^2 - pn}$$
....(10)

When the deformation in the most remote fiber is equal to one fourth of the ultimate or crushing deformation  $(q=\frac{1}{4})$ , a condition approaching that found in beams of the usual percentage of reinforcement, the general equation for neutral axis reduces to,

$$k = \sqrt{\frac{\frac{24}{11} pn + \frac{144}{121} p^2 n^2 - \frac{12}{11} pn \dots (11)}$$

Equation (8) of Bulletin No. 4 may be used for the general case and (9) when the concrete is at the limit of the compressive strength.

The diagram given on page 16 of Bulletin No. 4 will be useful in determining the position of the neutral axis if equation (11) is to be used. With 1% reinforcement, for a ratio n equal to 12, k will be .40; for a ratio n equal to 15, k will be .43.

For a beam in which the compressive stress developed is less than the ultimate strength of the concrete (and this condition covers all the usual cases of T-beams), the formula for the resisting moment of the beam may best be expressed in terms of the tensile stress in the reinforcing bars, as given in the two equations:

$$M = Af(d-z)...$$

$$M = Afd'...$$
(12)

If k=.40, or .43, the latter equation may be written M=.86 A f d, and this equation for the resisting moment of the T-beam may be used with sufficient accuracy for many purposes, even for quite a range of reinforcement. If the bending moment is known, the stress in the steel may be calculated by substituting the value of the bending moment for M in equation (13) or in the reduced form M=.86 A f d. The effect of substituting the inclosing rectangle for the exact T-shape in determining the position of the neutral axis and the center of the compressive stresses is so slight that the error may be neglected and the above formulas used when the flange extends at least two thirds of the distance to the neutral axis or, say, when the thickness of the flange is at least one fourth of the depth of the beam. Even for thinner flanges the error in the use of these formulas will not be large.

Values for compressive stresses in T-beams are not of very general usefulness since the percentage of reinforcement (based on the inclosing rectangle) will generally not be large and the compressive stresses hav therefore not need to be considered and may be sufficiently guarded by limiting the percentage of reinforcement. To illustrate, if in a T-beam made up of a beam and its connecting portion of the floor a width equal to four times the width of the beam itself be considered to be tributary to the T-beam and if the area of the reinforcing bars is 4% of the area inclosing the stem of the T-beam (b'd, of Fig. 1), this reinforcement will be only 1% of the inclosing rectangle of the Under conditions of good construction, the assumed T-beam. compressive stress developed in the concrete, would, as has been shown for rectangular beams, be well below any danger of a compression failure. This amount of steel is larger than would ordinarily be used in such construction.

If, however, it is desired to compute the compressive stress, an approximate solution may be made by equation (15) of Bulletin No 4,

$$c = \frac{2Af}{kbd} \cdot \frac{1 - \frac{1}{2}q}{1 - \frac{1}{3}q} \cdot = \frac{2pf}{k} \cdot \frac{1 - \frac{1}{2}q}{1 - \frac{1}{3}q} \dots (15)$$

where b and p refer to the inclosing rectangle. For the conditions of T-beams the fraction  $\frac{1-\frac{1}{2}q}{1-\frac{1}{3}q}$  will likely range between

.92 and .97, so that its use or non-use does not affect the results materially.

There is a greater proportional error in the use of equation (15) for beams in which the flange does not extend down to the neutral axis than there is in the use of equation (13), but as the purpose is only to find whether a limiting value is exceeded, the limits for depth of flange used with equation (13) may be considered allowable. This is further borne out by the fact that in floor systems a width of floor even greater than here used will generally be tributary to the T-beam, and hence the compressive stress will be lower than for an assumed ratio of 4.

7. Web Stresses.—Bond, Shear, and Diagonal Tension.—In T-beams the bond stresses developed are practically the same as would be found with the same steel in a rectangular beam. The shearing stresses developed and the corresponding diagonal tensile stresses are higher, since the width of stem is relatively small; and even with a moderate amount of reinforcement the resistance to web stresses may constitute the weakest element of the beam.

The bond stress developed in a T-beam when the longitudinal reinforcing rods are laid horizontally throughout the length of the beam may be determined by equation (17) of Bulletin No. 4, (p. 19),

$$u = \frac{V}{mod'}....(17)$$

where u is the bond unit-stress developed, V is the total external vertical shear, m is the number of reinforcing bars, o is the effective circumference or periphery of one bar, and d' is the distance from the center of the longitudinal reinforcement to the center of gravity of the compressive stresses. The only approximation to be made is in getting the value of d'. As in the preceding article, d' may be taken to be d (1-.34 k), and k may be obtained as before suggested by the use of the method of rectangular beams with the width of the beam taken as that of the inclosing rectangle. For most conditions d' may be called .86d.

The reasoning for the determination of vertical and horizontal shearing stresses given on page 20 of Bulletin No. 4 is directly applicable to T-beams, and formula (18) will give the horizontal shearing unit-stress (and therefore its equal, the vertical shear-

ing unit-stress), if we use in it the width b', the width of the stem of the T-beam.

$$v = \frac{V}{b'd'}.$$
 (18)

In equation (18) v is either the horizontal or the vertical shearing unit-stress, the two shearing unit-stresses being always equal. For most conditions d' may be taken as .86d, as in the last paragraph. The amount of the vertical shearing unit-stress developed in T-beams may be much higher than in ordinary rectangular beams, but it will be well below the ultimate shearing strength of the concrete.

The diagonal tensile stress in the stem of the T-beam is a function of the shearing stress and the horizontal tensile stress in the concrete. As the horizontal tensile stresses may not be well determined, it seems best for our purpose to use the horizontal and vertical shearing stresses as a means of comparison of the diagonal tensile stress developed. If part or all of the reinforcing bars are bent up at the ends, the problem is further complicated. The beams described in this bulletin were reinforced with vertical stirrups, and as the concrete itself failed to resist the diagonal tension at points well below the maximum load put on the beam, the resistance of the concrete to diagonal tension will be disregarded for these tests and the effect of the vertical stirrups studied.

Two forms of metallic web reinforcement are used to counteract the diagonal tension: (1) bending the reinforcing bars or strips sheared from them into a diagonal position, and (2) vertical stirrups carried under and around the longitudinal reinforcement and extended upward to the top of the beam or to some anchorage. The T-beams tested were reinforced with vertical stirrups, and hence this form of web reinforcement will be considered further.

The diagonal tension existing in the web may be resolved into horizontal and vertical components. Considering the longitudinal bars to be all horizontal, we may expect, when the bond resistance is sufficient, that the horizontal component will be taken by the longitudinal reinforcement. Considering that the test has passed the point where the concrete of the web resists the diagonal tension, we may count that the whole vertical component of the

web stresses is taken by the stirrups. The amount of this vertical component per unit of length of beam is for the T-beams equal to the horizontal shear for the width of the stem as given by

equation (18), and  $vb' = \frac{V}{d'}$  will give the rate of vertical stress

per unit of length of beam which will go to the stirrups. If the stirrups are 6 inches apart, the stress to be taken by the two prongs of the stirrup will be 6 vb'. This calculation is on the basis of a test loading which gives a constant shear from support to load point, as, for example, a loading at the one-third points. For a uniformly distributed load, the value vb' will be the rate of stress at a given section. To illustrate further, for a T-beam having a width of stem of 8 in., and d' = 8.6 in., and a load of 60 000 lb.,  $V = 30\,000$  lb., and v = 437 lb. per sq. in. With stirrups 6 inches apart the total stress on one prong of the stirrup will be 10 500 lb. These calculations do not take into account the resistance to bending of the reinforcing bars themselves. In the T-beams having also a part of the bars bent up, in order to avoid complicated calculations and to give a general comparison, the same formulas will be used herein, although the results are not an accurate measure of the stresses produced.

8. Integrity of Flanges.—In discussions on T-beams it is frequently stated that the thickness of the flange must be at least one half as great as the width of the stem or rib, in order that the shearing stresses at the junction of the flange and stem may not exceed those in the lower part of the stem. As the actual shearing stresses in both sections are well within the shearing strength of the concrete, there is no danger of failure by shear in either section, using the term shear in its strict sense. In the stem we have used the shearing unit-stress as a measure or method of comparison for the diagonal tensile stresses. In the flange these stresses do not need consideration. Longitudinal shearing stresses in the flange, then, will not require consideration, and the limit of depth given above is unnecessary.

Another statement sometimes made is that the compressive stress in the flange varies across the width of the flange from a maximum amount next to the stem to zero at the edge of the flange. A little consideration will show that this cannot be true. The flange must transmit stress laterally to its edges, acting in a way as a beam with a load applied longitudinally and horizontally. The width of the overhang of the flange may be considered to be the span of this cantilever beam, and the distance from the load to the support (one-third the span length in the beams tested) may be thought of as the depth. Evidently this will be a very stiff beam, and the result will be a close approach to uniformity of compressive stress at points across the width of the flange. Little variation from a plane section may therefore be expected, the change that may exist being produced more largely by other causes. Of course, there must be a limit to this assumed integrity of the cross section, but for T-beams with the ordinary amount of reinforcement the compressive stress developed is small and the variation may generally be neglected.

As usually constructed, the floor, and hence the flange of the T-beam, will have reinforcement at right angles to the stem. This will resist a breaking of the flange next to the stem and assist in giving the whole flange the curved shape which the beam takes when the load is applied.

- 9. Method of Treatment.—For the investigation herein recorded, the preceding method of analysis will be used. The T-beam will be treated as a rectangular beam of the dimensions given by the inclosing rectangle, when tensile, compressive, and bond stresses are under consideration. The width of the stem will be considered to enter into calculations for shear and for diagonal tension. The integrity of the cross section will be investigated somewhat, and the bearing of the approximation involved in the above assumptions will be looked into.
- 10. Other Formulas for T-beams.—If it is desired to take into account the exact section above the neutral axis the following formula for the proportionate depth of the neutral axis may be used, if we consider q = 0, or if we use a straight-line modulus of elasticity. Other values of q may be used.

$$k = \sqrt{2 pn \begin{pmatrix} b \\ b^{7} \end{pmatrix} - \frac{h^{2}}{d^{2}} \left( 1 - \frac{b}{b^{\prime}} \right) + \left[ pn \begin{pmatrix} b \\ b^{\prime} \end{pmatrix} + \frac{h}{d} \begin{pmatrix} b \\ b^{\prime} - 1 \end{pmatrix} \right]^{2}}$$
$$- pn \begin{pmatrix} b \\ b^{\prime} \end{pmatrix} - \frac{h}{d} \begin{pmatrix} b \\ b^{\prime} - 1 \end{pmatrix} \dots (10^{\prime})$$

For a beam with 1% reinforcement and having a ratio of depth of flange to effective depth of steel  $\left(\frac{h}{d}\right)$  of  $\frac{1}{4}$ , using for

comparison n=15, this formula gives k=.44, and the approximate method previously described gives k=.42. For  $\frac{h}{d}=\frac{1}{5}$ , k=.46. It is easily seen that the effect of this difference upon the calculated resisting moment of the beam (when based on tension in the steel) is small.

### III. MATERIALS, TEST PIECES, AND METHOD OF TESTING.

11. Materials.—The stone was a good quality of rather hard limestone from Kankakee, Illinois, ordered screened through a 1-in. screen and over a \(\frac{1}{4}\) in. screen. It contained 45% to 50% voids and weighed 85 pounds per cubic foot. In the determination of the voids of both stone and sand, the material was poured slowly into water so that the voids became filled with water and no air was caught.

The sand was of good quality from near the Wabash river at Attica, Indiana. It was fairly clean, sharp and well graded, contained 28% voids, and weighed 115 lb. per cu. ft. Table 1 gives the results of a mechanical analysis of this sand.

TABLE 1.
MECHANICAL ANALYSIS OF SAND.

Sieve No.	Per cent Passing
4 10	100 73
$\begin{array}{c} 20 \\ 30 \\ 74 \end{array}$	36 12 5
100	2

The cement used was furnished by the Joint Committee on Concrete and Reinforced Concrete. It was made up of a mixture of five standard American portland cements, selected and mixed by the manufacturers and was of excellent quality.

The concrete was made of the proportions of 1 of cement, 2 of sand, and 4 of stone, measured by loose volume. The mixing was done and the beams made by men skilled in concrete work. Care was taken in measuring, mixing, and tamping, to secure as uniform a concrete as possible. The mixing was done with

shovels by hand; the stone having been wetted a day or so before being used. The sand and cement were first mixed dry, the stone being then added and the mass mixed until uniform in appearance. Water was added in such proportion that the tamping of the central portion of the beam really amounted to a churning action.

The steel used for the horizontal reinforcement in some of the beams was  $\frac{3}{4}$ -in. mild steel plain round rods, and in the rest was  $\frac{3}{4}$ -in. high steel Johnson corrugated bars. The stirrups were in all cases  $\frac{1}{2}$ -in: high steel Johnson corrugated bars. Table 2 gives physical tests of these rods, the samples tested being from

TABLE 2.

Tension Tests of Steel Used in T-beams.

Average Values.

T-beam	Size of Bar inches	Per cent Elongation in 8 in.		Maximum Load pounds	Yield Point lb. persq. in.	Maximum Load
		111 0 111.	pounds	Pounds	to. persq. iii.	to. per sq. m.
1	$\frac{3}{4}$ -in. Johnson	13.5	30 700	51 300	54 900	91 600
$^2$	bar (new section)	15.0	30 250	48 000	53 750	86 200
3	Area=.56 sq. in.	14.5	29 700	50 000	52 700	89 000
5	•	15.0	30 100	48 900	53 380	86 980
Av.		14.5	30 200	49 500	53 800	88 400
4	.750 plain round	34.5	16 600	24 600	35 100	55 500
8	.750 plain round		18 100	26 600	40 700	59 900
9						
<i>9</i>	.750 plain round	32.0	17 300	26 100	39 100	59 100
Av.		32.4	17 300	25 800	38 300	58 200

the ends left after the bars were cut for the beam. The average ultimate strength of the plain round rods was 58 200 lb. per sq. in. and the yield point 38 300 lb. per sq. in. The \(\frac{3}{4}\)-in. Johnson bars developed an average ultimate strength of 88 400 lb. per sq. in., and a yield point of 53 800 lb. per sq. in.

12. Test Specimens.—Table 3 shows the specimens which were made and tested. The nine T-beams were 11 ft. long and the span used was 10 ft. The following dimensions were constant for all the beams: thickness of flange, 3½ in.; width of web, 8 in.; depth over all, 12 in. and depth from top fiber to center of steel, 10 in. The width of flange varied, three speci-

mens being made of each of the widths; 16 in., 24 in., and 32 in.

The proportion of reinforcement was from .92% to 1.10%, based on the area of the inclosing rectangle, as shown in Fig. 2; that is, it was obtained by dividing the area of the steel by the product of the breadth of the flange and the effective depth of the beam. This percentage was made as near 1.00 as the size of the reinforcing bars would permit. It will be noted that if the percentage were based on the area of the rectangle inclosing the stem, it would be very high, the amount for the beams 32 in. wide amounting to about 4%. The reinforcing rods were symmetrically arranged with respect to the axis of the beam. In some, a part

TABLE 3.
LIST OF TEST SPECIMENS.

All Beams Have Stirrups of ½ in. Johnson Bars Placed as Shown in Fig. 2.

		Minor	Specimens				
		Reinforcen					
T-beam Width			Ar	Area		Cylinders	
No.	Flange inches	Kind	sq. in.	per cent	Cubes	Cymaers	
1	16	3 ¾-in. Johnson bars	1.68	1.05	$\begin{cases} 1_1 \\ 1_2 \\ 1_3 \end{cases}$	1	
2	32	$6^{\frac{3}{4}}$ -in. Johnson bars	3.36	1.05		2	
3	24	4 ¾-in. Johnson bars	2.24	0.93	$\begin{cases} 3_1 \\ 3_2 \\ 3_3 \end{cases}$	3	
4	16	$4^{\frac{3}{4}}$ in. plain round	1.76	1.10	( 03	4	
5	32	$ \int_{0}^{6} \frac{1}{2} - in $ In Johnson bars Left bars bent up	3.36	1.05	$\begin{cases} 5_1 \\ 5_2 \end{cases}$	5	
6	24	$\begin{cases} 5 \frac{3}{4}$ -in. plain round $\end{cases}$ 2 bars bent up	2.20	0.92	, -		
7	16	4 ¾-in. plain round	1.76	1.10	$\left\{egin{array}{c} 7_1 \ 7_2 \ 7_3 \end{array} ight.$	7	
8	24	$\begin{cases} 5 & \frac{3}{4}$ -in. plain round $2 & \text{bars bent up} \end{cases}$	2.20	0.92	$\begin{cases} 8_1 \\ 8_2 \\ 8_3 \end{cases}$	8	
9	32	$\begin{cases} 7^{-\frac{3}{4}}\text{-in. plain round} \\ 3 \text{ bars bent up} \end{cases}$	3.08	0.97	(00		

of the rods was turned up beyond the one third points to within 4 in. of the top of the beam. Ten U-shaped stirrups of ½-in. high steel Johnson corrugated bars were used in each beam. These stirrups were spaced 6 in. apart on the portions of the beam between the load points and supports. They passed under the corrugated




Fig. 2. Arrangement of Reinforcement.

reinforcing bars, alternate ones inclosing only the middle bars. In two of the 32-in. beams three ½-in. Johnson corrugated bars were placed transversely in the upper side of the flange at and near the load points. Fig. 2 shows the arrangement of the reinforcement in all of the beams. In some of the beams in which the reinforcing bars were placed in two layers, the upper bars sank down in the mortar until they were in contact with the lower layer of bars.

Fourteen 6-in. cubes were tested. The numbering is the same as that for the beams for which the batch was made. Seven 8-in. cylinders were made in a similar manner.

13. Forms.—Fig. 3 shows the plan of the forms used in making the T-beams. 2-in. planks were used for the sides and ends. Clamps and struts were of 2-in. x 4-in. pieces. The planks




Fig. 3. Plan of Forms.

were soaked in water for some time before using, in order to prevent the absorption of water from the beams.

14. Fabrication and Storage.—The beams were made on the concrete floor of the laboratory, strips of building paper being laid on the floor to prevent the concrete from adhering to it. As already stated, the concrete was proportioned by loose volume and mixed by hand. Generally, two batches were mixed in making a beam.

After the form was set up, a layer of concrete 1-in, to  $1\frac{1}{2}$  in. thick was put in, the reinforcement placed, and the rest of the concrete filled in in layers about 3 in thick. The sides and ends were spaded, the concrete tamped, then spaded again and tamped. This gave a very good surface to the test pieces.

The forms were kept on until a day or so before testing the beams, the beams being sprinkled twice daily in the meantime. The temperature of the room ranged from 60° to 70° F. during the period of storage.

15. Method of Testing.—Fig. 4 shows the method of loading used. The beams were tested in the 600 000-lb. Riehle' testing machine, the load being applied at the one-third points through turned steel rollers, which were 2 in. or  $4\frac{1}{2}$  in. in diameter, according to the size of the beam. Each of these rested on a cast iron plate, 2 in. x 3 in. x 2 ft. 8 in., faced on both sides, which distributed the load laterally over the beam. The supports had curved bottoms to permit rocking, and plates 8 in. x  $1\frac{1}{2}$  in. x 8 in. were used as bearing plates. These plates, together with the bearing plates on the top of the beam, were bedded in




Fig. 4. METHOD OF TESTING.

plaster of paris which was allowed to harden under the weight of the beam and the aparatus used in loading, before the load was applied. The movement of the head, in testing, was  $\frac{1}{2^{10}}$  inch per minute. Center deflections were read on all T-beams and deformations were observed on a few. The deflections were obtained by means of a thread stretched between two points over the supports and about seven inches from the top of the beam. The frame used for holding the extensometer dials was improvised and its lack of rigidity seriously impaired its usefulness, the readings being sometimes inconsistent and therefore untrustworthy. Since at the present time tests are being made here in which reliable deformation readings are expected, diagrams from the readings taken in this series will not be reproduced.

The cubes, cylinders, and steel were tested on the 100 000-lb.

Riehle' machine, the speed of the head being .1 inch per minute. The cubes and cylinders were bedded in plaster of paris before testing.

#### IV. EXPERIMENTAL DATA AND DISCUSSION.

- 16. Cube and Cylinder Test Data.—Table 4 gives the results of the tests of the cubes and cylinders. The breaking strength of the cylinders is somewhat below that of the cubes. The concrete showed very good quality.
- 17. Deflection Diagrams.—Fig. 7 to 15 at the end of the text give the load-deflection diagrams for the T-beams. The ordinates (vertical distances) represent the applied loads, and the abscissas

TABLE 4.
RESULTS OF CUBE AND CYLINDER TESTS.

	~	Cubes		Cylinders				
No.	Age at Test Days	Maxi Total Pounds	lb. per sq. in.	No.	Age at Test Days	Maxim Total pounds	lb. per sq. in.	
$\begin{array}{c} 1_1 \\ 1_2 \\ 1_3 \\ \hline A_V. \\ \hline 3_1 \\ 3_2 \\ 3_3 \\ \hline A_V. \\ \hline 5_1 \\ 5_2 \\ \hline A_V. \\ \hline 7_1 \\ 7_2 \\ 7_3 \\ \hline A_V. \\ \hline 8_1 \\ 8_2 \\ 8_3 \\ \hline A_V. \\ \hline \end{array}$	59 59 59 57 57 57 57 57 58 58 56 56 56 56 54 54	62 120 84 690 66 390 42 120 49 620 46 200 69 800 81 500 57 600 71 100 68 300 68 100 55 600 94 500	1720 2350 1840 1970 1170 1380 1280 1280 1280 2100 2100 1600 1980 1900 1830 1840 2620	1 2 3 4 4 5 7 8 Av.	63 63 61 59 58 56 54	95 000 94 200 88 200 67 000 60 000 73 000 88 000	1890 1870 1760 1330 1190 1450 1750 1610	

(horizontal distances) the corresponding deflection at the center of the beam. It will be seen that at or near the maximum load the curve changes direction abruptly, and that for nearly all the beams the load does not fall off materially until a considerable deflection has been obtained. The stress-deformation curves found (not reproduced) show an abrupt change on the tension side of the beam.

18. Phenomena of Tests.—In Table 5 (p. 25) are given the maximum loads which the beams sustained. Fig. 5 and 6 give sketches showing position of cracks as they appeared after the maximum load and also the shape of the flange in Beam No. 2 after it broke off. The general phenomena of the tests of the T-beams were quite similar to those attending the tests of rectangular beams




Fig. 5. Sketch of Beams after Failure.

having a similar percentage of reinforcement. When the tension in the steel reached 13000 to 20000 lb. per sq. in., minute vertical cracks became visible in the concrete on the lower part of the faces of the stem of the T-beam at points in the middle third of the span length. These grew more distinct as the load was increased. When the load became sufficient to strain the steel to its yield point, these cracks opened up and finally became quite large and extended up into and along the flange of the




Fig. 6. Sketch of Beams after Failure.

beam. The evidences of failure by tension in the steel were apparent in every beam, as much so in those reinforced with corrugated bars as in those having plain rods.

At loads somewhat above the amounts at which it would be expected that failures by diagonal tension in the concrete would occur in beams not having metallic web reinforcement, minute diagonal cracks appeared on the face of the stem in the outer thirds of the span length. These cracks had the direction and appearance of cracks attending failure by diagonal tension. Their consideration will be taken up under "21. Web Stresses," (p. 26).

In general, the flanges gave no sign of failure. In one (Beam No. 2) the flange split off after the maximum load was reached, as shown in Fig. 6. In this beam there was no lateral reinforcement in the flange. It seems evident that the tearing off occurred by reason of the warping of the flange as bending took place, and as this effect was not found in the other two beams of 32-in. width, the presence of the lateral rods in the beams was probably advantageous. Such rods would, of course, be present in ordinary floor construction, and uneven bending would be resisted by this lateral reinforcement.

In the representation of diagonal and vertical cracks after the maximum load had been reached, shown in Fig. 5 and 6, the tension crack which caused failure is indicated by a heavy line. The diagonal crack first to appear is numbered 1. These diagonal cracks generally intersected the plane of the reinforcing bars at their intersection with the stirrups. The description of the action of the beams which follows is given only in sufficient detail to indicate their general behavior, though individual peculiarities of beams are also noted.

Beam No. 1.—Two tension cracks at points at the level of the reinforcing bars between the load points appeared at an applied load of 16 000 lb. Before 20 000 lb. was reached eight more tension cracks appeared in the middle third of the span length. At 20 000 lb. the first diagonal crack appeared. At 26 000 lb. it had extended to within 2 inches of the flange. With further loading a large number of diagonal cracks developed. After reaching a load of 42 000 lb., (deflection 0.5 in.), the load fell off to 41 000 lb., as the machine speed did not keep up with the deflection of the beam under the given load. The load

then slowly rose to 44 500 lb., the deflection increasing to 1.34 in. During this period the tension cracks opened up quite rapidly, while the diagonal cracks remained about the same, one diagonal crack becoming  $\frac{1}{32}$  in. wide. Finally, at a deflection of 1.6 in., and an applied load of 43 800 lb., the concrete crushed at one of the load points.

Beam No. 2.—The failure of this beam was peculiar in that after it had passed the maximum load and had shown all the evidences of failure by tension of the steel, instead of holding about the same load and deflecting considerably more as the machine was run down, the final breaking was by the flanges splitting off as shown in Fig. 6. This was the only one of the three beams with 32-in. flanges which did not have lateral reinforcing rods in the flange at and near the load points. The first tension crack appeared at a point 10 in. west of the center at a load of 26 000 lb. and others appeared at 28 000 lb.

The first diagonal crack was observed 19 in. west of the west load point at 36 000 lb., and reached half-way to the flange. A number of other diagonal cracks appeared as the load was increased. At 56 000 lb. one diagonal crack had reached the flange and small horizontal cracks formed at the junction of the flange and stem. The beam carried the load well and reached a maximum of 78 300 lb. applied load. The load gradually fell off as the deflection was increased, and finally the flange on both sides from the east end to the west load point broke off suddenly, as shown in Fig. 6.

Beam No. 3.—In beam No. 3 it was noticed that each diagonal crack passed through the intersection of the stirrups and the longitudinal reinforcement. At the maximum load one of the tension cracks extended well into the flange.

Beam No. 4.—In Beam No. 4, some time after the maximum load of 29 900 lb. had been reached, the principal tension crack extended to the flange and then extended along the junction of the stem and flange, but no consequences were traceable to this. As in the other cases, the failure was by tension in the steel, followed finally by compression in the concrete.

Beam No. 5.—At an applied load of 25 000 lb., two tension cracks and one diagonal crack appeared, others following later. At 74 000 lb. the deflection curve makes an abrupt change of direction, the deflection at this load being .54 in. The tension

cracks increased in size and failure by tension in steel was evident. With increased deflection the load ran up slowly, reaching a maximum of 80 000 lb. at a deflection of 1.4 in., when one roller rolled off its bearing and one pedestal fell forward, allowing the beam to drop and break. At the maximum load there were evidences of crushing in the concrete.

Beam No. 6.—In Beam No. 6, after the maximum load of 37 000 lb. was reached the principal tension crack extended into the flange and finally extended horizontally along the junction of flange and stem. The test was then discontinued.

Beam No. 7.—In Beam No. 7, the maximum load was maintained from a deflection of .3 in. to one of 1.9 in. before final failure.

Beam No. 8.—In Beam No. 8, the maximum load was maintained from a deflection of .3 in. to one of 2.6 in. before final failure. The stress-deformation diagram gave a compressive unit deformation of .0005 at the point where the steel yielded.

Beam No. 9.—The stress-deformation curve and the deflection curve show failure by tension in the steel. The position of cracks is shown in Fig. 5.

19. Tension in Steel.—As already noted, the abrupt turn in the deflection diagrams (Fig. 7 to 15, following the text), taken in connection with the action of the concrete on the compressive side, indicates that the beams failed in every case through the steel becoming stressed beyond the yield point. The stressdeformation diagrams of the four beams on which observations of longitudinal deformations were made, also give marked evidence of failure by tension in the steel. In Table 5 are given the calculated stresses in the reinforcement at the maximum load, based on the formula M = .86 A f d. The weight of the beam and of the loading apparatus was included in the calculations. average stress in the reinforcement in the beams reinforced with plain mild steel rods at the maximum load is 39800 lb. per sq. in. The average stress in the corrugated bars at the maximum load is 58700 lb. per sq. in. It will be recalled that the average yield point for the coupons taken from the ends of the reinforcing bars was 38 300 lb. per sq. in. for the mild steel plain rods and 53800 lb. per sq. in. for the corrugated bars. The calculated stresses at the maximum load are therefore somewhat above the average yield point of the metal. It may also be noted that

there is no marked difference in the results obtained for beams of different width of flange. The tests and calculations go to show that equation (13) may be used for calculating the resisting moment, and it is believed that this formula may properly be used at least up to a reinforcement equal to 1% of the inclosing rectangle.

TABLE 5.

RESULTS OF TESTS OF T-BEAMS. M = .86 A f d.All failed by tension in steel.

	idth	Longitudinal Reinforcement		M	aximum l pounds	Bending	Stress	
Beam No. Flange Width inches		Per cent	Kind	Ap- plied	With Beam and Ap- paratus	Per 8 inches of Width	Moment M lbin.	Steel  f lb. per sq. in.
1	16	1.05	$3\frac{3}{4}$ -in. Johnson bars	44 500	46 700	23 350	923 000	64 300
4	16	1.10	$4^{\frac{3}{4}}$ -in. plain round	29 900	32 410	16 200	631 000	41 500
7	16	1.10	$4\frac{3}{4}$ -in. plain round	27 300	30 100	15 050	579 000	38 100
3	24	0.93	$4^{-3}_{4}$ -in. Johnson bars	53 500	55 700	18 570	1 107 500	57 500
6	24	0.92	$\left\{ egin{array}{ll} 5 & rac{3}{4} \mbox{-in. plain round} \\ 2 & \mbox{bars bent up} \end{array}  ight.$	36 800	39 300	13 100	773 500	40 700
8	24	0.92	$\begin{cases} 5^{-\frac{3}{4}}\text{-in. plain round} \\ 2 \text{ bars bent up.} \end{cases}$	37 300	40 100	13 370	783 500	41 200
2	32	1.05	$6\frac{3}{4}$ -in. Johnson bars	78 300	80 500	20 120	1 608 000	55 700
5	32	1.05	$\begin{cases} 6^{-\frac{3}{4}}\text{-in. Johnson bars 2} \\ \text{bars bent up. (6 trans-verse bars in flange}) \end{cases}$	80 800	83 300	20 820	1 658 000	57 400
9	32	0.97	$\begin{cases} 7 & \frac{3}{4}\text{-in. plain round } 3 \\ \text{bars bent up. (6 transverse bars in flange)} \end{cases}$	48 100	50 900	12 720	1 004 000	37 600

20. Compression in Concrete.—The stress-deformation diagrams obtained in four beams show clearly that the full compressive strength of the concrete was not developed when the yield point of the beam was reached, the amount of shortening being about .0005. The fact that the final deflection of the beam generally was several times as much as that at the yield point of

the beam shows that with the stretch of the steel beyond the yield point the neutral axis must have risen very much before final or ultimate failure by crushing of the concrete occurred, and this corroborates the preceding statement. The results bear out the assertion that beams with 1% reinforcement will have only a part of the compressive strength of the concrete developed, even when steel of 54 000 lb. per sq. in. yield point is used. As in T-beams having a width of flange equal to four times the thickness of the stem a 1% reinforcement (4% of the stem area) is very large, it does not seem that the compressive strength of the concrete in the upper fiber may be expected to be a controlling element in floor construction of this kind.

Web Stresses.—Rectangular beams which do not have metallic web reinforcement and in which the longitudinal bars are laid horizontally may be expected (for concrete of this quality) to fail by diagonal tension when the calculated vertical shearing unit stresses reach, say, 120 lb. per sq. in., provided, of course, the amount of reinforcement and relation of depth to length of span are not such that failure by tension or compression will occur before this amount of stress is developed. the assumption that the method of calculation given on page 10 is applicable to T-beams so reinforced. For the T-beams tested. no matter what the width of flange, the load which would produce failure by diagonal tension in the concrete calculated in this way would be 17 000 lb. As all beams failed by tension in the steel and as the loads ran as high as 80 000 lb. it is apparent that the metallic web reinforcement was efficient and adequate.

The conditions of testing were not favorable for determining the time of appearance of the first diagonal cracks (the minute cracks which appear in the outer third of the span length and which in beams without metallic web reinforcement presage early and sudden failure), and in some cases these may have appeared before their presence was noted. However, the load at which their existence was observed is given in Table 6. In Beam No. 7 the load for the first visible crack, 18 000 lb., gives by equation (18) a value of the vertical shearing unit stress of 147 lb. per sq. in., not much above that at which a beam without metallic web reinforcement would fail. The general average time of observation of the first visible diagonal crack corresponded to a value of about 180 lb. per sq. in. This higher value of v may

be an indication that the stiffness of the stirrups holds back the growth of cracks of the size at which they become visible or even that the stirrups act with the concrete in taking these secondary stresses up to the load where the cracks become visible, or else that the method of calculation gives too high results.

After the diagonal cracks have appeared, it must be considered that the secondary tensile stresses are taken mainly or wholly by the metallic reinforcement. In Table 6 are given the values of the vertical shearing unit-stresses for the maximum loads, calculated by equation (18). As in no case was there a

TABLE 6.
Web Stresses.

-		At First Diagonal Crack			At Maximum Load		
No.	Flange Width inches	Load in	Pounds Including Beam and Apparatus	lb. per sq. in.	Bond, u lb. per sq. in.	Shear, v lb. per sq. in.	
1	16	20 000	22 200	161	302	340	
4	16	29 900	32 100	234	200	236	
7	16	18 000	20 200	147	186	219	
3	24	28 000	30 500	222	270	405	
6	24	20 000	22 500	164	194	286	
8	24	27 000	29 500	214	198	292	
2	32	36 000	38 800	282	260	<b>5</b> 85	
5	32	35 000	37 800	275	269	• 605	
9	32	32 000	34 800	253	180	370	

failure by diagonal tension, we are most interested in the beams which carried the highest loads and hence developed the greatest shearing unit-stresses. Beam No. 2 developed 585 lb. per sq. in. and beam No. 5, 605 lb. per sq. in. These results are several times as great as the values obtained with rectangular beams without metallic reinforcement which failed by diagonal tension of the concrete.

The stresses in the stirrups may be calculated tentatively by the method given under "7. Web Stresses", (p. 9). For a load of 80 000 lb.,  $V = 40\,000$  lb.; v = 580. For the width of stem of 8 in. and stirrups 6 in. apart the tension in each prong of the stirrups,

calculated in this way, will be 13 900 lb., equivalent to 55 500 lb. per sq. in. The bond developed is also very high.

In the foregoing discussion the horizontal and vertical shearing stresses have been used as a means of comparing resistances to diagonal stresses. Viewed by themselves, they are also interesting. 600 lb. per sq. in. is evidently well below the actual shearing resistance of concrete, but it is considerably above the values given as the ultimate shearing strength of concrete by those who hold that shearing strength is but little more than the tensile strength of concrete.

- 22. Beam Deflection,—Considering the beams all as rectangular beams having the full section of the inclosing rectangle and as having reinforcement equal to 1% of this rectangle, the deflection in beams of different width of flange should be the same at loads proportional to the flange width. That is, a load of 10 000 lb. on a rectangular beam 8 in. wide, one of 20 000 lb. on a T-beam with flange 16 in, wide, one of 30 000 lb, on a T-beam with 24-in. flange, and one of 40 000 lb. on a T-beam with 32-in. flange, all having 1% reinforcement, should, on this assumption, give the same deflection. However, the T-beams do not have the full compressive area just above the neutral axis. As the concrete on the tension side of the neutral axis also adds to the stiffness of the beam, especially in the part in the outer thirds of the span length, the narrow width of the stem will detract from the stiffness of the beam. It may be expected, then, that the deflection of the T-beams will increase somewhat as the width of flange increases, when compared on the basis of loads proportional to the width of flange or on the basis of a load which gives the same stress in the steel. In Table 7 are given the deflections of the beams for loads which give a stress of 35000 lb. per sq. in. in the steel, as calculated by the formula, M = .86 A f d. results average .27 in. for the 16-in. flange, .27 in. for the .24-in. flange, and .32 in. for the 32-in. flange. The decrease in stiffness for the wide flange, while apparent, is not very great.
- 23. Position of Neutral Axis.—Little can be said here concerning the position of the neutral axis except that the data and analysis go to confirm the statement that for ratios of width of flange to width of stem not exceeding those used in the experiments, the position given by considering the T-beam as a rectangular beam of the full section of the inclosing rectangle is

sufficiently close for purposes of ordinary calculation. The stress-deformation diagrams for the beams on which observations were made, so far as these results may be used, also corroborate this view. As the compressive stresses in T-beams will generally be low, the error in any use of the assumed inclosing rectangle likely to be made will be small enough to be neglected, especially if we

Beam No.	Flange Width inches	Per cent Reinforce- ment	Applied Load pounds	Deflection inches
1 4 7	16 16 16	1.05 1.10 1.10	25 200 26 500 26 500	0.24 0.25 0.31
Av.			1	0.27
3 6 8	24 24 24	0.93 0.92 0.92	33 600 33 200 33 200	0.25 0.27 0.28
Av.				0.27
2 5 9	32 32 32	1.05 1.05 0.97	50 500 50 500 46 700	0.31 0.31 0.34
Av.				0.32

limit the use to the condition that the flange shall extend twothirds of the distance to the neutral axis.

24. Applicability of Results.—The tests are not numerous enough or sufficiently diversified to show that the results are generally applicable to beam construction. It seems clear, however, from the general behavior of these beams that for calculations on strength the T-section may be considered to be the equivalent of rectangular beams of the size of the inclosing rectangle for widths of flange equal at least to four times the width of stem. It seems probable that this relation may be applicable to even greater widths of flange. However, the actual value of this limit cannot be of great practical importance, since a greater width would not materially change the value of the calculated resisting moment (considering it based upon tensile strength of steel and moment arm measured to center of compressive stress), and since the amount of steel will at any rate

be limited by the space in the stem and by practical considerations in placing and bedding it to an amount which will keep the maximum compressive stress within a reasonable limit.


The method of calculating the tension in the stirrups is used tentatively and is not regarded as a final method for use. It is probable that experiments will show that a different method of calculation should be adopted. The efficacy of stirrups of this kind is well brought out, but at the same time, it should be noted that the size, spacing, and bonding of the web reinforcement are of larger capacity than is usually given. The fact that all the beams, and especially the wide beams, escaped failure by diagonal tension is of especial importance.


Nothing in the observed phenomena of the tests indicates that there was an appreciable distortion from a plane cross section even in the flanges of the beam. The tearing of the flange in one beam was evidently due to unequal bending and seems not to be traceable to shear or to variations from a plane cross section.


- 25. Summary.—The following summary of the discussion is given:
- 1. Beams of flange width of two, three, and four times the width of stem or web and reinforced in each case with steel equal to 1% of the inclosing rectangle exhibited in a common way the characteristics of rectangular beams, and the critical failure in every case came through the longitudinal reinforcement becoming stressed beyond its yield point.
- 2. The full compressive strength of the concrete at the most remote fiber was not developed at the yield point of the beam, even in the beams which were reinforced with steel of 54000 lb. per sq. in. yield point.
- 3. The beams with the wide flanges were deflected somewhat more than the narrower beams, as may be expected from the lack of full width of concrete on both the compression and the tension sides of the neutral axis, the deficiency affecting the stiffness of the beam but having little effect upon its strength at points of maximum bending moment.
- 4. The vertical stirrups used proved to be very effective web reinforcement. The diagonal tension cracks appeared at or above the loads at which failure by diagonal tension may be expected in beams without web reinforcement. A high resistance

to diagonal tensile stresses was developed, as measured by the calculated maximum vertical shearing unit-stress, which in one beam was 605 lb. per sq. in. Since no beam failed by diagonal tension, the limit of strength of the web reinforcement was not determined.

- 5. The observed phenomena of the tests give no indication of distortion from a plane cross section and there was no indication that the thin flange was an element of weakness. The tearing of the flange of one beam after the maximum load was reached was due to causes which would not exist in a floor system as usually constructed. It seems clear that the limit of useful width of flange was not reached in the beams tested.
- 6. The maximum strength of T-beams to resist horizontal tension and compression (flange stresses) may well be calculated by using the ordinary methods and formulas in use for rectangular beams and considering the inclosing rectangle of the T-beam to be the equivalent rectangular beam. This approximation is at least applicable for reinforcement not exceeding 1% of the inclosing rectangle. It gives little error when the thickness of flange is at least one quarter of the depth of beam and the width of flange not more than four times the width of stem, and may be used for an even greater range without great error. clusion of a greater width of flange than four times the width of stem would not materially change the calculated strength of the beam, since the amount of steel which may be put into the stem is usually limited by considerations which of themselves will hold the compressive stresses within proper limits, and since the moment arm of the horizontal couple will not change much with an increase in width of flange. The web stresses, which here are very important, will differ from those found for rectangular beams, and for T-beams the actual width of stem must be used in the calculations for vertical shear and diagonal tension.







#### Publications of The Engineering Experiment Station

Bulletin No. 1. Tests of Reinforced Concrete Beams, by Arthur N. Talbot. 1904.

Circular No. 1. High-Speed Tool Steels, by L. P. Breckenridge. 1905.

Bulletin No. 2. Tests of High-Speed Tool Steels on Cast Iron, by L. P. Breckenridge and Henry B. Dirks. 1905.

Circular No. 2. Drainage of Earth Roads, by Ira O. Baker. 1906.

Bulletin No. 3. The Engineering Experiment Station of the University of Illinois, by L. P. Breckenridge. 1906.

Bulletin No. 4. Tests of Reinforced Concrete Beams, Series of 1905, by Arthur N. Talbot. 1906.

Bulletin No. 5. Resistance of Tubes to Collapse, by Albert P. Carman. 1906.

Bulletin No. 6. Holding Power of Railroad Spikes, by Roy I. Webber. 1906.

Bulletin No. 7. Fuel Tests with Illinois Coals, by L. P. Breckenridge, S. W. Parr and Henry B. Dirks. 1906.

Bulletin No. 8. Tests of Concrete: I. Shear; II. Bond, by Arthur N. Talbot. 1906.

Bulletin No. 9. An Extension of the Dewey Decimal System of Classification Applied to Engineering Industries, by L. P. Breckenridge and G. A. Goodenough. 1906.

Bulletin No. 10. Tests of Plain and Reinforced Concrete Columns, Series of 1906, by Arthur N. Talbot. 1907.

Bulletin No. 11. The Effect of Scale on the Transmission of Heat through Locomotive Boiler Tubes, by Edward C. Schmidt and John M. Snodgrass. 1907.

Bulletin No. 12. Tests of Reinforced Concrete T-beams, Series of 1906, by Arthur N. Talbot. 1907.



## UNIVERSITY OF ILLINOIS ENGINEERING EXPERIMENT STATION

Bulletin No. 13

NOVEMBER, 1906

# AN EXTENSION OF THE DEWEY DECIMAL SYSTEM OF CLASSIFICATION APPLIED TO ARCHITECTURE AND BUILDING

by

N. CLIFFORD RICKER, D. ARCH., PROFESSOR OF ARCHITECTURE

#### Introduction

The Dewey Decimal Classification was invented and introduced by Dr. Melvil Dewey, also the originator of the schools for the training of librarians and their assistants. Several successive and much extended editions of his book have appeared, and the system has been found so convenient for practical uses that it is now more commonly employed in America and Europe than are any competing systems of arrangement.

All science, arts, literature, and tangible objects to be classified are distributed into ten classes or centuries:

0 to 100 General Works

100 to 200 Philosophy

200 to 300 Religion

300 to 400 Sociology

400 to 500 Philology

500 to 600 Natural Science

600 to 700 Useful Arts

700 to 800 Fine Arts

800 to 900 Literature

900 to 1000 History

Each one of these primary classes or centuries is next divided into ten secondary divisions or decades, like that for the Fine Arts:

700 Fine Arts

710 Landscape Architecture

720 Architecture

730 Sculpture

740 Drawing

750 Painting

760 Engraving

770 Photography

780 Music

790 Amusements

Each secondary class or decade is further divided into ten subdivisions or units, for example, like Architecture:

720 Architecture

721 Construction

722 Ancient

723 Mediæval

724 Modern

725 Public

726 Religious

727 Educational

728 Residence

729 Design

In this manner are obtained 1000 unit divisions, which form a system usually found sufficient for a small library, a collection of general memoranda, or a series of notes and clippings of moderate extent. But a specialist requires a much more extended subdivision of perhaps only a few of these units comprising the topics in which he is chiefly interested. This introduces a very useful property of the decimal system, namely, that it may be almost infinitely extended in any part by the subdivision of certain units without affecting others or requiring any rearrangement of the general system.

First subdivide into tenths of the unit, like Modern Architecture, for example:

724. Modern Architecture

.1 Renaissance

- .2 Grecian revival
- .3 Gothic revival
- .4 Tudor revival
- .5 Queen Anne
- .6 Neo Grec
- .7 Swiss revival
- .8 Romanesque revival
- .9 Other modern styles

If one is particularly interested in the comparative study of the various types of the Renaissance style found in different countries, it will be convenient to subdivide 724.1 into hundredths, for example:

- 724.1 Renaissance
  - .11 Scotland
  - .12 England
  - .13 Germany
  - .14 France
  - .15 Italy
  - .16 Spain
  - .17 Russia
  - .18 Scandinavia
  - .19 Minor countries

A collection of notes and memoranda or photographs of Italian Renaissance buildings may then be so large, that it may profitably be subdivided into thousandths of the unit, as follows:

- 724.15 Renaissance in Italy
  - .151 Cinquecento
  - .152 High Renaissance
  - .153 Decadence
  - .154 Barocco
  - .155 Rococo

This would evidently arrange the materials most conveniently for a thorough study of the Italian Renaissance style in the order of its historical development. Therefore it is sufficiently evident that the decimal system of classification is capable of unlimited extension in any of its parts.

To apply the system to a collection of books, memoranda, or other materials, each particular item is simply numbered as indicated by the decimal classification. The collection is then arranged in numerical sequence, which places the objects classified in the same order. Persons not accustomed to the use of the decimal system of classification may at first find some difficulty in finding the proper number for a particular object or article. Therefore an alphabetically arranged index of the more important topics and their numbers has been added for their convenience.

It is believed that this extension of the Dewey Decimal Classification will be found useful and convenient by architects, builders, engineers and all other persons practically or theoretically concerned with Architecture and Building. Most of it has been in use for many years in the department of Architecture of this University for classifying extensive collections of lantern slides, photographs, a card index to architectural periodicals, and other materials for instruction. As meriting careful attention, the following points are suggested:

- 1. The suggested classification of all materials relating to each one of the architectural styles together, in order to bring them into the most compact and convenient arrangement for the student of the History of Architecture.
- 2. The careful separation of 690, Building Materials and Trades; 721, Architectural Construction; and 729, Architectural Forms and Design, making it now easy to assign any topic to its proper place.

## TABLE OF

## CLASS NUMBERS

690	See 721 for Architectural Cons See 729 for Architectural Form	truction.	I rades
.1 .11	Theories of construction Systems of construction	1	
.2	Compends		
.21	Manuals		
.22	Handbooks		
.23	Recipes, collections of		
<b>.</b> 3	Dictionaries		
.31	Cyclopedias		
.4	Essays		
.41	Lectures		
.42	Discussions		
.5	Periodicals		
.51	Daily		
.52	Weekly		
.53	Monthly		
.54	Quarterly		
.55	Annual		
.6	Societies; Proceedings		
.61	Trade unions		
.62	Exhibitions		
.621	Materials		
.622	Methods		
.623	Construction 5		
	3		

69 <b>0.7</b>	Education and Training of		
.72	.Apprenticesh		
.73	Tools and th	-	
.10		de for special tools.)	
.74	Shop practic	e	
.75	Trade school	S	
.76	Manual train	iing	
.8	Museums		
.81	Collections		
.82	Patents		
.83	Inventions		
.84		r manufacturii	າອ
.841	Wood		<b>'</b> 8
.842	Stone		
.843	Steel and ir	on	
.844	Bricks		
.845	Tiles	1*	
.846	Cement and Concrete	lime	
.848	Asphalt		
.849	,		
.9	History of Bui	lding Materials	š
.91	Ancient		
.92	Mediæval		
.93	Renaissance		
.94	Modern		
.95	History of b	uilding constri	action
.96	Ancient	G	
.97	Mediæval		
.98	Renaissance		
.99	Modern		
691	Materials	Processes	Preservatives
	See 620.1 for St See 693 to 699 fo	rength of Materials r Uses of Prepared	Materials.
.1	Woods		
.11	Hard conifer	rs	
.111	Pine, longle	af	
119	Pine hard		

691.113	Pine, yellow	
.114	Pine, Norway	
.115	Pine, pitch	
.116	Tamarack; hackmat	acl
.117	·	
.118	Yew	
.119		
.12	Soft conifers	
.121	Pine, white	
.122	Pine, shortleaf	
.123	Cedar, white	
.124	Cedar, red	
.125	Hemlock	
.126	Spruce .	
.127	Fir	
.128	Cypress	
.129		
.13	Hard leaf woods	
.131	Oak	
.132	Beech	
.133	Sycamore	
.134	Maple, sugar	
.135	Ash	
.136	Hickory	
.137	Walnut, black	
.138	Locust	
.139		
.14	- Soft leaf woods	
.141	Poplar	
.142	Gum	
.143	Birch	
.144	Maple, white, red	
.145	Basswood; linden	
.146	Elm	
.147	Catalpa	
.148	Butternut	
.149		
.15	Defects of woods	
.151	Sapwood	
.152	Shakes; cracks	
.153	Spots; streaks	
.154	Knots	
.155	Decay	
.156	Stains	
.157	Pitch	
.158	Shrinkage-	
.159		

691.16	Injuries to woods
.161	Wet rot
.162	Dry rot
.163	Ants
.164	Borers
.165	Fungus
.169	•
.17	Preservation of woods
.171	Painting
.172	Oiling
,173	Creosoting
.174	Zincking
.175	By corrosive sublimate
.176	By crude kerosene
.177	By fireproof paint
.178	By sulphate copper
.179	
.2	Stone Material Protection
.211	Limestone
.212	Marble
.213	Gypsum
.214	Bedford; Oolite
.221	Granite
.222	Syenite
.223	Porphyry
.231	Sandstone, ordinary
.232	Sandstone, brown
.233	Sandstone, portage
.24	Slate
.251	Serpentine
.252	Soapstone
.253	Talc
.261	Trap
.262	Basalt
.271	Tufa
.272	Travertine
.273	Peperino
.28	Other building stones
.29	Preservation
.291	By painting
,292	By oiling
.293	By paraffine
.294	By silicate of soda
.295	By glue and tannin
,296	By cement wash
.299	

691.3	Stone, artificial Concrete
.31	Beton coignet
.32	Ransome
.33	Hollow block
.34	Selenitic
.35	Lime concrete
$.3\bar{6}$	Cement concrete
.39	Aggregate
.4	Bricks Tiles Ceramic products
.41	Bricks, ordinary
.42	Bricks, pressed
.43	Bricks, moulded
.44	Bricks, glazed or enameled
.45	Bricks, self-colored
.46	Tiles
.461	Roofing
.1	Spanish
.2	Ludovici
.3	Celadon
.4 .9	Ornamented
.462	Flooring
.1	Self-colored
.9	Inlaid
3	Embossed
.4	Glazed
.9 .463	Wall tiles
.403	Self-colored
.1	Inlaid
.3	Embossed
.4	Glazed
.5	Picture
.6	Paience panels
.7	Mouldings
.8	Painted
.47	Hollow structural tiles
.471	Floor
.1	Side arch
.2	End arch
.3	Mixed arch
.9	

691,472	Roof and ceiling tiles
.1	Book tiles
.2	Ceiling plates
.9	337 11 ./1
.473	Wall linings
.1	Wall linings Bond courses
.3	Partition
.48	Terra cotta
.481	Manufacture
.482	Face blocks
.483	Bands and mouldings
.484	Columns and pilasters
.485	Cornices
.486	Ornamental
49	Sewer tiles
.491	Salt-glazed
.492	Drain tiles
.493 .499	Fittings
.5	Lime Cement Plaster
.51	Lime, ordinary
.52	Lime, hydraulic
.53	Lime, selenitic
.54	Cement, natural
.55	Cement, portland
.56	Plaster of paris
.57	Keene's cement
.58	Hard plaster
.59	
.6	Glass
<b>.6</b> .61	<b>Glass</b> Window
	Window
.61	
.61 .62	Window Plate, rough Rolled
.61 .62 .63	Window Plate, rough Rolled Plate, polished
.61 .62 .63 .64	Window Plate, rough Rolled Plate, polished Luxfer prism, etc.
.61 .62 .63 .64 .65	Window Plate, rough Rolled Plate, polished Luxfer prism, etc. Sidewalk lights
.61 .62 .63 .64 .65	Window Plate, rough Rolled Plate, polished Luxfer prism, etc. Sidewalk lights Moulded

691.7	Iron Steel Anti-rust processes
.71	Cast iron
.72	Malleable cast iron
.73	Wrought iron
.74	Steel, blister or tool
.75	Steel, crucible
.76	Steel, bessemer
.77	Steel, open hearth
79	Protection of iron and steel
.791	Painting
.792	Tinning.
.793	Zincking (galvanizing)
.794	Electroplating
.795	Bower-Barff process
.796 .797	Cement coating
.798	
.799	
.8	Other metals
.81	Copper
.82	Brass
.83	Zinc
$.\dot{\mathrm{S4}}$	Lead
.85	Aluminum
:S6	Bronze
.87	Tin
.88	1 111
.89	
.9	Other materials
.91	Mineral wool
.921	Hair
.922	Jute fiber
.923	Hemp fiber
.93	Paper
.931	Sheathing C. Levi and the
.932 .933	Cabot's quilt Slating
.934	Roofing
.94	Fabrics woven
.941	Duck

691,942	Burlap	
.943	Carpets	
.944	Rugs	
.945	Linings	
.95	Asbestos	
.951	Pipe coverings	
.952	Hot air insulation	
.953	Fire protection	
.961	Asphalt, Trinidad	
.962	Asphalt, rock	
.963 .964	Pitch Resin	
.965	Coal tar	
.966	Tar	
.967	Damp-proof felt	·
.969	Edinp proof tell	
.97	Felt, roofing	
.98	Linoleum	
	Linoletini .	
.99		
692	Plans Specifications	Estimates
	-	
.1	General drawings	
1.1	Dian lagation	
.11	Plan, location	
.12	Plan, foundation	
	Plan, foundation	
.12 .13	Plan, foundation Plans, floor	
.12 .13 .14	Plan, foundation Plans, floor Plan, roof	
.12 .13 .14 .15	Plan, foundation Plans, floor Plan, roof Elevations	
.12 .13 .14 .15	Plan, foundation Plans, floor Plan, roof Elevations Front	
.12 .13 .14 .15	Plan, foundation Plans, floor Plan, roof Elevations	
.12 .13 .14 .15 .151	Plan, foundation Plans, floor Plan, roof Elevations Front Side	
.12 .13 .14 .15 .151 .152 .153	Plan, foundation Plans, floor Plan, roof Elevations Front Side Rear	
.12 .13 .14 .15 .151 .152 .153 .154	Plan, foundation Plans, floor Plan, roof Elevations Front Side Rear	
.12 .13 .14 .15 .151 .152 .158 .154 .159	Plan, foundation Plans, floor Plan, roof Elevations Front Side Rear Court Sections	
.12 .13 .14 .15 .151 .152 .153 .154 .159 .16	Plan, foundation Plans, floor Plan, roof Elevations Front Side Rear Court	
.12 .13 .14 .15 .151 .152 .153 .154 .159 .16	Plan, foundation Plans, floor Plan, roof Elevations Front Side Rear Court  Sections Longitudinal	
.12 .13 .14 .15 .151 .152 .153 .154 .159 .16 .161	Plan, foundation Plans, floor Plan, roof Elevations Front Side Rear Court  Sections Longitudinal	
.12 .13 .14 .15 .151 .152 .153 .154 .159 .16 .161 .162	Plan, foundation Plans, floor Plan, roof Elevations Front Side Rear Court  Sections Longitudinal Cross	
.12 .13 .14 .15 .151 .152 .153 .154 .159 .16 .161 .162 .169	Plan, foundation Plans, floor Plan, roof Elevations Front Side Rear Court  Sections Longitudinal Cross Other general drawings	
.12 .13 .14 .15 .151 .152 .153 .154 .159 .16 .161 .162 .169 .19	Plan, foundation Plans, floor Plan, roof Elevations Front Side Rear Court  Sections Longitudinal Cross  Other general drawings  Detail drawings	
.12 .13 .14 .15 .151 .152 .153 .154 .159 .16 .161 .162 .169 .19	Plan, foundation Plans, floor Plan, roof Elevations Front Side Rear Court  Sections Longitudinal Cross  Other general drawings  Detail drawings  Masonry	

692.214	Tiles
.215	Slate
.216	Brickwork
.217	Bricks, ornamental
.218	Terra cotta
.219	
.22	Woodwork
.221	Carpentry
.222	Joinery
.223	Cabinet work
.224	Furniture, special
.229	
.23	Metal work
.231	Cast iron, structural
.232	Cast iron, ornamental .
.233	Steel, structural
.234	Steel, ornamental
.235	Copper
.236	Tin
.237	Zinc
.238	Brass
.239	
.24	Plumbing
.241	Water supply
.242	Sanitary fixtures
.243	Drainage
.249	
.25	Heating and ventilating
.251	Furnaces
.252	Steam
.253	Hot water
.254	Gas
.255	Electric
.256	Combination systems
.257	
.258	Ventilation, natural
.259	Ventilation, forced
.26	Plastering
.261	Plain
.262	Ornamental
.263	Stucco work
.269	
.27	Roofing
.271	Gutters
272	Leaders

	•
392.28	Glass work
.281	Stained
.282	Beveled
.289	
.29	Other drawings
.3	Specifications
.31	General conditions
.32	Excavation and grading
	Masonry
.33	Stonework
.331	Brickwork
,332	Terra cotta
.333	Concrete, plain
.334	Concrete, reinforced
.335 $.34$	Carpentry
.341	Carpentry proper
.342	Joinery
.343	Cabinet work
.35	Metal work
.351	Cast iron
.352	Wrought iron
.353	Steel
.354	Copper
.355	Tin
,356	Ornamental
.357	Bronze
.359	
.36	Plastering
.37	Painting and glazing
.371	Painting
.372	Glazing
.373	Finishing
.38	Plumbing
.39	Other specifications
.391	Lighting
.392	Heating
.393	Ventilation
.399	
.4	Contracts Bids Advertisements
.41	Advertisements
.42	Bids
.43	Agreements, informal

692.44	Contracts, signed
.441	Sealed
.442	Guaranteed
.443	Variations
.444 $.45$	Arbitration .
.49	Bonds, security
• 20	
<b>.5</b>	Estimates Quantities Cost  Methods of estimate
.52	
	Volume
.53	Area
.54	Units
.55	Quantities, priced
.56	Comparison
.57	Classification of data
.58	
.59	
.6	Superintendence
.61	Occasional
.62	Architect's stated
.63	Constant
.64	Clerk of works
.65	Special
.69	
.7	Supervision of accounts
.71	Bookkeeping, system of
.72	Approval of bills
.73	Oversight of payments
.74	Statements to owner
.75	Reserved payments
.76	Extras and omissions
.77	Settlement, final
.79	
.8	Professional services Fees Commissions
.81	Services, ordinary
.82	Services, extra
.o. 83	Services special

692.84	Rates of commission	
.85	Account of payments	
.86	Expenses, extra	
.87	Bye commissions	
.89		
.9	Building laws Liabilities of and contractors	architects, owners
.91	General or state laws	
.92	City ordinances	
.93	Town or village ordinances	
.94	Other laws	
.95	Liabilities of architects	
.96	Liabilities of owners	
.97	Liabilities of contractors	
.98	Lien laws	
.99		
693	Masonry Plastering	Fire-proofing
.1	Stone construction  See 515.8 for Stereotomy See 736 for Stone Carving	
.11	Bonds	
.12	Stonecutting	
.13	Stonesetting	
.14	Stone tools	
.19		
.2	Brick construction	
.21	Bonds	
.22	Adobes	
.23	Cut or rubbed	
.24	Ornamental	
.25	Polychrome	
.26	Tools	
.29		
.3	Terra cotta construction	
.31	Setting	
.32	Anchoring .	
.33	Backing	

93.4	Hollow tile and porous terra cotta
.41	Walls
.42	Floors .
.43	Roofs
.44	Partitions
.45	Linings
.49	
.5	Concrete and beton construction See 693.3 for Rejuforced Concrete
.51	Massive
.52	Layers
.53	Hollow block
.54	Sidewalks
.55	Ornamental
.56	Surface finish
.59	ourace misi
.6	Plastering
.61	External
.62	Internal
.63	Ornamental ·
.64	Scagliola
.69	
.7	Reinforced concrete
.71	Systems of construction
.711	Ordinary round rods
.712	Ransome
.713	Unit
.714 .715	Hennebique Roebling
.716	Thacher
.719	
.72	Forms and centers
.73	Testing and inspection
.74	Data from experiments
.75	Formulas
.76	Applications, special
.79	*

693.8	Fire-proofing	
.81	Systems	
.811	Hollow tiles	
.812	Porous terra cotta	
.813 .814	Brickwork Concrete	
.815	Wood and sheet metal	
.816	Mortar	
,819		
.82	Walls and partitions	
.83	Floors	
.84	Roofs	
.85	Columns	
.86	Girders	
.87	Trusses	
.85	Vaults	
.89		
.9		
694	Carpentry Joinery Cabinet-Work Stairbuilding	
.1	Wood construction in general	
.2	Framing and joints	
.3	Strengthened beams	
.4	Posts and columns	
.5	Paneled and lattice construction	
.6	Joinery in general	
.7	Cabinet work	
.8	Stairbuilding	
.9		
695	Roofing	
.1	Shingle	
.2	Slate	

6 <b>95.4</b> .41	Metal Tin
.42 .43 .44	Copper Lead Zinc
.5	Iron or steel
.6	Asphalt
.7 .71 .72	Felt and gravel Asbestos Paper
.8 .81 .82	Fabrics Duck Canvas
.9	
96	Plumbing Gas and Steam Fitting
.11 .12 .13 .19	Plumbing Piping Fixtures Tools
.2 .21 .22 .23 .29	Gas Fitting Piping Fixtures Tools
.31 .32 .33	Steam Fitting Piping Fittings Tools
<b>.4</b> .41	Rivets and riveted joints Tools .
<b>.5</b> .51	Screws and screw joints Tools

696.6	Rust or calked joints
.61	Rust joints
.62	Calked joints
7.	Anchors Bond irons
.71	Bond irons
.72	Anchors, wall
.73	Anchors, angle
.74	Anchors, through
.75	Anchors for gutters and leaders
.76	Anchors for masonry
.79	
.8	Other branches
.9	Plumbing laws and ordinances
.91	General or state
.92	City ordinances
.93	Town or village ordinances
697	Heating and Ventilation
.1	Fireplaces
.11	Ordinary
.12	Ventilating
.2	Stoves
.3	Furnaces, hot air
.31	Furnaces
.32	Pipes, cold air
.33	Pipes, hot air
.34	Registers
.35	Regulators
4	Hot water
.41	High pressure
.4:2	Low pressure
.43	Conservatory
.44	Heaters with steam supply
.45	Boilers
.46	Pipes
.47	Regulators

Low pressure Low p	697.5	Steam
Low pressure Exhaust Vacuum Boilers Boilers Fipes Fipes Fregulators Air valves Fuel Gas	.51	High pressure
Jenum	.52	
.55 Boilers .56 Pipes .57 Regulators .58 Air valves .59  .6 Gas .61 Illuminating .62 Fuel .63 Natural .64 Acetylene  .7 Electric and other .8 Smoke flues and chimneys .81 Built in walls .82 Isolated  .9 Ventilation Ducts Fans .91 Natural .92 Plenum .93 Exhaust .94 Fresh air ducts .95 Foul air ducts .96 Treatment of air .961 Filtration .962 Dampening .963 Cooling .964 Testing .97 Regulation of air supply .98 Fans .981 Side fans .981 Side fans .981 Central fans	.53	Exhaust
.56 Pipes .57 Regulators .58 Air valves .59  .6 Gas .61 Illuminating .62 Fuel .63 Natural .64 Acetylene  .7 Electric and other .8 Smoke flues and chimneys .81 Built in walls .82 Isolated  .9 Ventilation Ducts Fans .91 Natural .92 Plenum .93 Exhaust .94 Fresh air ducts .95 Foul air ducts .96 Treatment of air .961 Filtration .962 Dampening .963 Cooling .964 Testing .97 Regulation of air supply .98 Fans .981 Side fans .981 Central fans	.54	Vacuum
.57 Regulators .58 Air valves	.55	Boilers
.57 Regulators .58 Air valves	.56	Pipes
.58 Air valves .59  .6 Gas .61 Illuminating .62 Fuel .63 Natural .64 Acetylene  .7 Electric and other .8 Smoke flues and chimneys .81 Built in walls .82 Isolated  .9 Ventilation Ducts Fans .91 Natural .92 Plenum .93 Exhaust .94 Fresh air ducts .94 Fresh air ducts .96 Treatment of air .961 Filtration .962 Dampening .963 Cooling .964 Testing .97 Regulation of air supply .98 Fans .981 Side fans .982 Central fans	.57	-
.6 Gas .61 Illuminating .62 Fuel .63 Natural .64 Acetylene .7 Electric and other .8 Smoke flues and chimneys .81 Built in walls .82 Isolated .9 Ventilation Ducts Fans .91 Natural .92 Plenum .93 Exhaust .94 Fresh air ducts .95 Foul air ducts .96 Treatment of air .961 Filtration .962 Dampening .963 Cooling .964 Testing .97 Regulation of air supply .98 Fans .981 Side fans .982 Central fans	.58	
.61 Illuminating .62 Fuel .63 Natural .64 Acetylene  .7 Electric and other .8 Smoke flues and chimneys .81 Built in walls .82 Isolated  .9 Ventilation Ducts Fans .91 Natural .92 Plenum .93 Exhaust .94 Fresh air ducts .95 Foul air ducts .96 Treatment of air .961 Filtration .962 Dampening .963 Cooling .964 Testing .97 Regulation of air supply .98 Fans .981 Side fans .982 Central fans	.59	
.62 Fuel .63 Natural .64 Acetylene  .7 Electric and other .8 Smoke flues and chimneys .81 Built in walls .82 Isolated  .9 Ventilation Ducts Fans .91 Natural .92 Plenum .93 Exhaust .94 Fresh air ducts .95 Foul air ducts .96 Treatment of air .961 Filtration .962 Dampening .963 Cooling .964 Testing .97 Regulation of air supply .98 Fans .981 Side fans .982 Central fans	.6	Gas
.62 Fuel .63 Natural .64 Acetylene  .7 Electric and other .8 Smoke flues and chimneys .81 Built in walls .82 Isolated  .9 Ventilation Ducts Fans .91 Natural .92 Plenum .93 Exhaust .94 Fresh air ducts .95 Foul air ducts .96 Treatment of air .961 Filtration .962 Dampening .963 Cooling .964 Testing .97 Regulation of air supply .98 Fans .981 Side fans .982 Central fans	.61	Illuminating
.64 Acetylene .7 Electric and other .8 Smoke flues and chimneys .81 Built in walls .82 Isolated .9 Ventilation Ducts Fans .91 Natural .92 Plenum .93 Exhaust .94 Fresh air ducts .95 Foul air ducts .96 Treatment of air .961 Filtration .962 Dampening .963 Cooling .964 Testing .97 Regulation of air supply .98 Fans .981 Side fans .982 Central fans	.62	
.64 Acetylene .7 Electric and other .8 Smoke flues and chimneys .81 Built in walls .82 Isolated .9 Ventilation Ducts Fans .91 Natural .92 Plenum .93 Exhaust .94 Fresh air ducts .95 Foul air ducts .96 Treatment of air .961 Filtration .962 Dampening .963 Cooling .964 Testing .97 Regulation of air supply .98 Fans .981 Side fans .982 Central fans	.63	Natural
.8 Smoke flues and chimneys .81 Built in walls .82 Isolated  .9 Ventilation Ducts Fans .91 Natural .92 Plenum .93 Exhaust .94 Fresh air ducts .95 Foul air ducts .96 Treatment of air .961 Filtration .962 Dampening .963 Cooling .964 Testing .97 Regulation of air supply .98 Fans .981 Side fans .982 Central fans		Acetylene
.81 Built in walls .82 Isolated  .9 Ventilation Ducts Fans .91 Natural .92 Plenum .93 Exhaust .94 Fresh air ducts .95 Foul air ducts .96 Treatment of air .961 Filtration .962 Dampening .963 Cooling .964 Testing .97 Regulation of air supply .98 Fans .981 Side fans .982 Central fans	.7	Electric and other
.81 Built in walls .82 Isolated  .9 Ventilation Ducts Fans .91 Natural .92 Plenum .93 Exhaust .94 Fresh air ducts .95 Foul air ducts .96 Treatment of air .961 Filtration .962 Dampening .963 Cooling .964 Testing .97 Regulation of air supply .98 Fans .981 Side fans .982 Central fans	.8	Smoke flues and chimneys
.82 Isolated  .9 Ventilation Ducts Fans .91 Natural .92 Plenum .93 Exhaust .94 Fresh air ducts .95 Foul air ducts .96 Treatment of air .961 Filtration .962 Dampening .963 Cooling .964 Testing .97 Regulation of air supply .98 Fans .981 Side fans .982 Central fans	.81	
.91 Natural .92 Plenum .93 Exhaust .94 Fresh air ducts .95 Foul air ducts .96 Treatment of air .961 Filtration .962 Dampening .963 Cooling .964 Testing .97 Regulation of air supply .98 Fans .981 Side fans .982 Central fans	.82	
.92 Plenum .93 Exhaust .94 Fresh air ducts .95 Foul air ducts .96 Treatment of air .961 Filtration .962 Dampening .963 Cooling .964 Testing .97 Regulation of air supply .98 Fans .981 Side fans .982 Central fans	.9	Ventilation Ducts Fans
.92 Plenum .93 Exhaust .94 Fresh air ducts .95 Foul air ducts .96 Treatment of air .961 Filtration .962 Dampening .963 Cooling .964 Testing .97 Regulation of air supply .98 Fans .981 Side fans .982 Central fans	.91	Natural
.93 Exhaust .94 Fresh air ducts .95 Foul air ducts .96 Treatment of air .961 Filtration .962 Dampening .963 Cooling .964 Testing .97 Regulation of air supply .98 Fans .981 Side fans .982 Central fans		
.94 Fresh air ducts .95 Foul air ducts .96 Treatment of air .961 Filtration .962 Dampening .963 Cooling .964 Testing .97 Regulation of air supply .98 Fans .981 Side fans .982 Central fans		
Foul air ducts  .96 Treatment of air  .961 Filtration  .962 Dampening  .963 Cooling  .964 Testing  .97 Regulation of air supply  .98 Fans  .981 Side fans  .982 Central fans	.94	Fresh air ducts
.961 Filtration .962 Dampening .963 Cooling .964 Testing .97 Regulation of air supply .98 Fans .981 Side fans .982 Central fans	α5	Foul air ducts
Dampening  .963 Cooling  .964 Testing  .97 Regulation of air supply  .98 Fans  .981 Side fans  .982 Central fans	.96	Treatment of air
.963 Cooling .964 Testing .97 Regulation of air supply .98 Fans .981 Side fans .982 Central fans	.961	Filtration
.964 Testing .97 Regulation of air supply .98 Fans .981 Side fans .982 Central fans		
.97 Regulation of air supply .98 Fans .981 Side fans .982 Central fans		
.98 Fans .981 Side fans .982 Central fans		
.981 Side fans .982 Central fans		
.982 Central fans		
/ . /	.99	Central Jans

698	Painting Glazing Paperhanging	Finishing
.1	Painting Oil	
.11	Lead	
.12	Zinc	
.13	Iron	
.14	Mixed paints	
.15	Oil	
.16	Turpentine	
.17	Dryers	
.18	Tools	
.19		
.2	Distemper and Fresco	
.21	Distemper	
.22	Milk wash	
.23	Cement wash	
.24	Other washes	
.25	Fresco, real	
.26	Fresco, other methods	
.27	Stencils	
.28	Tools	
.29		
•3	Varnishing Polishing	
.31	Varnish	
.311	Oil	
.312	Spirit	
.319	Shellac	
.33	French polish	
.34	Wax	
.35	Oiling	
.36	Other finishes	
.37	Polishing	
.38	Tools ·	
30	1000	

698.4	Other modes of protection
.41	Asphalt
.42	Tar
.43	Graphite .
.49	
.5	Glazing
.51	Puttying, ordinary
.52	Puttying, hard
.53	Cutting -
.54	Setting
.55	Leading ·
.56	Tools
.59	
.6	Paperhanging
.61	Paper
.62	Paste
.63	Hanging
.64	Tools
.69	
.7	Textile Hangings Tapestry
.71	Burlap
.72	Chintz
.73	Tapestry, real
.74	Tapestry, painted
.75	Tools
.79	
.8	Relief work
.81	Embossed paper
.82	Lincrusta
.83	Stamped leather
.84	Tools
.89	
.9	Other branches
699	Car and Shipbuilding

700	Fine Arts
701	Theories Esthetics
702	Compends Manuals Outlines
703	Dictionaries Cyclopedias
704	Essays Lectures Discussions
705	Periodicals
.1	Daily
.2	Weekly
.3	Monthly
.4	Quarterly
.5	Annual
.6	Occasional
.9	
706.1	Societies
.11	Painters
.12	Sculptors
.13	Illustrators
.14	Transactions
.15	Proceedings
.16	Reports
.19	
707.1	Education
.11	Study
.12	Instruction
.13	Practice
708	Art Galleries and Museums
.11	Scotland
.15	Ireland
.2	England
.31	Germany
.36	Austria

708.4	France
.5	Italy
.61	Spain
.69	Portugal
.7	N. America
.71	Canada
.72	Mexico
.70	United States
.8	S. America
.9	Australia
.992	Holland
.993	Belgium
.994	Switzerland
709	History of Art in General
.3	Ancient
.311	China
.312	Japan
.313	Korea
.32	Egypt
.331	Phœnicia
.332	Philistine
.333	Judea
.334	Carthage
.335 .336.1	Cyprus Pelasgian
.000.1	Etruria
.34	India
.351	Chaldea
.352	Assvria
.333	Persia
.357	* Sassania
.36	° Celtic
.37	Roman
.38	Greece
.39	Minor countries
.4	Modern Europe
.411	Scotland
.415	Ireland
.4:2	England

09.43	Germany
.431	Northern
.434	Southern =
.436	Austria
.44	France
.442	Normandy
.445	Auvergne
.446	Poitou
.449	Provence
.45	Italy
.452	Lombardy
.453	Venice
.455	Tuscany
.457	Naples
.458	Sicily
.461	Spain
.469	Portugal
.47	Russia
.48	Scandinavia
.481	Norway
.485	Sweden
.489	Denmark
.49	Minor countries
.492	Holland
.493	Belgium
.494	Switzerland Modern Greece
.495	Turkey in Europe
.496	Turkey III Europe
.499	
.5	Asia
.51	China
.52	Japan
.54	India
.55	Persia
.59	Farther India
.6	Africa
.61	Northern
.62	Egypt
.63	Abyssinia
.64	Morocco
.65	Algeria

.69

709.7	North America
.71	Canada
.72	Mexico
.728 .729	Central America West Indies
.73	United States
.8	South America
.81	Brazil
.82	Argentina
.83	Chili
.84	Bolivia ·
.85	Peru
.87	Venezuela
.89	
.9	Oceanica
10	Landscape Architecture
711	Parks
712	Private Grounds
713.1	Walks
.2	Roads
.3	Drives
714.1	Lakes
.2	Streams
•3	Fountains
715.1	Trees
.2	Shrubs .
.3	Hedges
.4	Vines
716.1	Plants
.2	Flowers
.3	Conservatories

716.4	Window gardens
.5	Ferneries
717.1	Arbors
.2	Summer Houses
.3	Seats
.4	Outlooks
.5	Pergolas
.6	Garden walls
.7	Niches
.8	Statues Vases
.9	
718.1	Monuments
.2	Tombs
.3	Mausoleums
719.	Cemeteries
.1	Gates
.2	Walls

## 720 Architecture

Walks

Drives

Vaults

.3

.5

.11	Theories, general
.12	Esthetics
.13	Architectonics
.21	Compends
.22	Manuals
.23	Handbooks
.31	Dictionaries
.32	Encyclopedias

720.33	Glossaries
.34	Dictionaries of foreign terms
.41	Essays, general
.42	Lectures
.43	Articles
.44	Discussions
.44	Discussions
.5	Periodicals
.51	Daily
.52	Weekly
.53	Monthly
.54	Quarterly
.55	Annual
.56	Occasional
.6	Societies
.61	School
.62	Architects' local
.63	Draftsmen's
.64	National
.65	State
.71	Education
.72	Study
.73	Training, professional
.74	Schools, architectural
.741	Scotland
.742	England
.743	Germany
.5 .744	Austria France
.745	Italy
.746	Spain Portugal
.747	Russia
.1 .2	Canada Mexico
.3	United States
.8	South America
.748.1	Norway
.5	Sweden
.9 .749	Denmark
.190	

20.8	Collections	
.81	Materials	
.82	Fixtures	
.83	Fittings	
.84	Drawings	
.85	Models	
.86	Photographs	
.89	2.00-03-01	
.9	History of architecture, general Classify under 722, 723 or 724, if possible.	
.94	Europe	
.941	Scotland	
.5	Ireland	
.942	England	
.943	Germany	
.1	Prussia Central Germany	
.2	Bayaria	
.5	South Germany	
.5	Northwest Germany	
.6	Austria	
.7	Bohemia	
.8	Poland	
.9	Hungary	
.944	France	
.1	Brittany, etc.	
.2	Normandy Isle de France	
.5	Burgundy	
.5	Anvergne	
.6	Poitou	
.7	Gascony	
.8	Languedoc	
.9	Provence	
.945	Italy Piedmont	
.1	Lombardy	
.3	Venice	
.5	Tuscany	
.7	Naples	
.8	Sicily	
.9	Sardinia	
.946	Spain	
.9	Portugal	

720.947	Russia
.1	Norway
.5	Sweden
.9	Denmark -
.949	Minor countries
.2	Holland
.3	Belgium
.4	Switzerland
.5	Modern Greece
.7	Servia
.8	Roumania
.9	
.95	Asia
.96	Africa
.962	Egypt
.97	North America
.971	Canada
.972	Mexico
.973	United States
.98	South America
.981	Brazil
.982	Argentina
.983	Chili
.984	Bolivia
.985	Peru
.986	Equador
.987	Venezuela
.989	Paraguay
.99	Oceanica
.993	New Zealand
.994	Australia
.999	
21	Architectural Construction  See 729 for Forms and Design.  See 690, etc., for Materials, Tradés, etc.
.1	Foundations
.11	Dimension stone
.12	Rubble
.13	Concrete
.131	Plain
.132	Reinforced by bars
1 T O 10	remittiece by bars

Reinforced by rails

Sand or gravel

Reinforced by beams

.133 .134

```
721.15
               Gratings, wooden
              Piles
    .16
                  Wood
    .161
    .162
                  Sand
    .163
                  Steel
    .164
                  Concrete, plain
                  Concrete, reinforced
    .165
               Wells, sunken
    .17.
               Tubes, sunken
    .18
    .181
                  Caissons, wood
                  Caissons, steel
    .182
    .19
    .191
                  Piers, stone
                  Piers, brick
    .192
                  Piers, concrete
    .193
                  Piers, concrete-steel
    .194
                  Piers, steel-framed
    .195
             Walls
    .2
    .211
                  Wood
                  Half-timber
    .212
    .22
               Stone
    .231
                  Concrete
                  Hollow block
    .232
                   Concrete-steel
    .233
                   Pise (Tamped earth)
    .234
                   Brick, solid
    .241
                   Brick, hollow
    .242
    .25
               Bases, belts, etc.
                   Base Plinths
    .251
                   Water tables
    .252
    .253
                   Belt courses
    .254
                   String courses
                   Colonnades
    .261
        .1
                    Stone
                    Brick
        .2
                    Terra cotta
        .3
                     Steel
        .4
        .5
                     Iron
                     Concrete
        .6
                     Concrete-steel
        .7
                     Wood
                   Arcades
     .262
                     Stone
        .1
        .2
                     Brick
```

721.262.3	Terra cotta
.4	Steel
.5	Iron
.6	Concrete
.7	Concrete-stee!
.8	Wood
.9	
.263.1	Arcade, blind
.2	Arcade band
.3	Arched frieze
.27	Cornices
.271	Stone
.272	Brick
.273	Terra cotta
.274	Steel
.275	Iron
.276	Concrete
.277	Concrete-steel
.278	Wood
.279	
.28	Pediments
.281	Stone
.282	Brick
.283	Terra cotta
.284	Steel
.285	Iron
.286	Concrete
.287	Concrete-steel
.288	Wood
.289	
.29	Gables
.291	Stone
.292	Brick
.293	Terra Cotta
.294	Stee1
.295	Iron
,296	Concrete
.297	Concrete-steel
.298	Wood
.299	
.3	Piers Columns
.31	Wood
.311	Exposed
.312	Protected
.32	Stone

M12 4 0 0			
721.33	Concrete		
.331	Solid		
.332	Block		
.333	Concrete-steel		
.34	Brick		
.341	Brick, cut		
.342	Brick, moulded		
.343	Terra cotta		
.35	Metal		
.351	Cast iron		
.352	Wrought iron		
.353	Steel		
.1	Rolled Solid		
.0	Riveted		
.3	Latticed		
.36	Fireproof Protected		
.361	By mortar		
.362	By hollow tiles		
.363	By porous terra cotta		
.364	By brickwork		
.365	By concrete		
.39			
	Arched construction.		
.39	Arched construction.  See 624.5 for Bridges.		
.39	See 624.5 for Bridges. See 729.3 for the different forms.		
.39	See 624.5 for Bridges. See 729.3 for the different forms. See 690 for Materials.		
.39	See 624.5 for Bridges. See 729.3 for the different forms.		
.39 .4	See 624.5 for Bridges. See 729.3 for the different forms. See 690 for Materials.  Stone Dressed		
.39 .4 .41 .411 .412	See 624.5 for Bridges. See 729.3 for the different forms. See 600 for Materials.  Stone  Dressed Rubble		
.39 .4 .41	See 624.5 for Bridges. See 729.3 for the different forms. See 690 for Materials.  Stone Dressed		
.39 .4 .41 .411 .412	See 624.5 for Bridges. See 729.3 for the different forms. See 600 for Materials.  Stone  Dressed Rubble		
.39 .4 .41 .411 .412 .42	See 624.5 for Bridges. See 729.3 for the different forms. See 600 for Materials.  Stone Dressed Rubble Brick		
.39 .4 .41 .411 .412 .42 .43	See 624.5 for Bridges. See 729.3 for the different forms. See 690 for Materials.  Stone Dressed Rubble Brick Terra cotta		
.39 .4 .41 .411 .412 .42 .43 .44	See 624.5 for Bridges. See 729.3 for the different forms. See 690 for Materials.  Stone Dressed Rubble Brick Terra cotta . Steel		
.39 .4 .41 .411 .412 .42 .43 .44 .45	See 624.5 for Bridges. See 729.3 for the different forms. See 600 for Materials.  Stone Dressed Rubble Brick Terra cotta Steel Cast iron		
.39 .4 .41 .411 .412 .42 .43 .44 .45 .46 .461	See 624.5 for Bridges. See 729.3 for the different forms. See 600 for Materials.  Stone Dressed Rubble Brick Terra cotta Steel Cast iron Concrete Massive Hollow block		
.39 .4 .41 .411 .412 .42 .43 .44 .45 .46 .461 .462 .463	See 624.5 for Bridges. See 729.3 for the different forms. See 600 for Materials.  Stone Dressed Rubble Brick Terra cotta Steel Cast iron Concrete Massive Hollow block Solid block		
.39 .4 .41 .411 .412 .42 .43 .44 .45 .46 .461 .462 .463 .464	See 624.5 for Bridges. See 729.3 for the different forms. See 600 for Materials.  Stone Dressed Rubble Brick Terra cotta Steel Cast iron Concrete Massive Hollow block Solid block Concrete-steel		
.39 .4 .41 .411 .412 .42 .43 .44 .45 .46 .461 .462 .463	See 624.5 for Bridges. See 729.3 for the different forms. See 600 for Materials.  Stone Dressed Rubble Brick Terra cotta Steel Cast iron Concrete Massive Hollow block Solid block		

### 721.5 Roofs See 695 for Roof Coverings. See 729.35 for Forms of Roofs. .51 Wood .511 Sheathing .512 Rafters Purlins .513 .514 Ceiling .515 Truss Wood .1 Types 9 Loads Stress diagrams .4 Dimensioning Connections .5 Weight .6 Cost .8 Economy .9 .52 Masonry .53 Glass Glass .531 .532 Rafters Purlins .533 .534 Ceiling See 721.515 or 721 545 for Truss. .54Metal Sheathing .541 Wood .1 . . . Corrugated steel Lining for drip .542 Rafters .543 Purlins .544 Ceiling .545 Truss, steel or iron .1 Types .2 Loads .3 Stress diagrams Dimensioning .4 Connections .6 Weight

.7

.S

.9

.55

.551

Cost

Windows

Luthern

Economy

Openings in roofs

721,552	Dormer
,553	Skylights
.554	Scuttles
.555	Gables
.56	Roof crestings, etc.
.561	Crestings
.562	Balustrades
.563	Reliefs
.564	Statuary
.565	Cornice
.566	Bands
.57	Spires
.571	Stone
.572	Brick
.573	Terra cotta
.574	Steel
.575	Iron
.576	Concrete
.577	Concrete-steel
.578	Wood
.579	0.11
.58	Gablets
.59	
.59 .6	Floors
.6	
.6 .61	Wood
.6 .61	Wood Flooring
.6 .61 .611	Wood Flooring Deafening
.6 .61 .611 .612	Wood Flooring
.6 .61 .611	Wood Flooring Deafening Sheathing
.6 .61 .611 .612 .613	Wood Flooring Deafening Sheathing Joists
.61 .611 .612 .613 .614	Wood Flooring Deafening Sheathing Joists Beams
.6 .61 .611 .612 .613 .614 .615	Wood Flooring Deafening Sheathing Joists Beams
.6 .611 .612 .613 .614 .615 .616	Wood Flooring Deafening Sheathing Joists Beams Girders
.6 .61 .611 .612 .613 .614 .615 .616 .619	Wood Flooring Deafening Sheathing Joists Beams Girders
.6 .61 .611 .612 .613 .614 .615 .616 .619	Wood Flooring Deafening Sheathing Joists Beams Girders  Stone Slabs
.6 .61 .611 .612 .613 .614 .615 .616 .619 .62	Wood Flooring Deafening Sheathing Joists Beams Girders  Stone Slabs Slabs and beams
.6 .61 .611 .612 .613 .614 .615 .616 .619 .62 .621 .622	Wood Flooring Deafening Sheathing Joists Beams Girders  Stone Slabs Slabs and beams Paneled Coffered Marble
.6 .61 .611 .612 .613 .614 .615 .616 .619 .62 .621 .622 .623	Wood Flooring Deafening Sheathing Joists Beams Girders  Stone Slabs Slabs and beams Paneled Coffered
.6 .61 .611 .612 .613 .614 .615 .616 .619 .62 .621 .622 .623 .624	Wood Flooring Deafening Sheathing Joists Beams Girders  Stone Slabs Slabs and beams Paneled Coffered Marble Brick Tiles Brick arched
.6 .61 .611 .612 .613 .614 .615 .616 .619 .62 .621 .622 .623 .624 .625 .63	Wood Flooring Deafening Sheathing Joists Beams Girders  Stone Slabs Slabs and beams Paneled Coffered Marble Brick Tiles Brick arched Hollow tile, arched
.6 .61 .611 .612 .613 .614 .615 .616 .619 .62 .621 .622 .623 .624 .625 .63	Wood Flooring Deafening Sheathing Joists Beams Girders  Stone Slabs Slabs and beams Paneled Coffered Marble Brick Tiles Brick arched Hollow tile, arched
.6 .61 .611 .612 .613 .614 .615 .616 .619 .62 .621 .622 .623 .624 .625 .631 .632	Wood Flooring Deafening Sheathing Joists Beams Girders  Stone Slabs Slabs and beams Paneled Coffered Marble Brick Tiles Brick arched Hollow tile, arched
.6 .61 .611 .612 .613 .614 .615 .616 .619 .62 .621 .622 .623 .624 .625 .631 .632	Wood Flooring Deafening Sheathing Joists Beams Girders  Stone Slabs Slabs and beams Paneled Coffered Marble Brick Tiles Brick arched Hollow tile, arched

Cast Iron

21.642	Steel
.649	
.65	Composite
.651	Stone and cast-iron beams
.652	Stone and steel beams
.653	Hollow tile and steel beams
.654	Porous tile and steel beams
.655	Concrete and steel beams
.656	Concrete-steel
.657	Concrete and Roebling wire Arches
.658	Concrete and expanded metal
.659	
.66	Parquetry floors
.67	Mosaic
.671	Marble, plain
.672	Marble, patterns
.673	Marble, geometrical
.674	Marble, ornamental
.675	Marble and cement
.676	Inlaid concrete
.679	
.68	Tiles .
.681	Inlaid
.682	Self-colored
.683	Glazed
.684	. Embossed
.685	Tesserae
.69	
.691	Cement
.692	Artificial stone
.693	Xylolith
.694	Linoleum
.699	
.7	Ceilings
	See 721.4 for Construction of Vaulted Ceilings
	See 729.6 for Forms of Ceilings.
.71	Wood
.711	Matched and beaded
.712	Panels planted on
.713	Beam
.714	Mill-floor system
.715	Paneled
.716	Coffered
.719	

721.72	Stone		
.721	Flac		
.722	Beam		
.723	Paneled		
.724	Coffered		
.73	Brick or tile and steel		
.731	Flat, plain		
.732	Flat, enameled		
.733	Flat, ornamented		
.734	Paneled		
.735	Coffered		
.74	Metal		
.741	Cast iron with steel beams		
.742	Steel trough plates and beams		
.743	Steel buckled plates and beams		
.744	Steel panels and beams		
.745	Steel sheets on wood sheathing		
.746	Steel stamped on wood ceiling		
.75	Concrete Plaster		
.751	Concrete, plain		
1.752	Concrete-steel		
.753	Concrete-steel beams		
.754	Concrete-steel paneled		
.755	Plaster, plain		
.756	Plaster, ornamental		
.757	Plaster, paneled		
.758	Plaster, painted		
.759			
.79	Other ceilings		
.8	Doors Enclosures Windows		
.81	Doors, wood		
.811	Single		
.512	Double		
.813	Sliding		
.814	Folding -		
.815	Concealed or secret		
.816	Glazed		
.82	Doors, metal		
.821	Single		
.822	Double		
.823	Sliding		
.824	Concealed		
.825	Fire-proof		
.526	Sheet metal on wood		

721.827	Wire-glazed			
.828	Vault			
.829				
.84	Windows, external			
.841	Sliding			
.842	Casement			
.843	Fixed			
.444	Wire-glazed			
.845	Fireproof			
.846	Leaded			
.847	Transoms			
.85	Windows, internal			
.851	Sliding .			
.852	Hinged			
.853	Fixed			
.854	Wire-glazed			
.855	Fireproof			
.856	Leaded			
.857	Transoms			
.86	Enclosures of doors and windows			
.861	Architrave			
.862	Cap, horizontal			
.863	Pediment on consoles			
.864	Pediment on pilasters			
.865	Pediment on engaged columns			
.866	Pediment on free columns			
.867	Lintel only			
.868	Sill and stool			
.869				
.87	Shutters Blinds Screens Grilles			
.871	Shutters, wood			
.872	Shutters, steel			
.873	Blinds, ordinary			
.874	Blinds, Venetian			
.875	Screens, fly			
.876	Grilles, plain			
.877	Grilles, ornamental			
.88	Fastenings Locks			
.881	Shutter fastenings			
.882	Blind fastenings			
.883	Door locks			
.1	Rebated			
.2	Mortise			
.3	Rim			
.4	Dead			
.5	Latch			

```
721.883.6
                  Sliding door
                  Bolts
      .7
                  Espagnolette bolts
      .8
      .9
   .89
             Other fixtures
                 Hinges, blind
   891
                 Hinges, door
   .892
                  Fast
      .1
                  Loose joint
      .2
      .3
                  Pin
                  Spring
      .4
                  Self-closing
   .893
                 Door closers
                 Sash fasts
   .894
                 Blind fasts
   .895
   .899
  .9
           Iron and composite structures
                 See 620.1 for Strength of Materials.
                 Classify here only that which cannot be placed elsewhere, under 721
             Cast-iron structures
   .91
  .92
             Wrought-iron structures
             Steel structures
   .93
   94
             Composite structures
             Steel and wood
   .95
             Steel and stone
   96
  97
             Steel and ceramic
  .971
                 Steel and brick
                 Steel and tile
  .972
                 Steel and terra cotta
  .973
  .98
             Steel and glass
  .99
             Wood and glass
```

# 722, 723, 724 History of Architecture

Classify modern American buildings of importance in the History of Architecture under 724; generally all other American buildings under 725 to 728 inclusive.

Modern foreign buildings are usually placed under 724, unless of special importance as examples of the class or purpose, when they are to be treated like American buildings.

## CLASSIFICATION OF HISTORICAL DATA

The following subdivision is recommended for the convenient arrangement of all data particularly referring to the History of Architecture. It is readily applicable to each subordinate or general division under 722, 723 and 724, being simply annexed to the style numbers.

.001	General		
.0011	Country		
.0012	Climate		
.0013	History		
.0014	Religion		
.0015	Government		
.0016	Social conditions		
.0017	Character of style		
.0018	Derivation of style		
.0019	Influence of style		
.002	Materials		
.0021	Wood		
.0022	Stone		
.0023	Concrete		
.0024	Bricks Tiles		
.0025	Mortar Cement		
.0026	Glass		
.0027	Iron Steel		
.0028			
.0029			
.003	Construction		
.0031	System employed		
.0032	Arch Vault Dome		
.0033	Foundations		
.0034	Floors		
.0035	Walls Supports		
.0036	Ceilings		
.0037	Roofs Spires		
.0038	Doors Windows		
.0039			
.004	Design		
.0041	Facades		
.0042	Sections		
	~ ***		
.0043	Ceilings, treatment of		
.0043 .0044	Ceilings, treatment of Roofs, forms of		

.0047	Arcades
.0048	Cornices Belts Entablatures
.0049	Proportions, system of
.005	Decoration
.0051	Mouldings
.0052	Statues
.0053	Sculptures
.0054	Painting
.0055	Mosaics .
.0056	Gilding
.0057	Furniture
.0058	Fabrics
.0059	Pottery
.006	Sanitation
.0061	Water supply
.0062	Drainage
.6006	Sewage disposal
.0064	Plumbing
.0065	Lighting
.0066	Heating
.0067	Ventilation
.0068	Burial
.0069	
.007	Buildings, kinds of
.0071	Religious
.0072	Mortuary
.0073	Memorial
.0074	Military
.0075	Residence
.0076	Public
.0077	Amusement
.0078	Engineering
.0079	
.008	Examples described
.0081	Religious
.0082	Mortuary
.0083	Memorial
.0084	Military
.0085	Residence
.0086	Public
.0087	Amusement
.0088	Engineering
.0089	
.009	Biographies
.0091	Architects
.0092	Sculptors

.0093	Painters
.0094	Art-workers
.0095	Connoisseurs
.0096	Builders
.0097	Engineers
.0098	Rulers ·
.0099	

# 722. Ancient or primitive architecture

```
Prehistoric
.0
              Scotland
.011
.015
              Ireland
.019
              Wales '
           England
.02
.031
              Germany
.036
              Austria
.04
           France
              Italy
.051
.052
              Sardinia
              Sicily
.053
.061
              Spain
              Portugal
.069
.07
           Russia
              Canada
.071
              Mexico
.072
              United States
073
    .1
                Indian
                Mound-builders
                Pueblo
                Cave-dwellers
              S. American
.074
              Peru
.075
           Scandinavia
.08
.081
              Norway
.085
              Sweden
.089
              Denmark
.09
               Egypt
.091
               Holland
.092
               Belgium
.093
              Switzerland
.094
              Greece
.095
              Turkey
.096
.097
               Russia
```

N. Africa

722.11 .12 .13	China Japan Korea		
.14 .2 .21 .22	Philippine <b>Egypt</b> Nubia  Abyssinia		
.31 .32 .33 .34	Phoenician, Jewish, etc. Phoenicia Philistia Judea Carthage		
.35 .4 .41 .42 .43 .44 .45 .46 .47	Cyprus  India, East  Buddhist  Jaina  Himalayan  Dravidian  Chalukyan  Indo-Aryan  Burmah  Siam		
.49 .5 .51 .52 .53 .54 .61 .611	Western Asia Babylonia Assyria Persia, ancient Sassania Pelasgian Greece Asia Minor Etruria		
.7 .71 .72 .73	Roman Rome England Germany Austria		

722.74	France		
.75	Italy, except Ro	ne	
.76	Spain Portuga	11.	
.77	Asia		
.78	Africa		
.79			
.8	Grecian		
.81	Athens		
.82	Peninsula		
.83	Mainland, excep	t Athens	
.84	Archipelago		
.85	Asia Minor		
.86	Italy		
.87	Sicily		
.88	Africa		
.89			
.9	Other ancient style	S	
23.	Mediaeval C	hristian	Mohammedan
.1	Early Christian		
.11	Syria		
.12	England Saxo	)11	
.13	Germany Ans	tria	•
.14	France		
.15	Italy		
.151	Rome		
.152	Ravenna		
.16	Coptic in Egypt		
.17	N. Africa		
.18	Scandinavia		
.19			
.2	Byzantine		
.21	Byzantine prope	17	
.22	Armenia		
.23	Russia		
.24	Bulgaria		
.25	Greece		·
.29			

723.3	Mohammedan
.311	Arabia
.312	Syria
.32	Egypt
.33	Persia
.34	Turkey
.35	India
.36	Spain Moorish
.37	North Africa
.38	
.39	
.4	Romanesque
.411	Scotland
.415	Ireland
.4:2	England
.431	Germany
.436	Austria
.44	France
.441	Anjou
.442	Normandy
.445	Auvergue
.446	Poitou
.449	Provence
.45	Italy
.451	Piedmont
.452	Lombardy
.453	Venice
.455 .457	Tuscany Naples
.458	Sicily
.459	Sieny
.461	Spain
.469	Portugal
.48	Scandinavia
.481	Norway
.485	Sweden
.489	Denmark
.49	
.492	Holland
.493	Belgium
.494	Switzerland
100	

723.5	Gothic
.511	Scotland
.515	Ireland
.52	England
.521	Early English
.522	Decorated
.523	Perpendicular
.531	Germany
.536	- Austria
.537	France
.55	Italy
.552	Lombardy
.553	Venice
.555	Tuscany
.558	Sicily
.561	Spain
.569	Portugal
.58	Scandinavia
.581	Norway
.585	Sweden
.589	Denmark
.59	Minor countries
.592	Holland
.593	Belgium
.594	Switzerland
.599	
24.	Modern
.1	Renaissance
• • •	
.111	Scotland
.115	Ireland
.12	England
.121	Elizabethan
.122	Jacobean
.123	17th Century
.124 .131	18th Century
.131	Germany Austria
.1.4	France
.141	Francis I Henry IV
.143	Louis XIV
.170	LOUIS ALI

Louis XVI

Empire

.144

724.15	Italy	
	•	
.151	Cinquecento	30
.152	High Renaissand Decadence	. e
.153	Barocco	
.154	Spain	
.161	Portugal	
.17	Russia	
.171	Canada	
.172	Mexico United States	
.173	Old colonial	
.1	Spanish coloni	21
.178	South Americ	aı
.176	Brazil	
.1	Argentina	
.3	Chili	
.4	Bolivia	
.5	Peru	
.6	Ecuador	
.7	Venezuela	
.9	Paraguay	
.18	Scandinavia	
.181	Norway	
.185	Sweden	
.189	Denmark	
.19	Minor countries	
.192	Holland	
.193	Belgium	
.194	Switzerland	
.199		
.2	Classical revival	Grecian
.211	Scotland	
.212	Ireland	
.22	England	
.231	Germany	
.236	Austria	
.24	France	
.25	Italy	
.261	Spain	
.269	Portugal	
.27	Russia	
.271	Canada	
.272	Mexico	

24.273	United States
.278	South America
.281	Norway
.285	Sweden .
.289	Denmark
.292	Holland
.293	Belgium
.294	Switzerland
.299	
.3	Gothic revival
.311	Scotland
.315	Ireland
.32	England
.331	Germany
.336	Austria
.34	France
.35	Italy
.361	Spain
.369	Portugal
.37	Russia
.371	Canada
.373	United States
.381	Norway
.385	Sweden
.389	Denmark
.392	Holland
.393	Belgium
.394	Switzerland
.4	Tudor Gothic revival
.411	Scotland
.412	Ireland
.42	England
.471	Canada
.473	United States
.49	
_	0 4 ! .!
.5	Queen Anne revival
.511 .512	Scotland Ireland
.52	England
.571	Canada
.573 5.0	United States
F, C)	

724.6	Neo Grec
.62	England
.631	Germany
,636	Austria
.64	France
.65	Italy
.661	Spain
.669	Portugal
.671	Canada
.673	United States
.68	Scandinavia
.69	
.7	Half-timber Swiss
.711	Scotland
.712	Ireland
.72	England
.731	Germany
.736	Austria
.74	France
.75	Italy
.761	Spain
.769	Portugal
.77	Russia
.771	Canada
.772	Mexico
.773	United States
.781	Norway
.785	Sweden
.789	Denmark Holland
.792 .793	Belgium
.794	Switzerland
.799	Differential
.8	Romanesque revival
.811	Scotland
.812	Ireland
.82	England
.831	Germany
.836	Austria
.84	France
.85	Italy
.861	Spain
.001	Portugal

724.871	Canada
.873	United States
.881	· Norway
.885	Sweden
.889	Denmark
.892	Holland
.893	Belgium
.894	Switzerland
.899	
9	Other recent styles
.911	Scotland
.915	Ireland
.92	England ·
.931	Germany
.936	Austria
.94	France
.95	Italy
.961	Spain
.969	Portugal
.97	Russia
.971	Canada
.972	Mexico
.973	United States
.978	South America
.1	Brazil
.9	Argentina
.3	Chili
.4	Bolivia
.5	Peru
.6	, Ecuador
.7	Venezuela
.8	Paraguay
.9	3.*
.981	Norway
.985	Sweden
.989	Denmark
.992 .993	Holland Belgium
.993	Switzerland
.999	DHRIDSHWG
	- 44 44
25	Public Buildings

## .1 Administration Government National capitols .111 State capitols. .112

Provincial capitols .113

25.111	Houses of parliament
.115	Provincial buildings
.12	Ministries .
.121	State
.122	Finance
.123	War
.124	Navy
.125	Foreign affairs
.126	Interior
.127	Education
.128	Commerce
.129	
.13	City buildings
.131	City halls
.132	Town halls
.133	Guild halls (public)
.134	Office buildings
.14	Custom houses, etc.
.141	Custom houses
.142	Customs warehouses
.143	Bonded storehouses
.144	Excise offices
.15	Court houses Record offices
.151	Supreme court houses
.152	Appeal court houses
.153	Court houses
.154	Justice courts .
.155	Record office buildings
.156	Archive buildings
.159	
.16	Postal buildings
.161	National buildings
.162	City post offices
.163	Village post offices
.164	Railway postal cars
.165	City postal cars
.17	Official residences Palaces of rulers
.171	National
.172	State
.173	City
.18	Barracks Police buildings
.181	National barracks
.182	State barracks
.183	Armories
16.1	National police buildings

120.189	State ponce buildings
.186	City police buildings
.19	Fire buildings
.191	Fire administration
.192	Engine houses
.193	Fire patrol
.194	Fire alarm stations
.2	Business and commercial buildings
.21	Stores
.211	Wholesale
.212	Department
.213	Retail city
.214	Retail village
.215	Warehouses, wholesale
.216	Warehouses, retail
.22	Mixed store, office and apartment buildings
.221	Stores and offices
.222	Stores and flats
.223	Offices and flats
.224	
.23	Office buildings
.231	Office only
.232	Telegraph and office
.233	Insurance and office
.234	Hall and office
.24	Bank buildings
.241	Banks only
.242	Bank and office
.243	Savings banks
.244	Savings bank and office
.245	Safe deposit
.25	Exchanges Boards of trade
.251	Stock exchanges
.252	Provision exchanges
.253	Cotton exchanges
.254	Lumber exchanges
.255	Oil exchanges
.259	
.26	Markets
.261	City
.262	Provisions
.263	Commission
.264	Retail

725.27	Cattle markets
.271	Stock yards
.272	Cattle
.273	Horses Mules
.274	Sheep Goats
.275	Hogs
.276	Fowls
.279	
.28	Abattoirs
.281	Public
.282	Private
.283	Packing houses
.284	Storehouses
.29	Other commercial buildings
.3	Transportation and storage
.31	Railway passenger stations
.311	Country
.312	City through
.313	City terminal
.314	Union
.315	
.316	Electric passenger
.317	Street-car
.318	Elevated
.319	Underground
.32	Railway freight houses
.321	Terminal
.322	Local
.323	Express
.33	Railway shops
.331	Metal
.332	Wood
.333	Painting
.334	Round houses
.335	Car barns
.336	Water tanks
.337	Storehouses
.338	Tool houses
.339	D 1 1 311
.34	Dock buildings
.341	Passenger
.342	Freight
.343	Wharf boats
.344	Wharf storehouses

725.35	Warehouses
.351	Merchandise
.352	Cold storage
.353	Ice plants
.354	Storage of furniture, etc.
.36	Grain elevators
.361	Brick
.362	Tiles
.363	Wood
.364	Concrete-steel
.365	Steel
.37	
.371	Coals
.372	Ores
.373	Cement Lime Plaster
.374	Malt
.375	Sand
.39	
· <b>.</b> 4	Manufactories
.41	Textile
111	Wool
.411	Wool
.412	Cotton
.412 .413	Cotton . Silk
.412	Cotton . Silk Linen
.412 .413 .414	Cotton . Silk
.412 .413 .414 .415	Cotton . Silk Linen Hemp
.412 .413 .414 .415	Cotton . Silk Linen Hemp
.412 .413 .414 .415 .416	Cotton . Silk Linen Hemp Jute
.412 .413 .414 .415 .416 .419	Cotton Silk Linen Hemp Jute Beer Alcohol, etc.
.412 .413 .414 .415 .416 .419 .42	Cotton Silk Linen Hemp Jute  Beer Alcohol, etc. Breweries Distilleries Wood alcohol
.412 .413 .414 .415 .416 .419 .42 .421	Cotton Silk Linen Hemp Jute  Beer Alcohol, etc. Breweries Distilleries
.412 .413 .414 .415 .416 .419 .42 .421 .422 .423	Cotton Silk Linen Hemp Jute  Beer Alcohol, etc. Breweries Distilleries Wood alcohol
.412 .413 .414 .415 .416 .419 .42 .421 .422 .423 .424	Cotton Silk Linen Hemp Jute  Beer Alcohol, etc. Breweries Distilleries Wood alcohol Spirits turpentine
.412 .413 .414 .415 .416 .419 .42 .421 .422 .423 .424 .425	Cotton Silk Linen Hemp Jute  Beer Alcohol, etc. Breweries Distilleries Wood alcohol Spirits turpentine Malteries
.412 .413 .414 .415 .416 .419 .42 .421 .422 .423 .424 .425	Cotton Silk Linen Hemp Jute  Beer Alcohol, etc. Breweries Distilleries Wood alcohol Spirits turpentine Malteries Iron and steel
.412 .413 .414 .415 .416 .419 .42 .421 .422 .423 .424 .425 .431	Cotton Silk Linen Hemp Jute  Beer Alcohol, etc. Breweries Distilleries Wood alcohol Spirits turpentine Malteries Iron and steel Smelters Foundries Rolling mills
.412 .413 .414 .415 .416 .419 .42 .421 .422 .423 .424 .425 .431 .432 .433 .434	Cotton Silk Linen Hemp Jute  Beer Alcohol, etc. Breweries Distilleries Wood alcohol Spirits turpentine Malteries Iron and steel Smelters Foundries Rolling mills Machine shops
.412 .413 .414 .415 .416 .419 .42 .421 .422 .423 .424 .425 .431 .432 .433 .434 .435	Cotton Silk Linen Hemp Jute  Beer Alcohol, etc. Breweries Distilleries Wood alcohol Spirits turpentine Malteries Iron and steel Smelters Foundries Rolling mills Machine shops Pattern shops
.412 .413 .414 .415 .416 .419 .42 .421 .422 .423 .424 .425 .431 .432 .433 .434 .435	Cotton Silk Linen Hemp Jute  Beer Alcohol, etc. Breweries Distilleries Wood alcohol Spirits turpentine Malteries Iron and steel Smelters Foundries Rolling mills Machine shops Pattern shops Nail and screw works
.412 .413 .414 .415 .416 .419 .42 .421 .422 .423 .424 .425 .431 .432 .433 .434 .435 .436 .437	Cotton Silk Linen Hemp Jute  Beer Alcohol, etc. Breweries Distilleries Wood alcohol Spirits turpentine Malteries Iron and steel Smelters Foundries Rolling mills Machine shops Pattern shops Nail and screw works Wire and fence works
.412 .413 .414 .415 .416 .419 .42 .421 .422 .423 .424 .425 .431 .432 .433 .434 .435	Cotton Silk Linen Hemp Jute  Beer Alcohol, etc. Breweries Distilleries Wood alcohol Spirits turpentine Malteries Iron and steel Smelters Foundries Rolling mills Machine shops Pattern shops Nail and screw works

725.44	Wood
.441	Saw mills
.442	Planing mills
.443	Cabinet mills
.444	Furniture works
.445	Agricultural works
.446	Specialty works
.449	
.45	Carriage and car shops
.451	Carriages
.452	Wagons
.453	Automobiles
.454	Bicycles
.455	Car shops (contract)
.456	Locomotives (contract)
.46	Paper mills
.461	Paper
.462	Wall paper
.463	Straw board
.469	
.47	Milling
.471	Flour
.472	Meal
.473	Feed
.48	Ceramic Glass Works
.481	Bricks, ordinary
.482	Bricks, pressed and moulded
.483	Terra cotta
.484	Tiles, roofing
.485	Tiles, floor
.486	Potteries
.487	Glass, window Bottles
.488	Plate
.489	Stained
.49	
.5	Hospitals Asylums
.51	General
.511	Sick
.512	Surgical
.513	Eye
.514	Ear
.515	Lying-in
.516	Incurables
.517	Consumption
.518	Contagious
.519	

```
Insane
725.52
                 National
   .521
                 State
   .522
   .523
                 City
   .524
                  Incurables
   .525
                 Private
              Feeble-minded
   .53
   .531
                 Idiots
                 Defectives
   .532
                 Defective diseased
   .333
              Blind Deaf
   .54
   .541
                 Blind
                 Deaf.
   .542
   .543
                 Schools
   .544
                 Shops
                 Colleges
   .545
   .55
              Almshouses
                  National
   .551
                 State
   .552
                 County
   .553
   .554
                 City
                 Town
                 Endowed
   .556
                 Subscription
   .557
   .558
                 Society
   .559
   .56
              Homes for aged
                 Public
   .561
                 Society
   .562
   563
                 Endowed
                 Subscription
   .564
   .565
                 Private
   .57
              Homes for children, orphans
                 National
   .571
   .573
                 State
   .573
                 City
   .574
                 Church
                 Society
   .576
                 Endowed
              Foundlings
   .58
   .581
                 City
   .553
                 Church
                 Society
   .583
   .584
                 Private
              Homes for soldiers and seamen
   .59
                 National
   .591
```

~0	5.509	State	
1 .~	5.592 $593$	State Society	
	.594	Private	
	.595	Widows	
	.596	Orphans	
		*	
	.6	Prisons Reformatories	
	.61	Penitentiaries	
	.611	National	
	.612	State	
	.613	City	
	.62	Jails	
	.621	County -	
	.622	City	
	.623	Village	
	.624	Police cells	
	.63	Reformatories for adults	
	.631	Houses of correction	
	.632	Houses of detention	
	.633	Work houses	
	,634	Houses for women	
	.64	Reformatories for young	
	.641	Boys	
	.642	Girls	
	.643	Parental schools	
	.644	Truant school	
	.65	Asylums for inebriates	
	.651	Washingtonian	
	.652	Hospitals	
	.653	Drug victims	
	.654	Incurables	
	.7	Refreshments Baths F	Parks
	.71	Cafes Restaurants	
	.711	Buffets	
	.712	, Dairies	
	.713	Cafes	
	.714	Restaurants	
	.715	Restaurant gardens	
	.72	Saloons Sample rooms	
	.73	Baths	
	.731	Ordinary	
	.732	Medicated	
	.733	Turkish	
	.734	Russian	
	.735	Shower	

72	5.736	Rain
	.737	Vapor
	.739	
	.7±	Swimming baths
	.741	Public
	.742	Society
	.743	Private .
	.75	Buildings for watering places
	.751	Spring houses
	.752	Casinos
	.753	Bowling alleys
	.754	Tennis courts
	.755	Porticos
	.76	Buildings for parks
	.761	Shelters
	.762	Music pavilions
	.763	Kiosks
	.764	Animals
	.765	Plants
	.766	Conservatories
	.767	Refreshments
	.768	Toilet
	.769	
	.8	Recreation
	.811	Music halls
	.S12	Concert halls
	.813	Orchestra halls
	.821	Theatres
	.822	Marionette theatres
	.823	Opera houses
	.824	·Vaudevilles
	.S31	Lecture halls
	.832	Recital halls
	.841	Bowling alleys
	.842	Billiard halls
	.843	Card halls
	.851	Gymnasiums
	.852	Turn halls
	.S53	Drill halls for boys
	.86	Rinks
	.861	Skating
	.862	Roller skating
	.863	Bicycle
	.864	Running

725.87	· Boat houses
.871	Club
.872	Private
.873	Public
.881	Riding halls
.882	Riding schools
,883	Bicycle halls
.89	Shooting galleries
.891	Public
.892	Military
.893	Club
.894	Society
.895	Private
.9	Other public buildings
.91	Exhibition buildings
.911	International
.912	National
.913	State
.914	County
.915	City
.916	Memorial
.917	Art
.918	Antiquities
.919	** u *
.92	Halls for temporary purposes
.921	Shooting contests
.922	Musical contests
.923	Religious meetings
.924	Chautauqua assemblies
.925	Political meetings Convention halls
.926	
.93	Workingmen's clubs, etc.
.931	Institutes
.932 .933	Unions
726	Ecclesiastical and religious buildings
.1	Temples
.11	Egyptian
.12	Assyrian
-	· ·
.13	Jewish
.14	Etruscan
.15	Grecian

726.16	Roman
.17	Chinese
.18	Japanese
.19	·
.2	Mosques
.21	Courtyard
.22	Byzantine
.23	Indian
.3	Synagogues
.4	Chapels S. S. buildings
.41	University
.42	College
.43	Asylum
.44	Memorial
.45	Cemetery
.46	Private
.47	Sunday school buildings
.49	·
.5	Churches
.51	Roman Catholic .
.52	Protestant Episcopal
.53	Greek
.54	Methodist Episcopal
.55	Presbyterian Congregational
.56	Baptist Christian
.57	Friends
.58	Christian Science
.59	
.6	Cathedrals
.61	Roman Catholic
.62	Protestant Episcopal
.63	Greek .
.7	Monasteries
.71	Abbeys
.72	Monasteries

200 20	Priories
726.73	
.74	Convents
.75	Houses for clergy
.76	Paulist fathers
.8	Mortuary buildings
.81	Chapels, cemetery
.82	Chapels, memorial
.83	Vaults, public
.84	Vaults, family
.85	Tombs, memorial
.86	Tombs, family
.87	Tombs, society
.88	Tombs, private
.89	
.9	Y. M. C. A. buildings
.91	Y.M.C.A. houses
.9:2	Y.M.C.A. hotels
.93	Y.W.C.A. houses
.94	Y.W.C.A. hotels
.94 <b>727</b>	Y.W.C.A. hotels  Educational and scientific
727	Educational and scientific
727 .1	
727 .1	Educational and scientific Schools Public
727 .1 .11 .12	Educational and scientific  Schools  Public  Private
727 .1 .11 .12 .13	Educational and scientific  Schools  Public  Private  Defectives
727 .1 .11 .12	Educational and scientific  Schools  Public  Private  Defectives  Preparatory
727 .1 .11 .12 .13 .14	Educational and scientific  Schools  Public  Private  Defectives  Preparatory  Military for boys
727 .11 .12 .13 .14 .15	Educational and scientific  Schools  Public  Private  Defectives  Preparatory  Military for boys  Orphans
727 .1 .11 .12 .13 .14 .15 .16	Educational and scientific  Schools  Public  Private  Defectives  Preparatory  Military for boys
727 .1 .11 .12 .13 .14 .15 .16 .17	Educational and scientific  Schools  Public  Private  Defectives  Preparatory  Military for boys  Orphans  Manual training
727 .1 .11 .12 .13 .14 .15 .16 .17 .18 .19	Educational and scientific  Schools  Public  Private  Defectives  Preparatory  Military for boys  Orphans  Manual training
727 .1 .11 .12 .13 .14 .15 .16 .17 .18	Educational and scientific  Schools  Public  Private  Defectives  Preparatory  Military for boys  Orphans  Manual training  Trades
727  .1  .11  .12  .13  .14  .15  .16  .17  .18  .19  .2  .21	Educational and scientific  Schools  Public  Private  Defectives  Preparatory  Military for boys  Orphans  Manual training  Trades  Academies  Academies  Seminaries  Academies
727  .1  .11  .12  .13  .14  .15  .16  .17  .18  .19  .2	Educational and scientific  Schools  Public  Private  Defectives  Preparatory  Military for boys  Orphans  Manual training  Trades  Academies Seminaries

727.3	Colleges Universities
.31	National
.32	State
.33	City .
.34	Graduate
.35	Sectarian
.36	Scientific
.4	Professional schools
.41	Theology
.42	Medicine
.43	Law
.44	Normal
.441	
.442	National State
.443	City
.444	Private
.449	rinate
.45	Engineering
.451	Architecture
.452	Architectural engineering
.453	Civil
.454	Electrical
.455	Mechanical
.456	Railway
.457	Sanitary
.458	Gas
.459	
.46	Music
.461	Voice
.462	Piano
.463	Organ
.464	Violin
.465	Minor instruments
.47	Art
.471	Elementary
.472	Painting
.473	Sculpture
.474	Illustration
.475	Institutes
.476	Academies
.481	Chemistry
.482	Agricultural
.49	
.491	Dairy

27.5	Laboratories
.51	Agriculture
.52	Horticulture
.53	Chemistry
.54	Physics
.55	Engineering
.551	Materials
,552	Hydraulic
.553	Steam
.554	Gas
,555	Fuel
.556	Electricity
.557	Mechanics
.558 .559	Machines
.56	
.57	Zoölogical gardens
.58	
	Botanic gardens
.59	Aquariums
.6	Museums
.61	Ethnology
.62	Zoölogy
.63	Botany
.64	Industry
.65	History
.66	War
.67	Art
.68	Private
.69	
.7	Aut mallautes
.71	Art galleries
	Painting
.72	Sculpture
.73	Engravings
.74	Art industries
.751	Medals
.752	Coins
.753	Postal
.76	~
.771	Studios, painters'

27.772	Studios, sculptors'
.773 .78	Private
	Frivate
.79	•
.8	Libraries
.81	National
.82	State
.83	City
.84	Town
.851	College
.852	University
.853	Society
.86	Professional
.861	Theology
.862	Medicine
.863	Law
.864	Normal
.865	Engineering
.866 .869	Music
2 ~	. \ ••+
.87	Art
.88	Art History
.88	
.88 .89	History
.88 .89 <b>.9</b>	History  Learned societies' buildings
.88 .89 .9 .91 .911	History  Learned societies' buildings  Art  Painting  Sculpture
.88 .89 .9 .91 .911 .912 .913	History  Learned societies' buildings  Art  Painting  Sculpture  Art industries
.88 .89 .9 .91 .911 .912 .913 .914	History  Learned societies' buildings  Art  Painting  Sculpture  Art industries  Engraving
.88 .89 .9 .91 .911 .912 .913 .914 .915	History  Learned societies' buildings  Art  Painting Sculpture Art industries Engraving Medals and coins
.88 .89 .9 .91 .911 .912 .913 .914 .915	History  Learned societies' buildings  Art  Painting Sculpture Art industries Engraving Medals and coins Science
.88 .89 .9 .91 .911 .912 .913 .914 .915 .92	History  Learned societies' buildings  Art Painting Sculpture Art industries Engraving Medals and coins Science Physics
.88 .89 .9 .91 .911 .912 .913 .914 .915	History  Learned societies' buildings  Art Painting Sculpture Art industries Engraving Medals and coins Science Physics Chemistry
.88 .89 .9 .91 .911 .912 .913 .914 .915 .92	History  Learned societies' buildings  Art Painting Sculpture Art industries Engraving Medals and coins Science Physics
.88 .89 .9 .91 .911 .912 .913 .914 .915 .92 .921 .922 .923	History  Learned societies' buildings  Art  Painting Sculpture Art industries Engraving Medals and coins Science Physics Chemistry Natural science
.88 .89 .9 .91 .911 .912 .913 .914 .915 .92 .921 .922 .923 .1 .2 .3	History  Learned societies' buildings  Art  Painting Sculpture Art industries Engraving Medals and coins  Science Physics Chemistry Natural science Biology Zoölogy Botany
.88 .89 .9 .91 .911 .912 .913 .914 .915 .92 .921 .922 .923 .1 .2 .3 .4	History  Learned societies' buildings  Art Painting Sculpture Art industries Engraving Medals and coins  Science Physics Chemistry Natural science Biology Zoölogy Botany Entomology
.88 .89 .9 .91 .911 .912 .913 .914 .915 .92 .921 .922 .923 .1 .2 .3 .4	History  Learned societies' buildings  Art  Painting Sculpture Art industries Engraving Medals and coins  Science Physics Chemistry Natural science Biology Zoölogy Botany Entomology Geology
.88 .89 .9 .91 .911 .912 .913 .914 .915 .92 .921 .922 .923 .1 .2 .3 .4	History  Learned societies' buildings  Art Painting Sculpture Art industries Engraving Medals and coins  Science Physics Chemistry Natural science Biology Zoölogy Botany Entomology

727.93	Engineering
.931	Architecture
.932	Architectural
.933	Civil
,934	Electrical
.935	Mechanical
.936	Railway
.937	Sanitary
.939	
.94	Education
.941	National
.942	State
.943	County
.944	City
.945	Local
.95	Religion
.951	Ministerial
.952	Missionary
.953	Benevolent
.96	Medicine
.961	National
.962	State
.963	County
.964	City
.965	Local
.969	
.99	
728	Residences
.1	Tenements
.11	City, for poor
.12	City, for workers
.13	City, for clerks, etc.
.14	Country
.15	Factory
17	Society
.19	Society
.2	Apartment buildings
.21	Flats, small
.22	Flats, medium
.23	Flats, large
.24	Bachelor's
*14 1	

728.25	Women's
.26	Family
.27	Double houses
.28	Rooming houses
.29	
.3	City houses ·
.31	Small, wood
.32	Small, brick
.33	Small, stone
.34	Medium, brick
.35	Medium, stone
.36	Mansions, inside
.37	Mansions, corner
.38	Mansions, detached
.39	
.4	Buildings for clubs and societies
.41	Clubs, dining
.42	Clubs, meeting .
.43	Masonic
.44	Odd Fellows
.45	Knights of Pythias
.46	Elks
.47	G.A.R.
.48	Insurance, fraternal
.49	
.5	Hotels
.51	Country inns
.52	Village inns
.53	City, rooming
.54	City, European
.55	City, American
.56	City, largest
.57	Suburban
.58	Summer
59	

728.6	Village and country homes
.61	Small ·
.62	Brick
.63	Stone
.64	Concrete
.65	Plastered
.66	Masonry and wood
.67	Farm houses
.68	Cottages for laborers
.69	
.7	Summer homes
.71	Tents
.72	Portable
.73	Wood
.74	Brick
.75	Stone
.76	Mixed
.77	Concrete
.78	Metal ·
.79	
.8	Country seats
.81	Castles
.82	Chateaux
.83	Manor houses
.84	Villas
.89	
.9	Out buildings
.91	Gate lodges
.92	Cottages for helpers
.921	Servants
.922	Laborers
.923 .924	Gardeners Grooms
.925	Coachmen
.926	Keepers
.927	Foresters

728.93	Kitchens, laundries, etc.
.931	Kitchens
	Laundries
.932	Dairies, house
	Smoke houses
.934	Shoke houses Store houses
.935	Granaries
937	Commissaries
938	Commissaries
	C4-1-1 1 1
.94	Stables, carriage houses, etc.
.941	Stables, village
.942	Stables, city
.943	Stables, largest
.944	Kennels
.945	Carriage houses
.949	
.95	Barns, granaries, etc.
.951	Barns, small
.952	Barns, village
.953	Barns, farm
.954	Barns, store
.955	Granaries, small
.956	Granaries, large
.957	Corn cribs
.959	
.96	Dairies
.961	Dairies, large
.962	Dairy stables
.963	Dairy stores .
.97	Refrigeration accommodations
.971	Ice houses
.972	Ice plants
.973	Cold storage houses
.974	Fruit houses
.975	Cellars, store
.98	Conservatories, greenhouses, etc.
.981	Window gardens
.982	Greenhouses
.983	Conservatories
.984	Cold houses
.985	Grape houses
.986	Palm houses
.987	Forcing houses
.988	Store houses
.989	

728.99	Miscellaneous outbuildings
.991	Sheep houses
.992	Pig houses
.993	Fowl houses
.994	Pigeon houses
.995 .996	Rabbit houses
729	Auchitectural design and decoration
127	Architectural design and decoration
	See 721 for Construction.
	Classify Forms and Design here.
.1	The elevation
.11	Composition
.12	Subdivision
.13	Proportions
.14	Light and shade
.15	Perspective effect
.16	Balance -
.17	Axial lines
.18	Accenting
.19	The section .
.191	Longitudinal
.192	Transverse
.193 .194	Diagonal Broken
.195	Oblique
.2	The plan
.21	Composition
.22	Distribution
.23	Proportions
.24	Sequence of rooms
.25	Communications, horizontal
.26	Communications, vertical
27	Axial lines
.28	Balance
.29	Buttinee
.3	Florentener former
•0	Elementary forms See 721 for Construction of Forms.
.31	Walls
.311	Plinth Water table
.312	Basement

729.313	Wall proper
.314	Belts String courses
.315	Bands, ornamental
.316	Polychrome .
.317	Entablatures
.1	Architrave
.2	Frieze
.3	Cornice
.4	Balustrade
.318	Mansard cornices
.319	mansard cornices
.32	Cupporto
.321	Supports
	Piers, simple
.322	Piers, compound
.323	Orders, architectural
.1	Tuscan
.2	Dorie
.3	Ionic
.4	Corinthian
.5	Composite
.324	Columns, other forms
.325	Pilasters, other forms
.326	Colonnades
.33	Arches and arcades
.331	Semicircular
.332	Segmental
.333	Pointed
.334	Horizontal
.335	Elliptical
.336	Oval
.337	Tudor
.338	Arched frieze
.339	Arcades
.34	Vaults and domes
*.341	Tunnel
.342	Annular
.343	Cross
.344	Cloister
.345	Gothic, ribbed
.1	Tunnel
.2	Cross
.3	Cloister
.4	Polygonal
.5	Star
.6	Net
.7	
.8	Fan, square
.9	Fan, rectangular

729.346	Helicoidal
.347	Domes, circular
.348	Domes, pendentive
.349	
.35	Roofs Spires
.351	Gable, roofs
.352	$\mathrm{Hip}$
.353	Valley
.354	Flat
.355	Cylindrica1
.356	Conical
.357	Spires
.1	Square
.2	Octagonal
.3	Round
.4	Open Tracery
.358	Gablets
.359	
.36	Towers
.361	Square
.362	Rectangular
.363	Polygonal
.364	Round
.365	Lanterns
.366	Turrets
.369	
.37	Gables Pediments
.371	Gables
.372	Gables, stepped
.373	Pediments, triangular
.374	Segmental
.375	Semicircular
.376	Polygonal
.377	Broken
.378	Mixed
.379	-
.38	Doors Windows
.381	Doors
.1	External single
.2	External double
.a	External transom
.4	Internal single
.5	Internal double
.6 .7	Internal transom
.7 •.8	Glazed
.9	Secret
.:/	

729.382	7777
120.002	Windows
.9	Laternal Shung
.8	External casement
.4	External staitled
.9	Dianicasc
.a .6	1 laccit
.0	rittCritar
	CITIC
.9	Lattice
υ. 383.	D
.355	Bay windows
.1	Rectangular
.3	Polygonal
	Circular
.384	Diagonal
.054	Oriel windows
2.	Square
.3	Rectangular
.3	Polygonal
 .5	Circular
.385	Diagonal
.386	Luthern windows
.330	Dormer windows
.1	Rectangular
.3	Triangular
.4	Circular
.5	Eye-brow
.6	Tracery Lattice
.7	Blind
.9	pind
.39	Ct. D.
	Stairs Balustrades
.391	External steps
.392	External ramps
.393	External staircases
.394	External balustrades
.395	Staircase towers
.396	Internal stairways
.397	Elevators
.398	Lifts
.399	
.4	Painted decorations
.41	Plant forms
.421	Animal forms
.422	Human forms
.423	
. 1.00	Mythological forms

729.43	Grotesques
.441	Conventional forms
.442	Geometrical forms
.443	Fanciful forms
.45	Mouldings
.461	Architraves
.462	Friezes
.463	Cornices
.464	Bands
.465	Panels
.466	Cartouches
.467	Centers
.468	Borders
.469	
.47	Painted orders
.471	Simple
.472	With pedestals
.473	Pilasters
.474	Arcades
.475	Mixed
.48	Painted ceilings and vaults
.481	Centers
.482	Panels
.483	Borders
.484	Compartments
.485	Historical
.486	Biblical
.487	Mythological
.488	Decorative
.489	D: 1
.49.	Painted walls
.491	Centers
.492	Panels
.493	Borders
.494	Dados
.495 .496	. Historical Biblical
.496	
.498	Mythological Decorative
.499	Detorative
.5	Relief decoration
.51	Plant forms
.521	
.522	Animal forms Human forms
.523	Mythological forms
10 mg O	Mythological forms

729.53	Grotesques
.541	Conventional forms
.542	Geometrical forms
.543	Fanciful forms
.55	Mouldings, sculptured
.561	Architraves
.562	Friezes
.563	Cornices
.564	Bands
.565	Panels
.566	Cartouches
.567	Borders
.568	Centers
.569	
.57	Orders in relief
.571	Simple
.572	With pedestals
.573	Pilasters
.574	Arcades
.575	Mixed
.58	Sculptured ceilings and vaults
.581	Centers
.582	Panels
.583.1	Borders
.2	Ribs
.584	Compartments
.585	Historical reliefs Biblical reliefs
.586 $.587$	Mythological reliefs
.588	Decorative reliefs
.589	Decorative Teners
.59	Reliefs on walls
.591	Centers
.592	Panels
.593	Borders
.594	Dados
.595	Historical
:596	Biblical
.597	Mythological
.598	Decorative
.599	
.6	Incrustation
.61	Walls, external
.611	Stone
019	Morble

```
729.613
                 Brick
  .614
                Terra cotta
  .615
                Tiles
  .616
                 Metal
  .617
                 Polychromatic
                 Plastering
                             Stucco
  .618
  .619
             Walls and ceilings, internal
  .62
  .621
                 Stone
  .622
                 Marble
  .623
                 Brick
  .624
                Terra cotta
                Tiles
  .625
  .626
                 Metal
                 Polychromatic
  .627
                 Plastering
                              Stucco
  .628
  ,629
  .68
             Inlays
  .631
                Stone
  .632
                 Marble
  .633
                Tiles
  .624
                Faience
  .625
                Metal
  .626
                Ivory
  .627
                Shell
  .628
                Polychromatic
  .629
             Niello work
  .64
  .641
                Engraved
  .642
                Etched
                Electroplated
  .643
             Enamel decoration
  .65
  .651
                Metal
                  Champleve
      .1
                  Cloisonnee
                  Glaze
      .3
                Tiles
  .652
      .1
                  Glazed
      .2
                  Painted
                  Printed
             Plaster
  .66
  .661
                Inlaid
                Sgraffito
  .662
```

Polychromatic

.663

23	
729.67	Veneering
.671	Wood on wood
.672	Metal on wood
.673	Burl work .
.674	Inlaid work
.675	Polychromatic
.68	Lacquer
.681	Plain
.682	Relief
.683	Sprinkled
.684	Inlaid
.69	
.7	Mosaic
.71	Ceilings
.711	Centers
.712	Panels
.713	Borders
.714	Ornaments
.715	Figures Pictures
.716	Inscriptions
.717 .719	This criptions
.72	Walls
.721	Centers
.722	Panels
.723	Borders
.724	Ornaments
.725	Figures
.726	Pictures
.727	Inscriptions
.729	
.73	Floors
.731	Panels
.732	Geometrical
.733	Tesserae
.734	Borders *
.735	Ornaments
.736	Figures
.737	Inscriptions
.738	Mixed
.739	
.74	
.741	Fireplaces
.742	Furniture
.743	Jewelry
.744	Pictures

29.8	Stained glass designs
	See 691.6 for Materials.
	See 692.37 for Construction.
.81	Geometrical
.82	Medallions
.83	Canopy
.84	Figures
.85	Mosaic
.86	Polychromatic
.87	Historical
.88	Biblical
.89	Diblicat
.00	•
.9	Accessories and Equipment
.91	Altars
.911	Free
.912	Wall
.913	Canopy
.914	Reredos
.915	Railing
.916	Steps
.917	Screen
.918	Tabernacle
.919	
.92	Rostra
.921	Ambos
.922	Pulpits *
.923	Tribunes
.924	Desks
.93	Thrones
.94	Buffets
.941	Sideboards
.942	Built-in
.943	Restaurant
.944	Railway
.945	Saloon
.95	Fireplaces
.951	Mantles, marble
.952	Mantels, brick
.953	Mantels, terra cotta
.954	Mantels, wood
.955	Mantels, metal
.956	Overmantels

729.937	Ornaments
.958	Mirrors
.959	
.96	Screens, fixed
.961	Stone
.962	Metal
.963	Wood
.97	Confessionals
.98	Organs, pipe
.981	House
.982	Church
.983	Yacht
.984	Hall
.985	Theater
.989	
.99	

•	C. 1
A	Steel 721.262.4
Abattoirs Arrangement 725.281	Stone 721.262.1
Abbeys Buildings 726.71	Terra cotta 721.262.3
Academies Buildings 727.21	Wood 721.262.8
Account of payments, Architect's 692.85	Arched construction Brick 721.42
Acetylene gas heating 697.64	Cast-iron 721.45
Administration buildings Gov-	Concrete 721.46
ernment 725.1	concrete, Hollow 721.462
Adobes Building 693.22	Concrete-steel 721.464
Advertisements Contracts 692.41	Plaster Staff 721.48
Africa History of architecture 720.96	Steel 721.44
Africa, North Mohammedan	Stone 721.41
architecture 723.37	Terra cotta 721.43
Agreements Contracts 692.43	Wood 721.47
Agricultural schools Buildings 727.48	Arched frieze Architectural
works 725.445	design 729.338
Air valves Steam heating 697.58	Construction 721.263.3
Almshouses City 725.554	Arches and vaults Construction 721.4
County 725.553	Architectonics 720.13
General 725.55	Architect's extra expenses 692.86
Society 725.558	extra services 692.82
State 725.552	liabilities 692.95
Altars Design 729.91	services Building 692.81
Aluminum Materials 691.85	special services 692.83
Anchors Building 696.7	Architectural construction Gen-
for gutters 696.75	eral 721
for leaders 696.75	decoration 729
for masonry 696.76	design 729
Through 696.74	engineering Schools 727.452
Wall 696.72	forms 729
Ancient architecture History 722	Architecture, Ancient or primitive 722
Animal houses Parks 725.764	Fine arts 720
Ants Woods 691.163	General 720
Apartment buildings General 728.2	General history 720.9
Approval of bills Building 692.72	Modern styles 724
Aquariums Buildings 727.59	Prehistoric 722
Arabia Architecture 723.311	Schools 727.451
Arbitration Contracts 692.444	Archive buildings Arrange-
Arcade band Construction 721.263.2	ment 725.156
Arcades, blind Construction 721.263.1	Argentina Recent architec-
Brick 721,262,2	ture 724,978.2
Concrete 721,262.6	Renaissance architecture 724.178.2
Concrete-steel 721.262.7	Armenian architecture 723.22
Iron 721.262.5	Armories Military 725.183

Art academies Buildings	727.476	Asylums Deaf and dumb	725.542
galleries See Art museums	131.410	for inebriates	725,65
buildings	727.7	for idiots	725.531
Fine arts	708	Insane	725.52
Art history See name of		Austria Architectural school	
country	709		720,743.5
Art institutes Buildings	727.475	Architecture	
libraries	727.37	Classical revival	724.236
Art museums Fine arts	708	Gothic	723.536
Australia	708.9	revival	724.336
Austria	708,33	Half-timber, Modern	724.736
Belgium	708,993	History of	720.943.6
Canada	708.71	History of art	709.436
Denmark .	703.99	Neo-Grec	724.636
England	708.2	Prehistorie	722,036
France	708.4	Recent	724.936
Germany	708.31	Renaissance	724.136
Holland	708,992	Romanesque	723,436
Ireland	708.15	revival	724.836
Italy	708.5	Automobile shops Building	725,453
Mexico	703.72		
Norway	708.91	В	
Portugal	708.69	Babylonia Architecture	722.51
Russia	708.7	Art history	709.351
Scotland	708.11	·Balustrades Roofs	721.562
South America	708.8	Bank and office buildings	725.242
Spain	708.61	Bank buildings Arrangement	
Sweden	708 95	exclusively	725.241
Switzerland	708.994	Barns for dwellings	728.95
United States	708.73	for farms	728.953
Art schools Buildings	727.47	Barracks, Soldiers' Arrange	
Articles Architecture	720.43	ment	725.18
Artificial stone Materials Arts, Fine General	691.3 700	National	725.181
Asbestos Materials		State	725.182
fire protection	691.95 691.953	Basalt Materials	691.262
heat insulation	691.952	Basswood Woods	691.145
pipe covering	691.951	Baths Buildings	725.73
reofs Roofing	695,71	Swimming	725.74
Ash Woods	691.135	Bay windows Architectural	200 000
Asphalt Painting	698.41	design .	729,383
heaters Materials	690,848	Beams, Strengthened Carpen Wood Wood floors	
Rock Materials	691.962	Bedford stone Materials	721.615
roofs Roofing	695.6	Beech Woods	691.214
Trinidad Materials	691.961	Belgium Classical revival	691.132
Assyria Architecture	722.52	Architecture	724.293
Art history	709.352	Gothic	724.293
- in thotory	100.003	Counc	425.093

revival	724.393	Cut Building	693.23
History of	720.949.3	drawings	692.216
History of art	709,493	Ornamental Buildings	693.24
Recent	724.993	Ornamental Drawings	692.217
Renaissance	724.193	Polychrome Building	693.25
Romanesque	723,493	Pressed	725.482
Belt courses Construction	721.253	Rubbed Building	693,23
Beton construction Building	693.5	Bronze Materials	691.86
Beveled glass Drawings	692.282	Specifications	692.357
Bicycle rinks Buildings	725.863	Buffets Design	729.91
shops	725,454	Building Exhibitions	690.62
Bids Contracts	692.42	Handbooks	690.2
Billiard halls Buildings	725.842	History of construction	690,95
Birch Woods	691.143	laws · City	692.92
Blinds Windows	721.87	State	692.91
Blower ventilation Drawing	s 692,259	Machinery	690.84
Board of trade buildings	725.25	materials General	691
Boat houses Buildings	725.87	ordinances Miscellaneous	692.91
Boilers Hot water heating	697.45	Town	692.93
Steam heating	697.55	Village	692.93
Bolivia Recent architecture	724.978.4	periodicals	699,5
Bolts, Door	721.883.7	preservatives	691
Bond irons Building	696.71	processes	691
Bonded warehouses Arrange	2-	socicties	690.6
ment	725.143	system	690.11
Bonds of brick masonry	693,21	Trade schools	690.75
Bonds of stone work	693.11	Trade unions	690,61
Bonds, Surety Contracts	692.45	Training and study	690.7
Bookkeeping, System Buildi	ng 692.71	Woods	690.1
Borers Woods	691,164	Burlap Decoration	698.71
Botanic gardens Buildings	727.58	Materials	691,942
Bowling alleys Buildings	725,841	Burmah Architecture	722.47
Brass Materials	691.82	Butternut Woods	691.148
Brass work detail drawings	692 238	Byzantine architecture	723.21
Brazil Recent architecture	724.978.1		
Renaissance architecture	724.178.1	C	
Breweries Beer	725.421		
Brick yards Manufactories	725.481	Cabinet shops Buildings	725,443
Bricks, Common Materials	691.41	work	694.7
Enameled	691,14	drawings Details	692,223
Glazed	691.44	specifications	692.343
Moulded	691.43	Cabot's quilt paper Materials	
Pressed	691.42	Cafes Buildings	725.713
Self-colored	691.45	Calked joints Building	696,62
Brickwork Bonds	693.21		
building	693.2	Architecture	721.371
specifications	692,332	Half-timber, Modern	721.771

Recent	724.971	Cemeteries Landscape archi	_
Renaissance	724.171	tecture	719
Capitols, National Arrange-		Tombs, Family	726.86
ment	725.111	Memorial	726.85
Provincial Provincial	725.113	Society	726.87
State =	725.112	Vaults, Family	726.84
Car barns Railway	725,335	Public	726.83
building General	699	Cemetery chapels Buildings	726.81
shops Contract	725.455	Chaldea Art history	709.351
Carpenter's drawings Details	692.221	Chapels, Cemetery Buildings	726.81
Carpentry Building	694.1	Chateaux Modern residences	728.83
Specifications	692.34	Chili Recent architecture	724.978.3
Carpets Materials	691.943	Renaissance architecture	724.178.3
Carriage shops Buildings	725.451	Chimneys Building	697.8
Carthage Architecture	722.34	China Architecture	722.11
Art history	709.334	Art history, Ancient	709.311
Casinos Buildings -	725.752	Chintz Decoration	698.72
Cast-iron construction draw-		Churches	726.5
ings	692.231	Baptist	726.56
ornamental drawings	692.232	Christian	726.56
Castles Modern residences	728.81	Christian Science	726.58
Catalpa Woods	691.147	Congregational	726.55
Cathedrals Greek	726.63	Friends	726.57
Protestant Episcopal	726.62	Greek or Russian	726.53
Roman Catholic	726.61	Methodist Episcopal	726.54
Cattle markets	725.272	Presbyterian	726.55
Cedar, Red Woods	691.124	Protestant Episcopal	726.52
White	691.123	Roman Catholic	726,51
Ceilings, Brick or tiles and steel	721.73	City buildings Municipal	725.13
Concrete	721.75	halls Arrangement	725.131
Concrete-steel	721.752	Civil engineering schools	727.453
Construction	721.7	Classical revival Modern	724.2
Metal	721.74	Classification of cost data	692.57
Mill system	721.714	Clergy houses Buildings	726.75
Plaster	721.755	Clerk of works Building	692.64
Sculptured Design	729.58	Club houses General	728.4
Stone Construction	721.72	Coal tar Materials	691.965
Wood Beam	721.713	Cold storage plants	725.352
Coffered Construction	721.716	Collections Architecture	720.8
Construction	721.71	Drawings	720.S4
Painted Design	729.48	Models	720.85
Wood Paneled	721.715	Photographs	720.86
Celtic art history	709.36	Colleges Buildings	727.3
Cement, Keene's Materials	691.57	Engineering	727.45
Natural	691.54	Law	727.43
Portland	691.55	Medical	727.42
wash Painting	698.23	Normal	727.44

Scientific	727.36	Materials	691.33
Sectarian	727.35	Cement Materials	691.36
State	727.32	Construction Building	693.5
Colonnades, Brick	Construc-	Data for Reinforced	693.74
tion	721.261.2	Forms and centers Building	693.72
Concrete	721.261.6	Formulas for Reinforced	693.75
Concrete-steel	721.261.7	inspection Reinforced	693.73
Construction of	721.261	Lime Materials	691.35
Iron	721.261.5	Mixers Materials	690.847
Steel	721.261.4	Ornamental Building	693.55
Stone	721.261.1	Ransome Materials	691.32
Terra cotta	721.261.3	Reinforced Hennebique	693.714
Wood	721.261.5	Ransome rods	693.712
Columns and posts	Carpentry 694.4	Roebling	693.715
Columns, Block con		Round rods .	693.711
struction	721.332	Special applications	693.76
Cast-iron	721,351	Systems	693.71
Concrete	721.33	Thacher rods	693.716
	Construction 721.333	Unit system	693.713
Construction of	721.3	sidewalks Building	693.54
Fireproofed	721.36	Solid Building	693.51
by brickwork	721.364	steel Building	693.7
by concrete	721.365	steel floors	721.656
by hollow tiles	721.362	testing Reinforced	693.73
by mortar	721.361	Confessionals Design	729.97
by porous terra	721.363	Conditions, General Specifica-	
Steel lattice	721.353.3	tions	692.31
Steel riveted	721,353.2	Conifers, Hard Woods	690.11
Steel solid	721.353.1	Soft Woods	690.12
Stone	721.32	Conservatories, Music Build-	0001210
Terra cotta	721.343	ings	727.46
Wood	721.31	<del>Q</del>	697.43
Exposed	721.311	Conservatory Heating	
Protected	721.311	Construction, Arched	721.4
Wrought iron	721.352	Architecture	721 690.2
Commerce, Ministry	v of Build-	Handbooks	
ings	725.128	Periodicals	690.5
Commercial building	ngs General 725.2	Roofs	721.5
Commission, Archi		Systems	690.11
Commissions, Secre	et Building 692.87	Walls	721.2
Compends Arch		Contracts Building	692.44
Fine arts	702	Convents Buildings	726.74
Concert halls A	rrangement 725.812	Cooling air Ventilation	697.963
Concrete Aggreg		Copper Materials *	691.81
Beton coignet	691.31	Specifications	692,354
Materials	691.3	Detail drawings	692.235
Block, Hollow	Construction 693.53	Roofs Roofing	695.42

Cornices, Brick Construction	721.272	Design, Architectural General	720
Concrețe	721.276	Dictionaries Architecture	720.31
Concrete-steel	721.277	Fine arts	703
Construction	721.27	of foreign terms	720.34
Iron	721.275	Discussions	720.44
Steel	721,274	Fine arts	704.3
Stone	721.271	Distemper painting Building	698.21
Terra cotta	721.273	Distilleries Alcohol	725.425
Wood	721.278	Turpentine	725.424
Cost data, Classification	692.57	Dock buildings General	725.34
Cost, Estimates of Building	692.5	Door closers Doors .	721.893
Cottages for gardeners	728.92	Doors Architectural design	729.381
for laborers	728.68	Enclosures of Construction	721.80
Cotton factories	725.412	Metal	721.85
Court Houses, Appeal	725.152	Wood	721.81
Arrangement	725.153	Dormer windows Construc-	
Supreme	725.151	tion	721.55
Courts, Justices'	725.154	Design	729.386
Cracks Woods	691.152	Down-spouts Roofing	692.273
Crestings Roofs	621.561	Drainage Drawings	692.243
Custom houses Arrangement	725.141	Drawings Elevations	692.13
Customs warehouses Arrang	e-	General	692.1
ment	725.142	Masonry details	692.21
Cyclopedias Fine arts	703	Masonry details Miscellaneous Plan Floor	692.29
Cypress Woods	691.128	Plan, Floor	692.13
Cyprus Art history, Ancient	709.335	Foundation •	692.13
architecture	727.35	Location	692.11
		Roof	692.14
D		Sections	692.16
Dairy farm buildings	728.961	Drill halls for boys	725.853
schools Buildings	727.491	Drives Cemeteries	719.4
Deafening Wood floors	721.612	Landscape architecture	713.3
Decay Woods	691.155	Dryers Painting	698.17
Decoration, Painted Design	729.4	Duck Materials	691,941
Relief Design	729.5	Ducts, Foul air Ventilation	697.95
Defects in woods Materials	691.15	Fresh air	697.94
Denmark Classical revival	091.10	•	
Architecture	724.289	E	
Gothic	723.589	Early Christian architecture	723.1
revival	724.389	Italy	723.15
Half-timber, Modern	724.789	Education Architecture	720.71
History of art	709.489	Fine arts	707.1
Prehistoric	722.089	Ministry of	725.127
Recent .	724.989	Educational buildings General	
Renaissance	724.189	Egypt Architecture	722.2
Romanesque		Art history, Ancient	709.32
	720.748.9	Art history, Ancient Mohammedan architecture	723.32
Caroots of	· word training	2.20	11017.17.0

Electric heating Building	697.7	Estimates of Cost Building
Drawings	692.255	of buildings 692.5
Electrical engineering schools	727.454	Estimating by area 692.53
Elevation, Court Drawings	692.154	by comparison 692.56
Front	692.151	by priced quantities 692.55
Rear	692,153	by units 692.54
Side	692.152	by volume 692.52
Elevations Architectural designation	gn 729.1	Etruria Architecture 722.62
Drawings	692.15	Art history 709.336.2
Ecuador Recent architecture	724.978.6	Europe Art history, Modern 709.4
Elevators Cement Lime	725,373	History of architecture 720.94
Coal General	725.371	Excavation Specifications 692,32
Design	729.397	Exchange buildings General 725.25
Grain	725.36	Exchanges, Cotton 725.253
Malt	725.374	Lumber 725.254
Ore	725.372	Oil 725.255
Sand	725.375	Provision 725.252
Elks' buildings Arrangement	728.46	Stock 725,251
Elm Woods	691.146	Excise offices Arrangement 725.144
Enamel decoration Design	729.65	Exhaust ventilation Building 697.93
Encyclopedias Architecture	720.32	Exhibition buildings Antiqui-
Fine arts	703	ties 725.918
Engine houses Fire	725.192	Exhibitions Building 690.62
England Classical revival		Art 725.917
Architecture	724.22	City 725.915
Gothic •	723.52	County 725.914
revival	724.32	International 725.911
Half-timber, Modern	724.72	Memorial 725.916
History of	720,942	National 725.912
History of art	709.42	State 725.913
Neo-Grec	724.62	Express houses Railway 725.323
Prehistoric	722.02	***
Queen Anne revival	724.52	F
Recent	724.92	Fabrics, Woven Materials 691.94
Renaissance	724.12	Faience panels for walls 691.463.6
Romanesque	723.42	Fair buildings General 725.91
revival	724.82	Fans, Central Ventilation 697.982
schools of	720.742	Side 697.981
Tudor Gothic revival	724.42	Farm barns Buildings 728.953
Entablatures Architectural de	-	houses 728.67
sign	729.317	Fastenings Doors and windows 721,88
Construction	721.27	Feed mills Buildings 725.473
Espagnolette bolts Doors	721.883.8	Felt and gravel roofs Roofing 695.7
Essays Architecture	720.41	Felt, Damp proof Materials 691.967
Fine arts	704.1	Roofing 691.97
Esthetics Architecture	720.12	Ferneries Landscape architec-
Fine arts	701	ture 716.4

Filtration of air Ventilation 6	397.961	Floors, Brick arched Constru	c-
Finance, Ministry Arrange-		tion	721.631
ment 7	725.122	Cement	721.691
Fine arts Architecture	720	Concrete and expanded metal	721.658
Art galleries See Art Mu-		Concrete and steel beams	721.655
seums	708	Concrete and wire netting	721.657
Art museums	708	Concrete-steel	721.656
Esthetics	701	Guastavino arched	721.634
General	700	Hollow tile Arched Cor	1-
History	709	struction	721.632
Finishing woods Specifica-		Hollow tile Building	693.42
tions	392.373	flat	721.633
Fir Woods	591.127	Mosaic	721.67
Fire administration buildings . 7	725.191	Design	729.73
alarm stations 7	725.194	Stone	721.62
engine houses	725.192	Stone and cast-iron beams	721.651
patrol buildings	725.193	Stone and steel beams	721.652
Fireplaces, Ventilating Heating	697.12	Tile	721.68
Design	729.95	Tile and steel beams	721.653
Heating	697.11	Wood	721.61
Fireproof linings Building	693.45	Flour mills Buildings	725.471
Fireproofing by brickwork	393.813	Flowers Landscape architec-	
by concrete 6	393.814	ture	716.2
by hollow tiles	393.811	Flues, Chimney Building	697.82
by mortar	693.816	in walls	697.81
by porous terra cotta	593.812	Isolated	697.82
by wood and sheet metal	393.815	Smoke	697.S
columns	693.85	Forced ventilation Building	697.92
floors	593,42	Foreign affairs, Ministry of	725,125
floors	693.83	Foundations Caissons, Steel	721.182
girders	693,86	Wood	721.181
partitions	693.44	Concrete-steel	721.132
roofs	693.43	Construction	721.1
roofs	693.84	Concrete	721.13
systems	693.81	Piers, Brick	721.192
tiles	693.4	Concrete	721.193
trusses	693.87	Concrete-steel	721.194
vaults	693,88	Steel-framed	721.195
walls	693.41	Stone	721.191
walls and partitions	693.S2		
Fire station buildings General		Piles	721.16
Fittings Steam fitting	696.32	Plan of Drawings	692.12
Fixtures Gas fittings	696.22	Rubble	721.12
Plumbing	696.12	Sand or gravel	721.14
Flat and office buildings 7	25.223	Stone	721.11
Flat buildings General	728.2	Tubes, Sunken	721.18
Flooring Wood 7	21.611	Wells, Sunken	721.17

Waadaa maatissa	721,15	Drawings	000.0*4
Wooden gratings Foundling asylums General	725,58	Fuel gas	692.254 697.62
Foundries Iron	725.432	Illuminating gas	697.61
Fountains Landscape archi-	100,100	Natural gas	697.63
tecture	714.3	Gate lodges Buildings	
	694.2	Gates Cemeteries	728.91
Framing Carpentry France Classical revival	094.4	Germany Classical revival	719.1
Architecture	724.24	Architecture	*01001
Gothic	723.54	Gothic	724.231 723.531
revival	724.34	revival	724.331
Half-timber, Modern	724.74	Half-timber, Modern	724.731
History of	720.944	History of	720.943
History of art	709.44	History of art	
Neo-Gree	724.64	North	709.43
Prehistoric	722.04	South	709.431 709.434
Recent	724.94	Neo-Grec	724.631
Renaissance	724.14	Prehistoric	722.031
Romanesque	723.44	Recent	724.931
revival	724.84	Renaissance	724.131
Schools of	720.744	revival	724.831
Freight houses Railway	725.32	Romanesque	7:3 431
French polishing	695.33	Schools of	720.743.1
Fresco painting	698.25	Girders, Wood Wood floors	721.616
Fuel gas heating	697.62	Glass Materials	691.6
Fungus Woods	691.165	Beveled Drawings	692.252
Furnaces, Hot air Drawings	692.251	Cathedral Materials	691.67
Heating	697.31	cutting Glazing	695.53
Furniture, Special Details	692.224	Luxfer prism Materials	691.64
works Buildings	725.444	Moulded	691.66
Works Diffidings	1.00.111	Polished plate	691.63
G		Rolled plate	691.62
Gables Architectural design	729,37	Rough plate	691.62
Brick Construction	721.292	setting Glazing	698.54
Construction	721.29	Sidewalk lights Materials	691.65
Concrete	721,296	Stained Drawings	692.281
Concrete-steel	721.297	Window Materials	691.61
Iron	721,295	work Drawings	692.28
on roofs	721.555	Glass works Plate	725.488
Roof	721.58	Stained	725.489
Steel	721.294	Window	725.487
Stone	721,291	Glazing Building	698.5
Terra cotta	721,293	Cutting	698.53
Wood	721,298	Specifications	692.37
Gas engineering schools	727.458	Glossaries Architecture	720.33
fitting Building	696.2	Gothic architecture Austria	723.536
heating Acctylene	697.64	Belgium	723.593
Building	697.6	Denmark	723.589

D 1 1	*a0 *a	Durale
England	723,52 723,54	Russia 724.77 United States 724.773
France	723.5±	
General	723.531	
Germany	723.592	Temporary General 725.92 Handbooks Architecture 720.23
Holland		
Ireland	723.515 723.55	Construction 690.2 Fine arts 702
Italy	723.681	
Norway		Heating Building 697 Specifications 692.392
Portugal	723.569	
Scotland	723.511	systems Drawings 692.25
Spain	723.561	Heating apparatus Drawings 692.25
Sweden	723.585 723.594	Hedges Landscape architecture 715.3 Hemlock Woods 691.125
Switzerland		
Gothic revival General ,	724.3 692.32	F
Grading Specifications		Hennebique concrete Building 693.714
Grain elevators Brick Grain elevators Concrete	725.361	Hickory Woods 691.136 Hinges Doors 721.892
	mar act	0
Concrete-steel	725.364	
Steel Tile	725.365	
Wood	725.362	of art See name of country 709
	725,363	of building construction 690.95 of fine arts. General 709
G. A. R. buildings Granite Materials	728.47	Hog markets 725.275
	691.221	Holland Classical revival
Graphite Painting	698.43 697.12	Architecture 724,292
Grates, Ventilating Heating Grecian art history	709.38	Gothic 723.592
revival Modern architectur		revival 724.392
Greece Architecture	722.S	History of 720.949.2
Greenhouse Heating	697.43	History of art 7.09.492
Greenhouses, for dwellings	728.982	Recent 724.992
Landscape architecture	716.3	Renaissance 724.192
Grilles Windows	721.87	Romanesque 723,492
Grounds Landscape architect		Homes for aged General 725.56
Guild halls Arrangement	725.133	for children Church 725.574
Gum Woods	691.142	General 725.57
Gutters Drawings	692.271	Society 725.575
Gymnasiums Buildings	725.S51	for seamen 725.59
Gypsum Materials	691.213	for soldiers 725.59
Gypstiin Materials	091.213	Horse markets 725.273
· H		Hospitals Consumption 725.517
Hackmatack Woods	690,116	Contagious 725.518
Hair Materials	691.921	General 725.51
Half-timber, Modern	001.001	Insane 725.52
Architecture	724.7	Lying-in 725.515
Austria	724.736	Surgical 725.512
England	724.72	Hot water heating Building 697.4
Germany	724.731	Drawings 692.253
Germany	1.01.101	Diamings

High pressure	Carrantana	CO# 40	Decemb	
Low pressure   Steam supply mains   697.42   Romancsque   723.415     Steam supply mains   697.44   Iron Painting   698.131     Hotels, City American Buildings   728.53   Malleable cast   691.71     Cast Malleable cast   691.72     Country   728.51   Structures   721.91     European   728.57   Wrought   721.92     Suburban   728.57   Wrought   Materials   691.73     Suburban   728.57   Wrought   Materials   691.73     Suburban   728.57   Wrought   Materials   691.73     Suburban   728.58   Vrought   Materials   691.73     Summer   728.58   Specifications   692.352     Houses, City   General   728.3   Italy   Classical revival     Country seats   728.8   Architecture   724.35     Farm   Buildings   728.67   Gothic   723.55     for animals   Residences   728.99   revival   724.35     for animals   Residences   728.99   revival   724.35     General   728   Half-timber, Modern   724.35     Gothic   729.63   History of art   709.45     Summer   728.7   Neo-Grec   724.65     Village   Buildings   728.67   Prehistoric   722.05     Recent   724.95     Remaissance   724.95   Remaissance   724.95     Remaissance   729.63   Remaissance   729.62     Mohammedan architecture   729.45   Police cells   725.622     Institutes, Art   Buildings   727.473   Art history   709.313     Instruction   Fine arts   707.3   Art history   709.333     Instruction   Fi	Greenhouse	697.43	Recent	724.915
Steam supply mains				
Country			*	
ings         728.55         Malleable cast         691.72           City rooming         728.53         Specifications         692.351           Country         728.51         structures         721.91           European         728.54         roofs         Roofing         695.5           Suburban         728.55         Wrought         721.92           Summer         728.58         Wrought Materials         691.72           Village         728.55         Wrought Materials         692.352           Houses, City         General         728.3         Architecture         724.5           Farm Buildings         728.67         Gothic         723.55           for animals         Residences         728.99         revival         724.35           for animals         Residences         728.99         revival         724.35           General         728.99         revival         724.35           Outbuildings         728.93         History of art         709.45           Summer         728.7         Neo-Gree         724.95           Village         Buildings         728.6         Renaissance         724.95           Recent         728.95         Renaissance<				698.13
City rooming         728.53         Specifications         692.351           Country         728.51         structures         721.91           European         728.54         roofs Roofing         695.5           Suburban         728.57         Wrought         721.92           Summer         728.58         Wrought         Materials         691.73           Village         728.53         Wrought         Materials         691.73           Country         602.352         Mrought         Materials         691.73           Country seats         728.81         Architecture         724.55           Farm         Buildings         728.97         Gothic         723.55           For animals         Residences         728.99         revival         724.35           General         728.99         revival         724.35           General         728.93         History of         720.94           Outbuildings         728.93         History of art         709.45           Summer         728.73         Neo-Grec         724.65           Village         Buildings         728.97         Renaissance         724.65           Village         Prehistoric <t< td=""><td>Hotels, City American Build</td><td>1-</td><td></td><td>691.71</td></t<>	Hotels, City American Build	1-		691.71
Country         728.51         structures         721.91           European         728.54         roofs         Roofing         695.5           Suburban         728.57         Wrought         721.92           Summer         728.58         Wrought         Materials         692.352           Village         728.51         Specifications         692.352           Houses, City         General         728.3         Italy         Classical revival           Country seats         728.3         Architecture         724.5           Farm         Buildings         728.67         Gothic         723.55           for animals         Residences         728.99         revival         724.35           General         728.99         revival         724.35           Gothic         728.35         Half-timber, Modern         724.35           Gothic         728.35         History of art         709.43           Summer         728.73         History of art         709.45           Summer         728.73         History of art         729.94           Village         Buildings         728.62         Prehistoric         722.45           Recent         724.65	G .	728.55	Malleable cast	691.72
European         728.54         roofs Roofing         695.5           Suburban         728.57         Wrought         721.92           Summer         728.58         Wrought Materials         691.73           Village         728.52         Specifications         692.352           Houses, City General         728.3         Italy Classical revival         724.55           Country seats         728.67         Gothic         723.55           Farm Buildings         728.67         Gothic         723.55           for animals Residences         728.99         revival         724.55           General         728.67         Gothic         723.55           General         728.99         Half-timber, Modern         724.55           Outbuildings         728.93         History of art         709.45           Summer         728.7         Neo-Grec         724.65           Village         Buildings         728.6         Prehistoric         722.05           Recent         724.95         Recent         724.95           Recent         724.95         Remaissance         724.15           Interbustation         Design         729.6         725.622           India	City rooming	728.53	Specifications	692.351
Suburban         728.57         Wrought         721.92           Summer         728.58         Wrought Materials         691.73           Village         728.52         Specifications         692.352           Houses, City         General         728.3         Italy         Classical revival           Country seats         728.67         Gothic         723.55           Farm Buildings         728.07         Gothic         723.55           for animals         Residences         728.99         revival         724.55           General         728.99         revival         724.75           Outbuildings         728.93         History of         720.945           of parliament         Arrangement         728.77         Neo-Grec         724.65           Village         Buildings         728.6         Prehistoric         722.05           Summer         728.6         Prehistoric         722.05           Recent         724.95         Recent         724.95           Recent         724.95         Remaissance         724.15           Ilustrators' societies         Fine arts         706.13         J           Intrustation         Design         729.6         Ja	Country	728.51	structures	721.91
Summer         728.58         Wrought Materials         691.73           Village         728.52         Specifications         692.352           Houses, City General         728.3         Italy Classical revival           Country seats         728.8         Architecture         724.5           Farm Buildings         728.97         Gothic         724.5           for animals Residences         728.99         revival         724.35           General         728.93         Half-timber, Modern         724.75           Outbuildings         728.93         History of art         709.45           Summer         728.7         Neo-Gree         724.65           Village Buildings         728.7         Neo-Gree         724.65           Village Buildings         728.7         Neo-Gree         724.65           Village Buildings         728.7         Remaissance         724.65           Village Buildings         728.7         Remaissance         724.65           Ite houses for dwellings plants         728.7         Remaissance         724.65           Ilustrators' societies         Fine arts         Jails         City         725.622           India Architecture         729.6         Jails City	European	728.54	roofs Roofing	695.5
Village         728.52         Specifications         692.352           Houses, City         General         728.3         Italy         Classical revival           Country seats         728.8         Architecture         724.5           Farm         Buildings         728.97         Gothic         724.35           for animals         Residences         728.99         revival         724.35           General         728.93         Half-timber, Modern         724.75           Outbuildings         728.93         History of         729.94           Outbuildings         728.93         History of art         709.45           Summer         728.77         Neo-Gree         724.65           Village         Buildings         728.6         Prehistoric         729.05           Recent         724.95         Remaissance         724.15           Ice houses for dwellings         728.97         Remainssance         724.45           Ilse houses for dwellings         728.97         Remainssance         724.45           Ilse houses for dwellings         728.97         Remainssance         724.45           Ilse houses for dwellings         728.97         Remainssance         724.45           In	Suburban	728.57	Wrought	721.92
Houses, City   General   728.3   Tally   Classical revival   Country seats   728.5   Architecture   724.5   Farm   Buildings   728.67   Gothic   723.55   Goneral   728.99   revival   724.35   General   728.99   Half-timber, Modern   724.75   Outbuildings   728.93   History of   720.945   Outbuildings   728.93   History of   720.945   Outbuildings   728.93   History of   720.945   Outbuildings   728.7   Neo-Grec   724.65   Village   Buildings   728.6   Prehistoric   722.05   Recent   724.95   Renaissance   724.15   Renaissance   724.15   Renaissance   724.15   Renaissance   724.15   Renaissance   724.85   Illustrators' societies   Fine arts   Fi	Summer	728.58	Wrought Materials	691.73
Houses, City   General   728.3   Tally   Classical revival   Country seats   728.5   Architecture   724.5   Farm   Buildings   728.67   Gothic   723.55   Goneral   728.99   revival   724.35   General   728.99   Half-timber, Modern   724.75   Outbuildings   728.93   History of   720.945   Outbuildings   728.93   History of   720.945   Outbuildings   728.93   History of   720.945   Outbuildings   728.7   Neo-Grec   724.65   Village   Buildings   728.6   Prehistoric   722.05   Recent   724.95   Renaissance   724.15   Renaissance   724.15   Renaissance   724.15   Renaissance   724.15   Renaissance   724.85   Illustrators' societies   Fine arts   Fi	Village	728.52		692.352
Country seats         728.8         Architecture         724.5           Farm Buildings         728.67         Gothic         723.55           for animals         Residences         728.99         revival         724.35           General         728         Half-timber, Modern         724.75           Outbuildings         728.93         History of         720.945           of parliament         Arrangement         725.114         History of art         709.45           Summer         728.7         Neo-Grec         724.65           Village         Buildings         728.6         Prehistoric         722.05           Recent         724.95         Recent         724.95           Recent         724.95         Remaissance         724.15           Recent         724.95         Remaissance         724.15           Interustation         Design         729.6         Jails         City         725.622           India         Architecture         729.4         County         725.622           India         Architecture         723.35         Village         725.623           Injuries to woods         Materials         691.16         Japan         Architecture <td< td=""><td>_</td><td>728.3</td><td></td><td></td></td<>	_	728.3		
Farm         Buildings         728.67         Gothic         723.55           for animals         Residences         728.99         revival         724.35           General         728         Half-timber, Modern         724.75           Outbuildings         728.93         History of         720.945           of parliament         Arrangement 725.114         History of art         709.45           Summer         728.7         Neo-Grec         724.65           Village         Buildings         728.6         Prehistoric         722.05           Recent         724.05         Recent         724.05           Recent         724.05         Renaissance         724.15           Ice houses for dwellings         728.97         Romanesque         724.05           plants         725.353         revival         724.05           Ilustrators' societies         Fine arts         Jails         City         725.622           Illustrators' societies         Fine arts         706.13         Jails         City         725.622           Illustrators' societies         Fine arts         709.34         Police cells         725.622           India         Art history, Ancient         709.34 <td< td=""><td></td><td>728.8</td><td></td><td>724.5</td></td<>		728.8		724.5
For animals   Residences   728.99   revival   724.35			Gothic	
General Outbuildings				
Outbuildings         728.93         History of art         720.945           of parliament Arrangement 725.114         History of art         709.45           Summer         728.7         Neo-Grec         724.65           Village Buildings         728.6         Prehistoric         722.05           Recent         724.95         Recent         724.95           It         Renaissance         724.15           Ice houses for dwellings         728.97         Romanesque         724.15           plants         725.353         revival         724.85           Illustrators' societies         Fine arts         J           Incrustation Design         720.613         J           Intrustation Design         729.6         Jails City         725.622           India Architecture         722.4         County         725.622           Art history, Ancient         709.34         Police cells         725.623           Injuries to woods         Materials         691.16         Japan Architecture         725.623           Insane asylums         City         725.523         Art history         709.312           Insane asylums         City         725.523         Specifications         692.342 <tr< td=""><td></td><td></td><td></td><td></td></tr<>				
of parliament Summer         Arrangement 725.114         History of art         709.45           Summer         728.7         Neo-Grec         724.65           Village Buildings         728.6         Prehistoric         722.05           Recent         724.95         Recent         724.95           It         Renaissance         724.15           Ice houses for dwellings         728.97         Romanesque         724.15           plants         725.353         revival         724.85           Illustrators' societies         Fine arts         J           Incrustation         Design         726.13         J           Incrustation         Design         729.6         Jails City         725.622           India         Architecture         722.4         County         725.622           Art history, Ancient         709.34         Police cells         725.623           Injuries to woods         Materials         691.16         Japan Architecture         725.624           Insane asylums         City         725.523         Art history         709.312           Insane asylums         City         725.523         Specifications         692.342           Private         725.523				
Summer         728.7         Neo-Gree         724.65           Village         Buildings         728.6         Prehistoric Recent         722.05           I         Recent         724.95           Recent         Recent         724.95           Recent         Recent         724.95           Renaissance         724.15           Tevival         725.624         Romanesque         723.45           County         725.622           India         Architecture         725.623           Injuries to woods         Materials <td></td> <td></td> <td></td> <td></td>				
Village   Buildings   T28.6   Prehistoric   Recent   T24.95     Recent   Renaissance   T24.15     Recent   Recent   Recent   T24.15     Recent   Recent   Recent   T24.15     Recent   Recent   Recent   Recent   Recent   Recent   Recent     Recent   Rec				
Recent   Renaissance   724.15				
Renaissance   724.15     Ice houses for dwellings   728.97   Romanesque   723.45     plants   725.353   revival   724.85     Illustrators' societies   Fine arts	village Buildings	728.6		
Rechauses for dwellings   728.97   Romanesque   723.45     plants   725.353   revival   724.85     Illustrators' societies   Fine arts   706.13     Incrustation   Design   729.6   Jails   City   725.622     India   Architecture   722.4   County   725.621     Art history, Ancient   709.34   Police cells   725.624     Mohammedan architecture   723.35   Village   725.623     Injuries to woods   Materials   691.16   Japan   Architecture   722.12     Inlays   Design   729.63   Art history   709.312     Inns   General   728.5   Joinery drawings   Details   692.222     Insane asylums   City   725.523   General   Building   694.6     National   725.521   Specifications   692.342     Private   725.525   Joints   Carpentry   694.2     State   725.525   Joints   Carpentry   694.2     State   725.522   Joists, Wood   Wood floors   721.614     Institutes, Art   Buildings   727.475   Judea   Architecture   722.33     Instruction   Fine arts   707.3   Art history   709.333     Instruction   Fine arts   707.3   Art history   709.333     Instruction   Fine arts   725.126     Interior, Ministry   6725.126     Ireland   Architecture   723.515   Kilns   for cement   Materials   690.846     revival   724.315   for lime   690.846     History   6art   709.415   Kiosks   Parks   725.763	-			
Plants				
Illustrators' societies				
Total	k		revival	724.85
Incrustation         Design         729.6         Jails         City         725.622           India         Architecture         722.4         County         725.621           Art history, Ancient         709.34         Police cells         725.624           Mohammedan architecture         723.35         Village         • 725.623           Injuries to woods         Materials         691.16         Japan         Architecture         722.12           Inlays         Design         729.63         Art history         709.312           Insane Seneral         728.5         Joinery drawings         Details         692.222           Insane asylums         City         725.523         General         Building         694.6           National         725.521         Specifications         692.342           Private         725.522         Joints         Carpentry         694.2           State         725.522         Joists, Wood         Wood floors         721.614           Instruction         Fine arts         707.3         Art history         709.333           Insurance orders         Buildings         725.126         K           Ireland         Architecture         K	Illustrators' societies Fine ar	ts	_	
India         Architecture         722.4         County         725.621           Art history, Ancient         709.34         Police cells         725.624           Mohammedan architecture         723.35         Village         725.623           Injuries to woods         Materials         691.16         Japan         Architecture         722.12           Inlays         Design         729.63         Art history         709.312           Inns         General         728.5         Joinery drawings         Details         692.222           Insane asylums         City         725.523         General         Building         694.6           National         725.521         Specifications         692.342           Private         725.525         Joints         Carpentry         694.2           State         725.522         Joists, Wood         Wood floors         721.614           Institutes, Art         Buildings         727.475         Judea         Architecture         722.33           Instruction         Fine arts         707.3         Art history         709.333           Insurance orders         Buildings         725.126         K           Ireland         Architecture         K <td></td> <td>706.13</td> <td>J</td> <td></td>		706.13	J	
Art history, Ancient         709.34         Police cells         725.624           Mohammedan architecture         723.35         Village         725.623           Injuries to woods         Materials         691.16         Japan         Architecture         722.12           Inlays         Design         729.63         Art history         709.312           Inns         General         725.523         Joinery drawings         Details         692.222           Insane asylums         City         725.523         General         Building         694.6           National         725.521         Specifications         692.342           Private         725.525         Joints         Carpentry         694.2           State         725.522         Joists, Wood         Wood floors         721.614           Institutes, Art         Buildings         727.475         Judea         Architecture         722.33           Instruction         Fine arts         707.3         Art history         709.333           Insurance orders         Buildings         725.126         K           Ireland         Architecture         K           Gothic         723.515         Kilns for cement         Materials <t< td=""><td>Incrustation Design</td><td>729.6</td><td>Jails City</td><td>725.622</td></t<>	Incrustation Design	729.6	Jails City	725.622
Mohammedan architecture         723.35         Village         725.623           Injuries to woods         Materials         691.16         Japan         Architecture         722.12           Inlays         Design         729.63         Art history         709.312           Inns         General         725.523         Joinery drawings         Details         692.222           Insane asylums         City         725.523         General         Building         694.6           National         725.521         Specifications         692.342           Private         725.525         Joints         Carpentry         694.2           State         725.522         Joists, Wood         Wood floors         721.614           Institutes, Art         Buildings         727.475         Judea         Architecture         722.33           Instruction         Fine arts         707.3         Art history         709.333           Insurance orders         Buildings         728.48         Jute fiber         Materials         691.922           Incland         Architecture         K         K           Gothic         723.515         Kilns for cement         Materials         690.846           revival <td>India Architecture</td> <td>722.4</td> <td>County</td> <td>725.621</td>	India Architecture	722.4	County	725.621
Injuries to woods   Materials   691.16   Japan   Architecture   722.12     Inlays   Design   729.63   Art history   709.312     Inns   General   728.5   Joinery drawings   Details   692.222     Insane asylums   City   725.523   General   Building   694.6     National   725.521   Specifications   692.342     Private   725.525   Joints   Carpentry   694.2     State   725.522   Joists, Wood   Wood floors   721.614     Institutes, Art   Buildings   727.475   Judea   Architecture   722.33     Instruction   Fine arts   707.3   Art history   709.333     Insurance orders   Buildings   728.48   Jute fiber   Materials   691.922     Interior, Ministry of   725.126     Ireland   Architecture	Art history, Ancient	709.34	Police cells	725.624
Inlays         Design         729.63         Art history         709.312           Inns         General         728.5         Joinery drawings         Details         692.222           Insane asylums         City         725.523         General Building         694.6           National         725.521         Specifications         692.342           Private         725.525         Joints         Carpentry         694.2           State         725.522         Joists, Wood Wood floors         721.614           Institutes, Art         Buildings         727.475         Judea Architecture         722.33           Instruction Fine arts         707.3         Art history         709.333           Insurance orders         Buildings         728.48         Jute fiber         Materials         691.922           Interior, Ministry of Ireland         725.126         K         K         K           Gothic revival         723.515         Kilns for cement         Materials         690.846           History of art         709.415         Kiosks         Parks         725.763	Mohammedan architecture	723.35	Village •	725.623
Inlays         Design         729.63         Art history         709.312           Inns         General         728.5         Joinery drawings         Details         692.222           Insane asylums         City         725.523         General Building         694.6           National         725.521         Specifications         692.342           Private         725.525         Joints         Carpentry         694.2           State         725.522         Joists, Wood Wood floors         721.614           Institutes, Art         Buildings         727.475         Judea Architecture         722.33           Instruction Fine arts         707.3         Art history         709.333           Insurance orders         Buildings         728.48         Jute fiber         Materials         691.922           Interior, Ministry of Ireland         725.126         K         K         K           Gothic revival         723.515         Kilns for cement         Materials         690.846           History of art         709.415         Kiosks         Parks         725.763	Injuries to woods Materials	691.16	Japan Architecture	722.12
Inns         General         728.5         Joinery drawings         Details         692.222           Insane asylums         City         725.523         General Building         694.6           National         725.521         Specifications         692.342           Private         725.525         Joints Carpentry         694.2           State         725.522         Joists, Wood Wood floors         721.614           Institutes, Art Buildings         727.475         Judea Architecture         722.33           Instruction Fine arts         707.3         Art history         709.333           Insurance orders Buildings         728.48         Jute fiber Materials         691.922           Interior, Ministry of Ireland Architecture         725.126         K           Gothic revival History of art         724.315         Kilns for cement Materials         690.846           History of art         709.415         Kiosks Parks         725.763	Inlays Design	729.63		709.312
Insane asylums         City         725,523         General Building         694.6           National         725,521         Specifications         692,342           Private         725,525         Joints Carpentry         694.2           State         725,522         Joists, Wood Wood floors         721,614           Institutes, Art Buildings         727,475         Judea Architecture         722,33           Instruction Fine arts         707,3         Art history         709,333           Insurance orders Buildings         728,48         Jute fiber Materials         691,922           Interior, Ministry of Ireland Architecture         725,126         K           Gothic revival History of art         724,315         Kilns for cement Materials of 690,846         690,846           History of art         709,415         Kiosks Parks         725,763				692,222
National         725.521         Specifications         692.342           Private         725.525         Joints Carpentry         694.2           State         725.522         Joists, Wood Wood floors         721.614           Institutes, Art Buildings         727.475         Judea Architecture         722.33           Instruction Fine arts         707.3         Art history         709.333           Insurance orders Buildings         728.48         Jute fiber Materials         691.922           Interior, Ministry of Ireland Architecture         725.126         K           Gothic revival Five Ireland Architecture         723.515         Kilns for cement Materials         690.846           History of art         709.415         Kiosks Parks         725.763				
Private         725.525         Joints         Carpentry         694.2           State         725.522         Joists, Wood         Wood floors         721.614           Institutes, Art         Buildings         727.475         Judea         Architecture         722.33           Instruction Fine arts         707.3         Art history         709.333           Insurance orders         Buildings         728.48         Jute fiber         Materials         691.922           Interior, Ministry of Ireland         725.126         K         K         K           Gothic revival History of art         724.315         Kilns for cement         Materials         690.846           History of art         709.415         Kiosks         Parks         725.763				
State 725.522 Joists, Wood Wood floors 721.614 Institutes, Art Buildings 727.475 Judea Architecture 722.33 Instruction Fine arts 707.3 Art history 709.333 Insurance orders Buildings 728.48 Jute fiber Materials 691.922 Interior, Ministry of 725.126 Ireland Architecture Gothic 723.515 Kilns for cement Materials 690.846 revival 724.315 for lime 690.846 History of art 709.415 Kiosks Parks 725.763				
Institutes, Art Buildings 727.475 Judea Architecture 722.33 Instruction Fine arts 707.3 Art history 709.333 Insurance orders Buildings 728.48 Jute fiber Materials 691.922 Interior, Ministry of 725.126 Ireland Architecture Gothic 723.515 Kilns for cement Materials 690.846 revival 724.315 for lime 690.846 History of art 709.415 Kiosks Parks 725.763				
Instruction Fine arts 707.3 Art history 709.333 Insurance orders Buildings 728.48 Jute fiber Materials 691.922 Interior, Ministry of 725.126 Ireland Architecture Gothic 723.515 Kilns for cement Materials 690.846 revival 724.315 for lime 690.846 History of art 709.415 Kiosks Parks 725.763				
Insurance orders Buildings 728.48 Jute fiber Materials 691.922 Interior, Ministry of 725.126 Ireland Architecture Gothic 723.515 Kilns for cement Materials 690.846 revival 724.315 for lime 690.846 History of art 709.415 Kiosks Parks 725.763				
Interior, Ministry of Ireland         725.126         K           Gothic revival History of art         723.515         Kilns for cement for lime for li			-	
Ireland ArchitectureGothic723.515Kilns for cementMaterials690.846revival724.315for lime690.846History of art709.415KiosksParks725.763			Jute noer Materials	691,922
Gothic         723.515         Kilns for cement         Materials         690.846           revival         724.315         for lime         690.846           History of art         709.415         Kiosks         Parks         725.763		725.126	TZ	
revival         724.315         for lime         690.846           History of art         709.415         Kiosks         Parks         725.763		#20 h.//		200 242
History of art 709.415 Kiosks Parks 725.763				
Prehistoric 722.015 Knights of Pythias buildings 728.45				
	Prehistoric	722.015	Knights of Pythias buildings	728.45

Knots Woods	691.154	Selenitic	601.73
Korea Architecture	722.13	Limestone Materials	691.53
Art history	709.313	Linerusta Decoration	691.211
Alt history	100.515	Linden Woods	698:82
L		Linen factories	691.145
Tabandania Amin Itum I B	e . tr.ar		725.414
, 6	Build-	Lining fabrics Materials	691.945
ings	727.51	Linoleum Floors	721.694
Chemical	727.53	Materials	691.98
Electricity	727.555	Locks, Door	721.883
Engineering	727.55	Doors and windows	721.88
Fuel testing	727.554	Locomotive works Buildings	725.456
Horticultural	727.52	Locust Woods	691.138
Hydraulic	727.552	Luthern windows Architectur	al
Physics	727.54	design	729.385
Steam engineering	727.553	Construction	721.551
Testing materials	727.551		
Lacquer work Design	729.68	M	
Lakes Landscape architectur	e 714.1	. 171	
Landscape architecture Gene	ral 710	Machine shops	725.434
Latticed construction Carper	itry 694.5	Machinery for working material	s 690.84
Lead Materials	691.84	Machines for dressing stone	690.842
Painting	698.11	for making bricks	690.844
roofs Roofing	695.43	for making cement	690.846
Leaders Drawings	692.272	for making tiles	690.845
Leading Glazing	698.53	for working steel and iron	690.843
Leather, Stamped Decoratio	n 698.83	for working woods	690.541
Lectures Architecture	720.42	Malteries Buildings	725,425
Fine arts	704.2	Manor houses Modern resi-	
Liabilities of architects	692.95	dences	728.83
of contractors Building	692.97	Mansions, City General	728.3
of owners	692.96	Manual training Building	690.76
Libraries Buildings	727.8	Manuals Architecture	720.22
Art	727.87	Fine arts	702
City		· Manufactories Cotton	725.412
College	727.851	General	725.4
Historical	727.88	Silk	725.413
National	727.81	Wool	
Professional	727.86	Maple, Red Woods	725.411
Societies	727.S53	* *	691.144
State		Sugar	691.134
	727.82	White	691.144
Town	727.84	Marble Materials	691.212
University Lieu leves Building	727.852	Marble work drawings	692.213
Lien laws Building	692.98	Markets Buildings	725.26
Lifts Design	729.398	Cattle	725,272
Lighting Specifications	692.391	City.	725.261
Lime Materials	691.51	Commission	725,263
Hydraulic	691.52	Fowls	725.276

	725,275	Botany	727.63
Hogs Horses Mules	725.273	Ethnology	727.61
Provisions	725.262	General	727.6
Slicep	725.274	Historical	727.65
Masonic buildings	728.43	Industrial	727.64
Masonry Anchors	696.76	Private	727.68
Building Anchors	693	War	727.66
3	692.21	Zoology	727.62
Detail drawings	692.33		725.811
Specifications	691	Music halts Arrangement pavilions Buildings	725,762
Materials Building		paymons bundings	1.50,10.5
Mausoleums Landscape archi	718.3		
tecture	727.455	N	
Mechanical engineering schools	721.64	Nail and screw factories	725.436
Metal floors Construction	692,356	Natural gas heating	697.63
Ornamental Specifications	692.23	Navy, Ministry of Arrange-	
Work Drawings		ment	725.124
Specifications	692.35	Neo-Grec architecture	724.6
Methods of estimating Cost		Austria	724.636
Mexico History of architec-		England	724.62
ture	720.972	France	724.64
Prehistoric architecture	722.072	Germany	724,631
Recent	724.972	United States	724,673
Renaissance	724.172	Niches Landscape architectu	re 717.7
Milk wash Painting	698.22	Norman architecture Englan	d 723.42
Mill floor ceilings Construc-	*31 *11	France	723.44
tion	721.714	Norway Architecture	
Mineral wool Materials	691.91	Gothic	723.581
Ministry buildings Arrange-		1 1	
ment		revival	724.381
	725.12	Half-timber, Modern	724.381 724.781
Mixed paints Painting	698.14		
Mixed paints Painting Modern architecture General	698.14 724	Half-timber, Modern	724.781
Mixed paints Painting Modern architecture General Mohammedan architecture Ge	698.14 724	Half-timber, Modern History of art	724.781 709.481
Mixed paints Painting Modern architecture General Mohammedan architecture Ge	698.14 724 en- 723.3	Half-timber, Modern History of art Prehistoric	724.781 709.481 722.081
Mixed paints Painting Modern architecture General Mohammedan architecture General Moistening air Ventilation	698.14 724 en- 723.3 697.962	Half-timber, Modern History of art Prehistoric Recent	724.781 709.481 722.081 724.981
Mixed paints Painting Modern architecture General Mohammedan architecture General Moistening air Ventilation Monasteries Buildings	698.14 724 en- 723.3	Half-timber, Modern History of art Prehistoric Recent Renaissance	724.781 709.481 722.081 724.981 724.181
Mixed paints Painting Modern architecture General Mohammedan architecture General Moistening air Ventilation Monasteries Buildings Monuments Landscape archi-	698.14 724 en- 723.3 697.962 726.72	Half-timber, Modern History of art Prehistoric Recent Renaissance Romanesque	724.781 709.481 722.081 724.981 724.181 723.481
Mixed paints Painting Modern architecture General Mohammedan architecture General Moistening air Ventilation Monasteries Buildings Monuments Landscape architecture	698.14 724 en- 723.3 697.962 726.72	Half-timber, Modern History of art Prehistoric Recent Renaissance Romanesque Schools	724.781 709.481 722.081 724.981 724.181 723.481
Mixed paints Painting Modern architecture General Mohammedan architecture General Moistening air Ventilation Monasteries Buildings Monuments Landscape architecture Moorish architecture	698.14 724 723.3 697.962 726.72 718.1 723.36	Half-timber, Modern History of art Prehistoric Recent Renaissance Romanesque Schools	724.781 709.481 722.081 724.981 724.181 723.481 720.748.1
Mixed paints Painting Modern architecture General Mohammedan architecture General Moistening air Ventilation Monasteries Buildings Monuments Landscape architecture Moorish architecture Mortuary buildings	698.14 724 en- 723.3 697.962 726.72 718.1 723.36 726.8	Half-timber, Modern History of art Prehistoric Recent Renaissance Romanesque Schools  O  Oak Woods	724.781 709.481 722.081 724.981 724.181 723.481 729.748.1
Mixed paints Painting Modern architecture General Mohammedan architecture General Moistening air Ventilation Monasteries Buildings Monuments Landscape architecture Moorish architecture Mortnary buildings Mosaic ceilings Design	698.14 724 en- 723.3 697.962 726.72 718.1 723.36 726.8 729.71	Half-timber, Modern History of art Prehistoric Recent Renaissance Romanesque Schools  O  Oak Woods Odd Fellows' buildings	724.781 709.481 722.081 724.981 724.181 723.481 729.748.1
Mixed paints Painting Modern architecture General Mohammedan architecture General Moistening air Ventilation Monasteries Buildings Monuments Landscape architecture Moorish architecture Mortuary buildings Mosaic ceilings Design floors Construction	698.14 724 211- 723.3 697.962 726.72 718.1 723.36 726.8 729.71 721.67	Half-timber, Modern History of art Prehistoric Recent Renaissance Romanesque Schools  O  Oak Woods Odd Fellows' buildings Office and flat buildings	724.781 709.481 722.081 724.981 724.181 723.481 729.748.1 691.131 728.44 725.223
Mixed paints Painting Modern architecture General Mohammedan architecture General Moistening air Ventilation Monasteries Buildings Monuments Landscape architecture Moorish architecture Mortuary buildings Mosaic ceilings Design floors Construction Design	698.14 724 211- 723.3 697.962 726.72 718.1 723.36 726.8 729.71 721.67 729.73	Half-timber, Modern History of art Prehistoric Recent Renaissance Romanesque Schools  O  Oak Woods Odd Fellows' buildings Office and flat buildings Office and hall buildings	724.781 709.481 722.081 724.981 724.181 723.481 729.748.1 691.131 728.44 725.223 725.234
Mixed paints Painting Modern architecture General Mohammedan architecture General Moistening air Ventilation Monasteries Buildings Monuments Landscape architecture Moorish architecture Mortuary buildings Mosaic ceilings Design floors Construction Design walls	698.14 724 211- 723.3 697.962 726.72 718.1 723.36 726.8 729.71 721.67 729.73 729.72	Half-timber, Modern History of art Prehistoric Recent Renaissance Romanesque Schools  O  Oak Woods Odd Fellows' buildings Office and flat buildings Office buildings General	724.781 709.481 722.081 724.981 724.181 723.481 720.748.1 691.131 728.44 725.223 725.234 725.234
Mixed paints Painting Modern architecture General Mohammedan architecture General Moistening air Ventilation Monasteries Buildings Monuments Landscape architecture Moorish architecture Mortnary buildings Mosaic ceilings Design floors Construction Design walls Mosaics	698.14 724 211- 723.3 697.962 726.72 718.1 723.36 726.8 729.71 721.67 729.73 729.72 729.7	Half-timber, Modern History of art Prehistoric Recent Renaissance Romanesque Schools  O  Oak Woods Odd Fellows' buildings Office and flat buildings Office buildings General Municipal	724.781 709.481 722.081 724.981 724.181 723.481 720.748.1 691.131 728.44 725.223 725.234 725.234 725.23
Mixed paints Painting Modern architecture General Mohammedan architecture General Moistening air Ventilation Monasteries Buildings Monuments Landscape architecture Moorish architecture Mortnary buildings Mosaic ceilings Design floors Construction Design walls Mosaics Mosques Buildings	698.14 724 211- 723.3 697.962 726.72 718.1 723.36 726.8 729.71 721.67 729.73 729.72 729.7 726.2	Half-timber, Modern History of art Prehistoric Recent Renaissance Romanesque Schools  O  Oak Woods Odd Fellows' buildings Office and flat buildings Office buildings General Municipal Official residences City	724.781 709.481 722.081 724.981 724.181 723.481 720.748.1 691.131 728.44 725.223 725.234 725.234 725.134 725.173
Mixed paints Painting Modern architecture General Mohammedan architecture General Moistening air Ventilation Monasteries Buildings Monuments Landscape architecture Moorish architecture Mortnary buildings Mosaic ceilings Design floors Construction Design walls Mosaics	698.14 724 211- 723.3 697.962 726.72 718.1 723.36 726.8 729.71 721.67 729.73 729.72 729.7	Half-timber, Modern History of art Prehistoric Recent Renaissance Romanesque Schools  O  Oak Woods Odd Fellows' buildings Office and flat buildings Office buildings General Municipal	724.781 709.481 722.081 724.981 724.181 723.481 720.748.1 691.131 728.44 725.223 725.234 725.234 725.23

Oil Painting	698.15	Brick - 721.282
Oil polishing	698.35	Concrete 721.286
Old colonial United States	724.173	Concrete-steel 721.287
Oolite Materials	691.214	Construction 7:21.28
Opera houses Buildings	725.823	Iron 721.285
Orchestra halls Arrangement		Steel 721.284
Orders Architectural design		Stone 721.281
in relief	729.57	Terra cotta 721.283
Painted	729.47	Wood 721.288
Organs, Pipe Design	729.98	Pelasgian architecture 722.61
Oriel windows Architectural		Art history 709.336.1
design	729.384	1.05.010
Crnamental iron works Build		General 725.61
ings	725.438	National 725.611
Outbuildings Dwellings		State 725,612
Oversight of payments Build-		Peperino Materials 691.273
ing	692.73	Pergolas Landscape architec-
~		ture 717.5
P		Periodicals, Annual Architec-
Packing houses Arrangement		ture 720.55
Packing storehouses Buildings		Building 690.55
Painted ornamentation Design		Fine arts 705.5
Painters' societies Fine arts		Periodicals 720.5
Painting Specifications	692.37	Building 690.5
Oil Building	698.1	Daily 720.51
Paneled construction Carpents		Building 690.51
	691.93	Fine arts 705.1
Paperhanging Decorating	698.63	Fine arts 705
Embossed	698.81	Monthly 720.53
Mills Buildings	725,461	Building 690.53
Roofing Materials	691.934	Fine arts 705.3
Sheathing	691,931	Occasional Fine arts 705.6
Slating	691,933	Quarterly 720.54
Wall	698.61	Building 690.54
	725.761	Fine arts 705.4
Parks Landscape architec-		Weekly 720.52
ture	711	Building 690.52
Parliament houses Arrange-		Fine arts 705.2
ment	725.114	Persia, Ancient Architecture 722.53
Parquetry floors Construction		Art history, Ancient 709.355
	709.355	Mohammedan architecture 723.33
Partitions, Hollow tile Building		Peru Prehistoric architecture 722.075
Paste Paperhanging	698.62	Recent architecture 724.978.5
Pattern shops	725.435	Renaissance architecture 724.178.5
Payments, Reserved Building	692.75	
Pediments Architectural de-		Philippine Islands Architecture 722.14
sign	729.371	Philistia Art history 709.332

Phoenicia Architecture	722.31	Plain	692.261
Art history	709.331	Scagliola Building	693.64
Piers Construction	721.3	Specifications	692.36
Brick	721.34	Stucco Drawings	692.263
Concrete	721.33	Plate glass works Buildings	725.488
Stone	721.32	Plinth, Wall Construction	721.251
Terra cotta	721.343	Plumber's drawings	692.24
Pile foundations Concrete	721.164	Plumbing Building	696.1
Concrete-steel	721.165	Specification Specification	692.38
Steel	721.163	Plumbing laws State	696.91
Wood	721.161	Plumbing ordinances City	696.92
Pine, Hard Woods	690.112	Town	696.93
Longleaf woods	690.111	Police buildings City	725,186
Norway	690.111	National City	725.184
Pitch	690.114	State	725.184
Shortleaf	691.122	Polishing Varnishing	698.37
White	691.121	Poplar Woods	691.141
Yellow	690.1131	Porphyry Materials	691.223
Pipes, Cold air Heating	697.32	Portland cement concrete	691.36
Hot air	697.33	Portugal Architecture	723.569
Hot water	697.46	Gothic	723.569
Steam	697.56	History of art	709.469
	696.21	Recent	724,969
Piping Gas fitting Plumbing	696.21	Renaissance	724.169
Steam fitting	696.31	Romanesque	723,469
Pitch Materials	691.963	Post offices City	725.162
Woods	691.157	National	725.161
Plan of floor Drawings	692.13	Railway cars	725.164
of foundations	692.13	Village	725.163
of location	692.13	Postal buildings General	725.16
of roof	692.11	cars, City railway	725.165
Planing mills Buildings	725.442	Railway	725.164
Plans Architectural design	729.2	Posts and columns Carpentry	
of buildings Drawings	692.1	Potteries Factories	725,486
Plant houses Parks	725.765	Practice Fine arts	707.4
Plants Landscape architectur		Preservation of stone Materia	
Plaster ceilings Construction		of woods Building	691.17
Hard Materials	691.58	Prisons General arrangement	
of Paris	691.56	Proceedings of societies Fine	
ornament Design	729.66	arts	706.15
Plastering Building	693.6	Protection of iron and steel	691.79
External		Steel Bower-Barff	691,795
Internal	693.61 693.62	Cement coating	691.796
Ornamental Building	693.63	Electroplating	691.794
Drawings Stinding	692.262	Painting ·	691.791
Drawings	092,202	1 anning	001.791

Tinning	691,792	Registers Furnaces	697.34
Zincking	691.793	Regulation of air supply	697.97
Stone Cement wash	691.296	Regulators Furnaces	697.35
Glue and tannin	691.295	Hot water heating	697.47
Materials	691.2	Steam heating	697.57
Oiling	691.292	Reinforced concrete Building	693.7
Painting	691.291	Relief decoration Design	729.5
Paraffine	691.293	Not sculpture	698.8
Silicate soda	691.294	Reliefs on walls Design	729.59
Wood Corrosive sublimate		Religious buildings General	726
Creosoting	691.173	Residences General	728
Crude kerosene	691.176	Official	725.17
Fireproof paint	691.177	Resin Materials	691.964
Oiling .	691.172	Restaurant gardens	725,715
Painting	691,171	Restaurants Buildings	725.714
Sulphate of copper	691.178	Riding halls Buildings	725.881
Zincking	691.174	Rivets Building	696.4
Woods General	691.17	Roads Landscape architecture	713.2
Provincial buildings Arrange	:-	and the second s	693.715
ment	725.115	Roller skating rinks Buildings	725.862
Public buildings General	725	Rolling mills Steel	725.433
Purlins, Metal Roofs	721.543	Roman architecture General	722.7
Wood	721.513	Roman art history	709.37
Puttying Glazing	698.51	Romanesque architecture	723.4
Hard Building	698.52	. revival General	724.8
		Roof trusses Metal	721.545
Q		Wood	721.515
Quantities Building	692.5	Wood Ceiling	721.514
Zimanig	00.0.0	Construction	721.5
R		Purlins	721.513
		Rafters	721.512
Rafters, Metal Roofs	721.542	Sheathing	721.511
Roofs, Wood	721.512	Trusses Wood	721.515
Railway engineering schools	727.456	Roofing Asbestos	695.71
shops General	725.33	Asphalt	695.6
stations City terminal	725.313	Canvas	695.82
City through	725.312	Copper	695.42
Country	725.311	Drawings	692.27
Electrical	725.316	Duck	695.81
Elevated	725.318	Felt and gravel	695.7
Underground	725.319	General Building	695
Union	725.314	Iron	695.5
Ransome concrete Building	693.712		
Recent architecture General	724.9	Lead ·	695,43
Record offices Arrangement	725.155	Paper	695.72
Reformatories for adults	725.63	Shingle	695.1
for young	725.64	Slate	695.2

Steel	695.5	Saxon architecture England	723.42
Tile	695.3	Scagliola work Building	693.64
Tin	695.41	Scandinavia History of archi	
Zine	695.44	tecture	720.948
Roofs Architectural design	729.35	History of art	709.48
Glass Construction	721.53	Schools Architectural engineer	er-
Hollow tile Building	693.43	ing	727.452
Masonry Construction	721.52	Training	720.74
Metal Ceiling .	721.544	Architecture Buildings	727.451
Construction	721.54	Art	727.47
Purlins	721.543	Boys' boarding	727.23
Rafters	721.542	Buildings	727.1
Sheathing	721.541	Chemistry	727.47
Trusses	721.545	Civil engineering	727.453
Rooming houses Buildings	728.28	Electrical engineering	-
Rostrums Design	729.92		727.454
Rot, Dry Woods	691.162	Engineering	727.45
Wet	691.161	Gas engineering	727.458
Round houses Railway	725.334	Girls' boarding	727.24
Rubbing Varnishing	698.37	Law	727.43
Rugs Materials	691.944	Manual training _	727.17
Russia Classical revival		Mechanical engineering	
Architecture	724.27	•	727.455
General	723,23	Medical	727.42
Half-timber, Modern	724.77	Military	727.15
History of	720.947	Music	727.46
History of art	709.47	Normal	727.44
Recent	724.97	Preparatory	727.14
Renaissance	724.17	Private *	727.12
Schools of	720.747	Professional	727.4
Rust joints Building	696.61	Public	727.11
e		Railway engineering	
S Safe Assail Asia in its in a	201011	C *. * *	727,456
Safe deposit buildings	725,245	Sanitary engineering	****
Saloons Buildings	725.72	T1 1 1 1	727.457
Sandstone, Brown Materials	691.232	Theological	727.41
Materials	691.231	Trade	727.18
Portage	691.233	Scientific buildings General Scotland Architecture	727
Sanitary engineering schools	727.457 692.242	Cothic Architecture	200 244
fixtures Drawings Sapwood Woods			723.511
Sapwood Woods Sassania Architecture	691.151 722.54	revival	724.311
Art history	709,355	Half-timber, Modern	724.711
Savings bank and office build-	(199,655)	History of art Prehistoric	709.411 722.011
ings	725,244	Recent	722.011
Savings bank buildings	725,243	Renaissance	724.911
Saw mills Buildings	725.441	Romanesque	723.411
ean mins Dinimings	1.00.771	Romanesque	(~0.41L

Schools	720,741	Learned	727.9
Screens, Fixed Design	729.96	Medical	727.96
Windows	721.87	National Architecture	720.64
Screws Building	696.5	Religious	727.95
· Sculptors societies Fine art		School Architecture	720.61
Scuttles in roofs Construction	n 721.554	Scientific	727.92
Section, Cross Drawings	692.162	State Architecture	720.65
Architectural design	729.19	South America Renaissance	
Longitudinal	692.161	architecture	724.178
Seminaries Buildings	727.22	Spain Classical revival	
Theological	727.41	Architecture .	724.6
Serpentine Materials	691.251	Gothic	723.561
Settlement, Final Building	692.76	History of	720.946
Shakes Woods	691.152	History of art	709.461
Sheathing Wood floors	721.613	Moorish	723.36
Shellac Varnishing	698.32	Prehistoric	722.06
Shingle roofs Roofing	695.1 699	Recent	724.961 724.161
Shipbuilding Shooting galleries General	725,89	Renaissance Romanesque	723.461
Shop practice Building	690.74	Spanish colonial architecture	724.172
Shops, Machine Buildings	725.434	United States	+~T.11~
Railway General	725.33	Specifications of buildings	692.3
Shrinkage Woods		Spires Architectural design	729.357
Shrubs Landscape architec-	0011100	Brick Architectural design	721.572
ture	715.2	Concrete-steel	721.577
Shutters Windows	721.87	Construction	721.57
Siam Architecture	722.48		
Sicily History of art	709.458	Iron	721.575
Sideboards Design	729.941	Steel	721.574
Silk factories	725.413	Stone	721.571
Skating rinks Buildings	725.861	Terra cotta	721.573
Skylights in roofs Construc-		Wood	721,578
tion	721,553	Spots Woods	691.153
Slag wool Materials	691.91	Spring houses Buildings	725.751
Slate Materials	691.24	Spruce Woods	691.126
Slate roofs Roofing	695.2	Stables for dwellings	728.94
Slate work drawings	692.215	Stained glass design	729.S
Smelters Iron ore	725.431	work Drawings	692.281
Soapstone Materials	691.252	Buildings	725.489
Societies, Architects' local	720.62	Stains Woods	691.156
Art Buildings	727.91	Stairbuilding	694.8
Building	690.6	Stairs Design	729.39
Draftsmen's Architecture	720.63	State, Ministry of Arrange-	
Educational	727.94	ment	725.121
Engineering	727.93	Statements to owner Buildin	g 692.74
Fine arts	706.1	Stations, Railway General	725.31

Statutes Låndscape architec-		Railway	725.337
ture	717.8	Stores Arrangement	725.21
Steam fitting Building	696.3	Department	725.212
Steam heating Building	697.5	Retail city	725.213
Drawings	692.252	Retail village	725,214
Exhaust steam	697.53	Wholesale	725.211
Exhaust system	697.53	Stoves Heating	697.2
High pressure	697.51	Streaks Woods	691.153
Low pressure	697.52	Streams Landscape architect	ure
Vacuum system	697.54		714.2
Steel and brick structures	721.971	String courses Construction	721.254
and glass	721.98	Stucco plastering Building	693.61
and stone	721.96	work Drawings	692.263
and terra cotta	721.973	Study Fine arts	707.2
and tile	721.972	Summer houses Landscape	ar-
and wood	721.95	chitecture	717.2
Bessemer Materials	691.76	Sunday schools Buildings	726.4
Blister	691.74	Superintendence, Architect's	692.62
construction drawings	692.233	Building	692.6
Crucible	691.75	Constant	692.63
Open hearth	691.77	Occasional	692.61
ornamental drawings	692.234	Special	692.65
roofs Roofing	695.5	Supervision of accounts Bui	
Specifications	692,353	ing	692.7
structures	721.93	Sweden Architecture	
Tool Materials	691.74	Gothic	723.585
Stencils Painting	698.27	revival	724.385
Stock yards Buildings	725.271	Half-timber, Modern	724.785
Stone, Artificial Materials	691.3	History of art	709.485
floors Construction	721.62	Prehistoric	722.085
Materials	691.2	Recent	724.985
tools Building	693.14	Renaissance	724.185
work	693.1	Romanesque	723.485
Specifications	692.331	Schools	720.748.5
Tools	693.14	Swiss, Modern General	724.7
Stonecutting Building	693.12	Switzerland Architecture	
Drawings	692.211	Gothic	723.594
Stonesetting Building	693.13	Half-timber	724.794
diagrams	692.212	History of	720.949.4
Storage buildings	725.354	History of art	709.494
Store and flat buildings	725.222	Prehistoric	722.094
and office buildings	725.221	Recent	724,994
buildings Arrangement	725.21	Renaissance	724.194
Store, office and apartment bui		Romanesque	723,494
ings	725.22	Sycamore Woods	691.133
Storehouses Docks	725,344	Syenite Materials	691.222

Synagogues Religious buildings	296.2	Tile floors Construction	721.68
	1.0.0	Hollow Building	693.42
· ·	23.312	linings, Hollow	693.45
ture 12	3.312	partitions, Hollow	693,44
			-
${f T}$		roofs Roofing	695.3
57.4		Hollow Building	693.43
	1.253	walls, Hollow Building	693.41
	00.116	work drawings Building	692,214
The state of the s	398.73	works Floor and wall	725.485
	398.74	Roofing	725.484
	91.966	Tiles, Bond course Hollow	
	598.42	Book Materials .	691.472.1
Taverns General	728.5	Ceiling plates	691.472.2
Temples Religious Buildings	726.1	Drain Materials	691.492
Tenements, City clerks Build-		Embossed floor Materials	691.462,3
ings	28.13	Embossed wall	591.463.3
City poor	28.11	Faience panels for walls	691.463.6
City workers 7	28.12	Fireproof floor	691.471
Country	728.14	Fireproof roof	691.472
Factory	28.15	Fireproofing Materials	691.47
Society	28.17	Floor End arch	691.471.2
	25.764	Mixed arch	691.471.3
	693.32	Side *arch	691.471.1
backing	693.33	Glazed floor	691.462.4
9	1.483	wall	691,463.4
columns 69	01.484	Hollow partition	691.473.3
	1.485	Inlaid floor	691,462.2
	2.218	wall	691.463.2
	1.482	Materials	691.46
	01.481	Picture wall	691.463.5
	391.48	Roof and ceiling	691.472
	01.483	Roofing	691.461
9	1.486	Self-colored floor	101,100
	1.484	ben colored hoor	691.462.1
	593.31	wall	691.463.1
0	2.333	Sewer Materials	691.491
	693.3	Wall Fireproof	691.473
	25.483	Materials	691.463
	21.685	Wall linings Fireproof	691.473.1
Testing purity of air Ventila-	1.055	Wall mouldings Materials	
	\~ 0.0 4	0	
	07.964	painted Tin Materials	691.463.8
3	3.716		691.87
- 3	25.821	roofs Roofing	695.41
	20.11	Work Specifications	692.355
Theories Fine arts	701	Tinners' work Detail draw-	400.004
0	29.93	ings	692.236
Tile and steel beam floors 72	1.653	Tool houses Railway	725.335

Textile decoration	695.75	Turn halls B	aildings	725.852
Tools Textile decoration	698,75	Turpentine F	ainting	698.16
for brickwork Building	693.26	Tuscany Hist	ory of art	709.455
for relief decoration	698.84			
for stamped leather	698.84		**	
for working stone	693.14		U	
Gas fitting	696.23	Unit concrete	Building	693.713
Glazing	698.56	United States	Architectural	
Painting	698.25	schools		720.747.3
Oil .	698.18	United States	Classical reviv	al
Paperhanging	698.64	Architecture		724.173
Plumbing	696.13	Gothic reviv	al	724.373
Riveting	696.41	Half-timber,	Modern	724,773
Screw joints	696.51	History of		720,973
Steam fitting	696.33	Neo-Grec		724.673
Varnishing	698.38	Prehistoric		722.073
Towers Architectural design	729.36	Queen Ann	e revival	724.573
Spires Construction	721.57	Recent		724.973
Staircase Design	729,393	Renaissance		724.178
Town halls Arrangement	725.132	Romanesque		724.873
Trade schools Building	690.75	Tudor Goth		724.473
unions Building	690.61	Universities	Buildings	727.3
Training Architecture .	720.73	City		727.33
Transportation buildings	725,3	Engineering		727.45
Trap Materials	691.261	. Graduate		727.34
Travertine Materials	691.272	National		727.31
Trees Landscape architecture		Normal		727.44
Trasses, Metal Roofs	721.545	Scientific		727.36
Roof Metal Connections		Sectarian		727.35
	721.545.5	State		727.32
3	721,545.4			
	721.545.7		$\mathbf{v}$	
	721.545.8	**		20***
	721.545.2	Vacuum steam	_	697.54
	721.545.3 721.545.1	Variations C	ontracts	692,443 695,311
1 % L 2 c		Varnish, Oil		698,312
	721.545.6 721.515.5	Spirit	Duit time	695.3
Wood Connections	721.515.7	Varnishing Land	ounding scape architectu	
Cost	721.515.4		ters Building	
Dimensioning	721.515.8	Vaults Ceme		719.5
Economy Loads	721.515.2	Painted D		729.45
Stress diagrams	721.515.3	Public Ce		726.83
Types Types	721.515.5	Sculptured		729.58
Weight	721.515.6	Veneering I		729.67
Tufa Materials	691.271		Recent architect	
Turkey Mohammedan archit		Chezhen 1	eccent aremiteet	724.978.7
ture ture	723,34	Remaissance	architecture	724.178.7
CITA	* 10 (7,17)	recharacture.		

Venice History of art Ventilation Building Drawings Forced Drawings Natural Building Drawings Plenum Building Specifications Villas Residences Vines Landscape architecture	709.453 697 692.25 692.259 697.91 / 692.258 697.92 692.393 728.84	Wax polishing Wharfboats Steamer Window gardens Landscape a chitecture Windows Architectural design Bay Design Dormer Construction Design Enclosures of Construction	725,336 698,34 725,343 ir- 716,4 729,382 729,383 721,552 729,386 721,86
Wagon shops Buildings. Walks Cemeteries Landscape architecture Wall paper mills Buildings Wall reliefs Design Walls Architectural design Brick Construction Concrete Concrete-steel Construction Half-timber Hollow block Hollow tile Building Painted Design	725,452 719,3 713,1 725,462 729,59 729,3 721,24 721,231 721,233 721,2 721,212 721,232 603,41 729,49	External in roofs Internal Luthern Design Oricl Design Wire and fence works Wood and glass structures Woods Building Defects Hard leaf Materials Preservation Soft leaf Materials Woolen factories Work houses	721.84 721.55 721.85 721.85 721.85 721.85 729.384 725.437 721.99 690.1 691.13 691.13 691.14 725.411 725.633
Stone Construction Wood Walnut, Black Woods War, Ministry of Arrangement Warehouses, Bonded Arran ment Cold storage Merchandise Retail Arrangement Wholesale Water supply drawings Plu	721.22 721.211 691.137 725.123 ge- 725.143 725.352 725.351 725.216 725.215	roofs Roofing	690.118 726.91 726.93 691.83 698.12 695.44 692.237 727.57

### Publications of The Engineering Experiment Station.

Bulletin No. 1. Tests of Reinforced Concrete Beams, by Arthur N. Talbot, 1904.

Circular No. 1. High Speed Tool Steels, by L. P. Brecken-ridge. 1905.

Bulletin No. 2. Tests of High-Speed Tool Steels on Cast Iron, by L. P. Breckenridge and Henry B. Dirks. 1905.

Circular No. 2. Drainage of Earth Roads, by Ira O. Baker. 1906.

Bulletin No. 3. The Engineering Experiment Station of the University of Illinois, by L. P. Breckenridge. 1906.

Bulletin No. 4. Tests of Reinforced Concrete Beams, Series of 1905, by Arthur N. Talbot. 1906.

Bulletin No. 5. Resistance of Tubes to Collapse, by Albert P. Carman. 1906.

Bulletin No. 6. Holding Power of Railroad Spikes, by Roy I. Webber. 1906.

Bulletin No. 7. Fuel Tests with Illinois Coals, by L. P. Breckenridge, S. W. Parr and Henry B. Dirks. 1906.

Bulletin No. 8. Tests of Concrete: I. Shear; II. Bond, by Arthur N. Talbot. 1906.

Bulletin No. 9. An Extension of the Dewey Decimal System of Classification Applied to the Engineering Industries, by L. P. Breckenridge and G. A. Goodenough. 1906.

Bulletin No. 10. Tests of Plain and Reinforced Concrete Columns, Series of 1906, by Arthur N. Talbot. 1907.

Bulletin No. 11. The Effect of Scale on the Transmission of Heat through Locomotive Boiler Tubes, by Edward C. Schmidt and John M. Snodgrass. 1907.

Bulletin No. 12. Tests of Reinforced Concrete T-Beams, Series of 1906, by A. N. Talbot. 1907.

Bulletin No. 13. An Extension of the Dewey Decimal System of Classification Applied to Architecture and Building, by N. Clifford Ricker. 1907.

## UNIVERSITY OF ILLINOIS

# Engineering Experiment Station

BULLETIN No. 14

AUGUST 1907

# TESTS OF REINFORCED CONCRETE BEAMS SERIES OF 1906.

By Arthur N. Talbot, Professor of Municipal and Sanitary Engineering and in Charge of Theoretical and Applied Mechanics.

#### CONTENTS.

#### I. INTRODUCTION.

		Page
1.	Preliminary	. 5
2.	Scope of Tests	2
3.	Acknowledgment	•)
II	. MATERIALS, TEST PIECES, AND METHOD OF TESTIN	G.
4.	Materials	3
5.	Test Beams	()
6.	Making of the Beams	9
7.	Making of the Beams  Minor Test Pieces	10
8.	Storage	10
9.	Method of Testing	10
	III. EXPERIMENTAL DATA AND DISCUSSION.	
10.	Explanation of Tables 6 to 12	12
11.	Effect of Quality of Concrete	12
12.	Effect of Method of Loading	14
13.	Effect of Repetitive Loading	16
14.	Diagonal Tension Failures	21
15.	Summary	31

#### I. Introduction.

- 1. Preliminary.—The tests on reinforced concrete in the Laboratory of Applied Mechanics of the University of Illinois were continued during the college year of 1905-6. The results on shear and bond were reported in Bulletin No. 8 of the University of Illinois Engineering Experiment Station; those on columns, in Bulletin No. 10; those on T-beams, in Bulletin No. 12. The tests on rectangular beams will be described in this bulletin. The analytical theory of reinforced concrete beams was quite fully treated in Bulletin No. 4, and the methods and nomenclature used in this bulletin will follow those there given.
- Scope of Tests.—The discussion given in Bulletin No. 4 suggested many topics for investigation. Several of these were taken up and considerable information obtained, though it was not feasible to make the investigations complete enough to be fully conclusive. Effect of quality of concrete, effect of method of loading, effect of repetitive loading, and diagonal tension failures were among the topics considered. The beams were of the standard width and depth adopted by the Joint Committee on Concrete and Reinforced Concrete, but in the investigation of resistance to diagonal tension failure the length was varied and shortened to ensure this form of failure. Plain round rods of mild steel were generally used for reinforcement, but a deformed bar was used in some of the beams. The concrete was varied in quality both in the richness of the mixture and in the conditions of fabrication. These tests have since been followed with others bearing on some of the same topics.
- 3. Acknowledgment.—These tests were part of the work of the University of Illinois Engineering Experiment Station. The tests on effect of quality of concrete and effect of method of loading were made in co-operation with the Joint Committee on Concrete and Reinforced Concrete through the sub-committee on tests, of which Mr. Richard L. Humphrey is chairman. The work of testing the beams was done principally as thesis work. The students conducted the tests in a careful and skillful manner, and showed considerable discrimination in making observations and in drawing conclusions. The following members of the class of 1906 in Civil Engineering were connected with the work:
  - E. W. Sanford, Effect of Quality of Concrete.

- H. R. Armeling, Comparison of Methods of Loading.
- C. E. Andrew and J. L. Bannon, Effect of Repetition of Load.
- T. E. Phipps and R. H. Whipple, A Study of Diagonal Tension Failures.

The work was under the direct supervision of D. A. Abrams, Assistant in the Engineering Experiment Station, and to him and to W. R. Robinson, Assistant in the Engineering Experiment Station, acknowledgment is made for aid in the interpretation of results and in the preparation of this bulletin.

### II. MATERIALS, TEST PIECES, AND METHOD OF TESTING.

4. Materials.—Materials for the tests on "Effect of Method of Loading" and "Effect of Quality of Concrete" were furnished by the Joint Committee on Concrete and Reinforced Concrete through Mr. Richard L. Humphrey, chairman of the Committee on Tests. Materials for the tests on "Effect of Repetition of Load" and "Diagonal Tension Failure" were furnished by the Engineering Experiment Station. The terms "Joint Committee tests" and "Experiment Station tests" will be used to designate this difference of work and materials.

Stone.—The stone for the Joint Committee tests was a good quality of limestone from Kankakee, Illinois, ordered screened through a 1-in. screen and over a \(\frac{1}{4}\)-in. screen. It contained from 45% to 50% voids and weighed 85 lb. per cu. ft. loose. The stone for the Experiment Station tests was also a Kankakee limestone somewhat softer than the other, screened as above, and contained 50% to 54% voids. It was somewhat finer than the Joint Committee stone. In the determination of the voids in both stone and sand, the material was poured slowly into the water so that the voids became filled with water and no air was caught.

Sand.—The sand used was the same for all tests. It came from near the Wabash river at Attica, Indiana. It was of good quality, well graded, and fairly clean. It weighed 115 lb. per cu. ft. loose, and contained 28% voids. Table 1 gives the result of a mechanical analysis of this sand.

Cement.—The cement furnished by the Joint Committee was made up of a mixture of five standard American portland cements, selected and mixed by the manufacturers, and was of excellent quality. The cement furnished by the Experiment Station was Chicago AA portland, purchased in the open market of a local

TABLE 1.

MECHANICAL ANALYSIS OF SAND.

Sieve No.	Size of Mesh inches	Per cent passing
4	.208	100
10	.073	73
20	.034	36
50	.011	12
74	.0078	5
100	.0045	2

TABLE 2.

Tensile Strength of Chicago AA

Portland Cement.

	Ultimate Strength, lb. per sq. in								
Ref. No.	Age	7 days	Age 6	0 days					
	Neat	1-3	Neat	1-3					
1	634	283	890	443					
2	717	281	916	440					
$\frac{2}{3}$	732	275	840	422					
4 5	687	217	942	365					
	580	206	872	352					
6	731	189	885						
Av.	680	242	891	404					

dealer. The tensile strength of this last cement, as determined from briquettes made by standard methods, is given in Table 2.

Concrete.—Men accustomed to making concrete mixed the materials and made the test beams. Care was taken in measuring, mixing, and tamping, to secure as uniform a concrete as possible. All materials were measured by loose volume. The mixing was done with shovels by hand. The sand and cement were first mixed dry. The stone was then added and the mass mixed until uniform in appearance. Water was added in such proportion as to give a slightly wet concrete.

Steel.—The longitudinal reinforcement consisted generally of  $\frac{1}{2}$ -in. or  $\frac{3}{4}$ -in. mild-steel plain round rods. In a few beams  $\frac{1}{2}$ -in. high-steel Johnson corrugated bars were used. The results of tensile tests of the steel used are given in Table 3. The plain round bars had an average yield point of 40 500 lb. per sq. in. and an ultimate strength of 60 000 lb. per sq. in. The corrugated bars developed an average yield point of 57 300 lb. per sq. in. with an ultimate strength of 87 400 lb. per sq. in. In general, the yield points of the various bars in one beam varied less than 3% from one another.

TABLE 3.

TENSION TESTS OF STEEL USED IN BEAMS.

Values given are in general the average of results of tests of specimens cut from four different rods.

Specimens Taken from Beams No.	Nominal Size inches	Diameter inches	Per cent Elongation in 8 inches	Yield Point lb. per sq. in.	Ultimate Strength lb. per sq. in.
21 13 14 15 16 17 18 20 21 23 26 27 28 30 31 34 35 36 38 39 40 42 43 44 45 50	요약 요약 요약 나는? 나는? 나는? 나는? 나는? 나는? 요약 나는? 요약 나는? 요약 나는? 나는? 요약 나는 나는? 요약 요약 요약 나는? 나는? 나는? 나는? 나는?	.750 .747 .750 .501 .500 .500 .500 .497 .502 .502 .750 .500 .748 .503 .503 .504 .749 .502 .500 .750 .749 .502 .500 .750 .750 .750 .750 .750 .750 .750	31.0 33.0 29.7 29.3 28.5 28.0 29.0 28.0 31.2 31.5 29.0 31.2 29.1 29.1 29.5 32.5 29.0 32.5 29.0 32.5 29.0 32.5 29.0	34000 38800 38700 41400 37700 36700 40300 44400 41800 35000 37200 39400 42700 41000 41800 38800 36300 35800 35800 342800 42500 42100 42100 42000 42800	56300 56900 58900 61700 58100 57900 60200 62500 58000 58600 57100 60800 61100 60900 58400 58400 58400 58200 61200 61800 61800 61900 61900

TABLE 3-('oncluded.

Specimens Taken from Beams No.	Nominal Size inches	Diameter inches	Per cent Elongation in 8 inches	Yield Point lb. per sq. in.	Ultimate Strength Ib. per sq. in.
51 52 53 54 55 56 58 59 60 61 62 63 64 65 68 69 70 71 72 73 74 66* 67*	12 12 12 12 12 12 12 12 12 12 12 12 12 1	.502 .501 .504 .505 .503 .622 .753 .753 .750 .752 .750 .748 .747 .754 .747 .754 .747 .754 .749 .748	28.5 27.9 29.2 28.0 27.8 30.7 29.5 26.0 28.5 30.5 32.3 30.3 33.5 29.5 29.5 29.5 29.5 31.5 31.2 27.6 16.1 17.4	41800 44200 42500 42100 42000 37800 40300 41000 39200 39000 40600 42350 37800 41700 44200 44500 40100 39900 40700 43900 58800 57300	60900 63100 62800 61200 62300 60600 65300 65300 65300 62600 54400 61600 61900 62700 60700 59200 58900 56900 91100 87300

<sup>\*</sup> Corrugated bars.

5. Test Beams.—In all of the tests herein discussed the cross-section of the beams was 8 in. x 11 in., the center of the steel being placed 10 in. below the top surface except in some cases where the ends of the bars were bent up. In the tests on "Diagonal Tension Failure" the test span varied from 6 ft. to 12 ft. In all the other series of tests a 12-ft. span was used. Unless otherwise specified the reinforcing bars were straight and were placed horizontally throughout the beam. In the beams marked "Bars bent up" the bars were bent up at a point about 3 in. outside the load points and passed diagonally either in a straight line or in a slightly curved line to a point within 2 in. or 3 in. of the top of the beam near its ends. In several beams stirrups of ½-in. plain

round bars were used. These stirrups were placed 12 in. apart longitudinally throughout the outer thirds of the span length, beginning at the load points. They were U-shaped and passed under all the reinforcing bars and extended nearly to the top of the beam. The stirrups were left very close to the sides of the beam. For general data on all beams see Table 5.

TABLE 4.

Compression Tests of Cubes and Cylinders.

Concrete as in	Kind of		re Strength sq. in.		
Beam No.	Concrete	Cubes	Cylinders		
59 61 69	1-2-4 $1-2-4$ $1-2-4$ $1-2-4$	2030 3500 1510	1700		
Av.		2350	1700		
51 58 60 65 68 70* 72 73* Av.	$\begin{array}{c} 1-3-5\frac{1}{2} \\ 1-3-5\frac{1}{2} \end{array}$	1580 1690 2360 1850 2250 1770	1470 1060 1060 885 1100 540 770		
5† 6† 7† 12† 14 18	1-3-6 1-3-6 1-3-6 1-3-6 1-3-6 1-3-6 1-3-6	1390 1420 1050 1080 1600 1380 1170			
Av.		1300			
71	1-5-10	1230			

<sup>\*</sup> Poorly mixed.

<sup>†</sup> Poorly made.

TABLE 5. GENERAL DATA ON BEAMS.

Beam	Kind	Reinforcement	ft.	Test	Cla	ssi-
No.	of Con- crete	Per cent Amount and Disposition	Span, ft.	Age at Test days	Table No.	Kind
3 4 4 5 6 6 7 8 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 25 26 27 28 29 30 31 32 33 34 35 36 37 38 39 40 42 43 44 45 46 47 48 49 50 51	$\begin{array}{c} 1-3\cdot 6\\ 1-3-5\frac{1}{2}\\ 1-3-51$	0.98	12 12 12 10 10 10 10 10 10 10 10 10 10 10 10 10	72 74 71 71 71 71 76 76 73 73 73 76 76 86 86 99 70 71 71 75 67 76 86 870 70 71 78 97 73 75 61 75 64 64 62 60 60 60 85 884 82 60 60 60 60 60 60 60 60 60 60 60 60 60	10 12 10 10 11 10 10 11 11 11 10 10 11 11 11	E E E E E E E E E E E E E E E E E E E

TABLE 5.—Concluded

GENERAL DATA ON BEAMS.

Beam No.	Kind of Con- crete	Reinforcement  Per Amount and Disposition	Span, ft.	Age at Test days		kind
52 53 54 55 56 57 58 59 60 61 62 63 64 65 66 67 68 70 71 72 74	$\begin{array}{c} 1-3-5\frac{1}{2}\\ 1-3-5\frac{1}{2}\\ 1-3-5\frac{1}{2}\\ 1-3-5\frac{1}{2}\\ 1-3-5\frac{1}{2}\\ 1-3-5\frac{1}{2}\\ 1-2-4\\ 1-3-5\frac{1}{2}\\ 1-2-4\\ 1-3-5\frac{1}{2}\\ 1-2-4\\ 1-5-10\\ 1-5-10\\ 1-3-5\frac{1}{2}\\ 1-5-10\\ 1-3-5\frac{1}{2}\\ 1-5-10\\ 1-3-5\frac{1}{2}\\ 1-5-10\\ 1-3-5\frac{1}{2}\\ 1-3-$	0.98   \( \frac{1}{2} \) in. round. \( 0.98 \)   \( \frac{1}{2} \) in. round. \( 0.10 \)   \( 2 \) \( \frac{2}{2} \) in. round. \( 0.10 \)   \( 2 \) \( \frac{2}{2} \) in. round. \( 0.10 \)   \( 2 \) \( \frac{2}{2} \) in. round. \( 0.10 \)   \( 2 \) \( \frac{2}{2} \) in. round. \( 0.10 \)   \( 2 \) \( \frac{2}{2} \) in. round. \( 0.10 \)   \( 2 \) \( \frac{2}{2} \) in. round. \( 0.10 \)   \( \frac{2}{2} \) in. stirrups. \( 1.65 \)   \( 3 \) \( \frac{2}{2} \) in. round. \( 10 \) \( \frac{1}{2} \) in. stirrups. \( 1.65 \)   \( 3 \) \( \frac{2}{2} \) in. round. \( 10 \) \( \frac{1}{2} \) in. stirrups. \( 1.65 \)   \( 3 \) \( \frac{2}{2} \) in. round. \( 10 \) \( \frac{1}{2} \) in. stirrups. \( 1.65 \)   \( 3 \) \( \frac{2}{2} \) in. round. \( 10 \) \( \frac{1}{2} \) in. stirrups. \( 1.65 \)   \( 3 \) \( \frac{2}{2} \) in. round. \( 10 \) \( \frac{1}{2} \) in. stirrups. \( 1.65 \)   \( 3 \) \( \frac{2}{2} \) in. round. \( 10 \) \( \frac{1}{2} \) in. stirrups. \( 1.65 \)   \( 3 \) \( \frac{2}{2} \) in. round. \( 10 \) \( \frac{1}{2} \) in. stirrups. \( 1.65 \)   \( 2 \) \( \frac{2}{2} \) in. round. \( 10 \) \( \frac{1}{2} \) in. stirrups. \( 1.00 \)   \( 2 \) \( \frac{2}{2} \) in. round. \( 10 \) \( \frac{1}{2} \) in. stirrups. \( 1.10 \)   \( 2 \) \( \frac{2}{2} \) in. round. \( 10 \) \( \frac{1}{2} \) in. stirrups. \( 1.10 \)   \( 2 \) \( \frac{2}{2} \) in. round. \( 10 \) \( \frac{1}{2} \) in. stirrups. \( 1.10 \)   \(	12 12 12 12 12 12 12 12 12 12 12 12 12 1	60 60 60 60 60 60 61 61 62 61 61 62 60 60 60 60 60 60 60 60 61 61 62 61 60 60 60 60 60 60 60 60 60 60 60 60 60	7 7 7 6 6 6 6 6 6 6 7 10 6 6 6 6 6 6 6 6 6 6 6 6 6 6 6 6 6 6	J. C.

NOTE:—E. S. and J. C. refer to Engineering Experiment Station and Joint Committee respectively. For explanation of terms, see "4. Materials," p. 3.

6. Making of the Beams.—The beams were made directly on the concrete floor of the laboratory, a strip of building paper being laid beneath the forms. Several proportions of concrete were used, varying from 1-2-4 to 1-5-10 by loose volume. A number of the first beams were made of 1-3-6 mixture, and the later ones of  $1-3-5\frac{1}{2}$ , as it was thought that the voids in the stone were not properly filled in the 1-3-6 mixture. The forms, which were of the ordinary wooden knock-down type, were removed four days after making the beams and the beams were not moved in any way for 14 days. Generally the stone for the concrete was dampened and the concrete well mixed and wet enough to secure proper hardening. The making of the beams

was skillfully done. In Beams No. 3 to 13 inclusive, however, through some oversight the stone (a porous material), was not dampened, insufficient water was used in mixing, the making and




Fig. 1. 8-Point Loading.

tamping were not properly done, and the concrete was allowed to become too dry. The beams so made proved to be of inferior concrete and are referred to as poorly made concrete. The low results obtained are of interest in showing the effect of improper methods even if enough cement is used.

- 7. Minor Test Pieces.—Tests were made on 6-in, cubes and on 8-in, cylinders 16 in, high taken from concrete used in some of the beams. The results of these tests are given in Table 4. The values given for the cubes are the averages of three test specimens. For the cylinders, a single test specimen was used.
- 8. Storage.—The beams were stored in a room the temperature of which was from 60° F. to 70° F. They were tested at the age of about 60 days.
- 9. Method of Testing.—The usual method of testing was by loads applied at the one-third points as described in Bulletin No. 4, page 34. The beams were all tested in the 200 000-lb. Olsen testing machine, and in all cases except the tests on "Effect of Method of Loading," were loaded at the one-third points. The method used for loading at eight points is shown in Fig. 1. The supports of the beam allowed longitudinal movement, the bottom of the rocker being an arc of 12-in. radius, and the top, on which cast-iron blocks rested, having a radius of  $1\frac{1}{2}$  in. Turned steel rollers, 2 in. in diameter, were used for applying the load at the third points. The blocks at the supports and load points were bedded in plaster of paris which was allowed to harden under the weight of the beam and the apparatus used in loading before the

load was applied. The cubes, cylinders, and steel were tested in the 100 000-lb. Riehlé and 200 000-lb. Olsen testing machines.

Center deflections were read on all the beams. Deformations of the upper fiber and steel were measured by means of four extensometers. The methods of measuring deflections and deformations were fully described in Bulletin No. 4.

TABLE 6. EFFECT OF QUALITY OF CONCRETE. Loaded at one-third points.

Span 12 ft.

Beam No.	Maximum Load, lb.	k:	Per cent Rein- forcement	Stress in Steel lb. per sq. in.	Vertical Shearing Stress $v = \frac{V}{bd'}$ lb. per sq. in.	Manner of Failure					
1-2-4 Concrete.											
57 59 61 69*	11730 12000 10960 16000	.43 .53 .47 .57	1.15 $1.10$ $1.10$ $1.65$	39800 44000 39700 39000	96 97 90 129	Tension. Tension. Tension. Tension.					
			1	$-3-5\frac{1}{2}$ Co	ncrete.						
58 60 64 65 68* 70* 72* 73*	9860 10360 9850 10000 14220 13710 10270 9900	.52 .57 .55 .54 .57 .69 .47	1.10 1.10 1.10 1.10 1.65 1.65 1.10 1.10	36900 39400 37300 37600 35000 35800 37400 37000	82 85 82 83 115 112 85 82	Tension. Tension. Tension. Tension. Diagonal Tension. [crete Compression (Poor contension. Tension. Tension.					
1-5-10 Concrete.											
62 63 66† 67† 71*	8850 7360 8000 7850 7600	.60 .48 .63 .57 .59	1.10 1.10 1.25 1.25 1.65	34600 28100 29400 27100 20200	74 63 69 68 67	Diagonal Tension. Diagonal Tension. Diagonal Tension. Diagonal Tension. Diagonal Tension.					

<sup>\*</sup> Stirrups.

<sup>†</sup> Reinforced with corrugated bars.

# III. EXPERIMENTAL DATA AND DISCUSSION.

- 10. Explanation of Tables 6 to 12.—In Tables 6 to 12, the position of the neutral axis was obtained by the method used in Bulletin No. 4. In calculating the per cent of reinforcement the area of the beam above the center of the reinforcing bars is used. The columns headed "Maximum Applied Load" do not include the weight of the beam loading apparatus, but these weights were considered in calculating the stress in the steel. In determining the amount of the vertical shear, the weight of the beam and loading apparatus was considered, 6 lb. per sq. in. being added to the unitstress for a 6-ft. beam, 7 for an 8-ft. beam, 8 for a 10-ft. beam, and 10 for a 12-ft. beam. In obtaining the vertical shear, the formula  $v = \frac{V}{.86bd}$  or .0145 V was used for 1% beams and  $v = \frac{V}{.81bd}$  or .0154 V for 2.2% beams.
- 11. Effect of Quality of Concrete.—In this series, tests were made on beams made of three kinds or grades of concrete,—1.2.4,  $1.3.5\frac{1}{2}$ , and 1.5.10 mixtures. The purpose of this series was to determine the effect of quality of concrete upon the strength of the beam and upon the manner of failure. The beams were planned to give a variety of manners of failure,—tension in the steel, compression in the concrete, and diagonal tension in the concrete. Table 6 gives the results of this series. The calculations were made as described under "10. Explanation of Tables". No attempt is made to calculate the diagonal tensile stresses developed, but the ability to resist diagonal tension will be compared by means of the vertical shearing stresses developed. The load was applied at the one-third points of the beams. From the tables it will be noted that the manner of failure for beams of these proportions depends upon the richness of the concrete. Counting the effect of the weight of the beam and loading apparatus, it is seen that all the beams made with 1-2-4 concrete failed by tension in the steel at calculated stresses somewhat above the elastic limit of the steel. Beam No. 57, (Fig. 4), is typical of the appearance of the beams after failure. Beam No. 69, having 1.65% reinforcement, has a load-compression diagram (Fig.12) which indicates that the stress in the concrete at the maximum load was well within the limits of its ultimate compressive strength. The vertical shearing stress developed in this

beam was 124 lb. per sq. in. and there was no indication of approaching failure by diagonal tension.

Of the test beams of 1-3-5½ concrete all but two failed by tension in the steel. The calculated stresses in the steel, when allowance is made for the weight of the beam, are slightly above the elastic limit of the steel. The two not failing by tension in the steel, when compared by the stresses computed either from the bending moment or the observed deformations, gave stresses in the steel not much lower than the average of the remainder of · the series. Both of these beams, therefore, had hardly reached the load which would have been followed by failure by tension in the steel. Beam No. 68 failed by diagonal tension at a calculated vertical shearing stress of 115 lb. per sq. in. No. 70 failed by compression of the concrete. The compression diagram (Fig. 13) shows that the concrete in this beam lacked stiffness, the amount of deformation being more than for the average beam but not much more than that of No. 68, its companion beam, as is seen from the load-deformation diagrams. And yet this beam of  $1-3-5\frac{1}{2}$  concrete and 1.65% reinforcement carried a load nearly to the elastic limit of the steel reinforcement.

All the beams made with 1-5-10 concrete failed by diagonal tension at loads which show a rather narrow range regardless of the amount or method of reinforcement. The vertical shearing unit-stress developed averaged 68 lb. per sq. in. As the beams failed by diagonal tension at loads much smaller than those at which failure by compression in the concrete may be expected, there is nothing in these tests upon which to base the limit of the concrete or the amount of reinforcement at which the compressive strength of the concrete and the tensile strength of the steel may be considered to be balanced.

A comparison of beams having 1.1% reinforcement which failed by tension in the steel shows that the 1-2-4 beams carried greater loads than the 1-3-5½ beams, the additional load amounting to 10% or 15%. This increase of load probably is due to the fact that the greater strength of the richer concrete allows the steel to be stretched a greater distance beyond the elastic limit before developing the full compressive strength of the concrete and also that the moment arm of the couple formed by the compressive stresses is somewhat greater with the richer concrete. The added strength of the richer concrete in preventing failure by

diagonal tension is apparent. This feature of the series will be further discussed under "14. Diagonal Tension Failures". As will be shown afterward, the arrangement of stirrups used was not well planned and their presence seemed not to add to the strength of the beams, although in Beams No. 68 and 71 it might have been expected that well designed stirrups would prevent failure by diagonal tension.

12. Effect of Method of Loading.—It was the purpose of this series to determine the effect of the method of loading upon the resisting moment developed in the beam. With this in view, the beams were so proportioned that failure by tension in the steel was expected in all cases. In Bulletin No. 4, page 54, a discussion of this topic is given. It was there stated that beams loaded at the middle have been found to develop a higher moment of resistance than is to be expected if the distribution of stresses is as assumed in the ordinary theory of flexure. Six methods of loading were used in the tests of this series: (1) load applied at center of the span only; (2) load applied at two points 1\frac{1}{2} feet apart; (3) load applied at two points 3 feet apart; (4) load applied at the one-third points; (5) load applied at two points  $7\frac{1}{2}$  feet apart; (6) load applied at eight points (to approximate a uniform load). The appliances used for the loading at eight points have been described under "9. Method of Testing".

Table 7 gives the results of these tests, together with the calculated stresses in the steel. All beams failed by tension in the steel, as was clearly shown by the load-deformation diagrams. If the effect of the weight of the beam and loading apparatus is included, it will be seen that the calculated stresses in the steel all lie above the elastic limit. A comparison of the resisting moments of the beams may be made by comparing the calculated stresses in the steel, given in Table 7, since the tests of the steel used in these beams show that there was little variation in the yield point of the test pieces. It will be noted that the highest stress developed was in beams having the loading at the middle, and that when the two loads were close to the middle the results were not much lower. For the other methods of loading the variation in stress developed was not large, no greater than may be expected with the difference in the materials and fabrication in such beams, though the method in which the load was applied at eight points gave a somewhat higher resisting moment. These

TABLE 7.

#### EFFECT OF METHOD OF LOADING

Reinforcement .98%. Concrete 1-3-5½. Span 12 ft. All failed by tension in the steel.

Beam No.	Method of Loading	Maximum Applied Load Ib.	k °	Stress in Steel lb. per sq. in.
$\frac{50}{52}$	Center.	7400	.45	45200
	Center.	7650	.38	45400
53 54	$\frac{2}{2}$ points $1\frac{1}{2}$ ft. apart. $\frac{2}{2}$ points $1\frac{1}{2}$ ft. apart.	7900 8250	.45 .42	$\frac{42500}{43500}$
55	2 points 3 ft. apart.	8900	.44	40700
56	2 points 3 ft. apart.	9610	.51	45000
40	One-third points.	10000	.46	41000
42	One-third points.	9420	.47	39000
45	$\frac{2}{2}$ points $7\frac{1}{2}$ ft. apart. $\frac{2}{2}$ points $7\frac{1}{2}$ ft. apart.	17300	.50	40100
51		18000	.45	40700
43	8 points 18 in. apart.	14000	.44	42100
44	8 points 18 in. apart.	15000		44300

tests go to show the general applicability of the ordinary beam theory to simple beams without end restraint or horizontal restraint for any of the usual methods of loading, with the exception of center loading, provided, of course, that the proportions of the beam are such that the method of failure is by tension in the steel. It will be seen that the beams loaded at the middle give about 10% greater resistance than the more usual methods of loading. This excess is not so great as has been found in beams having a high percentage of reinforcement. With high reinforcement the resulting moment developed is considerably greater than for loading at the one-third points. Evidently under such conditions loading at the middle gives a distribution of stresses at sections near the center of the beam which is different from that assumed in the ordinary theory of flexure.

The load-deformation curves have the same general characteristics in all of the beams. The position of the neutral axis, as determined by the method used, is nearly the same for the several methods of loading, the variation being as little as may be ex-

pected in tests of this character and no characteristic difference being noticeable in any method of loading. Of course, with the load applied in the middle the deformations were taken over so great a gauged length that a discrepancy in the distribution of stress at a section at the middle had little effect on the values found.

13. Effect of Repetitive Loading.—Tests were made on six beams to determine the effect of repeatedly applying and releasing the load on the beam, from 24 to 30 applications of a single load being made. Three mixtures of concrete were used, thus permitting a study of the effect of quality of concrete. All beams were reinforced with 1% of steel. The load applied was 5000 lb.

TABLE 8.

EFFECT OF REPETITIVE LOADING.

Span 12 ft. Loaded at one-third points.

Beam No.	Mixture	Age days	Per cent Rein- forcement	Repeated Load lb.	No. of Applica- tions	Failed at lb.	Manner of Failure
28 31 29 32 30 35	$\begin{array}{c} 1-2-4\\ 1-2-4\\ 1-3-5\frac{1}{2}\\ 1-3-5\frac{1}{2}\\ 1-4-7\frac{1}{2}\\ 1-4-7\frac{1}{2} \end{array}$	70 78 71 79 71 75	0.98 0.98 0.98 0.98 0.98 0.98	6000 6000 5000 6000 5000 5000	26 25 30 24 30 30	9900 9400 10000 9800 5900 7500	Tension. Tension. Diagonal tension. Tension. Diagonal tension. Compression.

TABLE 9.

Deflections Under Repetitive Loading.

Beam No.	Mixture	Ce	nter Def		n inches		-lb. Load	1.
		lst	5th	10th	15th	20th	25th	30th
28 31 29 32 30 35	$\begin{array}{c} 1  2\text{-}4 \\ 1\text{-}2\text{-}4 \\ 1  3  5\frac{1}{2} \\ 1\text{-}3  5\frac{1}{2} \\ 1\text{-}4  7\frac{1}{2} \\ 1\text{-}4  7\frac{1}{2} \end{array}$	0.25 0.25 0.15 0.24 0.40 0.31	0 33 0.33 0.25 0.31 0.49 0.38	0.34 0.35 0.25 0.33 0.54 0.40	0.36 0.35 0.25 0.34 0.57 0.41	0.37 0.36 0.25 0.34 0.60 0.41	0.38 0.37 0.26 0.62 0.41	0.25 0.65 0.42

in three beams, and 6000 lb. in the other three. These loads were from 50% to 85% of the maximum load carried by the beam when the load was finally increased to the point of failure. The deflection at the midpoint of the span was measured, as were the deformations at the top and bottom for a gauged length along the middle of the beam, though the latter measurements were not entirely satisfactory. Table 8 and Table 9 give results of these tests.

The following notes show the principal features of the tests of the several beams.

Beam No. 28. The beam was made of 1-2-4 concrete. general behavior of this beam during the repetition of the 6000-lb. load is representative of the action of the other beams. cracks appeared on the tension side of the beam in the middle third of the length, one or more of them usually on the first application of the load and others at subsequent applications, as shown in Fig. 2. In this beam hair cracks appeared at the third. eighth, thirteenth, and twenty-sixth applications. In each case the cracks closed upon the removal of the load. Upon increasing the load after the twenty-sixth application of 6000 lb., the cracks opened still further. Finally the crack marked 8 opened much more rapidly, the beam failed by tension in the steel, and this was followed by the load dropping off and the concrete finally crushing at the top at a load much less than the maximum. It may be noted that the deflection of the beam increased with the repetition of the 6000-lb. load, the amount at the twenty-fifth application being 50% more than at the first. The position of the cracks is shown in Fig. 2, the numbers indicating the applications at which the cracks were noted.

Beam No. 31. The beam was of 1-2-4 concrete. Hair cracks appeared at the second, fifth, seventh, tenth, and twenty-fifth applications of the load of 6000 lb. On increasing the load after the twenty-fifth application, the cracks opened, and at 8000 lb. crack No. 2 (Fig. 2) rapidly widened. At a load of 9400 lb., the steel passed its yield point and as usual this was finally followed with the crushing of concrete at the top of the beam. The increase in the deflection of the beam at the twenty-fifth application over that at the initial application of the load was 50%. It should be noted that the diagonal crack marked 10 formed at the 10th application of the load, but, although it widened when the load was increased beyond 6000 lb., it did not cause failure. The vertical shearing

unit-stress, as calculated by equation 18 (See page 20, Bulletin No. 4), was 53 lb. per sq. in. for a load of 6000 lb., and 78 lb. per sq. in. at failure.




FIG. 2. SKETCHES SHOWING BEAMS AFTER FAILURE UNDER REPETITIVE LOADING.

Beam No. 29. The beam was made of 1-3-5½ concrete. A load of 5000 lb. was applied 30 times. Hair cracks appeared as shown in the sketch in Fig. 2. The deflection for the load of 5000 lb. increased 67% during the repetitions. At a load of 9000 lb. a diagonal crack appeared one foot outside the load point, and the beam finally failed by diagonal tension along this crack. The vertical shearing unit-stress at this load was 76 lb. per sq. in., and at the maximum load 83 lb. per sq. in.

Beam No. 32. The beam was made of 1-3-5½ concrete. A load of 6000 lb. was applied 24 times. Two hair cracks appeared at the first application, and several more at later applications of the load, but no additional effect was observed. As the load was finally increased to an amount near 9400 lb., a crack near the load point appeared, and failure by tension in the steel at this point followed at a maximum load of 9800 lb. The repetition of the load gave a greatly increased deformation in the upper fiber (See Fig. 14) but when the load was increased beyond 6000 lb., the upward direction of the deformation curve for the upper-fiber indicates that the concrete had not lost its strength or elasticity. The changes in the deflection are shown in Fig. 10.

Beam No. 30. The beam was made of 1-4-7½ concrete. A load of 5000 lb. was applied 30 times. Hair cracks appeared on the third and fourth applications. On increasing the load a diagonal crack appeared outside the load point, and the beam failed by diagonal tension at a maximum load of 5900 lb., followed by a stripping of the bars for some distance beyond. The vertical shearing unit-stress for this load was 53 lb. per sq. in. The exposed ends of the bars showed a slip in the concrete after the maximum load was reached. Fig. 8 gives the changes in deflection.

Beam No. 35. The beam was made of  $1-4-7\frac{1}{2}$  concrete. Thirty applications of the load of 5000 lb. were made. Fine hair cracks appeared at the bottom over the the middle third during the repetition, and a few outside of the load points. The beam finally failed by compression in the upper face of the beam at a load of 7500 lb. It seems possible that the strength of the concrete may have been affected by the repetition of stress, although it is more likely that the test is an example of the effect of poor concrete.

These tests throw light upon the phenomena of repetitive loading and show the need of further investigation in this direction, but they are not at all conclusive. The manner of failure in general is the same as may be expected with beams of the same reinforcement and same quality of concrete loaded progressively to final failure. Whether the maximum load carried in the case of the repetitive loading is less than would have been the case with progressive loading is not known. There are some indications that the maximum load was less than it would have been without repetition.

The increase in the deflection of the beams with repetition of the load is quite apparent. Much of this increase is due to the increased amount of shortening of the concrete in the compression side of the beam with repetition. A part is due to the breaking of the concrete in tension and the transferring of the tensile stress once taken by the concrete to the steel itself. This accounts for part of the set in the deflection curve upon the release of the load. Part of the set must be due to the concrete in the lower fiber not meshing, so to speak, when the load is released after numerous fine cracks have appeared. For this reason some tension remains in the steel reinforcement after the load is taken off. It seems evident that upon the removal of the load the beam does not regain its original shape and a section which was plane before bending will not be plane upon release of the load. The plastic nature of the concrete on the compression side gives a set, and the concrete on the tension side is unable to return to its original position; the two act together to cause the fibers not to return to the original plane section. These several causes operate together to produce the permanent deflection or set.

The load applied in the cases of the leaner concretes was 67% to 85% of the maximum load which the beam finally held. In the case of the better concrete, the repeated load was 50% to 60% of the maximum load. The effect of the quality of the concrete is seen in the manner of failure.

This topic is one of such importance that it merits fuller investigation. The few tests which have been made indicate that the deflection and the deformations increase with repetition. It seems quite probable that the breaking load under a number of repetitions will be smaller than under a single load. It seems to be true also that the amount of reinforcement for which the elas-

tic tensile strength of the steel used for reinforcement may be considered to balance the compressive strength in the concrete of the beam (which the writer calls "the balanced reinforcement") should be taken at a lower percentage in beams subjected to a repetition of load than is found necessary in the case of beams tested by means of a gradually applied load.

The term "balanced reinforcement" referred to above is a convenient term for general use. It should be taken to mean that amount of reinforcement for which the allowable stress in the steel and the allowable stress in the concrete both exist at the same time. The factors of safety for the two materials will not be the same. The determination of the balanced reinforcement for given conditions of materials, fabrication, and use is a matter involving calculation and experimentation, but in any event the judgment of the designer must enter into the choice of the amount.

14. Diagonal Tension Failures.—As shown in Bulletin No. 4 (pages 20, 21, and 26), certain secondary stresses or web stresses exist in the concrete of a reinforced concrete beam in addition to the horizontal or longitudinal tensile and compressive stresses which are always considered in the analysis. Strictly speaking, the shearing stresses developed under ordinary conditions are relatively light, and the actual shearing strength of concrete is considerably greater than the shearing stress which exists in ordinary beams at the time of failure. It is quite common, however, to use the term "shearing failure" as a name for a class of failures in the web of a beam, but it must not be understood from this use of terms that the failure necessarily involves actual failure by shear. Generally speaking, such failures are due to the inability of the concrete to resist the tensile stresses developed in the web in a diagonal direction, and the term "diagonal tension failure" is a much more appropriate name for this form of failure. It is a principle of mechanics that where shearing stresses exist tensile and compressive stresses are set up at an angle with the direction of the shearing stresses. If longitudinal tensile stress also exists in the concrete, the diagonal tensile stress induced by the combination of these with the shear is even higher than that due to shear alone. If v represents the horizontal and vertical unit-stress at any point in the web of a beam and s the horizontal tensile unit-stress existing in the concrete at the same

point, then, as shown in Bulletin No. 4, the formula for the maximum diagonal tensile unit-stress is

$$t = \frac{1}{2} s + \sqrt{\frac{1}{4} s^2 + v^2}.....(19)$$

If there is no longitudinal tension in the concrete, this formula reduces to

and maximum diagonal tension makes an angle of 45° with the horizontal and is equal in intensity to the vertical shearing stress.

It is evident then that the amount of this diagonal tension is dependent upon both the shearing stress and the longitudinal tensile stress in the concrete at the point considered. The amount of longitudinal tension is not easy to determine and hence the actual amount of the diagonal tensile stress is uncertain. The best method for ordinary computation seems to be to compute the vertical shearing unit-stress and make all calculations upon the basis of this value. The value of the vertical shearing unit-stress, where the longitudinal reinforcement is straight (not bent up or inclined), may be computed from the formula given in Bulletin No. 4,

where V is the total external vertical shear at the section considered, b is the breadth of the beam, d' is the distance from the center of the steel to the center of the compressive stresses. For beams with 1% reinforcement d' is about  $0.86 \ d$ , d being the distance from the center of the steel to the upper face of the beam.

The value of v thus calculated for beams which fail by diagonal tension ranges from one-half to one-third of the tensile strength of the concrete. Diagonal tension failures are frequently characterized by sudden failures without much warning, as is the case in the failure of plain concrete beams. A variation from this gives a slower failure, part of the shear being carried through the reinforcing bars, and the ultimate failure involving the splitting and stripping of the bars from the beam above. When the reinforcing bars are bent up or inclined toward the ends of the beams the distribution of the vertical shear is different from that just outlined and the analysis is more complex. However, for purposes of comparison, the use of equation (18) is advantageous, and the values of v given in the tables for beams

with bars inclined are calculated by this formula, using d as 10 in., though the amounts as calculated do not represent the actual vertical shear.

Forty test beams were made with a view of studying diagonal tension failure. To make a sufficient variety of conditions the concrete was varied from a fairly rich mixture to a very lean concrete. The first of the 1-3-6 concrete beams numbered up to 13 were very poorly made, as described under "6. Making of the Beams", and the general appearance of the concrete and its action during the tests go to show that the concrete was of a very inferior quality. The beams were made with the same depth, and their length was varied to give a variable relation between depth and span.

Table 10 gives the results of beams having the reinforcing bars horizontal and in which failure occurred by diagonal tension. The beams are grouped according to the quality of the concrete.

TABLE 10.

DIAGONAL TENSION FAILURES.

BARS HORIZONTAL.

All beams loaded at one-third points.

Beam No.	Span ft.	Per cent Rein- force- ment	k·	Maxi- mum Applied Load lb.	Vertical Shearing Stress lb. per sq. in. $v = \frac{V}{bd'}$	Manner of Failure		
	1-5-10 Concrete.							
62 63 66 67 71 Av.	12 12 12 12 12 12	1.10 1.10 1.25 1.25 1.65	.60 .48 .71 .57 .59	8850 7360 8000 7850 7600	74 63 69 68 67 68	Diagonal tension. Diagonal tension. Diagonal tension. Diagonal tension. Diagonal tension.		
1-4-7½ Concrete.								
30	12	0.98	.71	5900	53	Diagonal tension.		

TABLE 10-Concluded

TIDEN IV ( Weekingen								
Beam No.	Span ft.	Per cent Rein- force- ment	k·	Maxi- mum Applied Load lb.	Vertical Shearing Stress lb. per sq. in. $v = \frac{V}{bd'}$	Manner of Failure		
1 3-6 Concrete.								
3 5 6 8 9 15 16 18	12 12 10 10 10 8 8 6 6	0.98 0.98 0.98 2.21 2.21 0.98 0.98 0.98	.48 .44 .47 .56 .64 .52 .41 .40 .54	7380 6200 7050 8470 9150 13000 12420 13000 12760	64 55 59 73 79 107 97 101 99	Diagonal tension.		
Av.					81	×		
			1-	-3-5½ Conc	crete.			
11 29 68 23 27 34 37 25 33 46 49	12 12 12 10 8 8 8 6 6 6 6	0.98 0.98 1.65 2.21 2.21 2.21 2.21 0.98 0.98 0.98	. 52 . 55 . 57 . 61 . 67 . 76 . 70 . 56 . 57 . 34	10000 10000 14220 13830 11000 11230 15140 15430 15670 13700 19000	83 83 115 115 92 94 114 118 120 106 144	Diagonal tension.		
AV.	A.V 108							
1-2-4 Concrete.								
47 48 Av.	6 .6	0.98 0.98	.46	18800 17940	142 136 139	Diagonal tension. Diagonal tension.		

The value of v, calculated by equation (18), offers a means of comparison of the resistance of the concrete to failure by diagonal tension. The effect of lean concrete and of poorly made concrete is quite evident. The results are instructive. The low values

for the poor concrete may be helpful as a warning against assuming high web stresses for beams in which the concrete may not be well made.

The range of the values of the vertical shearing unit-stress v found in these tests with beams having the reinforcing rods in a horizontal position may be summarized as follows, the results being obtained with a single application of the load on beams about 60 days old:




Fig. 3. Sketches Showing Beams after Failure.

The one beam of  $1-4\cdot7\frac{1}{2}$  concrete which failed in this way gave 43 lb. per sq. in. This beam was subjected to repetitive loading. These results show the importance of using a rich concrete in the web of reinforced concrete beams which are subjected to any considerable amount of diagonal tension when there is no metallic web reinforcement or when the web reinforcement is not effective. It is probable that not enough attention has been given to this element in the design of short and deep beams.

Fig. 3 gives sketches showing the cracks which were observed in these beams. The sketches represent the position of the cracks after the failure of the beam, or after the load had reached a maximum, and do not indicate the position or extent of the cracks within the maximum load. Fig. 4 and 5 are reproduced from photographs and give the appearance of beams after failure. Generally speaking, the crack when first observed, extended from the bottom of the beam to the steel reinforcement and from the steel reinforcement diagonally a short distance toward a load point, although in some cases the diagonal crack was observed before the vertical crack was visible. Sometimes this diagonal crack was observed before the maximum load was reached and sometimes not until the maximum load had been passed. or even until after the beam had failed quite suddenly. In some of the beams the diagonal crack was seen to extend forward slowly toward the load point before or just after the maximum load was reached and then a horizontal crack grew along the level of the top of the reinforcing bars toward the support. phenomena of final failure were frequently connected with the slipping of the reinforcing bars or with the stripping of these bars from the concrete above as was described in Bulletin No. 4 for a former series of tests. The slipping of the bars which occurred was not observed until the maximum load had been passed, and generally in these cases the crack also extended along the bars. It seemed evident to the observers that this slip did not occur before the maximum load was applied and before the existence of the diagonal crack had materially modified the conditions in the beam. Beams No. 66 and 67 (See Fig. 3 and 5) throw some light upon this matter. They were made for this purpose with very lean concrete and reinforced with corrugated bars. The condition of the beam at failure showed that the horizontal crack was due to vertical tension and that horizontal








Fig. 4. Views Showing Beams after Failure.

26








Fig. 5. Views Showing Beams after Failure.







Fig. 7. Views Showing Beams after Failure.



shear or slip did not take place until after this crack had been formed. The indentations in the concrete formed by the corrugations of the bars were left in perfect condition and there was no crushing or tearing at the edges of these indentations. The bar had simply been pulled down and out of the place in which it had rested. Comparisons with the results of beams made with the same concrete and with smooth steel (Beams No. 62, 63, and 71) show values almost identical and go to indicate that slipping had no part in the critical failure of the beams made up with smooth bars. In all the cases where slipping of the bar took place the action extended progressively from the diagonal

TABLE 11.

DIAGONAL TENSION FAILURES.

BARS BENT UP.

All beams loaded at one-third points.

Beam No.	Span ft.	Per cent Rein- force- ment	k	Maxi- mum Applied Load lb.	Vertical Shearing Stress lb. per sq. in. $v = \frac{V}{bd'}$	Manner of Failure	
1-3-6 Concrete.							
7 13 14 17 20 21 22 Av.	10 10 10 8 6 6 6	0.98 2.21 2.21 0.98 0.98 0.98 0.98	.44 .7 <b>5</b> .66 .46 .48 .48	8370 9320 10560 9150 11620 16500 16760	69 80 89 74 90 126 128	Diagonal tension.	
$1\text{-}3\text{-}5\frac{1}{2}$ Concrete.							
36 38 39 Av.	10 8 8	0.98 2.21 2.21	.58 .70 .73	7910 11920 14000	64 99 115 93	Diagonal tension Diagonal tension Diagonal tension	

crack toward the load point, though in some cases this action was quite sudden. From all the information available it seems to be evident that, whatever slip of the bars may have taken place, the slipping did not exist before the time of the maximum load and resulted from the changed conditions incident to the formation of the diagonal crack. It therefore seems evident that the failure of these beams should be credited to diagonal tension.

Table 11 gives results of beams with reinforcing bars bent up, or inclined in the outer thirds of the length of the beam. The values of v are calculated by equation (18) and with d as 10 in., and hence do not give the actual amount of the shear. The amount and position of this bending have been described under "5. Test Beams". Fig. 6 gives the sketches of the appearance of




Fig. 6. Sketches Showing Beams after Failure.

the crack after final failure or after the maximum load had been passed. The view of Beam No. 39, shown in Fig. 7, is from a photograph of the beam after failure. Generally speaking, the vertical portion of the crack from the bottom of the beam to the reinforcement formed first, and was due to the failure of the concrete in tension. The diagonal crack then grew toward the load point, generally forming before the maximum load was reached, and the growth of the crack along the reinforcing bar generally

followed. It was expected that this method of bending up bars would give a higher value for the vertical shear as calculated by equation (18) in beams failing by diagonal tension than that found in beams with the bars horizontal, but in this the results were disappointing. In a few beams the values ran higher. Comparing Beam No. 21 with Beam No. 22 it will be seen that no difference was observed whether part of the bars were bent up and part left horizontal, or all were bent up. The values of v for these beams were among the highest found with this quality of concrete. In the phenomena of failure it appeared that the element of slip was present, though it is not known that this slip occurred before failure. Calculations indicate that the bond stress developed at the end of the bars must have been considerable. It should be noted that none of the bars were anchored at the ends.

Table 12 gives the beams in which failure occurred by tension in the steel or compression of the concrete. It will be seen that the dimensions of these beams were such that the diagonal tension developed (as measured by the vertical shear) at the time of failure was less than was found with beams which failed in diagonal tension and hence that the strength of the concrete in diagonal tension had not been reached. Beam No. 35 which failed in compression, was of 1-4- $7\frac{1}{2}$  concrete, a very lean mixture. Beam No. 10 was one of the beams with poorly made concrete and in this case the inferior quality of the concrete was especially noticeable.

In Beams No. 68, 69, 70, 71, 72, and 73, U-shaped stirrups of  $\frac{1}{2}$ -in. mild-steel round rods were placed in a vertical position and enveloped the horizontal reinforcing bars. The longitudinal spacing was inadvertently made 12 in. Beam No. 69 failed by tension in the steel at a value of v of 129 lb. per sq. in., which is below the resistances developed in the beams of 1-2-4 concrete which failed in diagonal tension, and the efficiency of the stirrups was not determined. Beams No. 72 and 73 also failed by tension in the steel at values of v below what was found in beams of 1-3-5 $\frac{1}{2}$  concrete of the same quality which failed in diagonal tension. Beam No. 70 failed by compression of the concrete, but a diagonal crack had formed, before the maximum load was applied, at a value of v which is high for 1-3-5 $\frac{1}{2}$  concrete, and the stirrups seemed to be effective in preventing sudden failure after the

TABLE 12.

#### MISCELLANEOUS FAILURES.

All beams loaded at one-third points.

Beam No.	Span ft.	Per cent Rein- force- ment	k	Maxi- mum Applied Load 1b.	Vertical Shearing Stress lb. per sq. in. $v = \frac{V}{bd'}$	Manner of Failure			
	1-4-7½ Concrete.								
35	12	0.98	.68	7500	64	Compression.			
	1-3-6 Concrete.								
10 12 Av.	12 12 10	0.98 0.98 2.21	.48 .64 .79	9360 9430 10200	78 77 89 81	Tension Compression. Compression			
			1-	-3-5½ Con	crete				
32 74 26 Av.	12 10 8	0.98 0.98 0.98	.57 .52 .51	9800 11950 14030	81 95 109 95	Tension. Tension. Tension.			
1-2-4 Concrete.									
28 31 Av.	12 12	0.98 0.98	.36	9900 9400	82 79 80	Tension. Tension.			

maximum load was passed. Beam No. 68 (Fig. 7) failed in diagonal tension at a value of v of 115 lb. per sq. in. At a load of 13 000 lb. the diagonal crack extended 7 in., and at the maximum load, 14 220 lb., it extended to a point under the load point and


was  $\frac{1}{3}$  in. wide. The load fell off very slowly, and the stirrups prevented sudden failure. Beam No. 71 (Fig. 7) failed by diagonal tension at a value of v nearly the same as the companion beams of 1-5-10 concrete which did not have stirrups. The load dropped off rapidly after the maximum load was reached and the stirrups seemed to have little effect. It is clear that the spacing of the stirrups in these beams caused them to be inefficient, the distance apart being too great, and besides, the stirrups were not properly placed in the beam. Further tests are now in progress, in which the dimensions of the beam and the size and spacing of the stirrups are expected to bring out the effectiveness of this method of metallic web reinforcement.


- 15. Summary.—The following summary of parts of the foregoing discussion is given:
- 1. For beams proportioned to give failure by tension in the steel reinforcement (i. e., when neither compression of concrete nor diagonal tension causes failure), those made with the richer concrete carried higher loads. The beams with 1-2-4 concrete carried loads greater by, say, 10%, than those with 1-3-5½ concrete.
- 2. In beams which failed by tension in the steel, the resisting moment developed was found to be about the same for loads applied at two points more or less far apart and at eight points (approaching a uniform load), thus confirming the general applicability of the ordinary beam theory to simple beams without end restraint or horizontal restraint for any of the ordinary methods of loading. For center loading the resisting moment developed ran 10% higher and in former tests even greater. This excess indicates a different distribution of stresses for center loading from that assumed in the ordinary beam theory.
- 3. The tests with repetitive loading are not conclusive and show the need of further investigation in this direction. The manner of failure in general was the same as may be expected with beams of the same reinforcement and same quality of concrete loaded progressively to final failure. Whether the maximum load carried in the case of this repetitive loading is less than would have been the case with progressive loading is not known, but there are some indications that the maximum load was less than it would have been without repetition. The in-

crease in the deflections of the beam with repetition of the load was marked, and the set in the beam was considerable. It should be remembered that the repetitive load was a considerable proportion of the maximum load finally applied and much higher than ordinary working loads. It seems evident that the amount of reinforcement for which the elastic tensile strength of the steel may be considered to balance the compressive strength of the concrete, (conveniently called the "balanced reinforcement"), should be taken at a lower percentage in beams subjected to a repetition of load than is found necessary in the case of beams tested by means of a gradually applied load, and that for the ordinary conditions of fabrication and use the "balanced reinforcement" selected should be much less than that determined by test beams.

- 4. The manner of failure depends not only upon the relative dimensions of depth and length of beam and the amount of reinforcement, but also upon the richness and strength of the concrete.
- 5. The loads carried by beams failing by diagonal tension depended both upon the richness of the concrete and upon its quality as influenced by the methods of mixing and storing. Poorly made concrete gave a vertical shearing stress averaging 71 lb. per sq. in. as compared with 99 lb. per sq. in. for well made concrete of the same mixture. The value, 138 lb. per sq. in., for the 1-2-4 concrete shows the advantage of the richer mixture.
- 6. Failure by diagonal tension generally occurs without warning, resembling somewhat in this respect the failure of unreinforced concrete beams. On account of the variability of concrete and its unreliability in resisting tensile stresses, relatively low diagonal tensile stresses (high factor of safety), as measured by the vertical shearing stresses, should be specified, unless there is effective metallic web reinforcement. The values allowed by many building ordinances seem too high to secure safety under the condition of ordinary building operations. Short, deep beams and beams restrained at the ends require that special attention be given to web stresses.
- 7. Slipping of bars and stripping of bars may accompany final failure of beams which fail by diagonal tension. It appears that slipping or stripping did not take place in the beams having the reinforcing bars horizontal until after the maximum load was

reached and the presence of diagonal cracks had modified the distribution of stresses. At these maximum loads the calculated bond resistance developed was low as compared with the bond strength of the steel and concrete. The beams reinforced with deformed bars carried no higher loads than those with plain bars. The beams with bars bent up or inclined toward the ends gave quite variable results, but in general the values were even lower than those with the bars in a horizontal position. There is some probability that slipping occurred in these tests at or before the maximum load and that anchoring the ends of the bars would have been beneficial. The results for the beams having vertical stirrups showed that the stirrups as used were not efficient in taking web stresses.





### PUBLICATIONS OF THE ENGINEERING EXPERIMENT STATION

Bulletin No. 1. Tests of Reinforced Concrete Beams, by Arthur N. Talbot. 1904. (Out of print).

Circular No. 1. High-Speed Tool Steels, by L. P. Breckenridge. 1905.

Bulletin No. 2. Tests of High-Speed Tool Steels on Cast Iron, by L. P. Breckenridge and Henry B. Dirks. 1905.

Circular No. 2. Drainage of Earth Roads, by Ira O. Baker. 1906.

Bulletin No. 3. The Engineering Experiment Station of the University of Illinois, by L. P. Breckenridge. 1906. (Out of print).

Bulletin No. 4. Tests of Reinforced Concrete Beams, Series of 1905, by Arthur N. Talbot. 1906.

Bulletin No. 5. Resistance of Tubes to Collapse, by Albert P. Carman. 1906.

Bulletin No. 6. Holding Power of Railroad Spikes, by Roy I. Webber. 1906.

Bulletin No. 7. Fuel Tests with Illinois Coals, by L. P. Breckenridge, S. W. Parr and Henry B. Dirks. 1906.

Bulletin No. 8. Tests of Concrete: I. Shear; II. Bond, by Arthur N. Talbot. 1906. (Out of print).

Bulletin No. 9. An Extension of the Dewey Decimal System of Classification Applied to the Engineering Industries, by L. P. Breckenridge and G. A. Goodenough. 1906.


Bulletin No. 10. Tests of Plain and Reinforced Concrete Columns, Series of 1906, by Arthur N. Talbot. 1907.


Bulletin No. 11. The Effect of Scale on the Transmission of Heat through Locomotive Boiler Tubes, by Edward C. Schmidt and John M. Snodgrass. 1907.

Bulletin No. 12. Tests of Reinforced Concrete T-beams, Series of 1906, by Arthur N. Talbot. 1907.

Bulletin No. 13. An Extension of the Dewey Decimal System of Classification Applied to Architecture and Building, by N. Clifford Ricker. 1907.

Bulletin No. 14. Tests of Reinforced Concrete Beams, Series of 1906, by Arthur N. Talbot. 1907.





VIEW IN CENTRAL HEATING STATION UNIVERSITY OF ILLINOIS

# UNIVERSITY OF ILLINOIS

# ENGINEERING EXPERIMENT STATION

Bulletin No. 15

August 1907

#### HOW TO BURN ILLINOIS COAL WITHOUT SMOKE

BY L. P. BRECKENRIDGE, DIRECTOR OF THE ENGINEERING EXPERIMENT STATION

It is the intention to discuss in this paper the fundamental principles that apply to smokeless furnace construction and operation and to illustrate by means of units in actual operation several ways in which these principles have been satisfactorily applied. With a clear idea of the principles involved, with a knowledge of the character of the coal to be used and the capacity at which it is desired to drive the furnace, there should be little difficulty in designing, constructing and operating stationary boiler furnaces which under ordinary conditions of service will operate with high economy and which will burn Illinois coal without smoke.

The writer does not profess to be acquainted with all the methods that have been found satisfactory for the purpose of smoke prevention, neither does he consider it advisable to describe in detail all the furnaces that are claimed to be capable of burning coal without smoke. All that can be attempted here will be a description of those furnaces with which the writer is personally familiar or which have been examined while in operation and have been found to give satisfactory results.

Perhaps the one thing that has most delayed progress toward success in the smokeless operation of furnaces is the fact that in the past so much in their operation has depended upon the human element. It will doubtless be found that those plants smoke less that are mechanically operated. Such operation is by no means a sure preventive of smoke, as certain constructive features are now well recog-

nized as necessary even with good mechanical stokers if smokeless combustion is to be obtained.

This discussion will be confined to those settings and furnaces that have been found to be most satisfactory in burning Illinois coals without smoke. From a study of the tests of the various coals of the United States, as presented in the reports of the United States Geological Survey fuel testing plant, it seems safe to say that engineers now have sufficient information available to enable them to design boiler furnaces that will burn any coal without smoke. The progress made in this direction during the last five years is surely encouraging and it is confidently believed that the time will soon come when no power plant can offer as an excuse for a smoky chimney the plea that no appliances are available which can be depended upon for smoke prevention. The problem of smoke prevention is the problem of perfect combustion. There is no such thing as smoke consumption and this term should never be used. There is such a thing as perfect combustion and this means smokeless combustion.

# THE PRINCIPLES OF SMOKELESS COMBUSTION

The subject of combustion should be familiar to all mechanical engineers. However, as a basis for a thorough understanding of the problems of smoke prevention, a brief review of the principles of combustion may prove acceptable in connection with this subject. In fact, the complete solution of the smoke problem consists in providing furnaces, so constructed and so capable of operation as to make combustion nearly perfect.

Combustion may be defined as a rapid chemical combination, resulting in heat and light. The combining elements are: (a) Oxygen, which is usually derived from atmospheric air; (b) Either carbon or

This bulletin was prepared at the suggestion of the Conference Committee on Fuel Tests, the members of which are given below. It should be stated, however, that the Committee is in no way responsible for the opinions expressed by the writer

H. Foster Bain, Director State Geological Survey, Urbana, representing the State Geological Survey; A. Bement, Consulting Engineer, Chicago, the Western Society of Engineers; Edwin H. Cheney, President Fuel Engineering Co., Chicago, the Building Managers' Association of Chicago; F. H. Clark, Supt. Motive Power Burlington Road, C. B. & Q. Ry., Chicago, the Western Railway Club; Adolph Mueller, President H. Mueller Mfg. Co., Decatur, Ill., the Illinois Manufacturers' Association; Carl Scholz, President Coal Valley Mining Co., Chicago, the Illinois Coal Operators' Association; Wm. L. Abbott, Chief Operating Engineer Chicago Edison Co., Chicago, the Board of Trustees, University of Illinois; L. P. Breckenridge, Director Engineering Experiment Station, University of Illinois, Urbana, Ill.

hydrogen, or a compound of the two. Sulphur sometimes appears with carbon and hydrogen, and also combines with oxygen. The substance that is formed by the chemical union is called the product of combustion; and the heat that is produced by the combustion of a unit weight (one pound) of the fuel is called the heat of combustion. This is usually measured in British thermal units (B. t. u.). One B. t. u. is the amount of heat required to raise the temperature of one pound of water one degree Fahrenheit. The following table relates to the complete combustion of hydrogen, carbon and sulphur:

# COMPLETE COMBUSTION OF THREE ELEMENTS

PRODUCT OF COMBUSTION							
Element	Chemical Symbol	Name	Chemical Symbol	Heat of Comb'st'n B. t. u. per lb.			
Hydrogen Carbon Carbon Sulphur	H C C S	Water Carbon Dioxide Carbon Monoxide Sulphur Dioxide	$egin{array}{c} H_2O \ CO_2 \ CO \ SO_2 \end{array}$	62000 14500 4400 4000			

In the complete combustion of carbon, the product of combustion, it will be observed, is carbon dioxide (CO<sub>2</sub>). Each atom of carbon combines with two atoms of oxygen. If sufficient oxygen is not provided, it may happen that each carbon atom will combine with but one oxygen atom, thus forming carbon monoxide (CO). As a result of this incomplete combustion, the heat developed is only 4400 B. t. u. The carbon monoxide may itself combine with oxygen, according to the formula

$$CO + O = CO_2$$

and the heat developed will be the difference, 14 500 - 4400 = 10 100 B, t. u. per pound of carbon in the carbon monoxide.

A knowledge of the relative weights of these elementary atoms gives a direct means of computing the amount of oxygen required for · combustion. The weights are as follows:

H	010	5
C12	S3.	2

In the burning of hydrogen to H<sub>2</sub>O, two atoms of hydrogen, each of weight I combine with one atom of oxygen, weight 16; hence the ratio of oxygen to hydrogen is 16:2=8:1, i.e., 8 lb. of oxygen are required for the combustion of t lb. of hydrogen, and

there results 8 + 1 = 9 lb. of water. This combination with others may conveniently be presented in a tabular form as follows:

THE COMBUSTION OF IMPORTANT ELEMENTS WITH OXYGEN

Elements	Chemical Equation	Relative Weights	Weights pounds
Hydrogen to H <sub>2</sub> O	$2H + O = H_2O$	$(2 \times 1) + 16 = 18$	1 + 8 = 9
Carbon to CO <sub>2</sub>	$C+2O=CO_2$	$12 + (2 \times 16) = 44$	1+223=323
Carbon to CO	C + O = CO	12 + 16 = 28	1 + 113 = 213
Sulphur to SO <sub>2</sub>	S +20=SO	$32 + (2 \times 16) = 64$	1 + 1 = 2
Methane or	$(CH_4)+4O=$	$(12+4)+(4\times 16=$	
Marsh Gas	$CO_2 + 2H_2O$	$ 12 + (2 \times 16) + 2(2 + 16) $	1 + 4 = 2.75
			+2.25

When the oxygen needed for combustion is taken from the atmosphere, the nitrogen always present must be taken into consideration. Nitrogen takes no part in the combustion but mingles with the products of combustion, absorbs heat from them and passes away with them. Approximately, it takes 4.25 lb. of air to furnish 1 lb. of oxygen; the remaining 3.25 lb. are nitrogen. When the combustion of the different elements takes place in air the resulting relative weights are modified on account of the presence of the nitrogen. This is exhibited below.

THE COMBUSTION OF IMPORTANT ELEMENTS IN AIR

Elements	Chemical Equation	Relative Weights	Weights pounds
Carbon in Air Marsh Gas	C +Air= CO <sub>2</sub> + 7.43N* CH <sub>4</sub> +Air=	$12+(2\times4.25\times16) = 44+104$ $(12+4)+(4\times4.25\times16) =$	3.67 + 8.66
in Air	$CO_2 + 2H_2O + 14.86N$	$44+(2\times18)+208$	2.75 + 2.25 + 13

<sup>\*</sup> The atomic weight of nitrogen is 14.

It will be seen from the above table that to burn I lb. of carbon 11.33 lb. of air must be supplied. The 8.66 lb. of nitrogen contained in the weight of air pass away with the 3.67 lb. of carbon dioxide (CO<sub>2</sub>) formed by the combustion. For the complete combustion of I lb. of marsh gas, 17 lb. of air are required. Chemical combinations of carbon and hydrogen, the so-called hydrocarbons, play an important part in the burning of coal, particularly in those coals of large volatile content. The most important of these are the following:

Hydrocarbon Element	Chemical Symbol	Heat of Combustion
Methane or Marsh Gas Ethylene or Olefiant Gas Acetylene	${^{ m C}_{1}}_{4} \ {^{ m C}_{2}}_{{ m H}_{4}} \ {^{ m C}_{2}}_{{ m H}_{2}}$	24020 B. t. u. 21930 B. t. u. 21850 B. t. u.

At the ordinary temperature and atmospheric pressure, a pound of air has a volume of about 13.1 cu. ft. Using this value, the following (round numbers) are obtained for the theoretical amount of air required for the complete combustion of various fuels:

Amount of Air Required to Burn One Pound of Various Fuels

Kind of Fuel	Carbon	Hydrogen	Sulphur	Methane
Weight of Air (lb.)	11.33	34	4.25	17
Volume of Air (cu. ft.)	150	445	55	220

The heat developed by the combustion is absorbed by the products of combustion, and as a result, the temperature of these gases rises in a marked degree. Thus when carbon is burned in air, the 14 500 B. t. u. developed should heat the  $3\frac{2}{3}$  lb. of CO<sub>2</sub> and  $8\frac{2}{3}$  lb. of nitrogen from an initial temperature of perhaps  $60^{\circ}$  to a calculated final temperature of about  $4500^{\circ}$ . The actual final temperature, for reasons to be explained presently, is considerably lower. The products of combustion act as a vehicle, carrying the heat developed by combustion to its final destination.

It may perhaps be profitable to picture an ideal perfect combustion, and then inquire in what ways actual combustion falls short of the ideal. The given fuel, composed of carbon, various volatile hydrocarbon gases, and perhaps sulphur, is to be burned in air. Theoretically, each atom of the fuel finds and seizes upon the number of oxygen atoms with which it will combine. Each atom will meet with two oxygen atoms at a temperature sufficiently high for ignition. They will combine, and the resulting  $CO_2$  will pass out of the furnace, carrying with it the heat arising from the combustion; likewise with the hydrogen and sulphur atoms. No more air will be delivered than is just sufficient to furnish the exact number of oxygen atoms, and no carbon or hydrogen atoms will pass out of the furnace without finding oxygen atoms with which they can combine.

Actual combustion deviates from ideal conditions in many respects. If only the theoretical amount of air is supplied, on account of the difficulty of properly mingling the fuel and air, some of the fuel atoms will not find oxygen atoms, and will escape uncombined. Or some of the carbon may burn to carbon monoxide instead of to carbon dioxide, and the CO will escape without further combustion. It is found in practice that to insure complete combustion, an excess of air must be furnished. This excess is usually 50 per cent, and may reach 100 per cent; i.e., while only 11.3 lb. of air are required for the com-

plete combustion of 1 lb. of carbon, it is usually necessary to furnish 18 to 24 lb. Since the heat of combustion is distributed throughout the excess of air introduced into the furnace as well as the products of combustion, the furnace temperature is lowered by the presence of the extra air.

In another important particular, the actual state of affairs is likely to be quite different from the ideal combustion outlined above. Carbon and oxygen atoms will not unite unless a certain temperature, the ignition temperature, is reached. In parts of the furnace, the temperature may fall below the ignition point because of the inrush of an excess of air, or because of cold bounding surfaces. As a result, carbon particles, even in the presence of plenty of oxygen, will refuse to burn. Let us further illustrate these principles by the use of some familiar examples.

If the reader understands why a torch smokes, why a flat wick is used in a lamp, why a circular burner is provided for the Argand or student lamp, why a chimney is provided for oil lamps, why a fish tail flame was used in early gas lighting, or why a vacuum bulb is provided for the incandescent lamp; if he understands these things, and most of us do, he will, it is believed, be able easily to see what conditions are necessary for perfect combustion in boiler furnaces.

If any fuel is to be burned without smoke it must be supplied with the correct amount of air. The torch smokes because the large round wick brings up oil, especially in the center, to which air cannot be supplied. If the air supply through the center tube of our student lamp is shut off a smoking flame results. candle with the small wick is an advance over the candle supplied with the large wick. The flame from the flat wick has an extended surface for air supply, while the circular burner not only has maximum surface for air supply, but the air coming up through the center of the tube is heated, making it still better suited to aid combustion and burn a large amount of oil. Thus it is that we have successfully solved the problem of burning a large oil supply without smoke. If we try to increase the oil consumption and turn up our lamps too high, they smoke, and because they are in the room with us we immediately turn them down. Furnaces burning coal sometimes smoke just because they are forced too hard, and because the top of the chimney is not in our room, but in the public's pure air we do not turn them down, but let them smoke.

Air correct in amount is a necessity for complete combustion and the simple experiments which we have all been making with our oil and gas flames should be sufficient evidence to us that only when we are able to supply our furnaces with the correct amount of air shall we be able to control the smoke which it is so easy to make. How much easier our problem would be if, as in the lamp, we could see all that was taking place and could regulate all by a simple knurled brass handle.

#### SMOKE PRODUCTION

Having briefly outlined the essential features of perfect combustion let us turn our attention to the conditions present when the combustion is imperfect, usually resulting in smoke. ducts of combustion, carbon dioxide. steam and dioxide are colorless gases. If nothing except these gases escaped from a chimney, there would be no smoke problem. Visible smoke is due to the volatile hydrocarbons which all bituminous coal contains to a greater or less extent, and which are driven off when the coal is heated. The percentage of volatile matter in coal varies widely; thus in the eastern anthracites, it may be as low as 3 per cent, while in the western lignites, it may rise as high as 50 per cent. The larger the percentage of volatile matter, the more liable is the coal to produce smoke, and the more difficult is smoke prevention.

When coal is heated in the furnace, the volatile content, consisting largely of methane and ethylene, is driven off. If the volatile gases should not enter any region of high temperature, they would simply pass out of the chimney with the products of combustion. But, as a rule, the gases are ignited, and burn, much as ordinary illuminating gas burns. The phenomena connected with the combustion of volatile gases are, however, not simple. There are grounds for supposing that a hydrocarbon, at a sufficiently high temperature, is decomposed into its elements. If oxygen is present, the hydrogen at once combines with it. The carbon particles will not combine with oxygen except under favorable conditions; if there is not a sufficient supply of air, or if it is not at a sufficiently high temperature, the carbon particles refuse to combine and are carried along with the products of combustion to be afterwards deposited as soot, or appear at the top of the chimney as smoke. This may be shown by an equation as follows:

$$C_2H_4 + 2O = 2H_2O + 2C$$

Ethylene and oxygen form water vapor and soot.

The mere explanation of the formation of black smoke suggests immediately the means that should be employed to prevent such formation. Evidently sufficient air must be furnished to burn the carbon particles liberated from the hydrocarbon gases; this air must be at a high temperature. If too great a volume of cold air is admitted to the furnace, and if at the same time the bounding surfaces of the combustion space are boiler plates or tubes of relatively low temperature, the result will be a low temperature in the space above the fuel, and it will be impossible to burn the carbon content of the volatile matter. To insure proper combustion, after the gases are driven from the coal, they should intimately mingle with sufficient air in a chamber, in which high temperature can be maintained. The heating surface of the boiler should not be permitted to come in contact with these gases until combustion has been completed.

#### Losses Due to Smoking Chimneys

The destruction of property or the effect upon the health of the community due to the smoke nuisance are matters upon which there is not an opportunity to dwell in this article. Both of these subjects are now matters of common every-day knowledge to the residents of our American cities. Something should be said, however, about the fuel losses due to smoking chimneys. The absence of smoke by no means indicates perfect combustion. It may simply mean excessive air dilution and this means uneconomical operation. Statements are frequently seen in the daily press to the effect that one-quarter or onethird of the fuel burned goes off in the black smoke issuing from the chimney. Such statements are very far from the truth. It is doubtful if the black carbon particles which issue from chimneys and which we call soot ever amount to one per cent of the fuel burned in any furnace. It takes but a small amount of soot to give a dense black color to smoke. If it were to save only these soot particles we could not afford expensive stoker and furnace settings. The appearance of black smoke is fortunately the signal of incomplete combustion and the losses due to this cause are many times the losses due to the carrying away of the small soot particles. This matter is well stated by that practical and clear writer, Wm. H. Booth, as follows:

"It is customary to speak of smoke and the smoke nuisance as though black smoke were the only feature of imperfect combustion

that demanded a remedy. But it cannot be too strongly emphasized that the visible impurities of the waste gases from factory chimneys are the least harmful part of their constituents; and that the invisible gases, which too often escape as the result of imperfect combustion, are far more detrimental in their effects upon vegetation and upon the health of the community. These invisible gases consist of unaltered hydrocarbons and of carbon monoxide; their presence is due either to deficiency of air, or to the lack of the requisite temperature in the combustion area. Smoke is the visible sign of the presence of these deleterious gases. It is, therefore, a useful signal of something wrong in the combustion process. Smoke ought to be attacked, not only because it brings dirt and depression in its train, but because its emission is accompanied by that of gases which are directly detrimental to the health of all living things, and at the same time carry away much heat from the plant of the fuel user. Both on humanitarian and economic grounds its suppression is called for\*."

If there is a deficient air supply part of the carbon atoms will not find enough oxygen atoms with which to combine and there will be a considerable part of the escaping gases leaving the chimney as carbon monoxide (CO) instead of being burned to carbon dioxide (CO<sub>2</sub>). For each pound of carbon burned only to carbon monoxide (CO) there will be a loss of approximately 10 000 heat units and this constitutes the great source of loss so frequently referred to as the loss due to incomplete combustion. This loss may readily amount to 5 per cent of the total heat in the coal. The density of the accompanying smoke may or may not be an indication of the proportion, though the loss due to carbon monoxide in perfectly smokeless chimney gases in practice will usually not exceed 0.05 of one per cent. Smokelessness is a relatively safe indication that the total heat has been liberated. Unfortunately it gives no indication of the degree of efficiency with which the heat is being utilized. The problem from the standpoint of the operator demands smokelessness with a minimum air supply. Losses due to sensible heat in the stack gases while seldom rising higher than 32 per cent of the total heat may be as low as 10 to 12 per cent without smoke or incomplete combustion. These figures are found in the fuel test reports of the United States Geological Survey under Illinois coals. The following tabulation will serve to indicate

SMOKE PREVENTION AND FUEL ECONOMY, Booth and Kershaw—Archibald, Constable & Co., London, 1904.

how the heat generated in a boiler furnace may be distributed when operating under poor, average and best conditions.

AN APPROXIMATE HEAT DISTRIBUTION FROM ILLINOIS COAL

	PERCENTAGE OF HEAT			
	Poor Condition	Average Condition	Best Condition	
Absorbed by the boiler     Carried away in dry chimney gases     Radiation and unaccounted for osses     Moisture formed by burning of	50.0 24.0 15.0	65.0 16.0 12.0	75.0 10.0 10.0	
hydrogen 5. Evaporating moisture in coal 6. Incomplete combustion of carbon	$ \begin{array}{c} 4.0 \\ 2.0 \\ 5.0 \end{array} $	$\begin{array}{c} 3.5 \\ 2.0 \\ 1.5 \end{array}$	3.0 1.5 0.5	
Total heat	100.0	100.0	100.0	

The per cents given in the last column of this tabulation are seldom attained in present practice, but they are by no means impossible. They represent conditions for which we should continually strive. Losses of 20 to 25 per cent are not unusual, both with and without smoke. Too little air is wrong. Too much air is wrong. Absolutely complete combustion can be obtained using Illinois coal burned on an automatic stoker with as low as 30 per cent excess of air. The question is one of proper furnace construction to meet the requirements of the fuel coupled with a good fireman and an intelligent use of instruments which will tell him at all times the conditions of the combustion and draft.

It has been stated elsewhere, what relation should exist between the weight of coal burned and the weight and volume of air required for perfect combustion. It is sometimes more striking, however, to bring out this point, by using a larger unit than the single pound. Take for instance, a 1000 horse-power boiler plant. Many such plants would burn 5000 lb. of coal an hour; the air supplied would weigh 100 000 lb. and the volume of this air at a chinney temperature of 500 degrees Fahr. would be about 2 400 000 cu. feet. The chinney for this plant must therefore discharge nearly 105 000 lb. (52.2 tons) of gases into the atmosphere each hour; that is, for each ton of coal burned the chinney will discharge from 18 to 22 tons of gases. To keep these gases of the right color and composition for 90 per cent of the time is the problem to be solved. Chinneys will still be needed when the so-called smoke problem is solved. The popular solution consists

in changing the color of the gases flowing from the chimney from black to a light gray, that is from No. 5 to No. 1 on the Ringelmann At least this is all that the public and the smoke inspector will demand. But even when this problem is well solved our chimneys must continue to discharge immense volumes of heated gases, and these gases will often carry with them fine particles of ash which cannot be burned; all of which may produce something of that disagreeable haze which floats over manufacturing cities. The dense black smoke from chimneys is certainly a nuisance. It can be stopped for about 90 per cent of the time, and if this is accomplished a most wonderful improvement will be observed in the atmosphere of our cities. If smoke is not largely prevented in large cities it will be because of laxity in carrying out the provisions of the law, combined with the indifference of power plant owners, rather than because of a lack of furnaces and boiler settings which are available for successfully burning bituminous coal without smoke.

#### THE OBSERVATION OF SMOKE

From the point of view of the general public there are but two kinds of chimneys, those that smoke and those that do not smoke. The emission of black smoke for a short period say of three minutes of an hour is sometimes enough to leave the impression on the casual observer that the chimney smokes all the time. It is therefore important that there should be some way devised for estimating the relative blackness of smoke and some plan adopted for recording the length of time during which smoke of varying degrees of blackness is emitted from chimneys. Numerous schemes have been proposed to accomplish this purpose. One of the most scientific of these plans is that invented by Professor Ringelmann of Paris.\*

"In making observations of the smoke proceeding from a chimney, four cards ruled like those in the cut; (See Fig. 1), together with a card printed in solid black and another left entirely white, are placed in a horizontal row and hung at a point about 50 feet from the observer and as nearly as convenient in line with the chimney. At this distance the lines become invisible, and the cards appear to be of different shades of gray, ranging from very light gray to almost black. The observer glances from the smoke coming from the chimney to the cards, which are numbered from 0 to 5, determines which card most nearly

<sup>\*</sup> Trans. A. S. M. E., Vol. XXI, Dec., 1899.

corresponds with the color of the smoke, and makes a record accordingly, noting the time. Observations should be made continuously during say one minute, and the estimated average density during that minute recorded, and so on, records being made once every minute. The average of all the records made during a boiler test is taken as the average figure for the smoke density during the test, and the whole of the record is plotted on cross section paper, (See Fig. 2), in order to show how the smoke varied in density from time to time. A rule by which the cards may be reproduced is given by Professor Ringelmann as follows:

Card o. All white.

Card I. Black lines I mm. thick, IO mm. apart, leaving spaces 9 mm. square.

Card 2. Lines 2.3 mm. thick, spaces 7.7 mm. square.

Card 3. Lines 3.7 mm. thick, spaces 6.3 mm. square.

Card 4. Lines 5.5 mm. thick, spaces 4.5 mm. square.

Card 5. All black.

The cards as printed on page 13 are much smaller than those used by Professor Ringlemann. The thickness and spacing of the lines are in the same proportion, but reduced to one-half size."

The smoke observations reported in the government fuel tests made by the Technologic Branch of the U. S. G. S. are all based on the Ringelmann chart. This chart has, therefore, been adopted in the reports of fuel tests made by the Engineering Experiment Station and the numbers used in its bulletins refer to this scale.

An observer soon becomes skilled in taking smoke records and when several observers have been trained to the system their records are very nearly alike. In fact one soon becomes so familiar with the scale of densities that he no longer needs the actual charts for comparison, but may be trusted to take the record without the aid of the chart. An attempt has been made to illustrate smoke densities in the plate shown in Fig. 2. Many difficulties surrounded the preparation and printing of such a plate and it is inserted with some misgivings. It is believed, however, that if it should prove successful it will give some reader a better idea of the value of the scale numbers 1 to 5, used to denote smoke densities than will the pictures of the Ringelmann charts.

When a record of a smoking chimney is desired numerous ways are adopted for showing its behavior. For many records a column of the scale density numbers is sufficient, set of course opposite the inter-




FIG. 1 THE RINGELMANN SCALE FOR GRADING THE DENSITY OF SMOKE

vals of time which are deemed short enough for the purpose for which the observations are taken. Where many records must be taken the work may be facilitated by using some of the simplemechanical devices which have been perfected for this purpose. These usually consist of a drum rotated by clockwork, and a marking pen movable by hand leaving a record on suitable paper that has been wrapped on the drum. The form of smoke chart record adopted in the work of the Engineering Experiment Station is shown in Fig. 3. This form needs little explanation. The scale density numbers are those at the left of the sectioned plates and these densities are approximately shown at the top under their respective numbers. It is intended that the time scale shall be chosen and placed along the zero horizontal lines. This time scale will vary according to the character of the tests being made. Graphic charts are for many purposes much preferable to any other scheme for exhibiting the continuous operation of chimneys supposed or claimed to be smokeless, and they are particularly useful when comparing several stacks for the same interval of time, or when changes made in a setting are being studied.

# FURNACES AND BOILER SETTINGS SUITABLE FOR BURNING ILLINOIS COAL WITHOUT SMOKE

General Principles of Construction.—Various writers on boilers and furnaces have enunciated the principles of smoke prevention in different ways. In "Steam Boiler Economy," Wnn. Kent says:

"Coal can be burned without smoke provided:

- (a) The gases are distilled from the coal slowly.
- (b) That the gases when distilled are brought into intimate contact with very hot air.
  - (c) That they are burned in a hot fire-brick chamber.
- (d) That while burning they are not allowed to come in contact with comparatively cool surfaces, such as the shell or tubes of a steam boiler; this means that the gases shall have sufficient space and time in which to burn before they are allowed to come in contact with the boiler surfaces."

Mr. A. Bement, who has made a careful study of the smoke problem, suggests\* some slight modifications of the Kent form of statement. He says: "Professor Kent's requirements may be modified as to two features as follows:

<sup>\*</sup>The Suppression of Industrial Smoke with Particular Reference to Steam Boilers.—Journal Western Society of Engineers. Dec., 1906.

- (a) That the evolution of gas from the coal shall proceed uniformly.
- (b) That the gases which are distilled uniformly from the coal shall enter a fire-brick chamber of either sufficient length to allow the flames to become entirely consumed naturally or that the chamber be provided with such auxiliary mixing and baffling devices as will cause the gases to be artificially mixed together before the exit of the chamber is reached."

Further discussing the subject, Mr. Bement presents clearly the importance of uniformity of the evolution of the volatile gases and points out that the lack of uniformity of the evolution of the gases when coal is hand-fired must be supplemented by efficient mixing devices such as fire brick piers or special baffling. The matter presented in this bulletin only corroborates the testimony presented in Mr. Bement's article, and except for the fact that possibly this publication may reach a larger number of manufacturers throughout the state than will Mr. Bement's paper, it need hardly have been presented.

Any fuel may be burned economically and without smoke if it is mixed with the proper amount of air at a proper temperature.

This is the statement of the smoke problem that the writer has sometimes presented. We have then three forms of presentation of the problem. To the fuel expert any one of these forms is sufficiently clear. It does, however, require some familiarity with the problem to understand just what these statements mean. To the owner who is trying to make his plant stop smoking or who must decide between several types of furnaces or boilers that he wishes to install, all these carefully stated formulas are often meaningless and provoking. What the owner wishes to know is what furnaces and boilers are in the market that are really suitable for burning Illinois coals without smoke. It is in many ways unfortunate that there are so many independent manufacturers of furnaces and boilers. Both furnace and boiler should preferably be sold and installed by the same company. It may not be long before this will be so. At least, the boiler companies should furnish complete plans with their boilers including the furnace. Possibly

The Peabody Atlas—Shipping Mines and Coal Railroads in the Central Commercial District of the United States, with Chemical, Geological and Engineering Data. A. Bement, 1906. 16\(^3\_4\times18\) in. 149 pp. An extensive and valuable work relating to the central coal fields of the United States, published by the Peabody Coal Co., Chicago. The section devoted to smokeless furnaces and smoke suppression contains many excellent illustrations which should be of great help to engineers who wish to be fully informed on this subject.

this matter might be left to the consulting engineers, but many firms buy their boilers directly from the boiler companies and follow the same setting plans that have been developed and found efficient with anthracite or other eastern coals, and often these are entirely unsuited for Illinois coals having such a high volatile content.

Much confusion has doubtless arisen and many disappointments have followed because of the fact that furnaces found entirely suitable for eastern coals have been tried further west without modification and have proved themselves failures. Some of the furnaces described in this paper would not be suitable for use with eastern coals. The use of the Dutch oven furnace, which was common before the chain grate stoker, doubtless paved the way for the various forms of automatic stokers which made use of the good points recognized in the old forms of the Dutch oven furnaces.

The history of the growth and development of the smokeless furnace could well form the subject for an engineering article. It is hoped that some one may soon make the steps in such a development a matter of record. The writer certainly makes no claims for discovery of invention in this connection. He has, however, experimented with many methods of firing, many devices for smoke prevention and many variations in furnace construction, not only in Illinois, but also in Pennsylvania and in New England.

The boiler plant at the University of Illinois at Urbana, Illinois, consists of 2000 horse-power in nine units. During the last two years this plant has been operated practically without objectionable smoke fully 90 per cent of the time. Over 200 separate boiler tests have been made in this plant to determine the economy of operation and for a study of furnace conditions. Many changes have been made in the constructive features of the furnaces and boiler baffling with the view of studying the smoke problem. Many varieties of coals have been tested for smokelessness. The character of the installation is indicated below.

- Boiler No. 1. Babcock & Wilcox (Special high-pressure boiler 275 lb.), equipped with B. & W. chain grate stoker, usual vertical baffling, capacity 150 H. P. This unit can be run without smoke at capacities from 50 to 120 per cent.
- Boiler No. 2. Babcock & Wilcox standard boiler (150 lb.) equipped with B. & W. chain grate stoker, usual vertical baffling, capacity 150 H. P. This unit can be run without smoke at capacities from 50 to 120 per cent.




Fig. 2 Chimneys Illustrating Smoke Densities Approximating the Ringelmann Smoke Charts




Fig. 3. Section of Smoke Chart Record

- Boiler No. 3. Stirling standard boiler (150 lb.) equipped with Green chain grate stoker, usual baffling and combustion arches, capacity 260 H. P. Setting shown in Fig. 4. This unit can be run without smoke at capacities from 50 to 140 per cent.
- Boiler No. 4. National water tube boiler (150 lb.), formerly equipped with Murphy furnace but now equipped with Green chain grate stoker: usual vertical baffling, capacity 250 H. P. This unit can be run without smoke at capacities from 50 to 120 per cent. When equipped with Murphy furnace, this unit was smokeless except when cleaning fires.
- Boiler No. 5. Babcock & Wilcox standard boiler (150 lb.), equipped with Roney stokers, usual vertical baffling, capacity 220 H. P. Setting shown in Fig. 5. This unit when handled carefully can be run up to capacity without smoke above No. 2 on the smoke chart. It requires careful attention and at capacities above 100 per cent cannot be run without objectionable smoke. This boiler is an exact duplicate of unit No. 6.
- Boiler No. 6. Babcock & Wilcox standard boiler (150 lb.), equipped with Roney stokers, special baffling making tile roof furnace. Boiler and stoker duplicate of unit No. 5. Capacity 220 H. P. Setting shown in Fig. 6. This unit can be run without smoke at capacities from 50 to 100 per cent.
- Boiler No. 7. Stirling standard boiler (150 lb.) equipped with Stirling bar grate stoker, usual baffling and combustion arches, same as Boiler No. 3, capacity 260 H. P. This unit can be run without smoke at capacities from 50 to 140 per cent.
- Boiler No. 8. Stirling standard boiler (150 lb.). Exact duplicate of boiler No. 7, capacity 260 H. P.
- Boiler No. 9. (Engineering Experiment Station special test boiler), Heine standard boiler (150 lb.) equipped with Green chain grate, usual combustion arch, tile roof furnace, adjustable water back at bridge wall, capacity 210 H. P. Setting shown in Fig 7. This unit can be run without smoke at capacities from 50 to 140 per cent.

A study of the various units mentioned above reveals the fact that any one of the four well known types of boilers may be set over at least three well known types of automatic stokers and be operated without objectionable smoke. The opinion of the writer, doubtless held by most engineers, is that the boiler has very little to do with the smoke problem, except perhaps that some types of boilers lend themselves more easily to the necessary furnace construction, which is of the utmost importance when perfect combustion is desired.





Fig. 4 Stirling Standard 260 H. P. Boiler Equipped with Chain Grates

(Operates easily without smoke at capacities from 50 to 140 per cent).

#### DESCRIPTION OF THE SETTINGS SHOWN BY THE FIGURES

In the figures which accompany this article there are shown several types of boilers and furnaces that have been found suitable for burning Illinois coals without smoke. These settings have been operated under the immediate observation of the writer. Each figure is supplied with a title which is at the same time a description of the setting and an indication of the possibility of its smokeless operation under varying conditions of service. The drawings themselves are sufficient to illustrate the conditions that must be fulfilled to secure smokelessness when using boilers of these types under usual service capacities. The stack draft available for boilers No. 1 to 8 is 0.75 in. to 1.0 in. supplied by a brick chimney 150 feet high with an inside diameter of 6 feet. Boiler No. 9 is supplied with an economizer and



BABCOCK & WILCOX 220 H. P. BOILER EQUIPPED WITH RONEY STOKERS, USUAL VERTICAL BAFFLING

(With careful handling may be run up to capacity without smoke above No. 2 on Smoke Chart; above 110 per cent capacity can not be run without objectionable smoke except by expert firemen.)

an induced draft fan permitting higher rates of combustion than are possible in the other settings.

In all of these settings it has been found necessary to pay particular attention to the coking arch under which the fresh charge of coal is being delivered. It seems to be true that over chain grates this arch should be inclined upwards more for a light than for a heavy draft. It is also believed that the arch of the Roney stoker should be kept well down toward the grates. The dimensions given in Fig 5 have given good results in these settings.

When Illinois coal is being burned in any furnace it is essential that the volatile products of combustion should be uniformly distilled from the coal and mixed with sufficient air at a high temperature. To accomplish this, particularly to maintain a high temperature, the mingling air and products of combustion must be kept away from the tubes or plates of the boiler which are comparatively cool, and which would therefore cool the gases before complete combustion had taken




Fig. 6 Babcock & Wilcox 220 H. P. Boiler Equipped with Roney Stoker

(Setting as in Fig. 2, but arranged with different baffling, forming a tile roof furnace. This unit can be run at capacities from 50 to 100 per cent without smoke.)




FIG. 7 HEINE STANDARD 210 H. P. BOILER EQUIPPED WITH GREEN CHAIN GRATE, COMBUSTION ARCH, TILE ROOF FURNACE, ADJUST-ABLE WATER-BACK AT BRIDGE WALL

(This is the Engineering Experiment Station Boiler furnished with induced draft. It can be run easily without smoke at capacities from 50 to 140 per cent; almost impossible to make smoke with this setting under any condition of operation.)

place. It is for the reason just mentioned that such forms of furnaces as shown in Fig. 6, 7, and 8 are planned. Special forms of fire clay tile are designed to be hung on the water tubes of boilers that are directly over the fire. The tiles form the roof of the furnace and prevent the hot gases, which are still not properly mixed, from coming in contact with the cooler tubes which are surrounded by the tiles. These tiles are made in various forms, three types being shown in Fig. 9. The kind shown at C makes a smooth flat roof for the furnace and has been found very satisfactory.

The length of a tile roof furnace or the distance of flame traveled before reaching the cool tube surface must evidently depend upon the total volume of volatile products distilled from the coal on the grate in a given time, which must be mixed with the air supply before the cooling tubes are reached. The higher the coal is in volatile content or the higher the rate of combustion per square foot of grate area, the longer will be this flame length. The coals that have been burned without smoke in the furnaces shown have had a combustile volatile content of from 30 to 40 per cent and they have been burned at a rate of from 16 to 40 lb. of coal per square foot of grate per hour. It will now be understood why such settings as shown in Fig. 5 cannot be depended upon for smokelessness. The cold tubes of the boiler are too near the flame, the temperature of the flame is reduced before combustion is complete and smoke results. There are coals low in combustible volatile matter that may easily be burned in such furnaces without smoke. In fact, when not forced, this furnace will burn many kinds of Illinois coals, but only with the greatest care have we been able to burn the usual grades of Illinois coals at desirable rates of combus-




Fig. 8 Smoke-proof Steam Generator described by A.Bement, W.S. E. Paper, October, 1906.

(A satisfactory plan when proper attention is given to the draft available and to the areas of the gas passages.)

tion (24 to 30 lb.) without objectionable smoke, (No. 2 to 3½ on the smoke chart).

When the baffling shown in Fig. 6 was installed a series of smoke trials was arranged with this setting and the setting shown in Fig. 5. The results shown by these trials were disappointing and unsatisfactory. Lack of sufficient draft made it impossible to run setting Fig. 6 above its rated capacity. Under this condition there was little difference in the smoke from the two furnaces. This result suggests that changes in baffling of existing plants must be made with careful consideration of draft areas available or capacities may be cut down to an undesirable extent. The capacity possible with the setting shown in Fig. 6 proved to be about 90 per cent to 98 per cent while the capacity of the settings shown in Fig. 5 with the same coal was from 100per cent to 120 per cent. The setting of Fig. 6 should prove satisfactory with higher draft pressures or by increased areas possible with a larger number of tubes in the vertical rows. From what has already been said about cool tubes, an inspection of the settings in Fig. 4, of a Stirling boiler over a chain grate stoker, might convey the impression that such a setting would produce smoke because of the absence of tile on the tubes below the path of the flame A B C. This setting has, however, proved to be a satisfactory and smokeless one. Looking the progress of combustion through the side openings provided in the three settings of this character in the University plant, it is seen that the flame rolls along over the edges of the two arches shown and is by these arches completely mixed. No part of the tubes below the flame path A B C is enveloped by the flames; therefore the tubes have little cooling effect. It is also very evident that the lower ends of the tubes next the furnace fulfill their duty as heat transmitters by taking care of a very considerable part of the radiant heat which is available in large quantities at that point. Boilers of this type are now being manufactured at almost any desired height, the necessary capacity being furnished by increased width. They have proved very satisfactory, smokeless furnaces being easily arranged under them.

The Heine boiler set over a Green chain grate shown in Fig. 7 is the boiler installed by the Engineering Experiment Station for fuel tests with Illinois coals. This boiler is exactly like the Heine boiler used in the government fuel tests at St. Louis.\* In this setting, how-

<sup>\*</sup>The characteristic feature of these two settings is a tile roof furnace, originating in 1901 with W. L. Abbott, at the Harrison St. station of the Commonwealth Edison Co., Chicago.




Fig. 9 Three Types of Tile Roofs for Boiler Furnaces

ever, we have a stoker furnace while the government boilers were set with hand-fired furnaces, evidently necessary where coals from many sections of the country were to be tested. The setting shown in Fig. 7 is provided with an economizer and a large induced draft fan making high rates of combustion possible. This setting is smokeless under the many and varied conditions of operation which have thus far been applied to it. Over 100 trials of about 10 hours' duration of various kinds of Illinois coal have been made in this setting. In all of these trials the smoke record has been "No smoke all day." This is the setting to which the writer has referred in several recent talks by saying that in this setting it has been impossible to make smoke. In order to justify any such statement, attention is called to the results of a series of tests made with this setting for the express purpose of smoke production if such was possible under apparently adverse conditions.




Fig. 10 General View of Engineering Experiment Station Fuel Testing Plant 210 H. P. Heine Boiler, Weighing Tanks, Ash Car and Hoist, Induced Draft



Those who desire to grasp the simple yet fundamental principles of smokeless combustion for Illinois coals should thoughtfully consider just how this furnace fulfills the conditions of perfect combustion, as stated on page 15 in the words of Kent, Bement and the writer. A detailed account of the process in this furnace may well bear repetition here.

The fresh coal, fairly uniform in size, advances slowly from the hopper along on the grate toward the furnace where the temperature is very high. The combustible volatile matter is continually being distilled from the coal, more and more rapidly, but with much uniformity, while it is passing under the combustion arch. Some of the necessary air flows in through the coal in the hopper, more through the grate under the arch, but by far the most flows through the redhot coals on that part of the grate beyond the arch. This air is thus heated and made ready for combining with the volatile products flowing from beneath the arch, and all together mix and roll along on the bottom of the tiles forming the roof of the furnace.

The bottom row of boiler tubes is covered with suitably formed tiles, which prevent the still actively mingling gases from being cooled by coming in contact with the tubes, and so the combustion processes go on until completed before reaching C, a point before the gases pass in among the cooling tubes. The tiles in the adjoining rows touch each other so that no gases pass between them. In such a furnace as this the smoke problem is settled somewhere between B and C. When the total volume of combustible material distilled from the coal is quite large in a given interval of time, the flame length may reach to C, while for smaller volumes the flame may end at B. Thus it is that the flame length indicates the end of the combustion processes and gives us valuable information concerning the proportions of smokeless furnaces.

It is important in the operation of this or any form of mechanical stoker that abundant opportunity be afforded for inspecting the condition of the fires and the progress of combustion. Appliances for continually indicating the composition of the escaping gases should be considered a necessity in all large and well managed plants.

The character of the draft apparatus available with this setting made it possible to make sudden changes in the rate of combustion. The rate of travel of the chain grate was easily adjusted by a throttle governor on the independent steam engine in driving the grate. The rate of combustion could be calculated very closely from the thickness

of the fuel bed and the rate of grate feed, by reference to the large number of tests already made with this unit. These special smoke tests were run on four different days, and on each day eight changes in condition of operation were made. The thicknesses of fire used were four, five, six and seven inches. The capacities varied from 60 to 150 per cent of the rated capacity (210 H. P.) of the boiler. The character and the size of the coal used are indicated in the tables. The results of these tests amply justify the conclusion that this type of furnace may be depended upon to operate even under adverse conditions without objectionable smoke, for out of a total of 32 tests in only six cases could any smoke be seen coming from the stack, and in three of these six smoke did not exceed No. I on the smoke chart. Where the most smoke was made, it was only No. 1½ and 2½, and here it will be observed that the draft had been suddenly reduced in the breeching, amounting to the condition of closing the damper with a brisk fire.

TABLE 1

Special Smoke Tests of Illinois Coal with a Chain Grate Stoker, Tile Roof Furnace and Heine Water Tube Boiler, with Varying Rates of Combustion. February 5, 1907. Coal--Washed, Size No. 4a.

Test Mati	1	2	3	4	5	6	7	8
Time, Start	8:10	9:00	9:30	9:56	1:00	1:30	2:00	2:35
Time, Stop	9:00	9:30	9:56	1:00	1:30	2:00	2:35	2:47
Thickness of Fuel Bed	4	4	4	4	4	4	4	4
Draft Pressure in								1
Furnace	.092	.110	.180	.095	.098	.057	.050	.080
Draft Pressure in	400	200	1 000	F00	00	250	000	240
Breeching Lbs. Coal Burned	.430	.600	1.260	.580	.500	.250	.090	.240
per sq.ft.of								
Grate Surface								
as Fired	31.4	39.3	45.5		35.8	28.3	23.4	
Do. Dry Coal	27.8	34.8	40.4		31.7	25.5	20.7	
Mean per cent of Rated								
Capacity Devel-			1	1				
oped	112	126	155		135	109	91	
Flue Gas Temper-	000	071	700	0.07	250	200	F01	~ ~ ~
ature, °F	629	671	762	661	659	600	521	560
Temperature over grate	2500	2550	2620		2530	2390	2310	
Temperature back of Bridge Wall	2470	2550	2710		2490	2390	2310	
Per cent CO <sub>2</sub>	12.0	12.8	12.2		12.8	12.8	14.4	
Smoke	0	12.0	1	0р	1 0	13.0	21	0

<sup>(</sup>a) Moisture in coal as fired, 11.3 per cent; ash, 7.5 per cent.

(b) Grate stopped for repairs.

TABLE 2

SPECIAL SMOKE TESTS OF ILLINOIS COAL WITH A CHAIN GRATE STOKER, TILE ROOF FURNACE AND HEINE WATER TUBE BOILER, WITH VARYING RATES OF COMBUS-TION. February 9, 1907.—Washed, Size No. 2a.

1	2	3	4	5	6	7	8
8:03 9:00 6	10:00	11:00 6	12:00 6	1:00	1:00 2:00 6	2:00 3:00 6	3:00 4:00 6
.126	.73	.178	.122	.12	.088	.060	.120
27.5 24.5	28.2 25.5	34.9 31.3	28.5 25.4	$23.7 \\ 21.5$	$\frac{21.5}{19.3}$	21.0 18.7	31.3 27.7
92	109	119	112	111	89	67	99
671 2375	679 2485	707 2420	663 2340	642	574 2280	516 2235	5 62 2465
2305 10.1 0	2385 10.1 0	2340 9.1 0	2360 10.0 0	9.8	$ \begin{array}{c c} 2210 \\ 11.6 \\ \frac{1}{8} \end{array} $	2090 11.4 0	$ \begin{array}{c} 2475 \\ 11.8 \\ 1\frac{1}{2}b \end{array} $
	8:03 9:00 6 .126 .56 27.5 24.5 92 671 2375 2305 10.1	8:03 9:00 9:00 10:00 6 6 .126 .154 .56 .73 27.5 28.2 24.5 25.5 92 109 671 679 2375 2485 2305 2385 10.1 10.1	$ \begin{array}{c ccccccccccccccccccccccccccccccccccc$	8:03         9:00         10:00         11:00           9:00         10:00         11:00         12:00           6         6         6         6           .126         .154         .178         .122           .56         .73         .96         .56           27.5         28.2         34.9         28.5           24.5         25.5         31.3         25.4           92         109         119         112           671         679         707         663           2375         2485         2420         2340           2305         2385         2340         2360           10.1         10.1         9.1         10.0	$\begin{array}{ c c c c c c c c c c c c c c c c c c c$	$\begin{array}{ c c c c c c c c c c c c c c c c c c c$	$\begin{array}{ c c c c c c c c c c c c c c c c c c c$

(a) Moisture in coal as fired, 11 per cent; ash, 7.97 per cent.
(b) Much unconsumed coke forced over back end, thus increasing the ratio of volatile carbon in the fuel actually consumed.

The results of these experiments are given in Tables 1, 2, 3 and 4, and they certainly demonstrate the possibilities of smokeless combustion of some typical Illinois coals.

It is not within the scope of this bulletin to enter into any lengthy discussion of the results as shown by these tables. It should, however, be stated that this setting has been operated not only without smoke, but also with economy, as may be seen by inspection of Table 5. The complete record of the results of the economy tests made under this boiler will form the subject of a separate bulletin soon to be published.

RELATION BETWEEN CAPACITY AT WHICH BOILERS ARE DRIVEN AND THE TENDENCY OF THEIR FURNACES TO SMOKE

There is a rate of driving a boiler furnace which, if exceeded, will result in producing smoke. This rate varies for different types of

furnaces and for the various methods of baffling or kinds of mixing piers used. It also varies for different kinds of coals. A strong draft will make a large air supply possible, and allow thicker fires or finer coal to be used. The possibility of sufficient air makes a furnace smokeless when an insufficient supply caused by a weak draft might cause the production of smoke. There is an always increasing tendency to drive boilers and furnaces a little harder. Boilers that were purchased for 1000 H. P. a few years ago are now being forced to 1400 and 1600 H. P. This means of course larger grate areas and a much higher rate of combustion per unit of grate area. As far as the boilers are concerned, they seem to be ready and willing to transmit about the same proportion of the heat available to the boiler as ever. It is doubtful if constructive furnace details have kept pace with the demands for the higher rates of combustion and at the same time have

TABLE 3

Special Smoke Tests of Illinois Coal with a Chain Grate Stoker, Tile Roof Furnace and Heine Water Tube Boiler, with Varying Rates of Combustion. February 11, 1907. Coal— $1\frac{1}{2}$ -inch Screenings. Ordinary Grade for Tests, 1, 2, 3, 4,  $5^a$ . Poor Grade for Tests, 6, 7, 8.

ITEM	Test No.	1	2	3	4	5	6	7	8
Time, Start		8:05 9:00 5	9:00 10:00 5	10:00 11:00 5	11:00 12:00 5	12:00 1:00 5	1:00 2:00	2:00 3:00	3:00 4:00
Draft Pressure in Furnace		.202			.23	.108	.302	.355	.58
Draft Pressure in Breeching Lbs. Coal Burned per		1.21	1.30		1.12	.23	1.48	1.21	
sq. ft. of Grate Surface as Fired. Do. Dry Coal Mean per cent of Rated		32.7 27.4	35.4 30.0	39,3 33.2	$\frac{30.2}{25.5}$	12.4 10.5	46.5	26.8	26.2
Capacity Developed		87	103	106	84	56	106	75	68
ture, F Temperature overGrate Temperature Back of		674 2360	704 2400	718 2615	650 2489	542 2180	674 2530	646 2425	625 2485
Bridge Wall Per cent CO <sub>2</sub> Smoke		6.8	7.6	6.6	7.2 $0$	6.2	7.0	4.7	4.3

<sup>(</sup>a) Moisture in coal as fired, 14.23 per cent; ash, 15.4 per cent.

TABLE 4

Special Smoke Tests of Illinois Coal with a Chain Grate Stoker, Tile Roof Furnace and Heine Water Tube Boiler, with Varying Rates of Combustion. February 12, 1907. Coal—1½-inch Screenings, selected <sup>a</sup>.

ITEM	1	2	3	4	5	6	7	8
Time, Start	8:00	9:00	10:00	11:00	12:00	1:00	2:00	3:00
Time, Stop	9:00	10:00	11:00	12:00	1:00	2:00	3:00	4:00
Thickness of Fuel Bed.	6	6	6	6	6	5.00	5	5
Draft Pressure in	''	0	0	0				0
Furnace	.18	.25	.20	.10	.06	.195	.10	.05
Draft Pressure in	.10	.20	.20	.10	.00	.100	.10	.00
Breeching	1.00-+	1.5+	.93	.36	.21	1.20	.57	.15
Lbs. Coal Burned per	1.00	1.0			.21	1.20	.51	,10
sq. ft. of Grate	1							
Surface as Fired.	28.3	32	28.3	23.9	16.8	31.0	26.5	22.6
Do. Dry Coal	24.2	27.3	24.2	20.4	14.3	26.5	22.6	19.3
Mean per cent of Rated				20.1	1110	2010		-0.0
Capacity Devel-		1						
oped	89.8	85	91	85	74	100	92	80
Flue Gas Tempera-								
ture F	649	662	639	588	544	676	624	540
Temperature over Grate	2450	2525	2450	2435	2525	2305	2470	2490
Temperature Back of								
Bridge Wall								
Per cent CO2	7	5.9	7	9.9	9.7	7.3	8.7	11.8
Smoke	0	0	0	0	0	0	0	0
	1							

(a) Moisture in coal as fired, 14.6 per cent; ash, 9.48 per cent.

provided efficient smoke preventing plans. In other words when boilers are forced much over 30 per cent of their rated capacity the probability of smoke from their furnaces rapidly increases. Nothing inherent in the boiler itself is at all responsible for smoking furnaces, for as elsewhere pointed out it is the total amount of volatile combustible evolved in the furnace per unit of time that imposes duties upon those constructive features of the furnace and combustion chamber which are designed to furnish the proper amount of suitably warmed air to the furnace and to provide for its effective mingling before the products of combustion reach the cooling surfaces of the boiler. It would seem necessary, therefore, that until further advances are made in furnace design and methods of operation, when a plant has reached the point of perhaps 140 per cent of its rated capacity, additional boilers ought to be added if only in the interest of a less amount of smoke. In

RESULTS OF EVAPORATIVE TESTS WITH ILLINOIS COALS ON A CHAIN GRATE STOKER

TABLE 5

Experiment Station Boiler with Tile Roof Furnace, Same Setting as Those Used for Special Smoke Tests in Tables 1 to 4.

	1	15.	12.	11.		10.	9.	œ	.7	6.	5.	4	ç	o i o	
Grate Surface, per hour	caping Flue Gases, °F Dry Coal per sq. ft.	Temperature of Es-	Excess Air Used,	Per cent $CO_2$ in Flue Gases $(3)$	Furnace, in. of water	Bed at Grate, inches. Draft Pressure in	Coal as Fired Thickness of Fuel	B. t. u. per Pound	Per cent Volatile Matter in Ash	Per cent Carbon in Ash Free, Dry Coal.	Per cent Ash in Coal	Per cent Moisture	of $Coal(I)$	Duration of Trial	Number
22.48	599.0	40.04	5 .	12.60	0.127	σ.	11898	39.59		60.41	7.31	10 79	$\frac{3}{4} - \frac{1}{4}(w)$	8.32	47
22.35	612.0	01.15	1	12.28	0.085	4-	11740	39.59		60.41	7.64	11 93	3-1(w)	8.32	50
26.41	613.4	1.061	180 1	7.00	0.258	6	10036	46.05		55 95	16.89	11 88	$\frac{3}{4} - \frac{1}{4}(\mathbf{w}) \left  1\frac{1}{2} - 0 \left( \mathcal{Z} \right) \right  \left( 1\frac{3}{4} - 1 \right)$	8.30	91
22.10	606.0	20.4	03	9.52	0.112	01	12305	39.59		60 41	8.42	7 14	$(1\frac{3}{4}-1)$	8.25	96
20.49	599.0	90.4	n	10.99	0.120	6	11922	37.57		62.43	8.21	0 10	$1 - \frac{3}{4}(w)$	8.10	107
27.62	624.0	145.8	1 5 0	7.10	0.387	OT.	9350	44.06		55.94	12.58		$\frac{3}{8} - 0(w)$	7.02	127
20.60	574.0	97.4	R 4	11.46	0.117	01	10274	42.61		57.89	7.68		7-3(w)	8.15	181
27.55	665.0	0.16	2 u	11.38	0.161	OT	10391	43.65		56 35	7.19	10 90	7 - 3 (W)	7.37	134

TABLE 5.—(Continued)

	20. En	<u>5</u> 2	29 as 19. Equ	18. Eq.		1. Tria
including Grate	Efficiency of Boiler	Free, Dry Coal	as Fired		Refuse, per cent of Dry Coal	15. Carbon in Ash and
66.89	69.93	10.51	8.24	109.4	4.00 150.0	4/
67.70	70.75	10.60	8.23	109.3	3.95 150.0	50
62.75	64.60	9.42	6.52	103.1	2.23 146.9	91
63.60	65.32	9.86	8.12	101.8	2.23 150.4	96
67.82	69.00	10.34	8.37	99.9	1.56 147.5	107
56.26	60.18	8.70	5.38	99.5	5.46 149.5	127
70.39	71.76	10.53	7.49	101.4	1.75	131
60 I.C	70.61	19.33	7.44	133.8	1.89	134

Item 3—Size is given in inches. (w) refers to washed coal. Sixty per cent of this coal was below \( \frac{1}{2} \) inch. The flue gases were free from carbon monoxide and smoke.

confirmation of this particular point the following discussion\* is worth presenting. "The work at the government coal testing plant has been somewhat in the direction of smoke abatement, although the principal object of the work has been the determination of the value of different fuels for steaming purposes. Whenever we tested a soft coal we tried to eliminate the smoke. We have reduced the smoke 50 per cent or more, and often we burn soft coal without smoke. We have a good fireman, and he is watched all the time. Our furnace has a fire clay tile roof with a smooth lower surface, and a large combustion chamber; it is equipped with a plain grate of 40 sq. ft. We fire about fifty pounds of coal at a time on one-half of the grate area, and every two or three minutes. The furnace has three fire doors and we fire alternately in the front of the first and the third doors and in the rear of the middle door at one time, and then the rear of the first and third doors, and the front of the middle door at the next time. In this manner the distilled volatile matter is divided into three streams and this division facilitates its mixing with the hot air coming from the uncovered portions of the fuel bed.

"Another point in connection with the hand-fired furnace is that it is usually forced to burn more volatile matter than it was built for. We have often found that coal burned slowly, say at the rate of 20 pounds per square foot of grate area per hour, made no smoke at all. However, when the rate of combustion was increased to 26 pounds or more, smoke was produced, even though as great care was used in firing, and the firing was as frequent. This fact is in accordance with Mr. Bement's paper, where he states that the combustion space of a furnace is of a certain capacity, and that one should not try to burn more coal in it than the furnace was built for. The fact is that whenever a furnace is run above its capacity, it is bound to make smoke.

"I have recently noticed an interesting fact, that with a chain grate stoker in a Heine boiler furnace, no smoke was made when the rate of combustion was 42 pounds. If the same coal were burned in a hand fired Heine boiler furnace, smoke would probably be produced at the rate of combustion of 26 pounds. This seems to indicate that with the chain grate stoker more of the coal burns on the grate as fixed carbon and less of the combustible is driven off and burned as volatile matter, than is the case with a hand-fired furnace. This is probably due to the fact that with the chain grate stoker the coal is fed in grad-

<sup>\*</sup>Jour. W. S. E., Dec. 1906. "Suppression of Industrial Smoke." A. Bement. Discussion by H. Kreisinger, U. S. G. S.

ually and is, therefore, heated gradually, while with the hand-firing, the coal is thrown on the top of the white-hot fire and is heated rapidly; this rapid heating is the cause of more combustible being distilled off as volatile matter and more smoke being produced.

"In conclusion I will say that the hand-fired furnace should be the last one to be considered for preventing smoke. In the first place it is rather expensive to operate, and the results are doubtful because too much dependence has to be placed on the fireman."

This discussion has been quoted because it definitely states a rate of combustion (20-26 lb.) as being about the limit for smokeless hand-firing in a certain type of furnace. It also gives good reasons why this rate may be nearly doubled on a chain grate stoker and not produce smoke. It might be well to point out, however, that while the average rate of combustion in the hand-fired furnace appears to be 20-26 lbs. for a short interval just after firing fresh coal, the rate is much higher, equal perhaps to the rate of 42 lb. of the chain grate stoker. It is entirely reasonable to suppose that furnaces will be planned that will provide for smokeless consumption of coal at much higher rates of combustion, but until they are available power plant owners should not be allowed to force boilers to such a point above capacity as will cause the furnaces to become troublesome smoke producers.

## SPECIAL MIXING DEVICES, PIERS, WING WALLS AND JETS

The method of introducing the coal into the furnace will in all cases have much to do with the type of furnace which must be used to stop smoke. When the coal is fed into the furnace mechanically, as it is when stokers are used, one of the most essential elements of successful smoke prevention has been met, namely, slow and uniform gas evolution. When coal is fed by hand into a hot furnace, six shovelfuls more or less at one time, this same element has been ruthlessly neglected. The gas evolution can neither be slow nor uniform. It is also very doubtful if the proper amount of air at the right temperature will be supplied. It is to assist in correcting such known violations of correct methods of coal supply to furnaces that certain devices have been introduced which are intended to correct these initial mistakes. A steam jet is such a mixing device. When properly applied it does not let the volatile gases and air supply escape from the furnace until very intimately mixed. It has, however, two very serious objections, noise and

large steam consumption. From 5 per cent to 8 per cent of the steam made is often used in these jets. The success of the steam jet in preventing smoke, due almost entirely to its ability to properly intermingle the fuel gases and the air supply, immediately suggests the accomplishment of the same intermingling in other ways. Such ways have been devised. One of the early plans was proposed by Professor Kent in his wing wall furnace. Other plans have followed as typified by the Wooley furnace, and the Kuss mixing piers. These methods of mixing are efficient and economical and are especially to be considered in connection with hand-fired furnaces. The particular arrangement to be adopted will be determined by several factors, viz.; (a) The composition of the coal to be used. (b) Size of coal. (c) Method of firing. (d) The rate of gas evolution.

#### SMOKE PREVENTION WITH THE HORIZONTAL FIRE TUBE BOILER

The horizontal fire tube boiler is still much in use in the smaller units of from 50 to 150 horse-power. It was brought into prominence in the early days of American steam boiler practice as the natural successor of the plain cylinder and flue boilers, all of which were externally fired. It soon became the standard type of boiler throughout manufacturing New England where in many places it still retains its position on account of its cheapness and its economical operation with all grades of anthracite and many grades of bituminous coals, especially those containing a high fixed carbon content.

With the coals just mentioned the combustion takes place mostly on the grate or at a short distance above it. Many plants have been installed with this type of boiler, in which the grate has been placed not more than 14 to 16 inches beneath the boiler. These plants have burned anthracite coal successfully. With the introduction of the West Virginia bituminous coals containing small amounts of volatile combustible matter the grates were lowered under this type of boiler to 24 and 30 inches with good effect. Still, with either coal, much the greater part of the heat was generated on or near the grate and the heat made available for transmission was largely radiant heat. The plates directly over the fire itself transmitted a correspondingly large part of the heat of the coal to the water in the boiler. The satisfactory performance of the fire tube boiler with eastern coals together with its availability made it naturally the boiler to be adopted by manufactur-

ers moving westward with the center of population. It is easily seen, however, that with Illinois coals carrying 30 to 40 per cent of volatile combustible matter and burned at rates which produce flame lengths of from 5 to 20 feet, this type of boiler as usually set is by no means adapted for the smokeless consumption of this kind of fuel. There is, in fact, no better method of producing dense black smoke with Illinois coal than to install a horizontal fire tube boiler with the usual furnace, and hand fire such a plant with run-of-mine coal. In such an outfit all the fundamental principles laid down elsewhere in this paper are disregarded. The method of introducing the coal directly into the hot furnace, in fine dust and large lumps, prevents slow or uniform distillation of the gases; the air supply through open doors, through holes in the fire, or through a fuel bed of varying thicknesses is neither correct in quantity nor is much of it properly heated; the mingling products of combustion come in contact with the cool surface of the plates of the boiler, reducing the temperature of the gases below the ignition temperature before combustion is completed.

Having in view these defects of the usual plan of operating the fire-tube boiler with Illinois coal, many ways suggest themselves by which these faults may be corrected. It is possible to burn Illinois coal without smoke with fire tube boilers, but the furnace requires special treatment and such settings are not common. The plans usually proposed are either low-set stokers or extended Dutch oven furnaces. When hand-firing is adopted the wing wall furnace or other form of mixing baffles or piers is of great assistance. With any of these devices careful firing is very necessary for satisfactory results. The twin brick arch furnace which keeps the gases away from the boiler plates altogether is an effective smoke preventive. Careful firing with low rates of combustion (12 to 16 lb.) per square foot of grate, assisted by automatically controlled air supply, will often enable these settings to be run so as to escape the fines of city smoke inspectors, but they can hardly be compared as to smokelessness with such settings as are illustrated in this paper. Horizontal tubular boilers are often adopted on account of their cheapness, and when such is the case the addition of any special furnace constructions or any special devices to aid in smoke prevention, is seldom given any consideration. From what has been said it is doubtless evident why this type of boiler is so frequently found to be one of our worst smoke offenders.

### BURNING ILLINOIS COAL IN LOCOMOTIVE BOILERS

The writer is compelled to admit that he does not know how to burn Illinois coal in a locomotive boiler under the usual operating conditions without making smoke. Careful firing is the most effective way of reducing the amount of smoke made, but no fireman can be found skillful enough to meet the exigencies which are always arising and to operate a locomotive boiler in service without smoke even 75 per cent of the time when using Illinois coal. It is not possible here even to enumerate the many devices which have been tried to prevent smoke production on locomotive boilers. The high rates of combustion on the grate of this boiler, often reaching 150 lb. and sometimes 200 lb. per square foot of area, produce temperatures which soon destroy all forms of fire resisting material or other constructions not backed up by water-jacketed metals. Were it not, however, for the many and sudden changes in the conditions of operation imposed by the very duties for which the locomotive is designed, all other obstacles might possibly be overcome and the locomotive become smokeless. Fortunately we can clearly see how to eliminate the smoking locomotive from the thickly populated districts by the use of the electric locomotive which now is able to meet the demands placed uponit for speed, acceleration, and tractive effort. It is also pointed out that the large power plant will now produce the electricity needed for this service with greater economy and at the same time burn Illinois coal without smoke.

## How to Hand Fire Illinois Coals so as to Reduce the Production of Smoke

There are many small power plant units that are hand-fired which smoke badly. The construction of many of these furnaces is such that it is almost impossible to operate the plant without smoke. Still something might be done to reduce smoke if the fireman exercised more care in firing. Whatever can be done by the fireman in the way of properly introducing the fuel into the furnace is just so much gained and it relieves the auxiliary mixing devices or baffles if such exist from just so much work later on. The best method of hand-firing for smokelessness is also the best method for attaining economy. There are three generally recognized methods of hand-firing: (a) The Spreading, (b) The Coking and (c) The Alternate. The first is satisfactory and generally used for anthracite; the second for coking coals and the last

for non-coking coals. It is the alternate method that is best suited to Illinois coals. This method is described as follows. The fuel bed area is divided into equal parts two, four, or six depending on the size of the entire surface. The fresh coal is fired alternately on one-half of these areas at a time at such intervals as may be necessary to hold the steam pressure. Depending on the rate of driving, these intervals will vary from one to five minutes. For small areas first one-half the surface of the fuel bed is covered and then perhaps three minutes later the other half. This method allows much of the air supply to come through the bright fuel bed and thus become heated and suitable for mixing with the highly volatile content which is being rapidly driven from the freshly fired coal on the other side. Tust because fresh fuel has been spread over one part of the fuel bed, the air most needed at that moment cannot as easily flow through it, and another part of the fuel bed should be left free for its passage at that time. When the fuel bed area is very large, some checker board system of firing may be adopted which, when alternately fired and left free for air passage, will result in a large reduction in the amount of smoke produced by the too common method of spreading the coal over the entire surface at each firing. It must not be forgotten that a large supply of warm air is needed immediately after fresh fuel is spread over a part or all of the fuel bed; this is best supplied as just explained, but it may be advantageous to provide for still more air by leaving the fire doors open slightly just after each firing. There are several devices on the market which provide for an air supply over the fire, which are turned on with the opening or closing of the fire door and which can be arranged to close at the end of any desired time depending upon the rate of driving and frequency of firing found desirable. The firing of small amounts of coal at frequent intervals produces less smoke than firing large amounts at longer intervals. The latter method, however, usually proves less tiresome to the fireman and is for that reason more frequently adopted.

# THE DISTANCE BETWEEN THE BOILER AND THE GRATES

Having in mind the horizontal fire tube boiler, the distance from the bottom of the boiler to the grates should be from 30 to 34 inches. At this distance the flame from Illinois coals will sweep along the bottom of the boiler and much smoke will result. Still it must be borne in mind that a large part of the heat to be obtained from the burning of the fixed carbon part of these coals is transferred to the shell in the form of radiant heat and for this purpose the grate should be near the boiler. While it is necessary in preventing smoke, that the flames be kept from the cooling surfaces of boilers, this cannot be accomplished by simply lowering the grates under a horizontal fire tube boiler, as the writer has unfortunately been incorrectly quoted as having stated. For boilers of this type some form of furnace extending partly or entirely in front of the boilers and either hand fired or fed by stokers of the Murphy type would undoubtedly furnish a satisfactory solution to the smoke problem. As elsewhere pointed out the smoke problem is not usually satisfactorily solved with Illinois coals and the horizontal fire tube boiler. The small unit hardly warrants an automatic stoker. Desire for a cheap plant prevents any special form of furnace and so it is that this kind of a setting frequently proves to be a troublesome smoker.

#### THE PREPARATION OF COAL FOR SMOKELESS BURNING

When the coal fed into a furnace is fairly uniform in size it. is much easier to burn it without smoke than when it is of different sizes. In all the settings described in this article as smokeless, the coalburned has been of such uniformity as to meet this requirement. The standard commercial sizes are all that are required, such as No. 1, 2, 3, 4, or 5. Take, for instance, the chain grate stoker; the very principle of its operation, complete consumption of the coal while it travels the length of the furnace, makes it very evident that if small pieces of coal are just consumed, the very large pieces will not be consumed. Just to what extent it will pay to size coal for regular use is not yet very clear, but experiments reported by Mr. W. L. Abbott in a paper before the Western Society of Engineers (Sept. 1906), makes it evident that the influence of variation in size of the fuel used is of much more importance than has heretofore been generally believed. In these tests the capacity as well as the efficiency of the plant tested increased rapidly with the size of the coal used between the average sizes of 0.12 inches and 0.30 inches, after which both these factors dropped again. The following table indicates the general results obtained.

		0
Size in inches	Horse-Power	Efficiency
.15	350	53
.20	525	60 .
.25	650	65
.30	725	65
-35	625	63
.40	550	60
.45	500	58
.50	525	58

Whether these results are generally applicable or whether they apply only to the conditions existing in the operation of a single plant, it is difficult to say. The plant in which these tests were made corresponds so closely to the plants described in the paper that it would seem very desirable that those operating such plants should take advantage of the results obtained and be sure that the mere matter of inattention to size should not be responsible for a capacity or efficiency loss of from five to ten per cent.

The washing of coal, which removes a considerable part of the ash and sulphur, has proved very advantageous to many plants, especially where capacity has been an important consideration. The washing itself, however, does not make coal burn without smoke. As explained elsewhere the total volume of volatile combustible distilled per hour from each square foot of grate area must determine those furnace proportions necessary, with the various methods of coal supply to the furnace, which will with any kind of coal prevent smoke. The writer desires to mention in this connection that since he began to use washed nut coal in his hot water residence heater and in his kitchen range black smoke is seldom seen coming from his chimneys. Previous to the use of this coal the kitchen range pipe required cleaning at least once, sometimes twice each year. It is now three years since this pipe was cleaned. No soot now gathers on the underside of the stove lids as was formerly the case. A fire is easily maintained eight to twelve hours in the residence heater. Experiments with two types of residence heaters, which are now available for test purposes, are in progress by the Experiment Station, and it is hoped that more exact information concerning the relative value of various coals used in this kind of furnace will soon be available. The writer confidently believes that we shall soon know how to burn Illinois coals

without smoke in residence heating boilers as readily and surely as we now know how to burn it under power plant boilers.

Briquetted coal offers some opportunity for smoke reduction in certain kinds of furnaces, and certain railroads have reported favorably on its use inside city limits. It does not appear that it can compete with raw coal, certainly not in Illinois, if any consideration is to be given to the cost. There are conditions arising where the question of cost need not be considered,—such for instance as on naval vessels in time of war. For this reason a series of tests is now being arranged between the steam engineering department of the U. S. Navy and the technologic branch of the United States Geological Survey to determine the comparative value of raw and briquetted coal on board several types of naval vessels. In these tests the question of smokeless operation will be a question of careful consideration.

Powdered fuel has been used with much success in places where the coal has not been too high in volatile combustible content, and where the cost of the coal ordinarily used exceeded five or six dollars a ton. Powdered fuel can be burned without smoke and it can be burned with excellent economy. It cannot, however, be cheaply reduced to a powder.

The writer will welcome suggestions relating to the smoke problem from engineers throughout the country, also drawings, blueprints, etc., and complete and reliable data pertaining to smokeless furnace construction. Bulletin No. 1. Tests of Reinforced Concrete Beams, by Arthur N. Talbot. 1904. (Out of print.)

Circular No. 1. High-Speed Tool Steels, by L. P. Breckenridge. 1905.

Bulletin No. 2. Tests of High-Speed Tool Steels on Cast Iron, by L. P. Breckenridge and Henry B. Dirks. 1905.

Circular No. 2. Drainage of Earth Roads, by Ira O. Baker. 1906.

Bulletin No. 3. The Engineering Experiment Station of the University of Illinois, by L. P. Breckenridge. 1906. (Out of print.

Bulletin No. 4. Tests of Reinforced Concrete Beams, Series of 1905, by Arthur N. Talbot. 1906.

Bulletin No. 5. Resistance of Tubes to Collapse, by Albert P. Carman. 1906.

Bulletin No. 6. Holding Power of Railroad Spikes, by Roy I. Webber. 1906.

Bulletin No. 7. Fuel Tests with Illinois Coals, by L. P. Breckenridge, S. W. Parr and Henry B. Dirks. 1906.

Bulletin No. 8. Tests of Concrete: I. Shear; II. Bond, by Arthur N. Talbot. 1906. (Out of print).

Bulletin No. 9. An Extension of the Dewey Decimal System of Classification Applied to Engineering Industries, by L. P. Breckenridge and G. A. Goodenough. 1906.

Bulletin No. 10. Tests of Plain and Reinforced Concrete Columns, Series of 1906, by Arthur N. Talbot. 1907.

Bulletin No. 11. The Effect of Scale on the Transmission of Heat through Locomotive Boiler Tubes, by Edward C. Schmidt and John M. Snodgrass. 1907.

Bulletin No. 12. Tests of Reinforced Concrete T-beams, Series of 1906, by Arthur N. Talbot. 1907.

Bulletin No. 13. An Extension of the Dewey Decimal System of Classification Applied to Architecture and Building, by N. Clifford Ricker. 1907.

Bulletin No. 14. Tests of Reinforced Concrete Beams, Series of 1906, by Arthur N. Talbot. 1907.

Bulletin No. 15. How to Burn Illinois Coal Without Smoke, by L. P. Breckenridge. 1907.









